

R&S®SMA100B

RF and Microwave Signal Generator

User Manual



1178383402
Version 14

ROHDE & SCHWARZ
Make ideas real



This document describes the R&S®SMA100B models, stock no. 1419.8888.02 and its options:

- R&S®SMAB-B1H
- R&S®SMAB-B28
- R&S®SMAB-B29
- R&S®SMAB-B32/-B34/-B35/-B36S/-B37/-B39
- R&S®SMAB-B80/-B85
- R&S®SMAB-B81/-B82
- R&S®SMAB-B86
- R&S®SMAB-B92/-B93
- R&S®SMAB-B103/-B106/-B112/-B120/-B131/-B140(N)/-B150(N)/-B167(N)
- R&S®SMAB-B709/-B710(N)/-B711(N)
- R&S®SMAB-K22/-K23/-K24/-K27
- R&S®SMAB-K25
- R&S®SMAB-K28
- R&S®SMAB-K31/-K33/-K36/-K38
- R&S®SMAB-K40
- R&S®SMAB-K554
- R&S®SMAB-K703
- R&S®SMAB-K704
- R&S®SMAB-K720/-K721
- R&S®SMAB-K722
- R&S®SMAB-K723
- R&S®SMAB-K724
- R&S®SMAB-K725
- R&S®SMAB-K726
- R&S®SMAB-K980

This manual describes firmware version FW 5.40.102.xx and later of the R&S®SMA100B.

© 2025 Rohde & Schwarz

Muehldorfstr. 15, 81671 Muenchen, Germany

Phone: +49 89 41 29 - 0

Email: info@rohde-schwarz.com

Internet: www.rohde-schwarz.com

Subject to change – data without tolerance limits is not binding.

R&S® is a registered trademark of Rohde & Schwarz GmbH & Co. KG.

All other trademarks are the properties of their respective owners.

1178.3834.02 | Version 14 | R&S®SMA100B

Throughout this document, R&S® is indicated as R&S.

Contents

1	Safety and regulatory information.....	15
1.1	Safety instructions.....	15
1.2	Labels on R&S SMA100B.....	18
1.3	Warning messages in the documentation.....	18
1.4	CE declaration of conformity.....	19
1.5	Where to find key documents on Rohde & Schwarz.....	19
1.6	Korea certification class A.....	19
2	Welcome.....	20
2.1	Key features.....	20
2.2	What's new.....	20
2.3	Documentation overview.....	20
2.3.1	Getting started manual.....	21
2.3.2	User manuals and help.....	21
2.3.3	Service manual.....	21
2.3.4	Instrument security procedures.....	21
2.3.5	Printed safety instructions.....	21
2.3.6	Specifications and product brochures.....	21
2.3.7	Calibration certificate.....	22
2.3.8	Release notes and open source acknowledgment.....	22
2.3.9	Application notes, application cards, white papers, etc.....	22
2.3.10	Videos.....	22
3	Getting started.....	23
3.1	Preparing for use.....	23
3.1.1	Lifting and carrying.....	23
3.1.2	Unpacking and checking.....	23
3.1.3	Choosing the operating site.....	23
3.1.4	Setting up the R&S SMA100B.....	24
3.1.5	Considerations for test setup.....	26
3.1.6	Connecting to power.....	26
3.1.7	Connecting to LAN.....	27
3.1.8	Connecting USB devices.....	27

3.1.9	Connecting to RF coaxial connectors.....	28
3.1.10	Connecting to RF 50 Ω	30
3.1.11	Connecting to Ref In/Ref Out.....	30
3.1.12	Switching on or off.....	30
3.2	Instrument tour.....	32
3.2.1	Front panel tour.....	32
3.2.2	Rear panel tour.....	39
3.3	Trying out the instrument.....	43
3.3.1	Generating an unmodulated carrier.....	43
3.3.2	Generating an RF frequency sweep signal.....	46
3.3.3	Saving and recalling settings.....	48
3.4	Operating the instrument.....	50
3.4.1	Means of manual interaction.....	51
3.4.2	Understanding the display information.....	52
3.4.3	Accessing the functionality.....	55
3.4.4	Entering data.....	56
3.4.5	Undo and redo actions.....	58
3.4.6	Getting information and help.....	58
4	RF signal configuration.....	60
4.1	Activating RF signal output.....	61
4.2	How to set the frequency and level.....	61
4.3	Phase continuous frequency.....	63
4.3.1	How to generate a phase continuous RF signal.....	63
4.4	RF connector settings.....	64
4.5	RF frequency settings.....	67
4.6	RF level settings.....	70
4.7	RF phase settings.....	74
5	Analog modulations.....	77
5.1	Required options.....	77
5.2	Modulation types and signal sources.....	77
5.3	Activating analog modulations.....	80
5.4	Modulation settings.....	80
5.4.1	Pulse modulation settings.....	80

5.4.2	FM, PhiM and AM modulation settings.....	82
5.4.3	Chirp modulation.....	90
5.4.4	Pulse generator.....	95
5.4.5	Pulse graph.....	108
5.4.6	Pulse external / trigger settings.....	109
5.4.7	FM, PhiM and AM modulation sources.....	110
5.4.8	LF signal output settings.....	117
5.4.9	Overview.....	119
5.5	How to generate an amplitude modulated signal.....	121
5.6	How to generate a pulse modulated signal.....	121
5.7	How to generate a pulse train modulated signal.....	122
6	Avionic standards.....	124
6.1	Required options.....	124
6.2	About avionics.....	124
6.3	Generating VOR signals.....	124
6.3.1	About VOR.....	125
6.3.2	VOR configuration and settings.....	126
6.4	Generating ILS signals.....	135
6.4.1	About ILS.....	135
6.4.2	ILS configuration and settings.....	139
6.5	Generating ADF signals.....	162
6.5.1	About ADF.....	162
6.5.2	ADF configuration and settings.....	163
7	Multiplying RF output frequencies.....	168
7.1	About frequency multipliers.....	168
7.2	Operating frequency multipliers.....	169
7.2.1	Test setup.....	169
7.2.2	Connecting a frequency multiplier.....	170
7.2.3	Controlling the frequency multiplier.....	171
7.2.4	Generating RF output signals.....	175
7.3	External RF configuration and settings.....	176
7.3.1	External RF settings.....	176
7.3.2	Remote instrument settings.....	178

7.3.3	RF frontend settings.....	180
8	List and sweep mode.....	187
8.1	Signal generation and triggering in the sweep and list modes.....	189
8.2	About sweep mode.....	196
8.2.1	Correlating parameters in sweep mode.....	197
8.2.2	Sweep signal shapes.....	199
8.3	About list mode.....	200
8.4	Significant parameters and functions.....	201
8.5	Sweep mode settings.....	203
8.5.1	General sweep settings.....	203
8.5.2	Frequency range settings.....	210
8.5.3	Level range settings.....	212
8.5.4	Output settings.....	214
8.5.5	Edit marker settings.....	215
8.6	List mode settings.....	217
8.6.1	General settings.....	218
8.6.2	List mode data settings.....	220
8.6.3	Import/export settings.....	221
8.7	List data editor.....	223
8.8	How to generate a signal in list or sweep mode.....	226
9	Improving level performance.....	228
9.1	Attenuator.....	228
9.1.1	Attenuator settings.....	229
9.1.2	Reverse power protection.....	231
9.2	Automatic level control (ALC).....	231
9.2.1	ALC settings.....	234
9.2.2	How to set up an external ALC.....	235
9.3	User correction.....	236
9.3.1	User correction settings.....	239
9.3.2	Ucor data editor.....	241
9.3.3	Fill with sensor.....	244
9.3.4	Import/export list files.....	246
9.4	Using power sensors.....	249

9.4.1	About.....	250
9.4.2	Connecting R&S NRP power sensors to the R&S SMA100B.....	251
9.4.3	NRP power viewer.....	253
9.4.4	NRP power control.....	254
9.4.5	NRP sensor configuration.....	258
9.4.6	NRP sensor mapping.....	263
9.4.7	NRP power analysis.....	266
9.5	Improving the RF signal performance.....	313
10	Reference oscillator.....	317
10.1	Required options.....	317
10.2	Reference frequency settings.....	317
10.3	Reference output settings.....	321
10.4	Adjustment settings.....	322
10.5	Using the reference frequency for instruments synchronization.....	323
11	Clock synthesis.....	327
12	File and data management.....	331
12.1	Accessing, retrieving and handling data.....	331
12.2	About the file system.....	332
12.3	Restoring an instrument configuration.....	335
12.3.1	Preset, set to default and factory preset settings.....	337
12.3.2	Identifying parameters with non-default values.....	338
12.3.3	Presetting the instrument to a user-defined state.....	339
12.3.4	Reference.....	339
12.4	Protecting data.....	340
12.5	Saving and recalling settings.....	341
12.5.1	Save/Recall settings.....	342
12.5.2	Saving and recalling instrument settings.....	344
12.6	Accessing files with user data.....	346
12.6.1	File select settings.....	346
12.7	Exporting and importing remote command lists.....	348
12.8	Loading, importing and exporting lists.....	348
12.9	Using the file manager.....	348

12.9.1	File manager settings.....	349
12.9.2	Map network share settings.....	350
12.9.3	Displaying all saved files.....	352
12.9.4	Mapping a network folder.....	352
12.10	Transferring files from and to the instrument.....	354
12.10.1	Removing file system protection.....	355
12.10.2	Accessing the file system using FTP.....	356
12.10.3	Accessing the R&S SMA100B file system using SMB (Samba).....	357
12.10.4	Using a USB storage device for file transfer.....	359
12.10.5	Using a file server for test files exchange.....	359
12.11	Creating screenshots of current settings.....	360
12.11.1	Hardcopy settings.....	360
12.11.2	Creating a hardcopy of the display.....	364
13	General instrument functions.....	366
13.1	Customizing the user interface.....	366
13.1.1	Display and keyboard settings.....	367
13.1.2	Display update settings.....	369
13.1.3	Defining the RF signal state on power on.....	370
13.1.4	How to set the initial instrument settings.....	370
13.2	Organizing frequently used settings as favorites.....	372
13.2.1	Configuring settings quickly with the user menu.....	374
13.2.2	How to assign actions to the [★ (User)] key.....	376
13.2.3	User menu settings.....	377
13.2.4	Define user key actions settings.....	378
13.3	Managing licenses and license keys.....	380
13.3.1	Manage license keys settings.....	380
13.3.2	Using the license server.....	383
13.3.3	How to move a portable license.....	387
13.4	Using the security settings.....	389
13.4.1	Disk & memory security settings.....	390
13.4.2	Manual operation security settings.....	392
13.4.3	Protection level settings.....	394
13.4.4	Configuring LAN services.....	395

13.4.5	Password management.....	399
13.4.6	Preventing unauthorized access.....	402
13.5	Undoing or restoring actions.....	406
13.6	Shutting down and rebooting the instrument.....	407
14	Network operation and remote control.....	408
14.1	Overview of remote access modes.....	409
14.2	Remote control interfaces and protocols.....	410
14.2.1	LAN interface.....	411
14.2.2	USB interface.....	413
14.2.3	GPIB interface (IEC/IEEE bus interface).....	414
14.2.4	LXI browser interface.....	415
14.3	Remote control programs and libraries.....	415
14.4	Status reporting system.....	418
14.4.1	Overview of the status registers.....	418
14.4.2	Instrument-specific status operation register.....	420
14.4.3	Instrument-specific status questionable register.....	420
14.4.4	Reset values of the status reporting system.....	421
14.5	Remote access settings.....	421
14.5.1	Network settings.....	422
14.5.2	VISA resource strings settings.....	425
14.5.3	GPIB address settings.....	426
14.5.4	RS232 settings.....	427
14.5.5	Instrument emulations settings.....	428
14.5.6	Active remote connection settings.....	430
14.5.7	Closed remote connection settings.....	431
14.5.8	HUMS settings.....	432
14.5.9	HUMS enhanced settings.....	434
14.5.10	QR code.....	443
14.6	LXI status settings.....	444
14.7	LXI browser settings.....	445
14.7.1	LAN configuration.....	447
14.7.2	SCPI remote trace.....	449
14.7.3	Health and utilization.....	451

14.7.4	Datasheet.....	451
14.8	Setting up remote control.....	452
14.8.1	Configuring remote access.....	453
14.8.2	Starting remote control with LXI.....	456
14.8.3	Starting remote control with VXI-11.....	457
14.8.4	Starting remote control with socket communication.....	462
14.8.5	Starting remote control over GPIB.....	463
14.8.6	Starting remote control over USB.....	464
14.8.7	Stopping remote control.....	464
14.9	Using remote command scripts.....	466
14.9.1	SCPI recording settings.....	466
14.9.2	Creating remote command lists.....	470
14.9.3	Checking and verifying a remote command list.....	473
14.9.4	Converting a remote command list to a script.....	474
14.9.5	Running a remote command script.....	476
14.10	Setting up remote operation over VNC.....	476
14.10.1	Using a controller PC.....	477
14.10.2	Using a smart device.....	479
14.10.3	Stopping remote operation.....	482
14.11	References.....	482
14.11.1	LXI functionality.....	482
14.11.2	Code generator templates.....	483
15	Remote control commands.....	486
15.1	Conventions used in SCPI command descriptions.....	486
15.2	Programming examples.....	487
15.3	Common commands.....	488
15.4	Preset commands.....	492
15.5	MMEMory subsystem.....	494
15.5.1	File naming conventions.....	494
15.5.2	Handling files in the default or in a specified directory.....	495
15.5.3	Programming examples.....	496
15.5.4	Remote control commands.....	498
15.6	CALibration subsystem.....	504

15.7	CSYNthesis subsystem	508
15.8	DIAGnostic subsystem	513
15.9	HUMS remote control commands	516
15.10	DISPlay subsystem	523
15.11	FORMat subsystem	528
15.12	HCOPy subsystem	529
15.12.1	Hard copy settings	531
15.12.2	Automatic naming	532
15.13	KBOard subsystem	535
15.14	OUTPut subsystem	536
15.15	Power sensor measurement subsystems	540
15.15.1	CALCulate subsystem	541
15.15.2	DISPlay subsystem	549
15.15.3	INITiate command	550
15.15.4	READ subsystem	550
15.15.5	SENSe SWEep subsystem	551
15.15.6	TRACe subsystem	583
15.16	SENSe, READ, INITiate and SLISt subsystems	595
15.17	SCONfiguration subsystem	608
15.17.1	External instruments	610
15.18	SOURce subsystem	613
15.18.1	Analog modulation subsystems	614
15.18.2	Avionic standards subsystems	646
15.18.3	SOURce:CORRection subsystem	689
15.18.4	SOURce:EFRontend subsystem	697
15.18.5	SOURce:FREQuency subsystem	700
15.18.6	SOURce:INPut subsystem	709
15.18.7	SOURce:LFOutput subsystem	710
15.18.8	SOURce:LIST subsystem	723
15.18.9	SOURce:NOISe subsystem	735
15.18.10	SOURce:PGEN subsystem	737
15.18.11	SOURce:PHASe subsystem	739
15.18.12	SOURce:POWer subsystem	740

15.18.13	SOURce:ROSCillator subsystem.....	754
15.18.14	SOURce:SWEEP subsystem.....	760
15.19	SYSTem subsystem.....	776
15.20	STATus subsystem.....	806
15.21	TEST subsystem.....	810
15.22	TRIGger subsystem.....	813
15.23	UNIT subsystem.....	817
16	Troubleshooting and notifications.....	818
16.1	Notifications.....	818
16.1.1	Volatile notifications.....	818
16.1.2	Permanent notifications.....	819
16.2	SCPI notifications.....	819
16.3	Device-specific notifications.....	819
16.4	Querying notifications.....	821
16.5	Resolving network connection failures.....	823
16.6	Resolving errors during internal adjustments.....	824
16.7	Measuring USB cable quality.....	825
16.8	Checking the instrument configuration.....	825
16.8.1	Hardware configuration settings.....	827
16.8.2	Versions and options settings.....	828
16.9	Collecting information for technical support.....	830
16.10	Contacting customer support.....	831
17	Transporting.....	833
18	Maintenance, storage and disposal.....	834
18.1	Cleaning.....	834
18.2	Storage.....	834
18.3	Performing maintenance tasks.....	834
18.3.1	Internal adjustments.....	834
18.3.2	Date and time.....	839
18.3.3	Check front panel.....	842
18.3.4	Check display screen.....	845
18.3.5	FPGA/uC update settings.....	846

18.3.6	Delete temporary files.....	848
18.4	Disposal.....	849
	Annex.....	850
A	Reference information for remote control.....	850
A.1	Telnet program examples.....	850
A.2	GPIB interface.....	855
B	Available user files and file extensions.....	857
C	Unit shortcuts.....	858
D	Morse code settings.....	860
	Glossary: Terms and abbreviations.....	861
	Glossary: Publications and references.....	865
	List of Commands.....	867
	Index.....	885

1 Safety and regulatory information

The product documentation helps you use the product safely and efficiently. Follow the instructions provided here and in the following sections.

Intended use

The product is intended for the development, production and verification of electronic components and devices. It generates radio frequency (RF) signals for test setups in industrial, administrative, and laboratory environments. Use the product only for its designated purpose. Observe the operating conditions and performance limits stated in the specifications document.

Target audience

The target audience of this document includes developers, technicians, operators, administrators and maintenance personnel. The required skills and experience of the users depend on the test setup and application of the product.

Where do I find safety information?

Safety information is part of the product documentation. It warns you of potential dangers and gives instructions on how to prevent personal injury or damage caused by dangerous situations. Safety information is provided as follows:

- In [Section 1.1, "Safety instructions"](#), on page 15. The same information is provided in many languages in printed format. The printed "Safety Instructions" for "Mains-Powered Products, Heavy" (document number 1171.1788.99) are delivered with the product.
- Throughout the documentation, safety instructions are provided when you need to take care during setup or operation.

1.1 Safety instructions

Products from the Rohde & Schwarz group of companies are manufactured according to the highest technical standards. To use the products safely, follow the instructions provided here and in the product documentation. Keep the product documentation nearby and offer it to other users.

Use the product only for its intended use and within its performance limits. Intended use and limits are described in the product documentation such as the specifications document, manuals and the printed "Safety Instructions" document. If you are unsure about the appropriate use, contact Rohde & Schwarz customer support.

Using the product requires skilled persons or specially trained personnel. These users also need sound knowledge of at least one of the languages in which the user interfaces and the product documentation are available.

Reconfigure or adjust the product only as described in the product documentation or the specifications document. Any other modifications can affect safety and are not permitted.

Never open the casing of the product. Only service personnel authorized by Rohde & Schwarz are allowed to repair the product. If any part of the product is damaged or broken, stop using the product. Contact Rohde & Schwarz customer support at <https://www.rohde-schwarz.com/support>.

Lifting and carrying the product

The product is heavy. Do not move or carry the product by yourself. A single person can only carry a maximum of 18 kg safely depending on age, gender and physical condition. Look up the maximum weight in the specifications document. Use the product handles to move or carry the product. Do not lift by the accessories mounted on the product. Accessories are not designed to carry the weight of the product.

To move the product safely, you can use lifting or transporting equipment such as lift trucks and forklifts. Follow the instructions provided by the equipment manufacturer.

Choosing the operating site

Only use the product indoors. The product casing is not waterproof. Water that enters can electrically connect the casing with live parts, which can lead to electric shock, serious personal injury or death if you touch the casing.

If Rohde & Schwarz provides accessories designed for outdoor use of your product, e.g. a protective cover, you can use the product outdoors.

You can operate the product up to an altitude of 2000 m above sea level. If a higher altitude is permissible, the value is provided in the specifications document. The product is suitable for pollution degree 2 environments where nonconductive contamination can occur. For more information on environmental conditions such as ambient temperature and humidity, see the specifications document.

Setting up the product

Always place the product on a stable, flat and level surface with the bottom of the product facing down. If the product is designed for different positions, secure the product so that it cannot fall over.

If the product has foldable feet, always fold the feet completely in or out to ensure stability. The feet can collapse if they are not folded out completely or if the product is moved without lifting it. The foldable feet are designed to carry the weight of the product, but not an extra load.

If stacking is possible, keep in mind that a stack of products can fall over and cause injury.

If you mount products in a rack, ensure that the rack has sufficient load capacity and stability. Observe the specifications of the rack manufacturer. Always install the products from the bottom shelf to the top shelf so that the rack stands securely. Secure the product so that it cannot fall off the rack.

Connecting the product

Before connecting the interfaces or measuring inputs of the product to other products or electrical circuits, make sure that the other products or electrical circuits provide special protection against electric shock. This protection principle is referred to as SELV (safety extra-low voltage) and is based on a low voltage level and increased insulation. Exceptions are indicated by a measurement category on the product and given in the specifications document.

Connecting to power

The product is an overvoltage category II product. Connect the product to a fixed installation used to supply energy-consuming equipment such as household appliances and similar loads. Keep in mind that electrically powered products have risks, such as electric shock, fire, personal injury or even death. Replace parts that are relevant to safety only by original parts, e.g. power cables or fuses.

Take the following measures for your safety:

- Before switching on the product, ensure that the voltage and frequency indicated on the product match the available power source. If the power adapter does not adjust automatically, set the correct value and check the rating of the fuse.
- Only use the power cable delivered with the product. It complies with country-specific safety requirements. Only insert the plug into an outlet with protective conductor terminal.
- Only use intact cables and route them carefully so that they cannot be damaged. Check the power cables regularly to ensure that they are undamaged. Also ensure that nobody can trip over loose cables.
- Only connect the product to a power source with a fuse protection of maximum 20 A.
- Ensure that you can disconnect the product from the power source at any time. Pull the power plug to disconnect the product. The power plug must be easily accessible. If the product is integrated into a system that does not meet these requirements, provide an easily accessible circuit breaker at the system level.

Cleaning the product

Use a dry, lint-free cloth to clean the product. When cleaning, keep in mind that the casing is not waterproof. Do not use liquid cleaning agents.

Meaning of safety labels

Safety labels on the product and its accessories warn against potential hazards.

	Potential hazard Read the product documentation to avoid personal injury or product damage.
	Heavy product Be careful when lifting, moving or carrying the product. Carrying the product requires a sufficient number of persons or transport equipment.

	Electrical hazard Indicates live parts. Risk of electric shock, fire, personal injury or even death.
	Hot surface Do not touch. Risk of skin burns. Risk of fire.
	Protective conductor terminal Connect this terminal to a grounded external conductor or to protective ground. This connection protects you against electric shock if an electric problem occurs.

1.2 Labels on R&S SMA100B

Labels on the casing inform about:

- Personal safety, see "[Connecting to power](#)" on page 17.
- Product and environment safety, see "[Labels regarding product and environment safety](#)" on page 18.
- Identification of the product, see the serial number on the rear panel.

Labels regarding product and environment safety

	Labeling in line with EN 50419 for disposal of electrical and electronic equipment after the product has come to the end of its life.
---	---

1.3 Warning messages in the documentation

A warning message points out a risk or danger that you need to be aware of. The signal word indicates the severity of the safety hazard and how likely it will occur if you do not follow the safety precautions.

DANGER

Imminently hazardous situation. Will result in death or serious injury if not avoided.

WARNING

Potentially hazardous situation. Could result in death or serious injury if not avoided.

CAUTION

Potentially hazardous situation. Could result in minor or moderate injury if not avoided.

NOTICE

Potential risks of damage. Could result in damage to the supported product or to other property.

1.4 CE declaration of conformity

The CE declaration of conformity of the base unit is delivered with the product. Keep the document for further reference. The current version of this CE declaration of conformity is available at:

www.rohde-schwarz.com/company-documents/sma100b

1.5 Where to find key documents on Rohde & Schwarz

Certificates issued to Rohde & Schwarz that are relevant for your country are provided at www.rohde-schwarz.com/key-documents, e.g. concerning:

- Quality management
- Environmental management
- Information security management
- Accreditations

1.6 Korea certification class A



이 기기는 업무용(A급) 전자파 적합기기로서 판매자 또는 사용자는 이 점을 주의하시기 바라며, 가정외의 지역에서 사용하는 것을 목적으로 합니다.

2 Welcome

The R&S SMA100B is a high-performance signal generator developed to meet demanding customer requirements. Offering excellent signal characteristic and straightforward and intuitive operation, the signal generator makes signal generation fast and easy.

2.1 Key features

Outstanding key features of the R&S SMA100B are:

- Frequency range from 8 kHz to up to 20 GHz (overrange 72 GHz)
- Excellent signal quality
- Excellent single sideband (SSB) phase noise
- Nearly no wideband noise
- Very high output power
- Low harmonics
- Unique pulse train generation
- High-stability reference oscillator
- Intuitive operation via touchscreen with the tile diagram as key element

For more information, refer to the specifications document.

2.2 What's new

This manual describes firmware version FW 5.40.102.xx and later of the R&S®SMA100B.

Compared to the previous version, it provides the new features listed below:

- ILS signal generation of CSB (carrier and sidebands) signals only, see "[ILS signals](#)" on page 136 and "[CSB signal](#)" on page 139.
- Editorial changes

2.3 Documentation overview

This section provides an overview of the R&S SMA100B user documentation. Unless specified otherwise, you find the documents at:

www.rohde-schwarz.com/manual/sma100b

2.3.1 Getting started manual

Introduces the R&S SMA100B and describes how to set up and start working with the product. Includes basic operations, typical measurement examples, and general information, e.g. safety instructions, etc. A printed version is delivered with the instrument.

2.3.2 User manuals and help

Contains the description of all instrument modes and functions. It also provides an introduction to remote control, a complete description of the remote control commands with programming examples, and information on maintenance, instrument interfaces and error messages. Includes the contents of the getting started manual.

The contents of the user manuals are available as help in the R&S SMA100B. The help offers quick, context-sensitive access to the complete information.

All user manuals are also available for download or for immediate display on the internet.

2.3.3 Service manual

Describes the performance test for checking compliance with rated specifications, firmware update, troubleshooting, adjustments, installing options and maintenance.

The service manual is available for registered users on the global Rohde & Schwarz information system (GLORIS):

<https://gloris.rohde-schwarz.com>

2.3.4 Instrument security procedures

Deals with security issues when working with the R&S SMA100B in secure areas. It is available for download on the internet.

2.3.5 Printed safety instructions

Provides safety information in many languages. The printed document is delivered with the product.

2.3.6 Specifications and product brochures

The specifications document, also known as the data sheet, contains the technical specifications of the R&S SMA100B. It also lists the firmware applications and their order numbers, and optional accessories.

The brochure provides an overview of the instrument and deals with the specific characteristics.

See www.rohde-schwarz.com/brochure-datasheet/sma100b

2.3.7 Calibration certificate

The document is available on <https://gloris.rohde-schwarz.com/calcert>. You need the device ID of your instrument, which you can find on a label on the rear panel.

2.3.8 Release notes and open source acknowledgment

The release notes list new features, improvements and known issues of the current software version, and describe the software installation.

The software uses several valuable open source software packages. An open source acknowledgment document provides verbatim license texts of the used open source software.

www.rohde-schwarz.com/firmware/sma100b

2.3.9 Application notes, application cards, white papers, etc.

These documents deal with special applications or background information on particular topics.

For some application sheets, see also:

www.rohde-schwarz.com/application/sma100b

2.3.10 Videos

Find various videos on Rohde & Schwarz products and test and measurement topics on YouTube: <https://www.youtube.com/@Rohde-Schwarz>

3 Getting started

3.1 Preparing for use

Here, you can find basic information about setting up the product for the first time.

3.1.1 Lifting and carrying

For safety information, see ["Lifting and carrying the product"](#) on page 16.

Use the handles for lifting and carrying the R&S SMA100B.




Figure 3-1: Instrument side view with front handles (1) and side handles (2)

3.1.2 Unpacking and checking

1. Unpack the R&S SMA100B carefully.
2. Retain the original packing material. Use it to protect the control elements and connectors when transporting or shipping the R&S SMA100B later.
See also [Section 17, "Transporting"](#), on page 833.
3. Using the delivery notes, check the equipment for completeness.
4. Check the equipment for damage.

If the delivery is incomplete or equipment is damaged, contact Rohde & Schwarz.

3.1.3 Choosing the operating site

Specific operating conditions ensure proper operation and avoid damage to the product and connected devices. For information on environmental conditions such as ambient temperature and humidity, see the specifications document.

For safety information, see ["Choosing the operating site"](#) on page 16.

Electromagnetic compatibility classes

The electromagnetic compatibility (EMC) class indicates where you can operate the product. The EMC class of the product is given in the specifications document.

- Class B equipment is suitable for use in:

- Residential environments
- Environments that are directly connected to a low-voltage supply network that supplies residential buildings
- Class A equipment is intended for use in industrial environments. It can cause radio disturbances in residential environments due to possible conducted and radiated disturbances. It is therefore not suitable for class B environments. If class A equipment causes radio disturbances, take appropriate measures to eliminate them.

3.1.4 Setting up the R&S SMA100B

See also:

- ["Setting up the product"](#) on page 16
- ["Intended use"](#) on page 15

3.1.4.1 Placing the R&S SMA100B on a bench top

To place the product on a bench top


1. Place the product on a stable, flat and level surface. Ensure that the surface can support the weight of the product. For information on the weight, see the specifications document.
2. **CAUTION!** Foldable feet can collapse. For safety information, see ["Setting up the product"](#) on page 16.

Always fold the feet completely in or out. With folded-out feet, do not place anything on top or underneath the product.

3. **WARNING!** A stack of products can fall over and cause injury. Never stack more than three products on top of each other. Instead, mount them in a rack.

Stack as follows:

- If the products have foldable feet, fold them in completely.
- It is best if all products have the same dimensions (width and length). If the products have different dimensions, stack according to size and place the smallest product on top.
- Do not exceed the permissible total load placed on the product at the bottom of the stack:
 - 50 kg when stacking products of identical dimensions (left figure).
 - 25 kg when stacking smaller products on top (middle figure).



Left = Stacked correctly, same dimensions
 Middle = Stacked correctly, different dimensions
 Right = Stacked incorrectly, too many products

4. **NOTICE!** Overheating can damage the product.

Prevent overheating as follows:

- Keep a minimum distance of 10 cm between the fan openings of the product and any object in the vicinity to provide sufficient airflow and ventilation.
- Do not place the product next to heat-generating equipment such as radiators or other products.

3.1.4.2 Mounting the product in a rack

To prepare the rack

1. Observe the requirements and instructions in ["Setting up the product"](#) on page 16.
2. **NOTICE!** Insufficient airflow can cause overheating and damage the product.
Design and implement an efficient ventilation concept for the rack.

To mount the product in a rack

1. Use an adapter kit that fits the dimensions of the R&S SMA100B to prepare the instrument for rack mounting.
 - a) Order the rack adapter kit designed for the R&S SMA100B.
For more information, refer to the specifications document.
 - b) Mount the adapter kit. Follow the assembly instructions provided with the adapter kit.
2. **WARNING!** The product is heavy. For safety information, see ["Lifting and carrying the product"](#) on page 16.
Lift the product to shelf height.
3. Grab the handles at the front.
4. Push the R&S SMA100B onto the shelf until the rack brackets fit closely to the rack.

5. Tighten all screws at the rack brackets with a tightening torque of 1.2 Nm to secure the R&S SMA100B in the rack.

To unmount the product from a rack

1. Loosen the screws at the rack brackets.
2. **WARNING!** The product is heavy. For safety information, see "[Lifting and carrying the product](#)" on page 16.
Bring the lifting equipment to shelf height.
3. Remove the R&S SMA100B from the rack.
4. If placing the R&S SMA100B on a bench top again, unmount the adapter kit from the R&S SMA100B. Follow the instructions provided with the adapter kit.

3.1.5 Considerations for test setup

For safety information, see "[Connecting the product](#)" on page 17.

Cable selection to minimize electromagnetic interference

Electromagnetic interference (EMI) can affect the measurement results.

To suppress electromagnetic radiation during operation:

- Use high-quality shielded cables, for example, double-shielded RF, LAN and USB cables.
- Always terminate open cable ends.
- Ensure that connected external devices comply with EMC regulations.

Signal input and output levels

Keep the signal levels within the specified ranges to avoid damage to the R&S SMA100B and connected devices.

For more information, refer to the specifications document.

Preventing electrostatic discharge (ESD)

Electrostatic discharge is most likely to occur when you connect or disconnect a DUT.

- **NOTICE!** Electrostatic discharge can damage the electronic components of the product and the device under test (DUT).

Ground yourself to prevent electrostatic discharge damage:

- a) Use a wrist strap and cord to connect yourself to ground.
- b) Use a conductive floor mat and heel strap combination.

3.1.6 Connecting to power

For safety information, see "[Connecting to power](#)" on page 17.

1. Plug the AC power cable into the AC power connector on the rear panel. Only use the AC power cable delivered with the R&S SMA100B.
2. Plug the AC power cable into a power outlet with ground contact.
The required ratings are listed next to the AC power connector.

For more information, refer to the specifications document.

3.1.7 Connecting to LAN

Network environment

Before connecting the product to a local area network (LAN), consider the following:


- Install the latest firmware to reduce security risks.
- For internet or remote access, use secured connections if applicable.
- Ensure that the network settings comply with the security policies of your company. Contact your local system administrator or IT department before connecting your product to your company LAN.
- When connected to the LAN, the product may potentially be accessed from the internet, which may be a security risk. For example, attackers might misuse or damage the product.

To connect to LAN

- Connect the LAN socket on the rear panel via an RJ-45 cable to the LAN.

Using DHCP (dynamic host configuration protocol), the R&S SMA100B assigns the IP address automatically.

If connected to the LAN, the R&S SMA100B displays the IP address and the host name at the left bottom of the home screen.



1 = Hostname
2 = IP address

If disconnected from the LAN, the R&S SMA100B displays the IP address 0.0.0.0.

See also [Section 14.8, "Setting up remote control"](#), on page 452.

3.1.8 Connecting USB devices

You can connect or disconnect all USB devices from the R&S SMA100B during operation.

To connect USB storage devices

USB storage devices, such as memory sticks, allow data transfer from or to the R&S SMA100B. You can also use them for firmware updates.

- ▶ Connect the USB storage device to any of the USB connectors.

To connect USB devices with an external power supply

1. **NOTICE!** Connected devices with external power supply can feed back current into the 5 V power supply of the USB interface and thus damage the R&S SMA100B.

Ensure that there is no connection between the positive pole of the power supply and the +5 V power pin of the USB interface (VBUS).

2. Connect the USB device to any of the USB connectors.

To connect a keyboard

- ▶ Connect the keyboard to any of the USB connectors.

When connected, the R&S SMA100B detects the keyboard automatically. A detected keyboard has the default layout English – US.

To connect a mouse

- ▶ Connect the mouse to any of the USB connectors.

When connected, the R&S SMA100B detects the mouse automatically.

To connect power sensors

Connect the power sensors of the R&S NRP families to any of the USB connectors.

See [Section 9.4, "Using power sensors"](#), on page 249.

To connect a frequency multiplier

- ▶ Connect the frequency multiplier for control connection to the "USB" connector on the front panel or rear panel.

3.1.9 Connecting to RF coaxial connectors

Here, you find information on how to prepare and to connect to RF coaxial connectors of the R&S SMA100B. Use these RF connectors, for example, for output of the RF signal or for input of an external reference signal.

To prepare for connecting

1. **NOTICE!** Damaged or not clean connections can lead to RF insertion loss and mismatch, and even premature wear of the connectors.

Before connecting to the port, inspect the RF connector visually. Check that it is clean, undamaged and mechanically compatible.

2. **NOTICE!** DC voltage at the RF connector can damage the instrument. Never apply DC voltage to the RF input connectors.
Make sure that the values are within the DC limits given in the specifications document.
3. If your test setup has a DC component at the RF input, insert a DC blocker.
4. Use a high-quality RF cable that matches the RF connector type. See also "[Cable selection to minimize electromagnetic interference](#)" on page 26.
5. You can connect to two kinds of connectors:
 - "[To connect to screwable connectors](#)" on page 29
 - "[To connect to pluggable connectors](#)" on page 29

To connect to screwable connectors

To connect the cable with the connector, proceed as follows:

1. Carefully align the connector of the cable and the connector along a common axis.
2. Mate the connectors along the common axis until the male pin of the inner connector engages with the female socket of the outer connector.
3. Turn the nut of the outer connector until you couple the connectors firmly.
4. **NOTICE!** Excessive tightening can damage the connectors.
Using a calibrated torque wrench torque the nut to the limit as in the table below.
Hold the opposite connector part stationary with a spanner.

The R&S SMA100B provides screwable RF connectors as in [Table 3-1](#).

Table 3-1: Connector name, type, size, torque limit and nut opening

Connector		Torque limit		Nut opening	
Type	Name	lb-Inch	Nm	Inch	mm
N	RF 50 $\Omega^*)$	13.3	1.5	3/4	20
SMA	Clk Syn Clk Syn N Ref In 1 GHz Ref Out 1 GHz	5	0.56	5/16	8
2.92 mm	RF 50 $\Omega^*)$	8	0.9	5/16	8
1.85 mm	RF 50 $\Omega^*)$	8	0.9	5/16	8

*) maximum frequency $f_{\max}$ depends on the connector type: $f_{\max}(\text{N}) \leq 7 \text{ GHz}$, $f_{\max}(2.92 \text{ mm}) \leq 40 \text{ GHz}$, $f_{\max}(1.85 \text{ mm}) \leq 67 \text{ GHz}$

To connect to pluggable connectors

The R&S SMA100B provides pluggable Bayonet Neill-Concelman (BNC) connectors.

To connect the RF cable with the BNC connector, proceed as follows:

1. Carefully align the connector of the cable and the BNC connector along a common axis.
2. Mate the connectors along the common axis until the male pin of the connector of the cable engages with the female socket of the BNC connector.

For more information on handling and maintaining coaxial RF connectors, see the application note [1MA99](#).

For information on mounting test port adapters onto the RF connector, see the application note [1MA100](#).

3.1.10 Connecting to RF 50 Ω

1. Before connecting, disable the RF output:
In the home screen, switch off the RF block.
2. For connection, use the connector "RF 50 Ω " on the front panel.
See ["To connect to screwable connectors"](#) on page 29.

To prevent RF output switch-off

- **NOTICE!** High reflected powers can force the R&S SMA100B to switch off the RF output.
Connect a load with sufficient return loss.
For more information, refer to the specifications document.

3.1.11 Connecting to Ref In/Ref Out

For connection, the R&S SMA100B provides BNC connectors or SMA connectors on the rear panel. See ["To connect to pluggable connectors"](#) on page 29 and ["To connect to screwable connectors"](#) on page 29.

3.1.12 Switching on or off

The following table provides an overview of power states, LEDs and positions of the power switch.

Table 3-2: Overview of power states

State	LED	Position of power switch
Off	● gray	[0]
Standby	● orange	[1]
Ready	● green	[1]

To switch on the R&S SMA100B

The R&S SMA100B is off but connected to power. See [Section 3.1.6, "Connecting to power"](#), on page 26.

1. Set the switch on the power supply to position [I] on the rear panel.

The LED of the [On/Standby] key on the front panel is orange.

2. Press the [On/Standby] key on the front panel.

The LED changes to green. The R&S SMA100B boots.

After booting, the R&S SMA100B starts up displaying the home screen on the screen on the front panel.

To check startup functions

When starting for the first time, the R&S SMA100B starts with the default settings. When restarting, the R&S SMA100B recalls the instrument configuration before shut-down.

See [Section 12.5.2, "Saving and recalling instrument settings"](#), on page 344.

When switched on, the R&S SMA100B monitors the main functions and logs erroneous functions. See the following:

See [Section 16.4, "Querying notifications"](#), on page 821.

To shut down the product

The product is in the ready state.

- Press the [On/Standby] key.

The operating system shuts down. The LED changes to orange. The product changes to standby state.

In the standby state, the power switch circuits are active. To deactivate them, disconnect the instrument from the power supply.

To disconnect from power

The R&S SMA100B is in the standby state.

1. **NOTICE!** Risk of data loss. If you disconnect the product from power when it is in the ready state, you can lose settings and data. Shut it down first.

Set the toggle switch on the power supply to position [0].

The LED of the [On/Standby] key is switched off.

2. Disconnect the R&S SMA100B from the power source.

3.2 Instrument tour

This section explains the control elements and the connectors of the R&S SMA100B. The views of the front panel and the rear panel help you to get familiar with the instrument and to perform the first steps. For specifications of the interfaces, see the specifications document.

The meanings of the labels on the R&S SMA100B are described in [Section 1.2, "Labels on R&S SMA100B"](#), on page 18.

3.2.1 Front panel tour

This section provides an overview of the control elements at the front panel of the R&S SMA100B. The figures below illustrate two instrument models with height units 2 HU (R&S SMAB-B92) and 3 HU (R&S SMAB-B93).

On the rear panel, you find all further connectors, see [Section 3.2.2, "Rear panel tour"](#), on page 39.



Figure 3-2: Front panel view of R&S SMA100B (2 HU, R&S SMAB-B92)

- 1 = Utility keys
- 2 = Touchscreen
- 3 = Function keys
- 4 = Navigation controls
- 5 = Display keys
- 6 = SD card slot
- 7 = USB connector
- 8 = RF 50 Ω
- 9 = Sensor
- 10 = Keypad
- 11 = On/Standby




Figure 3-3: Front panel view of R&S SMA100B (3 HU, R&S SMAB-B93)

- 1 = On/Standby
- 2 = Utility keys
- 3 = Touchscreen
- 4 = Keypad
- 5 = Function keys
- 6 = Navigation controls
- 7 = Display keys
- 8 = SD card slot
- 9 = USB connector
- 10 = Sensor
- 11 = RF 50 Ω
- 12 = Pulse signal connectors
- 13 = LF
- 14 = Ext 1/2
- 15 = Clock synthesizer connectors

3.2.1.1 Touchscreen

The screen display on the front panel is the graphical user interface. It shows the most important settings, the current configuration at a glance and provides access to the settings dialogs.




Figure 3-4: Touchscreen

The screen is touch-sensitive, offering an alternative means of user interaction for quick and easy handling of the instrument.

See also:

- [Section 3.4.2, "Understanding the display information"](#), on page 52.
- [Section 3.4, "Operating the instrument"](#), on page 50, for operating the touch-screen.
- [Section 18.1, "Cleaning"](#), on page 834, for cleaning the screen.

3.2.1.2 Utility keys

The utility keys set the R&S SMA100B to a defined state, and provide access to basic settings and information on assistance.

Table 3-3: Utility keys

Utility Key	Assigned functions
[Preset]	Sets the instrument to a defined state
[Local]	Switches from remote control to local (manual) control
[Setup]	Accesses the general instrument settings
[Help]	Displays context-sensitive help text

3.2.1.3 On/Standby

The [On/Standby] key switches the instrument from the standby to the ready state or vice versa.

The LED above the [On/Standby] key indicates the instrument state, see [Section 3.1.12, "Switching on or off"](#), on page 30.

3.2.1.4 Function keys

Function keys provide access to the most common generator settings and functions. You can find a detailed description of the corresponding functions in the user manual.

Table 3-4: Function keys

Function key	Assigned functions
[Freq]	Activates frequency entry.
[Level]	Activates level entry.
[Mod on/off]	Switches the modulation on and off.
[RF on/off]	Switches the RF output on and off.

3.2.1.5 Keypad

The keypad enables you to enter alphanumeric parameters, including the corresponding units. It contains the following keys:

Table 3-5: Keys on the keypad

Type of key	Description
Alphanumeric keys	Enter numbers and (special) characters in edit dialog boxes.
Decimal point	Inserts a decimal point "." at the cursor position.
Sign key	Changes the sign of a numeric parameter. For an alphanumeric parameter, inserts a "-" at the cursor position.
Unit keys (G/n dBμV, M/μ μV, k/m mV and x1 dB(m))	These keys add the selected unit to the entered numeric value and complete the entry. For level entries (e.g. in dB) or dimensionless values, all units have the value "1" as the multiplying factor. Thus, they have the same function as the [Enter] key.

3.2.1.6 Navigation controls

The navigation controls include a rotary knob, navigation keys, and the display keys. They allow you to navigate within the display or within dialog boxes.

Rotary knob

The rotary knob has several functions:

- Increments (clockwise direction) or decrements (counterclockwise direction) numeric instrument parameters at a defined step size.
- Moves the selection, e.g. to a function block in the block diagram
- Shifts the selection bar within focused areas (e.g. lists).
- Acts like the [Enter] key when it is pressed.

- Opens a context-sensitive menu when it is pressed and held.

Editing keys

Editing keys enable you to confirm an entry, delete individual characters, or exit the current operation.

Table 3-6: Editing keys

Type of key	Description
[Esc] key	Closes all kinds of dialog boxes, if the edit mode is not active. Quits the edit mode, if the edit mode is active. Equals selecting the "Cancel" button in dialogs, if provided. For "Edit" dialog boxes, the following applies: • If a data entry has been started, it retains the original value and closes the dialog box. • If data entry has not been started or has been completed, it closes the dialog box.
[Enter] key	Has the same effect as pressing the rotary knob. • Concludes the entry of dimensionless entries. The new value is accepted. • With other entries, this key can be used instead of the default unit key. • In a dialog box, selects the default or focused element. • Calls the next dialog level. • Confirms and closes open input windows.
[Backspace] key	Deletes the character to the left of the cursor in editing mode.

Navigation keys

As an alternative to the rotary knob or the touchscreen, you can use the navigation keys to navigate through dialog boxes, diagrams, or tables.

Table 3-7: Navigation keys

Type of key	Description
[Up/Down] Key	The [Up] and the [Down] key does the following: • In a numeric edit dialog box, increase or decrease the instrument parameter. • In a list, scroll forward and backward through the list entries. • In a table, move the selection bar vertically. • In windows or dialog boxes with vertical scrollbar, move the scrollbar.
[Left/Right] Key	The [Left] and the [Right] key does the following: • In an alphanumeric edit dialog box, move the cursor. • In a list, scroll forward and backward through the list entries. • In a table, move the selection bar horizontally. • In windows or dialog boxes with horizontal scrollbar, move the scrollbar.

3.2.1.7 Display keys

The display keys arrange different windows on the display.

Table 3-8: Display keys

Display key	Assigned functions
[Home]	Returns to the initial feature screen.
[Next window]	Toggles between the entry fields in the taskbar.
[On/Off]	- Switches highlighted elements or a function block on and off. - Switches between two or more settings, e.g. items of selection lists. At the end of a list, the cursor is set on the first entry again.
[Undo]	Reverts to the last operation.
[★ (User)]	Adds a parameter to the user menu for quick access.

3.2.1.8 SD card slot

Option: R&S SMAB-B85

Slot for removable mass storage.

To prevent from unauthorized removal, the SD card holder includes wholes that provide the opportunity of sealing the SD card. We recommend that you seal the SD card crosswise.

3.2.1.9 USB connector

Female USB type A connector, to connect devices like a keyboard, a mouse, a memory stick, or the R&S NRP-Z3/Z4 cable for the R&S NRP power sensors.

How to: [Section 3.1.8, "Connecting USB devices"](#), on page 27

3.2.1.10 Sensor

Connector for R&S NRP sensors.

A power sensor is connected to the R&S SMA100B by inserting the male connector. To disconnect, pull the connector by its sleeve. You cannot disconnect the sensor simply by pulling at the cable or the rear part of the connector.

The R&S SMA100B supports the use of R&S NRP power sensors in various ways including the use as a power viewer.



The female connector allows the mechanical connection of 6-pole and 8-pole male connectors.

It mates with the interface cables R&S NRP-ZK8 and R&S NRP-ZK6, used for connecting R&S NRPxx power sensors, and also with the six-pole push-pull plugs of the R&S NRP-Zxx series.

However, the signal pair of the common timebase clock assigned to the two pins in the center of the male connectors is not available. These pins are used by Rohde & Schwarz power meters to synchronize several power sensors.

Further information on connecting and using power sensors, see [Section 9.4.2, "Connecting R&S NRP power sensors to the R&S SMA100B"](#), on page 251, [Section 9.4.7, "NRP power analysis"](#), on page 266, [Section 9.4.6, "NRP sensor mapping"](#), on page 263, [Section 9.4.7, "NRP power analysis"](#), on page 266 and [Section 9.3, "User correction"](#), on page 236.

3.2.1.11 RF 50 Ω

Output of the RF signal.

The connector type depends on the installed frequency option.

Table 3-9: RF connector types of the frequency options

Installed RF frequency option	Connector type	Frequency range
R&S SMAB-B103	N female	$f_{\text{max}} \leq 6 \text{ GHz}$
R&S SMAB-B106		
R&S SMAB-B112	PC 2.92 mm female Instrument equipped with interchangeable PC 2.92 mm test port adapter.	$f_{\text{max}} \leq 40 \text{ GHz}$
R&S SMAB-B120		
R&S SMAB-B131		
R&S SMAB-B140(N)		
R&S SMAB-B150(N)	PC 1.85 mm female Instrument equipped with PC 1.85 mm inter-changeable female/female wear and tear adapter.	$f_{\text{max}} \leq 67 \text{ GHz}$
R&S SMAB-B167(N)		



The PC 1.85 mm male connector for up to 67 GHz comes with a protective 1.85 mm female adapter to prevent the sensitive connector from damage.

It is available as a spare part, and can be replaced if damaged. For more information, contact your Rohde & Schwarz support center or www.rohde-schwarz.com/support.

How to: [Section 3.1.10, "Connecting to RF 50 Ω"](#), on page 30

3.2.1.12 Pulse signal connectors

Pulse Sync

BNC connector for output of a signal to synchronize the pulse generator signal. The synchronization signal is generated at the beginning of each pulse. For double pulse generation, the synchronization signal is generated at the beginning of the first pulse.

Pulse Video

BNC connector for output of the internal pulse generator signal or the looped through pulse signal from Pulse Ext connector (video signal).

See [Section 5.4.1, "Pulse modulation settings"](#), on page 80.

Pulse Ext

BNC connector for input of an external pulse modulation signal or an external trigger/gate signal for the pulse generator.

3.2.1.13 LF modulation connectors**LF**

BNC connector for output of the internal LF generator signal.

For more information, refer to the specifications document.

Ext

BNC connector for input of external analog modulation signals.

See [Section 5, "Analog modulations"](#), on page 77.

3.2.1.14 Clock synthesizer connectors**Clk Syn/Clk Syn N**

SMA connectors for output of the clock synthesizer signal, or the inverted signal.

3.2.2 Rear panel tour

This section provides an overview of the connectors at the rear panel of the instrument. For technical data of the connectors, refer to the specifications document.




Figure 3-5: R&S SMA100B rear panel with height unit 2HU (option R&S SMAB-B92)

- 1 = Serial number (six digits in the string 1419.8888.02-<serial number>-<checksum>)
- 2 = IEC 625/IEEE 488
- 3, 5 = USB/USB In
- 4 = LAN
- 6, 7 = Ref In/Ref Out
- 8 = V/GHz X-Axis and Z-Axis
- 9 = Stop
- 10 = EFC
- 11 = Marker User1
- 12 = Inst Trig
- 13 = Signal Valid
- 14 = Clk Syn/Clk Syn N

- 15 = Pulse Sync, Pulse Video and Pulse Ext
- 16 = LF
- 17 = Ext 1/2
- 18 = AC power supply connector and switch
- 19 = RF 50 Ω




Figure 3-6: Rear panel view of the R&S SMA100B RF Signal Generator with height unit 3HU (option R&S SMAB-B93)

- 1 = Serial number (six digits in the string 1419.8888.02-<serial number>-<checksum>)
- 2 = IEC 625/IEEE 488
- 3, 5 = USB/USB In
- 4 = LAN
- 6, 7 = Ref In/Ref Out
- 8 = V/GHz X-Axis and Z-Axis
- 9 = Stop
- 10 = EFC
- 11 = Marker User1
- 12 = Inst Trig
- 13 = Signal Valid
- 14 = Clk Syn/Clk Syn N
- 15 = Pulse Sync, Pulse Video and Pulse Ext
- 16 = LF
- 17 = Ext 1/2
- 18 = AC power supply connector and switch
- 19 = RF 50 Ω

For more information, refer to the specifications document.

3.2.2.1 Connectors

IEC 625/IEEE 488

Option: R&S SMAB-B86

General purpose interface bus (GPIB) interface for remote control of the instrument. The interface complies with the standards IEC 625, IEEE 488 and SCPI.

Use this interface to connect a computer for remote control of the R&S SMA100B. See also the following sections:

- [Section 14.2.3, "GPIB interface \(IEC/IEEE bus interface\)"](#), on page 414
- [Section 14.5.3, "GPIB address settings"](#), on page 426

- [Section A.2, "GPIB interface"](#), on page 855

USB/USB In

- Female USB (universal serial bus) 3.0 connector of type A (host USB), to connect devices like a keyboard, a mouse, a memory stick, or the R&S NRP-Z3/Z4 cable for the R&S NRP power sensors
- Option: R&S SMAB-B86
Female USB 2.0 connector of type Micro-B (USB In), for example, for remote control.

How to: [Section 3.1.8, "Connecting USB devices"](#), on page 27

LAN

RJ-45 connector to connect the R&S SMA100B to a LAN for remote control, remote operation, and data transfer.

How to: [Section 3.1.7, "Connecting to LAN"](#), on page 27

Ref In/Ref Out

Input/output for external reference signal.

BNC connectors for reference signals from 1 MHz to 100 MHz.

SMA connectors for 1 GHz reference signals.

How to: [Section 3.1.11, "Connecting to Ref In/Ref Out"](#), on page 30

V/GHz X-Axis

BNC connectors for output of a voltage ramp signal:

- "V / GHz": the voltage is proportional to the frequency.
- "X-Axis": output of a voltage ramp for the X deflection of an oscilloscope or an XY recorder.

Z-Axis

BNC connector for output of a voltage pulse signal, e.g. for the combined blanking and marker generation of network analyzers.

Stop

BNC connector for input and output signals to stop a sweep in all modes.

This connector is bidirectional. Used as:

- "Input": enables you to stop a sweep triggered by an external network analyzer.
- "Output": enables the R&S SMA100B to stop the sweep of an external network analyzer.

EFC

BNC connector for input of an EFC (external frequency control) signal for electronic tuning of the internal reference frequency.

See [Section 10, "Reference oscillator"](#), on page 317.

Marker User1

BNC connector for output of a marker or trigger signal.

Inst Trig

BNC connector for input of external trigger signals. The signals trigger sweeps and list mode.

See [Section 8.1, "Signal generation and triggering in the sweep and list modes"](#), on page 189.

Signal Valid

BNC connector for output of a signal that determines the valid signal times (valid level and frequency) for all analog modulations.

Clk Syn/Clk Syn N

SMA connectors for output of the clock synthesizer signal, or the inverted signal.

Pulse Ext

BNC connector for input of an external pulse modulation signal or an external trigger/gate signal for the pulse generator.

Pulse Video

BNC connector for output of the internal pulse generator signal or the looped through pulse signal from Pulse Ext connector (video signal).

See [Section 5.4.1, "Pulse modulation settings"](#), on page 80.

Pulse Sync

BNC connector for output of a signal to synchronize the pulse generator signal. The synchronization signal is generated at the beginning of each pulse. For double pulse generation, the synchronization signal is generated at the beginning of the first pulse.

LF

BNC connector for output of the internal LF generator signal.

For more information, refer to the specifications document.

Ext 1/2

BNC connectors for input of external analog modulation signals.

See [Section 5, "Analog modulations"](#), on page 77.

AC power supply connector and switch

Mains power switch for performing the following tasks:

- Connecting the internal power supply to the power source
- Disconnecting the internal power supply from the power source

How to: [Section 3.1.6, "Connecting to power"](#), on page 26.

RF 50 Ω

Rear panel connector for the RF signal. This connector is for use of the instrument in a 19" rack.

How to:

- [Section 3.1.4.2, "Mounting the product in a rack"](#), on page 25
- [Section 3.1.10, "Connecting to RF 50 \$\Omega\$ "](#), on page 30

3.3 Trying out the instrument

This section introduces the first steps with the R&S SMA100B. It shows how to operate and configure the instrument using simple examples. The complete description of the functionality and its usage is given in the R&S SMA100B user manual. Basic instrument operation is described in [Section 3.4, "Operating the instrument"](#), on page 50.

Prerequisites

The instrument is set up, connected to the power supply, and started up as described in [Section 3.1, "Preparing for use"](#), on page 23.

The first signal generation tasks explain how to generate an unmodulated signal, to configure the RF signal output, and how you can vary the RF frequency and level in sweep mode.


The instrument is manually operated via the touchscreen. Try out the following:

- [Generating an unmodulated carrier](#)..... 43
- [Generating an RF frequency sweep signal](#)..... 46
- [Saving and recalling settings](#)..... 48

3.3.1 Generating an unmodulated carrier


We start to generate a simple unmodulated signal. In this example, the R&S SMA100B can be in its minimal configuration.

1. On the R&S SMA100B front panel, press the [Preset] key to set a defined initial instrument state.
2. Set the frequency:
 - a) In the "Status Bar", tap the "Frequency" field.
 - b) On the on-screen keypad, enter "6" and press the "GHz" key.



The on-screen key pad closes and the frequency value is displayed.

3. To set the signal level, tap the "Level" field and enter the level in the same way.
4. To activate RF signal output, select "Level" > "RF On" in the tile diagram.



The blue colored "RF On" icon indicates that the RF output is activated.

The R&S SMA100B provides the 6 GHz signal at the RF A connector at the front panel.




Figure 3-7: Generating an unmodulated signal

Alternative ways to access the instrument functions

To fulfill the same task, you can also use the front panel keys or the setting parameters provided in the frequency and level dialogs.

Try out the settings dialogs

- In the "Frequency" tile, select "Frequency...".
 - In the "RF Frequency" tab, tap the "Frequency" field.
 - Set the frequency via the on-screen keypad.
- Access the "RF Level" dialog via the "Level" tile.
 - In the "RF Level" tab, select "Amplitude".
 - Set the amplitude (level) via the on-screen keypad.
- Select "RF State > On" to activate the RF signal generation.

See [Section 4, "RF signal configuration"](#), on page 60.

Try out the front panel keys

- Use the [Freq], [Level], and [RF on/off] key on the front panel.



Connect RF 50 Ω of the R&S SMA100B to a signal analyzer, for example R&S®FSW, to display the generated signal.

For the required settings of the signal analyzer, refer to its user manual or its online help.

3.3.2 Generating an RF frequency sweep signal

The "Sweep" operating mode allows you to generate an RF signal with periodically varying frequencies or amplitudes.

This example deals with an RF signal with varying frequency and constant level. To configure the sweep, you need to determine a defined start and end frequency with constant time intervals between the frequency steps.

The sweep function does not require specific options.

1. On the front panel, press the [Preset] key to set a defined initial instrument state.
2. Set the signal output level, if required, e.g. set "Level > -25 dBm".
3. In the tile diagram, select "Sweep" > "Frequency Sweep".
4. In the "General" tab:

General		Frequency Range	
State	0	Current Frequency	570.000 000 000 MHz
Mode	Auto		
Shape	Sawtooth		
Spacing	Linear	Dwell Time	15.0 ms
Reset Sweep			

- a) Select "Mode > Auto" to run the sweep continuously.
 - b) Select "Shape > Sawtooth" to set the waveform shape of the sweep signal.
 - c) Select "Spacing > Linear", to determine the calculation method for the frequency shift of a step.
 - d) Set "Dwell Time > 15.0 ms", to determine the time interval of the sweep steps.
5. Select the "Frequency Range" tab.

General <i>Single</i>	Frequency Range	Output	Edit Marker		X
Start Frequency 100.000 000 000 MHz		Stop Frequency 500.000 000 000 MHz			
Center Frequency 300.000 000 000 MHz		Span 400.000 000 000 MHz			
Spacing Linear		Step Linear 1.000 000 000 MHz			

- a) Set "Start Freq > 200 MHz" and "Stop Freq > 600 MHz" to determine the frequency sweep range.
 - b) Set the step width "Step Lin > 10.0 MHz" to determine the width for a frequency step.
6. In the "General" tab, activate the frequency sweep with "State > On".
 7. Close the sweep dialog.
(Alternatively, tap the "Home" button to minimize the dialog. The R&S SMA100B indicates the "Sweep" dialog as active dialog in the task bar.)
 8. To activate the RF signal output, select "Level" > "RF On".

 SCPI(3) Frequency Sweep  Info	Frequency 500.000 000 000 MHz		Level -25.00 dBm
	Modulation <i>configure</i> <i>AM, FM, Phase and Pulse Modulation</i>	Frequency Ref Out: 10 MHz	Level Limit: 30.00 dBm
	Mod Off	Int Ref	RF On
	System Config IP: 10.124.0.207 GPIB Address: 28 FW: 4.15.148	Sweep Freq Sweep: Mode - Auto Start: 200.0 MHz Stop: 600.0 MHz	Clk Syn / Pow Sens <i>configure</i> <i>Clock Synthesis and Power Sensor Applications</i>
			Clock Syn Off

Figure 3-8: Generating a frequency sweep signal

The frequency field in the status bar indicates the continuously changing frequency, i.e. the running sweep.


3.3.3 Saving and recalling settings

To restore the results of our measurements later, we save the instrument settings in a file.

To save the instrument settings in a file

We assume, a test configuration as described in [Section 3.3.2, "Generating an RF frequency sweep signal"](#), on page 46.

1. Press the [Setup] key on the front panel.
2. In the "Setup" menu, select "Settings > Save/Recall".
3. In the "Save/Recall" dialog, select "Operation Mode > Save".




4. Tap the "Filename", use the on-screen keyboard, and enter *MyTestSignal*.
5. Tap the "Save" button.

The file `MyTestSignal.savrc1.txt` is stored in the default directory `/var/user/`.

To load saved instrument settings

You can restore the settings to the instrument at any time using the settings file.

1. Press the [Preset] button to restore the default instrument settings so you can check that the stored user settings are restored afterwards.
2. Press the [Setup] key on the front panel.
3. In the "Setup" menu, select "Settings > Save/Recall".
4. In the "Save/Recall" dialog, select "Operation Mode > Recall".
Navigate to the directory the file is saved in and select the `MyTestSignal` file.



5. Tap the "Recall" button.

All instrument settings are restored and the display resembles [Section 3.3.2, "Generating an RF frequency sweep signal"](#), on page 46, which shows the instrument display right before the settings were saved.




How to display all parameters with values different to their preset values


When you load a file to your instrument, you do not have enough information on the changed settings. In such case, it is useful to visualize all parameters that have been changed from their default state.

Try out the following:

- Touch and hold a spot in the tile diagram for at least 1 second to access the context-sensitive menu.
- Select "Mark All Parameters Changed from Preset".



- All changed parameters are highlighted.



See also [Section 12, "File and data management"](#), on page 331.

3.4 Operating the instrument

This section provides an overview on basic operating tasks. There are three ways to operate the R&S SMA100B.

Manual operation

Use the touchscreen, keys and rotary knobs, or an optional mouse and/or keyboard. The principles of manual operation are explained in this section.

Remote control

Create programs to automatize repeating settings, tests, and measurements. The instrument is connected to a computer that runs the program.

This way of operation is described in [Section 14.1, "Overview of remote access modes"](#), on page 409.

Remote operation

For remote monitoring and operation of the instrument, a VNC server is installed on the R&S SMA100B. You need a LAN connection to the computer, and a VNC client or browser to connect to the instrument.

This way of operation is described in [Section 14.1, "Overview of remote access modes"](#), on page 409.

The following sections show how to operate the instrument manually.

• Means of manual interaction	51
• Understanding the display information	52
• Accessing the functionality	55
• Entering data	56
• Undo and redo actions	58
• Getting information and help	58

3.4.1 Means of manual interaction

For the manual interaction with the R&S SMA100B, you have several methods that you can use as an alternative to perform a task:

- Touchscreen:
Touchscreen operation is the most direct way to interact. Almost all control elements and actions on the screen are based on the standard operating system concept. You can tap any user interface element to set parameters in dialog boxes, enter data, scroll within a dialog etc., as if you work with a mouse pointer.
Tapping the screen works like clicking mouse buttons:
 - Touch quickly = click: Selects a parameter or provokes an action.
 - Touch and hold = right-click: Opens a context-sensitive menu.
 - Touch and swipe = drag: Scrolls through the contents of a display element larger than the screen, e.g. a list or a table.
- Function keys and rotary knob:
The front panel provides nearly all functions and controls to operate the instrument in the classic way, without touchscreen.
- Optional mouse and/or keyboard:

These devices work like known from PCs. The navigation keys on the front panel correspond to the keys on the keyboard.

This manual describes the manual interaction with the instrument via the touchscreen. It mentions the alternative methods using the keys on the instrument or the on-screen keypads if it deviates from the standard operating procedures. The usage of the touchscreen and navigation keys is described in [Section 3.4.3, "Accessing the functionality"](#), on page 55.

Throughout the manual, the term "select" refers to any of the following methods:

- Using a finger on the touchscreen
- Using a mouse pointer in the display
- Using a key on the instrument or on a keyboard

3.4.2 Understanding the display information

The home screen of the R&S SMA100B displays all main settings and generator states, divided into main operation areas.




Figure 3-9: Home screen

- 1 = Taskbar/softkey bar with "Home" and "System Config" key
 2 = Status bar
 3 = Tile diagram

• Status bar	53
• Tile diagram	53
• Taskbar	53
• Additional display characteristics	54

3.4.2.1 Status bar

The status bar at the top of the screen indicates the RF frequency and the level of the output signal provided to the DUT. You can set both parameters directly here.

3.4.2.2 Tile diagram

The tile diagram is the main entry to the settings of the R&S SMA100B.





Tile	Access to:
"Modulation"	• Analog and stereo¹⁾, and pulse¹⁾ modulation settings • Built-in LF generator
"System Config"	• "Save/Recall": settings for saving and loading instrument configurations • "Remote access": Network and emulation settings. • "Setup": general system configuration • "System Configuration"¹⁾: settings for connecting external instruments
"Sweep"	• Frequency and level sweeps • List mode
"Frequency"	• RF frequency and phase • Reference frequency
"Level"	• RF level • Attenuator • Automatic level control • User correction
"Clk Syn / FE / Pow Sens"	• Clock synthesis¹⁾ • RF Frontend¹⁾ • Power sensors
¹⁾ requires additional options	

3.4.2.3 Taskbar

The "Taskbar" shows a home and an info button, and assigns a labeled button whenever you open a dialog. If more dialogs are open than the taskbar can display, touch and swipe the taskbar to scroll up and down.

The buttons shown in the following example represent the variants.


Table 3-10: Example of buttons in the taskbar

	"Home" button Returns to the home screen.
	"Busy" indicator Indicates a running process.
	"User Menu" Lists parameters that can be defined for quick access.
	Shows the current remote access connections when the instrument is remotely controlled. Tip: An indicator in the "System Config" tile shows the current remote control status.
	R&S NRP power sensors Shows a connected external power sensor. The button displays the current readings when the sensor is active.
	Active dialogs Indicates the dialog name of each active dialog in a separate button.
	"Info" key Provides access to status and error messages. Note: The warning symbol signifies a permanent error message.

3.4.2.4 Additional display characteristics


The following section provides a short insight on the indication of the screen in general, and significant elements that you see under specific modes, in dialogs or settings.

- **Appearance of active elements**
 - *Active* elements like On/Off switches, state buttons have a **blue** background.
 - *Selected* elements are framed or highlighted **orange**.
 - *Inactive* elements are **gray**.
- **On-screen keypads**
Either a numerical or alphanumerical on-screen keypad appears when you enable an entry field, see [Section 3.4.4, "Entering data"](#), on page 56.
- **Info line**
The "Info line" shows brief status information and error messages. It appears when an event generates a message. If selected, the R&S SMA100B shows information on static errors and the error history.



- **Key parameters indicated in tab labels**

- **Scrollbar handle**
An arrow icon that appears when you touch a scrollbar helps you to scroll in a dialog or list.
If no scrollbar handle appears, you can touch and swipe an element to scroll up and down.
- **Progress indicators**
A busy icon indicates a currently running process. If a process takes some time, a progress bar shows the current state.
- **Context-sensitive menus**
Within the entire screen display, including single parameters, you can access context-sensitive menus that provide some additional functions.



3.4.3 Accessing the functionality

All functionalities are provided in dialog boxes as known from computer programs. You can control the instrument intuitively with the touchscreen. This section provides an overview of the accessing methods.

The instrument's functions and settings can be accessed by selecting one of the following elements:

- System and function keys on the front panel of the instrument
- Taskbar/softkeys on the touchscreen
- Context-sensitive menus for specific elements on the touchscreen, or with the rotary knob (press and hold).
- Elements on the status bar in the touchscreen
- Displayed setting on the touchscreen that means block diagram and all settings available in dialogs.

To open a dialog box

► Perform one of the following actions:

- Select the required tile, and then the menu entry.
- Select the minimized view (button) on the taskbar.

Some of the utility keys access a dedicated dialog, too.

To minimize a dialog box

1. To return to the home screen, select the "Home" button.
2. To switch to another dialog, select the [Next Window] button.

To close a dialog box

To close a dialog box, you have the same controls as you know from computers or devices with touchscreen.

► Perform one of the following actions:

- Select the "Close" icon in the upper right corner.
- Select the [Esc] key on the front panel.
- Drag and drop a minimized dialog from the taskbar to the tile diagram.

To select an option in a dialog box

► Select the required option.

3.4.4 Entering data

Some parameters have their own key on the front panel. For data input in dialog boxes, the instrument provides on-screen keypads for entering numeric and alphanumeric values. You can always set the parameters via the touchscreen, the front panel or an external keyboard.

To enter numeric values with the on-screen keypad

For numeric settings, the instrument displays the numeric keypad. The units specified correspond to the units of the parameter.

1. Enter the numeric value.

Tip: For a quick entry, you can enter a value in an exponential representation, for example *1e7* for *10000000*.

2. Tap the unit button to complete the entry.

The unit is added to the entry.

Tip: For a quick unit change, you can enter shortcuts, for example for a frequency value *1e8h* for *100 MHz*.

For an overview of shortcuts supported by the R&S SMA100B, see [Section C, "Unit shortcuts"](#), on page 858.

3. If the parameter does not require a unit, confirm the entered value by pressing "Enter".

To enter numeric values with the front panel controls

1. Change the currently used parameter value by using the rotary knob or the [Up/Down] keys.
2. If the parameter does not require a unit, confirm the entered value by pressing the [Enter] key or any of the unit keys.
The instrument highlights the editing line to confirm the entry.

If you edit numeric data in tables, enable edit mode first. Press [Enter] or press the rotary knob.

To enter alphanumeric values

If a field requires alphanumeric input, you can use the on-screen keyboard to enter letters and characters including special characters.

To complete an entry

- Press the [Enter] key or the rotary knob.

To correct an entry


1. Using the arrow keys, move the cursor to the right of the entry you want to delete.
2. Press the [Backspace] key.
3. Deletes the entry to the left of the cursor.
4. Enter your correction.

To abort an entry

- Press the [Esc] key.
The dialog box closes without changing the settings.

3.4.5 Undo and redo actions

Accessed via the context-sensitive menus, "Undo" allows you to restore one or more actions on the instrument. Depending on the available memory, the "Undo" steps can restore all actions.



"Redo" restores a previously undone action.

3.4.6 Getting information and help

In some dialog boxes, graphics are included to explain the way a setting works.


For further information, you can use the following sources:

- Tooltips give the value range of the parameter.
- The context help provides a functional description on a setting.
- The general help explains a dialog box, provides instructions, and general information.

To display context help

- To access a help topic, perform one of the following:
 - a) Tap and hold the parameter for which you need information.
 - b) In the opening context menu, tap "Help".
 - c) Tap the parameter.
 - d) Press the [Help] key.

The "Help" dialog opens. You can browse the help for further information.



Contents of the help dialog box

The help dialog box covers two main areas:

- "Contents" - contains a table of help contents
- "Topic" - contains a specific help topic

The help system also provides an "Index" and a "Find" area, and "Zoom" functions that are accessed via the corresponding buttons.

To open general help

- ▶ Press the yellow [Help] key on the front panel.

If a dialog box is opened, the help topic for the current tab is shown. Otherwise the "Contents" page appears.

Navigating in the table of contents and in the help topics

1. To move through the displayed content entries, tap on an entry.
Entries with a plus sign contain further entries.
2. To display a help topic, tap on the topic name.
3. To follow a cross-reference, tap on the link text.
4. To return to the previous page, select "Back".
This function scrolls back all steps that you have performed before.
5. Use the "scroll bars" to shift the visible section of content shown.
6. To maximize the "Topics" area, tap the "Hide Contents Tree" button to hide the contents tree.

Using the index

1. Select the "Index" button.
2. Enter the first characters of the topic that you are interested in.
The entries starting with these characters are displayed.
3. Tap on the index entry.
The corresponding help topic is displayed.

4 RF signal configuration

The R&S SMA100B signal generator generates RF signals with outstanding spectral purity within the frequency range from 8 kHz up to 20 GHz and with adjustable signal level over a wide range.

In addition to these real-time CW signals, you can generate RF signals from predefined lists and sweep signals that vary according to the frequency or amplitude curves.

You can also apply versatile analog modulation types with definable characteristics.

The variably adjustable output level due to the built-in attenuator, allows you to vary the RF signal level over the full level range. Several methods enable you to improve the signal performance and to optimize the signal quality for the particular application, or to increase the accuracy and reliability of the generated RF signal.

The R&S SMA100B supports R&S NRP power sensors, e.g. to monitor the output level of the generator or to determine the level correction values for user correction lists.

Signal modes and characteristics

The R&S SMA100B generates unmodulated or analog modulated RF signals. You can output the signal in fixed mode or as a signal with periodically varying frequencies or amplitudes.

Signal modes for RF signal generation:

- Unmodulated signal
Generates an unmodulated continuous wave (CW) of constant frequency and amplitude.
For information on the signal frequency and level settings and an example on how to configure a simple CW signal, see:
 - [Section 4.5, "RF frequency settings"](#), on page 67
 - [Section 4.6, "RF level settings"](#), on page 70
 - [Section 3.3.1, "Generating an unmodulated carrier"](#), on page 43
- Analog modulated signal
Modulates the signal with an analog signal and generates amplitude, phase, frequency and pulse modulation.
See [Section 5, "Analog modulations"](#), on page 77.

The R&S SMA100B allows you to provide the RF signal with constant or varying frequencies and/or amplitudes at the output:

- Constant frequency and level (CW/Fixed mode)
The RF output signal has the set frequency and level.
- Varying frequency and/or level
 - Sweep mode
An RF or LF frequency and RF level sweep signal, processed continuously, step-by-step or individually and with selectable trigger modes. You can only run one sweep at a time.
 - List mode

The RF signal is based on a list of predefined frequency and level values pairs and step widths.

See [Section 8, "List and sweep mode"](#), on page 187.

4.1 Activating RF signal output

By default, the RF output signal is deactivated.

To activate the RF output signal

1. Configure the RF signal as required.
Set, for example, the frequency and level values.
2. Activate the RF output in one of the following ways:
 - a) Select "Level" > "RF ON" > "On"
 - b) Press the [RF on/off] key at the front panel.

When activated, the "RF On" icon in the "Level" tile turns blue.

RF State/RF ON	61
RF output impedance	61

RF State/RF ON

Activates or deactivates the RF output.

Acts as the [RF on/off] key.

Remote command:

[:OUTPut<hw>\[:STATe\]](#) on page 536

RF output impedance

You can query the impedance of the RF output.

Remote command:

[:OUTPut<hw>:IMPedance?](#) on page 538

4.2 How to set the frequency and level

The simplest form of the RF signal is a continuous wave (CW) of constant frequency and amplitude. The RF signal is defined by its frequency, level and phase.

To configure the RF signal.

1. Use one of the following:

- a) In the home screen select:
 - "Frequency" and "Level" in the status bar
 - "Frequency" in the "Frequency" tile
 - "Level" in the "Level" tile
 - "Phase" in the "Frequency" tile
- b) On the front panel:
 - Press the [Freq] key
 - Press the [Level] key

2. Enter the values as required.

The R&S SMA100B indicates the frequency and level settings in the status bar of the home screen, and shows active functions and parameters of the RF signal in the "Frequency" and "Level" tiles.

See ["RF frequency and level display with a downstream instrument"](#) on page 62.

RF frequency and level display with a downstream instrument

If your test setup includes a downstream instrument, you can enter the parameter of the downstream instrument in the frequency or level settings dialog of the R&S SMA100B. Examples of downstream instruments are mixers, frequency multipliers, amplifiers or attenuators and of their corresponding major parameters offset, multiplier, amplitude. The R&S SMA100B generates the signal without the downstream parameters, but considers all additional parameters concerning the frequency and level.

Example parameters that affect the frequency and level:

- Frequency offset
- Multiplication factor
- User correction

Any of these cases are indicated by a dedicated icon, displayed in the "Frequency" or "Level" tile, depending on the affected parameter.

[Figure 4-1](#) illustrates the calculation of the "Frequency" and "Level" values, displayed in the status bar.




Figure 4-1: Frequency and Level display vs frequency and level at the RF output

f_{RF} , $Level_{RF}$	= Frequency and level ("Status bar > Frequency and Level") at the output of the downstream instrument, see also Calculation of f_{RF} and $Level_{RF}$)
$f_{RF\ Out}$, $Level_{RF\ Out}$	= Frequency and level at the output connector [RF 50 Ω] ("RF > RF Frequency > Frequency" and "RF > RF Level > Amplitude")
$n*f$	= Multiplication factor ("RF > RF Frequency > Multiplier")
Δf	= Frequency offset ("RF > RF Frequency > Offset")
$\Delta Level$	= Power offset ("RF > RF Level > Offset")

Calculation of f_{RF} and $Level_{RF}$

- $f_{RF} = n * f_{RF\ Out} + \Delta f$
- $Level_{RF} = Level_{RF\ Out} + \Delta Level$

4.3 Phase continuous frequency

The R&S SMA100B enables you to generate a phase continuous RF signal over a certain frequency range. In this mode, the output sine wave signal shows no phase discontinuity or glitch when changing the frequency, e.g. in sweep mode.

At frequency changes, the switching transitions (intermediate frequencies) cause spurs. The spurs are due to adjustments in the synthesizer, e.g. adjusting the settings of dividers, filters, phase detectors can lead to phase discontinuities.

The phase continuous mode freezes the settings of the synthesizer components which can generate phase discontinuities when adjusted. The R&S SMA100B performs the frequency changes with the fine resolution synthesizer. The result is a phase continuous change from one frequency to another without transients.

The available frequency range for continuous-phase signal generation is determined by the fine resolution synthesizer used. The frequency range varies according to the RF frequency set at the time you activate phase continuous mode.

Equipped with the ultra low phase noise option (R&S SMAB-B711), the R&S SMA100B enables you to select between two frequency ranges, either to achieve a higher signal quality or an especially wide frequency range.

4.3.1 How to generate a phase continuous RF signal

To achieve an output sine wave signal with no phase discontinuity or glitch when changing the frequency, e.g. in RF frequency sweep mode, you can use the phase continuous mode provided by the instrument.



Activating frequency or phase modulation deactivates phase continuous mode and vice versa.

To select the phase continuous frequency mode

The following example requires, that the instrument is equipped with the option R&S SMAB-B711.



Before setting the parameters and activating the phase continuous mode, turn off active sweeps.

1. If the "RF Frequency Sweep" is running, select "Sweep" > "RF Frequency Sweep".
2. Turn off "State".
3. On the home screen, select "Frequency" > "Phase".
4. Turn off "Phase Continuous Active", if enabled.
5. Select "Frequency Range" > "Narrow".
6. Check if the range displayed in "Frequency Range From" and "To", corresponds to your range selection.
7. IF the displayed frequency range does not correspond to the selection, select "Frequency Range > Wide" (requires option R&S SMAB-B711).
8. If the displayed range corresponds to the selection, enable "Phase Continuous Active".
9. In the "RF Frequency Sweep" dialog
 - a) Modify the "Start Freq" and "Stop Freq" or "Center Frequency" and "Span" as needed.
 - b) Set the RF frequency sweep state to "ON".

To set a phase continuous frequency sweep

1. On the home screen, select "Sweep" > "RF Frequency Sweep" > "Frequency Range".
2. Set the "Start Frequency" and "Stop Frequency" or "Center Frequency" and "Span" for the sweep range.
3. In the "General" tab, configure the sweep parameters as required.
4. Turn on "State" to start the sweep signal generation.

4.4 RF connector settings

Access:


1. Select "Frequency" > "RF Connectors".

RF Connectors			
Signal	Connector	Show	
Instr. Trigger ...		 ...	
External Mod. ...	EXT 1	 ...	
External Mod. ...	EXT 2	 ...	
LF Output ...	LF Out	 ...	
Ref. Freq. Input ...	Ref In	 ...	
Ref. Freq. Output ...	Ref Out	 ...	
Signal Valid	Signal Valid		
Pulse In ...	Pulse Ext		
Pulse Video ...	Pulse Video		

The "RF Connectors" tab shows the assignment of the logical signals to the connectors. The connectors displayed depend on the options installed.

2. Select a "Signal" to access the corresponding settings dialog or directly set signal characteristics.
3. Use the built-in [Show/Show Connector](#) function to display the physical location of the selected connector.

The eye icon  in the tab header indicates the panel (front, rear or both) the selected connector is at.



Settings:

Signal.....	66
Connector.....	67
Show/Show Connector.....	67

Signal

Displays the signal that is assigned to the connector.

Selecting a signal opens the settings dialog for configuring the signal, or setting signal characteristics directly.

For additional information on the connectors, see:

- [Section 3.2.2.1, "Connectors"](#), on page 40
- ["Signal output"](#) on page 78 for the assignment of the input and output connectors used for analog modulation signals.

"Instr. Trigger" Input of an external trigger signal for sweep and list modes, see [Section 8.1, "Signal generation and triggering in the sweep and list modes"](#), on page 189.

"External Mod..." Input of an external modulation signal, see ["Signal sources"](#) on page 77.

"LF Output" Output of the internal LF generator signal, [Section 5.4.8, "LF signal output settings"](#), on page 117.

"Ref. Freq. Input" Input of an external reference signal, see [Section 10.2, "Reference frequency settings"](#), on page 317.

"Ref. Freq. Output"

Output of the internal reference signal, see [Section 10.3, "Reference output settings"](#), on page 321.

"Signal Valid" / "Signal Valid Neg."

Automatically generated output signal that identifies a valid signal time (level and frequency) for all analog modulation signals.
For "Signal Valid Neg." (inverted), the output signal is low during the valid signal time.

"Pulse In"

Input of an external pulse signal or input of external trigger/gate signal for the internal pulse generator (see [Section 5.4.4, "Pulse generator"](#), on page 95).

"Pulse Video"

Output of the internal pulse generator signal or the looped through "Pulse Ext" pulse signal (video signal), see [Section 5.4.1, "Pulse modulation settings"](#), on page 80.

Connector

Displays the assigned connector.

**Show/Show Connector**

Opens a dialog that displays the location of the connector on the front panel or rear panel of the instrument. A blinking rectangle shows the connector.


4.5 RF frequency settings

Access:

1. Select "Frequency" > "RF Frequency".

RF Frequency	Phase	Output		X
Frequency	1.000 000 000 000 GHz		Main PLL Bandwidth	Narrow
Offset	10.000 000 000 MHz		Multiplier	1.000
User Variation				
Variation Active	☐		Variation Step	1.000 000 000 MHz

2. Observe the information on the home screen, "Frequency" tile.



The "Frequency" tile indicates the reference frequency, current frequency offset and multiplier values, and phase offset value.

In the "RF Frequency" dialog, you can configure:

- RF frequency, incl. an offset or multiplication factor of a downstream instrument
- The step size for varying the frequency with the rotary knob.

The remote commands required to define the settings are described in [Section 15.18.5, "SOURce:FREQuency subsystem"](#), on page 700.

Settings

Frequency.....	68
Main PLL Bandwidth.....	69
Offset.....	69
Multiplier.....	69
User Variation.....	69
L Variation Active.....	69
L Variation Step.....	70

Frequency

Sets the RF frequency.

This frequency is output at the RF 50 Ω connector.

It does not consider any parameter that affect the frequency, as e.g., a frequency offset.

See ["RF frequency and level display with a downstream instrument"](#) on page 62.

Note: Suppressed values in the status bar

For security concerns or certain operating modes, you can hide the frequency and level display in the status bar.

- *********

The display has been disabled for security reasons.

See:

- [Annotation Frequency](#)
- [Annotation Amplitude](#)

- 

The display is disabled when list mode is running, see [Section 8, "List and sweep mode"](#), on page 187.

Remote command:

[\[:SOURce<hw>\]:FREQuency\[:CW|FIXed\]](#) on page 702

Main PLL Bandwidth

Selects the PLL (Phase Locked Loop) bandwidth of the **main synthesizer**.

"Normal" Default main PLL bandwidth.
The instrument provides the maximum modulation bandwidth and FM/PhiM deviation.

"Narrow" Sets the narrow PLL bandwidth.

Remote command:

[\[:SOURce<hw>\]:FREQuency:PLL:MODE](#) on page 707

Offset

Sets the frequency offset.

This value represents the frequency shift of a downstream instrument, like for example a mixer.

The "Frequency" value displayed in the status bar is the resulting frequency, as it is at the output of the downstream instrument. The frequency at the R&S SMA100B RF output is not changed.

See ["RF frequency and level display with a downstream instrument"](#) on page 62.

Remote command:

[\[:SOURce<hw>\]:FREQuency:OFFSet](#) on page 704

Multiplier

Sets the multiplication factor for the RF frequency.

This value represents the multiplication factor of a downstream instrument, as for example a multiplier. You can also assign a negative multiplication factor, for example -1.0 to support frequency converters working in the reverse frequency position.

The "Frequency" value displayed in the status bar is the resulting frequency, as it is at the output of the downstream instrument. The frequency at the R&S SMA100B RF output is not changed.

See ["RF frequency and level display with a downstream instrument"](#) on page 62.

Remote command:

[\[:SOURce<hw>\]:FREQuency:MULTiplier](#) on page 704

User Variation

Defines and activates a user-defined step width for varying the RF frequency or RF level with the rotary knob.

If disabled, the step width varies in steps of one unit at the cursor position.

Variation Active ← User Variation

Activates the set user-defined step width.

Remote command:

[:SOURce<hw>] :FREQuency:STEP:MODE on page 706

[:SOURce<hw>] :POWer:STEP:MODE on page 751

Variation Step ← User Variation

Sets the user-defined step width.

Remote command:


[:SOURce<hw>] :FREQuency:STEP [:INCRe ment] on page 707

[:SOURce<hw>] :POWer:STEP [:INCRe ment] on page 751

4.6 RF level settings


Access:

1. Select "Level" > "RF Level".




In the "RF Level" dialog, you can configure the offset-free level, the level limit, and the step width for varying the level with the rotary knob.

2. Select "User Variation" to set the step width to be used when .setting the RF level using the rotary knob.



3. Observe the information on the home screen, "Level" tile.



The "Level" tile indicates the level limit, the user correction status and current correction value, current setting characteristics incl. mode.

The remote commands required to define the settings are described in [Section 15.18.12, "SOURce:POWer subsystem"](#), on page 740.

Settings

RF State/RF ON.....	71
Amplitude.....	71
Limit.....	72
Offset.....	72
Setting Characteristics.....	73
Harmonic Filter.....	73
Level Range.....	74
Readjust.....	74
User Variation.....	74
L Variation Active.....	74
L Variation Step.....	74

RF State/RF ON

Activates or deactivates the RF output.

Acts as the [RF on/off] key.

Remote command:

:OUTPut<hw> [:STATe] on page 536

Amplitude

Sets the level of the RF signal.

The value is offset-free and corresponds to the level at the RF 50 Ω connector.

See ["RF frequency and level display with a downstream instrument"](#) on page 62.

Note: Suppressed values in the status bar


For security concerns or certain operating modes, you can hide the frequency and level display in the status bar.

- *********

The display has been disabled for security reasons.

See:

- [Annotation Frequency](#)
- [Annotation Amplitude](#)

- 

The display is disabled when list mode is running, see [Section 8, "List and sweep mode"](#), on page 187.

Remote command:

[\[:SOURce<hw>\]:POWer:POWer](#) on page 747

Note: The SCPI command [\[:SOURce<hw>\]:POWer\[:LEVel\]\[:IMMediate\]\[:AMPLitude\]](#) sets the level of the "Level" display.

This means, the level containing offset.

Limit

Sets an upper limit for the output power.

Note: The parameter "RF level" > **"Limit"** and "NRP power control" > **"RF Amplitude Limit"** are identical.

You can use this value to protect your DUT from damage due to high input power. If you enter an RF level above this value, the instrument limits the output power to this specified value, and generates the warning message:

"Pep value greater than the defined limit." However, the level indication in the status bar is not affected.

The setting is not affected by an instrument preset ([Preset] key or *RST) and the "Save/Recall" function. It is reset only by factory preset.

Remote command:

[\[:SOURce<hw>\]:POWer:LIMit\[:AMPLitude\]](#) on page 746

Offset

Sets a level offset.

This value represents the level shift of a downstream instrument, like, for example, an attenuator or an amplifier.

The "Level" value displayed in the status bar is the resulting level, as it is at the output of the downstream instrument. The level at the R&S SMA100B RF output is not changed.

See ["RF frequency and level display with a downstream instrument"](#) on page 62.

Remote command:

[\[:SOURce<hw>\]:POWer\[:LEVel\]\[:IMMediate\]:OFFSet](#) on page 752

Setting Characteristics

Selects additional quality characteristics to optimize the behavior of the RF signal level for the specific application.

- | | |
|---------------------------|--|
| "Auto" | <p>Sets the RF output level automatically according to the selected mode.</p> <p>In this mode, the instrument provides the highest dynamic range and fastest setting times.</p> <p>The RF signal is shortly blanked when the step attenuator is switching.</p> <p>For more information, refer to the specifications document.</p> |
| "Uninterrupted" | <p>Suppresses blanking at level transitions. Frequency transitions can lead to an RF level blanking due to hardware-specific switching points.</p> <p>This mode reduces the dynamic range of the instrument. The step attenuator is fixed.</p> |
| "Strictly Monotone" | <p>Executes signal level changes monotonically increasing or decreasing.</p> <p>The setting makes sure that increasing the level value exclusively results in an increased output level, and vice versa.</p> <p>All electronic switches, which can affect the monotonicity are fixed.</p> <p>The operation mode is useful for applications using level searching algorithms which rely on a strictly monotonous behavior.</p> |
| "Constant-VSWR" | <p>Suppresses output impedance variations at the RF 50 Ω output connector, due to changed level settings.</p> |
| "High Dyn. Uninterrupted" | <p>R&S SMAB-K724</p> <p>Provides a linear output power that is uninterrupted over a wide dynamic range.</p> <p>Note: The R&S SMA100B supports this characteristic at frequencies above 52 MHz. If you select the setting at lower frequencies (≤ 52 MHz), the instrument reports a settings conflict.</p> |
| "User" | <p>Selects this entry automatically when you change one of the following parameters from the default setting:</p> <ul style="list-style-type: none"> • "Attenuator" > Mode • "ALC" > State or Detector Sensitivity <p>Note: If you select another setting characteristic, the R&S SMA100B presets the modified attenuator and ALC parameters.</p> |

Remote command:

[\[:SOURce<hw>\]:POWer:LBEHaviour](#) on page 746

Harmonic Filter

Activates low harmonic filter or enables its automatic switching.

- | | |
|------|--|
| "On" | <p>Ensures best low harmonics performance but decreases the level range.</p> |
|------|--|

"Auto" Applies an automatically selected harmonic filter that fits to the current level setting.

Remote command:

`:OUTPut<hw>:FILTer:MODE` on page 537

Level Range

Shows the interruption-free range of the level that you can use in the currently selected mode.

Remote command:

`[ :SOURce<hw> ] :POWer:RANGe:LOWer?` on page 753

`[ :SOURce<hw> ] :POWer:RANGe:UPPer?` on page 753

Readjust

Recalculates and adjusts the internal switch positions of the RF chain according to the current level.

The R&S SMA100B provides the "Readjust" function when you change one of the following parameters from the default setting:

- "RF Level" > [Setting Characteristics](#)
- "Attenuator" > [Mode > FixedSetting Characteristics](#)

In "External ALC" mode, "Readjust" triggers the detector offset zeroing, see [Section 9.2.2, "How to set up an external ALC"](#), on page 235.

Remote command:

`[ :SOURce<hw> ] :POWer:ALC:SONCe` on page 744

User Variation

Defines and activates a user-defined step width for varying the RF frequency or RF level with the rotary knob.

If disabled, the step width varies in steps of one unit at the cursor position.

Variation Active ← User Variation

Activates the set user-defined step width.

Remote command:

`[ :SOURce<hw> ] :FREQuency:STEP:MODE` on page 706

`[ :SOURce<hw> ] :POWer:STEP:MODE` on page 751

Variation Step ← User Variation

Sets the user-defined step width.

Remote command:

`[ :SOURce<hw> ] :FREQuency:STEP [ :INCRe ment ]` on page 707

`[ :SOURce<hw> ] :POWer:STEP [ :INCRe ment ]` on page 751

4.7 RF phase settings

The phase in sinusoidal signals defines the initial angle at its origin.

Access:

1. Select "Frequency" > "Phase".

Phase Continuous Mode	
Phase Continuous Active	☒
Frequency Range	Narrow
Frequency Range From	To
997.291 990 63 MHz	1.018 511 804 98 GHz
Phase Settings	
Delta Phase	0.000 deg
Reset Delta Phase Display	

In the "Phase" tab, you can activate the phase continuous mode, set the delta phase parameter and reset the phase to this reference.

2. Switch to the home screen, "Frequency" tile.

The R&S SMA100B indicates the configured settings.

Frequency	
Offset: 10.000 MHz	
Multiplier: 2.000	
Ref Out: 10 MHz	
Δ Phase: 180.00 deg	
Int Ref	Freq Offs

The remote commands required to define the settings are described in [Section 15.18.11, "SOURce:PHASe subsystem"](#), on page 739.

Settings

Phase Continuous Active.....	75
Frequency Range.....	76
Frequency Range From / To.....	76
Delta Phase.....	76
Reset Delta Phase Display.....	76

Phase Continuous Active

Activates generation of a phase continuous frequency signal.

The R&S SMA100B generates a phase continuous output sinewave, i.e. without phase discontinuity or glitch when changing the frequency.

For a given RF frequency, the frequency range is limited.

Remote command:

`[ :SOURce<hw> ] :FREQuency:PHASe:CONTInuous:STATe` on page 709

Frequency Range

Selects the mode that determines the frequency range for the phase continuity of the RF signal.

The available frequency range depends on the selected mode and is limited by the resolution of the used synthesizer. It varies depending on the frequency, and is set when you activate the phase continuous settings.

"Narrow" Sets a small frequency range, asymmetrically around the RF frequency.

"Wide" Option: R&S SMAB-B711
Sets a large frequency range, symmetrically around the RF frequency.

Remote command:

`[ :SOURce<hw> ] :FREQuency:PHASe:CONTInuous:MODE` on page 708

Frequency Range From / To

Displays the frequency range for phase continuous settings.

The value range depends on the mode selected with [Frequency Range](#).

Remote command:

`[ :SOURce<hw> ] :FREQuency:PHASe:CONTInuous:LOW?` on page 708

`[ :SOURce<hw> ] :FREQuency:PHASe:CONTInuous:HIGh?` on page 707

Delta Phase

Sets the phase of the RF signal.

The current phase of the signal is used as the reference.

Remote command:

`[ :SOURce<hw> ] :PHASe` on page 739

Reset Delta Phase Display

Adopts the selected "Delta Phase" value as the current value, and resets delta phase to 0 degrees.

Remote command:

`[ :SOURce<hw> ] :PHASe:REFerence` on page 739

5 Analog modulations

The R&S SMA100B supports AM (amplitude modulation), FM (frequency modulation), Φ M (phase modulation (PhiM)), and also PULM (pulse modulation). It generates low frequency signals (LF) as sine, triangle, trapezoidal or square (pulse) waveform, that can be output and further processed by a downstream instrument.

Option: R&S SMAB-K22, enables generation of pulse modulated RF signals.

5.1 Required options

R&S SMA100B base unit equipped with the following options:

- Option frequency (R&S SMAB-B10x)
- Option pulse modulator (R&S SMAB-K22)
- Option pulse generator (R&S SMAB-K23)
(supports generation of single and double pulse signals)
- Option multi-function generator (R&S SMAB-K24)
- Option pulse train generator (R&S SMAB-K27)
(requires R&S SMAB-K23)
- Option AM/FM/PhiM (R&S SMAB-K720)
- Option Scan AM (R&S SMAB-K720 and R&S SMAB-K721)
- Option Chirp Signal Generation (R&S SMAB-K725)
(requires R&S SMAB-K22
R&S SMAB-K23, providing extended ranges for resolution, pulse width and pulse period
R&S SMAB-K720)

For more information, refer to the specifications document.

5.2 Modulation types and signal sources

Radio transmitters do not transmit an audio signal directly. Instead, they modulate the audio signal onto a continuous wave (CW) carrier with much higher frequency.

A CW carrier has a sinusoidal waveform with constant amplitude and constant frequency. Modulating a signal onto the carrier means varying a property of the carrier according to the modulating signal. The three basic modulation types FM, AM and PhiM for example, vary one property of the carrier proportional to the instantaneous amplitude of the modulating signal.

Signal sources

If fully equipped, the R&S SMA100B modulates signals from the following sources:

- **Internal modulation source**

- *Two LF generators*
Each of the LF generators provides a modulation signal with sine, pulse, triangle or trapezoid shape.
- *Noise generator*
The noise generator supplies white noise with selectable bandwidth and distribution.
- *High-performance pulse generator*
Generates single and double pulse, or pulse train signals.
- **External modulation source**
 - Amplitude, frequency or phase modulation signals are input at the Ext connector.
 - Pulse modulation signals, at the Pulse Ext connector.

Signal output

You can perform AM, FM and PhiM with the signal of any of the provided sources. Moreover, you can combine two modulation signals and generate a two-tone signal. Regardless of the signal source, the generated signal can be output for further processing in a downstream instrument.

Current configuration is indicated in the "Analog Modulations > Overview" dialog; the output signal routing can be changed, too.

Input and output connectors

Direction	Modulation	Connector	Required option
Output	Pulse modulation from internal signal Loop through of pulse signal from Pulse Ext	Pulse Video	R&S SMAB-K22/-K23
	All analog modulations Marks the valid level and frequency Inverted version; the output signal is low during the valid signal times.	Signal Valid Signal Valid Neg.	
	Chirp Modulation	Pulse Video Pulse Sync	R&S SMAB-K22/-K23
	Pulse generator	Pulse Sync	
	LF generator	LF	
Input	AM, FM, PhiM	Ext **)	R&S SMAB-K720
	Pulse modulation from external source*) Or External trigger or gate signal*)	Pulse Ext**)	R&S SMAB-K22

- *) External trigger signal and external signal for the pulse modulation cannot be used simultaneously, because these signals are expected at the same connector Pulse Ext. Signal polarity and impedance are the same for both signals.

- **) The external modulation signal must have a voltage of $U_S = 1\text{ V}$ ($U_{EFF} = 0.707\text{ V}$) to achieve the displayed modulation depth and range.
Note that the input voltage does not exceed 1 V, otherwise modulation distortions can occur.

For more information, refer to the specifications document.

Interactions and characteristics

- FM and PhiM modulations exclude each other and cannot be performed simultaneously.
- In sweep mode, LF frequency sweep is possible.
- The settings of the modulation signal affect all analog modulations that use an internal modulation source.
- You can feed an external LF signal in each of the two paths.
- Considerations to AM when using an external modulation signal:
If external modulation is enabled, the RF output amplitude follows the external modulation signal with a scaling factor defined by the modulation sensitivity setting.

With **Coupling (AC/DC) > DC**, the RF output signal behaves according to:

- input signal = 0 V: the RF output amplitude corresponds to the level value set in the R&S SMA100B
- input signal = +1 V: the output level increases up to the maximum value given by the set modulation sensitivity
- input signal = -1 V: the output level decreases down to the minimum value given by the set modulation sensitivity

With **Coupling (AC/DC) > AC**, the modulation input signal is internally highpass filtered. Therefore, the DC content of the input signal is removed before it reaches the amplitude modulator.

- Using exponential amplitude modulation with an external source, sets the coupling of the corresponding input automatically to DC.
See also [Section 5.4.7.2, "Source > external settings"](#), on page 115.
- Scan AM
 - Scan AM provides the scan mode, i.e. an amplitude modulation depth with an extended dynamic range that automatically uses the exponential amplitude modulation type.
 - If you use Scan AM with an external modulation input signal, the voltage range is adjusted to $\pm 6\text{ V}$ (usually $\pm 1\text{ V}$). Therefore, we recommend that you do not use the external modulation signal for FM or PhiM in parallel, since the voltage affects the modulations.
- The amplitude modulation types linear and exponential derive the carrier signal either linear in percent / volt, or as complex exponential in dB / volt.
- For pulse modulated signals, you can select between fast or smoothed transitions, see ["Transition Type"](#) on page 82.
This setting is available over the entire frequency range for all instruments with frequency options up to 6 GHz. For higher frequency options, the frequency range for the smoothed setting is limited.
- Chirp modulation

- excludes PhiM, avionics and pulse modulation
- disables automatic level control (ALC)
- can not be operated with an external modulation signal

For more information, refer to the specifications document.

5.3 Activating analog modulations

- Use one of the following:
 - Select "Modulation > Amplitude Modulation/Frequency Modulation/Phase Modulation > State > ON".
 - Select "Modulation > MOD ON".
 - Press the [Mod on/off] key.

[Mod on/off]

Activate one or more analog modulations and press the [Mod on/off] key to toggle the state of them all.

Pressing the key again restores the status that was active before the last switch-off.

Remote command:

`[ :SOURce<hw> ] :MODulation [ :ALL ] [ :STATe ]` on page 614

5.4 Modulation settings

Access:


- Select "Modulation" > "Modulation Sources".

The "Modulation" dialog contains all functions and settings to configure the analog modulations, the LF signal sources for performing a modulation, and the LF signal output.

5.4.1 Pulse modulation settings

Option: see [Section 5.1, "Required options"](#), on page 77.

- Access:
- Select "Modulation" > "Pulse Modulation".



The "Pulse Modulation" dialog contains all parameters required to configure the pulse modulator and the pulse generator. It also displays the pulse signal graphically.

For an overview of the supported signals sources and related connectors, see [Section 5.2, "Modulation types and signal sources"](#), on page 77.

The remote commands required to define these settings are described in [Section 15.18.1.6, "SOURce:PULM subsystem"](#), on page 635.

Settings

State.....	81
Source.....	81
Transition Type.....	82

State

- Activates pulse modulation and triggers the following automatic settings:
- Pulse generator is activated.
The signal is output at the Pulse Video connector.
To deactivate the signal output, set "Pulse Generator" > [Pulse Output State](#) > "Off".

Remote command:
[\[:SOURce<hw> \] :PULM:STATe](#) on page 639

Source

Selects between the internal "Pulse Generator" or an "External" pulse signal for the modulation.

- "Pulse Generator"
- Selects the internal generator.
See [Pulse generator](#).
- "External"
- Modulation source is fed to the input connector.
See ["Signal sources"](#) on page 77.

Remote command:

[:SOURce<hw>] :PULM:SOURce on page 639

Transition Type

Selects between "Fast" or "Smoothed" slew rate (slope).

"Fast" Enables fast transitions with shortest rise and fall times.

"Smoothed" Flattens the slew rate, resulting in longer rise / fall times. Use this mode if you are working with devices that are sensitive to steep slopes.

For more information, refer to the specifications document.

For more information, refer to the specifications document.

Note: The R&S SMA100B supports this functionality up to a certain frequency, depending on the installed frequency options, see also ["Interactions and characteristics"](#) on page 79.

For more information, refer to the specifications document.

Remote command:

[:SOURce<hw>] :PULM:TTYPe on page 640

5.4.2 FM, PhiM and AM modulation settings

Option: R&S SMAB-K720

Access:

- Select "Modulation" > "Amplitude Modulation/Frequency Modulation/Phase Modulation".

Sources		☒ FM	☐ Φ M	☒ AM	☐ Output	Overview	X
Path 1				Path 2			
State	☒			State	☒		
Source	LF Generator 1			Source	External 1		
Deviation	1.000 00 kHz			Deviation	1.000 00 kHz		
Deviation Mode	Fixed Ratio			Ratio Path 2 / Path 1	100.00 %		
Mode	High Bandwidth						

The "FM", " Φ M" and "AM" tabs contain the parameters per modulation type.

The remote commands required to define these settings are described in:

- [Section 15.18.1.2, "SOURce:AM subsystem"](#), on page 615
- [Section 15.18.1.4, "SOURce:FM subsystem"](#), on page 626
- [Section 15.18.1.5, "SOURce:PM subsystem"](#), on page 631

Settings

State.....	84
Source.....	84
FM settings.....	84
L Deviation.....	84
L Deviation Mode.....	85
L Total Deviation.....	85
L Ratio Path2/Path1.....	85
L Mode.....	85
PhiM settings.....	86
L Deviation.....	86
L Deviation Mode.....	86
L Total Deviation.....	86
L Ratio Path2/Path1.....	87
L Mode.....	87

AM settings.....	87
L Mode.....	88
L Type.....	88
L Depth.....	89
L Sensitivity.....	89
L Deviation Mode.....	89
L Total Depth.....	89
L Ratio Path2/Path1.....	90

State

Activates a modulation.

Note: Some modulations exclude each other and cannot be performed simultaneously. For more information, refer to the specifications document.

Remote command:

[:SOURce<hw>] :AM<ch> :STATe on page 618

[:SOURce<hw>] :FM<ch> :STATe on page 628

[:SOURce<hw>] :PM<ch> :STATe on page 632

Source

Selects the LF signal source.

You can vary the signal sources for each of the modulations.

"LF Generator 1/2"

Selects one or both of the internally generated LF signals.

See [Section 5.4.7.1, "Source > LF generator settings"](#), on page 111.

"External 1/2" Selects an externally supplied LF signal.

"Noise Generator"

Selects the internally generated noise signal.

See [Section 5.4.7.3, "Source > noise generator settings"](#), on page 116.

Remote command:

[:SOURce<hw>] :AM<ch> :SOURce on page 618

[:SOURce<hw>] :FM<ch> :SOURce on page 629

[:SOURce<hw>] :PM<ch> :SOURce on page 633

FM settings

The following settings are dedicated to FM.

Deviation ← FM settings

Sets the frequency modulation deviation in Hz.

The maximal deviation depends on the RF frequency and the selected modulation mode.

Maximal possible deviation is selected automatically, if one of the following applies:

- The selected deviation is too high for the particular frequency
- The selected frequency is outside of the range where deviation is possible.

A warning message indicates this situation, too.

For more information, refer to the specifications document.

Remote command:

`[ :SOURce<hw> ] :FM<ch> [ :DEViation ]` on page 628

Deviation Mode ← FM settings

Enables you to couple the LF signal of both paths and determines the mode for fixing the total deviation.

The total deviation is the sum of both paths. When the sum is exceeded, the R&S SMA100B reports a settings conflict, but does not change the settings.

- | | |
|---------------|--|
| "Uncoupled" | Enables you to adjust the deviation for each path independently. |
| "Fixed Total" | Couples the deviation of both paths in per Hz. If you change the deviation of any path, the R&S SMA100B automatically adjusts the value of the other path. The sum always results in the set Total Deviation . |
| "Fixed Ratio" | Couples the deviation ratio of both paths. If you change the deviation of any path, the R&S SMA100B adjusts the value of the other path. |

Remote command:

`[ :SOURce<hw> ] :FM:DEViation:MODE` on page 629

Total Deviation ← FM settings

Sets the sum of the signal deviation for path 1 and path 2 in Hz when using combined sources in [Deviation Mode > Fixed Total](#).

[Deviation](#) of both paths always sum up to the value of the total deviation.

Behavior when changing any depth settings:

- Changing the total deviation adjusts the deviation of both paths proportionally.
- Changing the deviation of one path adjusts the deviation of the other path. The sum always results in the set total deviation.

Remote command:

`[ :SOURce<hw> ] :FM:DEViation:SUM` on page 630

Ratio Path2/Path1 ← FM settings

Sets the deviation ratio (path2 to path1) in percent.

Example:

If the deviation in path1 is 10 kHz and the ratio is 50%, the deviation in path 2 is automatically set to 5 kHz.

Remote command:

`[ :SOURce<hw> ] :FM:RATio` on page 630

Mode ← FM settings

Selects the mode of the frequency modulation.

- | | |
|------------------|--|
| "High Bandwidth" | The maximum range for modulation bandwidth is available. |
|------------------|--|

"Low Noise" Phase modulation with phase noise and spurious characteristics close to CW mode. The range for modulation bandwidth and FM deviation is reduced.

To reduce the phase noise further, set the [Main PLL Bandwidth](#) = "Narrow"

For more information, refer to the specifications document.

Remote command:

[\[:SOURce<hw>\]:FM:MODE](#) on page 630

PhiM settings

The following settings are dedicated to PhiM.

Deviation ← PhiM settings

Sets the phase modulation deviation in radians or degrees.

The maximal deviation depends on the RF frequency and the selected modulation mode.

For more information, refer to the specifications document.

Maximal possible deviation is selected automatically, if one of the following applies:

- The selected deviation is too high for the particular frequency
- The selected frequency is outside of the range where deviation is possible.

A warning message indicates this situation, too.

Remote command:

[\[:SOURce\]:PM<ch>\[:DEViation\]](#) on page 635

Deviation Mode ← PhiM settings

Enables you to couple the LF signal of both paths and determines the mode for fixing the total deviation.

The deviation sum 2 rad at a maximum. When the sum is exceeded, the R&S SMA100B adjusts the settings automatically.

"Uncoupled" Enables you to adjust the deviation for each path independently.

"Fixed Total" Couples the deviation of both paths. If you change the deviation of any path, the R&S SMA100B automatically adjusts the value of the other path. The sum always results in the set [Total Deviation](#).

"Fixed Ratio" Couples the deviation ratio of both paths. If you change the deviation of any path, the R&S SMA100B adjusts the value of the other path.

Remote command:

[\[:SOURce<hw>\]:PM:DEViation:MODE](#) on page 634

Total Deviation ← PhiM settings

In [Deviation Mode = Fixed Total](#), sets the sum of the signal deviation for path 1 and path 2.

[Deviation](#) of both paths always sum up to the value of the total deviation.

Behavior when changing any depth settings:

- Changing the total deviation adjusts the deviations of both paths proportionally.

- Changing the deviation of one path adjusts the deviation of the other path. The sum always results in the set total deviation.

Remote command:

`[ :SOURce<hw> ] :PM:DEVIation:SUM` on page 634

Ratio Path2/Path1 ← PhiM settings

Sets the deviation ratio (path2 to path1) in per cent.

Example:

If the deviation in path1 is 10 rad and the ratio is 50%, the deviation in path 2 is automatically set to 5 rad.

Remote command:

`[ :SOURce<hw> ] :PM:RATio` on page 634

Mode ← PhiM settings

Selects the mode of the phase modulation.

"High Bandwidth"

The maximum range for modulation bandwidth and PhiM deviation is available.

However, phase noise increases at low frequencies, and the range of PhiM deviation is limited. This mode is suitable if you process high frequencies.

"High Deviation"

The maximum range for PhiM deviation is available.

Phase noise is improved for low frequencies compared to the default mode. The range for modulation frequency is limited.

This mode is suitable for low modulation frequencies and/or high PhiM deviation.

"Low Noise"

Frequency modulation with phase noise and spurious characteristics close to CW mode. The range for modulation bandwidth and FM deviation is reduced.

For more information, refer to the specifications document.

Remote command:

`[ :SOURce<hw> ] :PM:MODE` on page 633

AM settings

The following settings are dedicated to AM.

Sources	☒ FM	☐ Φ M	☒ AM	☐ Output	Overview	X
Mode		Type				
Normal		Linear				
Path 1			Path 2			
State		State				
☒		☒				
Source		Source				
LF Generator 1		External 1				
Depth		Sensitivity				
30.00 %		30.0 %/V				
Deviation Mode		Ratio Path 2 / Path 1				
Fixed Ratio		100.00 %				

Mode ← AM settings

Selects the mode to derive the carrier signal for amplitude modulation.

- "Normal" Performs the standard amplitude modulation with a single sinusoidal carrier signal.
- "Scan" (Option: R&S SMAB-K721)
Performs amplitude modulation with a higher dynamic range. The R&S SMA100B provides a special exponential amplitude modulation system optimized for highest dynamic range. You can use the scan mode to emulate level behaviors of transmitter/receiver systems with rotating antennas. Selecting "Mode > Scan" sets the modulation type to "Exponential".
Note: Using exponential AM with an external source affects other operating modes as described in ["Interactions and characteristics"](#) on page 79.

Remote command:

[:SOURce<hw>] :AM:MODE on page 619

Type ← AM settings

Selects the type of the amplitude modulation for both paths.

Using exponential AM with an external source affects the coupling mode and the external modulation input, see ["Interactions and characteristics"](#) on page 79.

- "Linear" Sets linear amplitude modulation with depths specified in percent / volt.
- "Exponential" Sets the exponential AM type with depths in dB / volt.

Remote command:

`[ :SOURce<hw> ] :AM:TYPE` on page 621

Depth ← AM settings

Determines the depth of the modulation signal in percent.

For "Type = Exponential", the unit of "AM Depth" changes to dB.

The depth is limited by the maximum peak envelope power (PEP).

Remote command:

`[ :SOURce<hw> ] :AM<ch>:DEPTh:LINear` on page 619

`[ :SOURce<hw> ] :AM<ch>:DEPTh:EXponential` on page 619

Sensitivity ← AM settings

Sets the input sensitivity of the external modulation signal.

Remote command:

`[ :SOURce<hw> ] :AM<ch>:SENSitivity[:LINear]` on page 621

`[ :SOURce<hw> ] :AM<ch>:SENSitivity:EXponential` on page 621

Deviation Mode ← AM settings

Enables you to couple the LF signal of both paths and determines the mode for fixing the total deviation.

The deviation sum of both paths is 100% in total. When the sum is exceeded, the R&S SMA100B reports a settings conflict, but does not change the settings.

- | | |
|---------------|--|
| "Uncoupled" | Enables you to adjust the deviation depth for each path independently. |
| "Fixed Total" | Couples the deviation depth of both paths in per cent. If you change the depth of any path, the R&S SMA100B automatically adjusts the value of the other path. The sum always results in the set Total Depth . |
| "Fixed Ratio" | Couples the deviation ratio of both paths. If you change the depth of any path, the R&S SMA100B adjusts the value of the other path. |

Remote command:

`[ :SOURce<hw> ] :AM:DEVIation:MODE` on page 620

Total Depth ← AM settings

Sets the sum of the signal [Depth](#) for path 1 and path 2 in per cent when using combined sources and [Deviation Mode > Fixed Total](#).

Using external LF signals, the R&S SMA100B indicates the [Sensitivity](#) per Volts for the input signal.

Provided both signal paths are turned on, the depth of both paths always sum up to the value of the total depth.

Behavior when changing any depth settings:

- Changing the total depth adjusts the depths of both paths proportionally.
- Changing the depth of one path adjusts the depth of the other path. The sum always results in the set total depth.

Remote command:

[:SOURce<hw>] :AM:DEPTh:SUM on page 620

Ratio Path2/Path1 ← AM settings

Sets the deviation ratio of the signal depth for path 2 to path 1 in per cent when using combined sources.

Using external LF signals, the R&S SMA100B indicates the [Sensitivity](#) per Volts for the input signal.

In conjunction with the deviation mode, you can set the depth of both paths independently or coupled.

- [Deviation Mode > Uncoupled](#)
Enables you to set the [Depth](#) or [Sensitivity](#) of both paths independently.
- [Deviation Mode > Fixed Ratio](#)
Couples the ratio of the two paths as follows.
 - Changing the ratio path2/path1 adjusts the depth of both path2. The depth of path1 remains the same
 - Changing the depth of one path adjusts the depth of the other accordingly. The ratio path2/path1 remains the same.

Remote command:

[:SOURce<hw>] :AM:RATio on page 620

5.4.3 Chirp modulation


Option: see [Section 5.1, "Required options"](#), on page 77.

About chirp modulation

Chirp modulation is used in radar technique to achieve pulse compression. Pulse compression increases the sensitivity and resolution of radar systems by modifying transmitted pulses to improve their auto-correlation properties. To chirp the radar signal is one way of accomplishing pulse compression. A chirp is a signal with increasing or decreasing frequency over time.

The R&S SMA100B always couples the chirp modulation with the pulse modulation. It generates the modulation signals for FM and pulse modulator, and synchronizes the signals internally. The internal pulse generator signal is the modulation source for the pulse modulator, and the internal LF generator signal is the signal source for the frequency modulation. Normal FM mode is used. Using an external modulation signals is not possible for chirp modulation.

The following graph shows the FM demodulated signal of chirped pulses with a chirp bandwidth of 80 MHz and a pulse width of 80 µs. Chirp direction is up.



The nominal level is used for typically 3 ms to 5 ms after level or frequency setting, if:

- No attenuator is fitted.
- "High Power" mode is enabled.
- "Auto" mode is enabled, and if the level is in the range of the high power, i.e. the mechanical relay bypass is switched.

For more information, refer to the specifications document.

5.4.3.1 Chirp modulation settings

Option: see [Section 5.1, "Required options"](#), on page 77.

- [Chirp modulation](#).....92
- [Pulse external / trigger](#).....95

Chirp modulation

Access:

- Select "Modulation" > "Chirp Modulation".

Chirp Modulation	Pulse External / Trigger	
State		
Direction	Up	Trigger Mode: Auto
Pulse Period	10.00 µs	Pulse Width: 2.00 µs
Bandwidth	1.000 00 kHz	Compression Ratio: 0.00
"Trigger Mode > Auto"		

Chirp Modulation	Pulse External / Trigger	
State		
Direction	Up	Trigger Mode: Single
Pulse Period	10.00 µs	Pulse Width: 2.00 µs
Bandwidth	1.000 00 kHz	Compression Ratio: 0.00
Number of Pulses per Trigger Event	5	
"Trigger Mode > Single"		

The "Chirp Modulation" dialog contains the parameters for configuring the modulation and trigger settings.

The remote commands required to define these settings are described in [Section 15.18.1.3, "SOURce:CHIRp subsystem"](#), on page 622.

State.....	92
Direction.....	92
Trigger Mode.....	93
Pulse Period.....	93
Pulse Width.....	94
Bandwidth.....	94
Compression Ratio.....	94
Number of Pulses Per Trigger Event.....	94
Execute Single Trigger.....	94
Show/Show Connector.....	94

State

Activates chirp modulation.

Note: Some modulations exclude each other and cannot be performed simultaneously. For more information, refer to the specifications document.

Remote command:


[:SOURce<hw>] :CHIRp:STATe on page 625

Direction

Selects the direction of the chirp modulation.


"Up"

The chirp starts with the lower frequency.



"Down"

The chirp starts with the higher frequency.



Remote command:

[\[:SOURce<hw>\]:CHIRp:DIRection](#) on page 624

Trigger Mode

Selects the trigger mode for chirp modulation signals.

To supply the external trigger signal, use the Pulse Ext connector.

"Auto" Generates the chirp modulation signal continuously.

"Single" Generates the chirp modulation signal once, triggered internally with ["Execute Single Trigger"](#) on page 94.

"Ext Single" Generates a single chirp pulse, triggered by an external signal.

"Ext Triggered" Generates the chirp pulse each time an external trigger event occurs.

"Extern Gated" Generates the chirp pulse signal triggered by an external gate signal.

Remote command:

[\[:SOURce<hw>\]:CHIRp:TRIGger:MODE](#) on page 626

Pulse Period

Sets the period of the generated chirp. Option: R&S SMAB-K23 provides higher resolution.

For more information, refer to the specifications document.

Remote command:

`[ :SOURce<hw> ] :CHIRp:PULSe:PERiod` on page 625

Pulse Width

Sets the width of the generated pulse. The pulse width must be at least 1 us less than the set pulse period. Option R&S SMA100B-K23 provides a higher resolution.

For more information, refer to the specifications document.

Remote command:

`[ :SOURce<hw> ] :CHIRp:PULSe:WIDTh` on page 625

Bandwidth

Sets the modulation bandwidth in Hz.

The modulation bandwidth is the difference between the maximum and minimum frequency. E.g. a bandwidth of 10 MHz at a center frequency of 1 GHz leads to a frequency modulation between 995 MHz and 1005 MHz.

The maximum bandwidth depends on the installed frequency option and the RF frequency. If the bandwidth exceeds the RF frequency, or the frequency is out of the bandwidth range, the R&S SMA100B sets the maximum bandwidth and generates an error message.

For more information, refer to the specifications document.

Remote command:

`[ :SOURce<hw> ] :CHIRp:BANDwidth` on page 624

Compression Ratio

Indicates the pulse compression ratio, i.e. the product of the pulse width in (s) and the bandwidth (Hz). Pulse compression increases the range resolution and the signal to noise ratio of pulsed signals.

Remote command:

`[ :SOURce<hw> ] :CHIRp:COMPression:RATio?` on page 624

Number of Pulses Per Trigger Event

Sets the number of pulses for the trigger modes "Single" and "Ext. Single".

To select the trigger mode, see "[Trigger Mode](#)" on page 93.

Remote command:

`[ :SOURce<hw> ] :CHIRp:PULSe:WIDTh` on page 625

Execute Single Trigger

If `[ :SOURce<hw> ] :CHIRp:TRIGger:MODE > SINGLE` "Trigger Mode = Single", initiates a single pulse sequence manually.

Remote command:

`[ :SOURce<hw> ] :CHIRp:TRIGger:IMMediate` on page 625




Show/Show Connector

Opens a dialog that displays the location of the connector on the front panel or rear panel of the instrument. A blinking rectangle shows the connector.

Pulse external / trigger

- Access:
1. Select "Modulation" > "Chirp Modulation".
 2. Select "Pulse External / Trigger".



The "Pulse External / Trigger" dialog contains the parameters for configuring the externally applied pulse and trigger signals.

The remote commands required to define these settings are described in [Section 15.18.1.6, "SOURce:PULM subsystem"](#), on page 635.

Settings

[Show/Show Connector](#).....95




Show/Show Connector

Opens a dialog that displays the location of the connector on the front panel or rear panel of the instrument. A blinking rectangle shows the connector.

5.4.4 Pulse generator

Option: see [Section 5.1, "Required options"](#), on page 77.

- Access:
- Select "Modulation" > "Pulse Modulation > Pulse Generator".



The "Pulse Generator" tab contains the settings for creating the pulse modulation signal internally.

- The remote commands required to define these settings are described in [Section 15.18.1.6, "SOURce:PULM subsystem"](#), on page 635.
- [Pulse generator > general settings](#)..... 96
 - [Pulse generator > pulse train settings](#)..... 102
 - [Import/export list files](#)..... 105

5.4.4.1 Pulse generator > general settings

Access:

► Select "Modulation" > "Pulse Modulation > Pulse Generator".

Settings


Pulse Mode	97
Trigger Mode	98
Pulse Period	100
Pulse Width	101
Double Pulse Width	101
Pulse Delay	101
Double Pulse Delay	101
Pulse Repetition Frequency	101
Pulse Output State	101

Show/Show Connector.....	101
Pulse Output Polarity.....	101
Execute Single Trigger.....	101

Pulse Mode


Sets the operating mode of the pulse generator. Depending on the selection, the instrument displays the associated parameters.

"Single" Generates a single pulse in one pulse period.



- 1 = Pulse delay
- 2 = Pulse width
- 3 = Pulse period

"Double" Generates two pulses in one pulse period.




- 1 = Pulse width
- 2 = Double pulse delay
- 3 = Double pulse width
- 4 = Pulse period

"Train"

Option: R&S SMAB-K27

Generates a user-defined pulse train.



1 = 1st pulse: On-time

2 = 1st pulse: Off-time

3 = 1st pulse: pulse period

4 = 2nd pulse: repeated 3 times

5 = 3rd pulse

6 = 4th pulse

See [Section 5.4.4.2, "Pulse generator > pulse train settings"](#), on page 102.

Remote command:

[\[:SOURce<hw>\]:PULM:MODE](#) on page 637

Trigger Mode

Selects between continuous triggering or triggering initiated by a trigger event from an external signal.

See also ["Input and output connectors"](#) on page 78.

"Auto" Generates the internal modulation signal continuously.


"Single" The pulse generator is triggered by an internal trigger event, initiated with [Execute Single Trigger](#).

The pulse signal is generated once.

"Ext Single" Generates a single pulse signal, triggered by an external signal.

"Ext Triggered" Generates the pulse signal each time an external trigger event occurs.

Example: Generation of single pulse signal ("Pulse Mode = Single") using "Trigger Mode = Ext Triggered"



1 = External trigger signal input with "Trigger Input Polarity = Normal" (the positive slope is active)

2 = Sync signal

3 = Pulse signal


Δt = Trigger delay between the trigger and the sync signal start.

delay = "Pulse Delay = 100 ns"

PW = "Pulse Width = 100 ns"

For more information, refer to the specifications document.


Example: Generation of double pulse signal ("Pulse Mode = Double") using "Trigger Mode = Ext Triggered"



- 1 = External trigger signal input with "Trigger Input Polarity = Normal" (the positive slope is active)
- 2 = Sync signal
- 3 = Pulse signal
- a = Trigger signal during double pulse generation is without effect
- Δt = Trigger delay between the trigger and the sync signal start.
- delay = "Double Pulse Delay = 200 ns"; the first pulse starts without a delay
- PW = "Double Pulse Width = 100 ns"

"Ext Gated" Generates the signal triggered by an external gate signal.

Example: Generation of single pulse signal ("Pulse Mode = Single") using "Trigger Mode = Ext Gated"



- 1 = External trigger signal input with "Trigger Input Polarity = Normal" (the positive slope is active)
- 2 = Sync signal
- 3 = Pulse signal
- Δt = Trigger delay between the trigger and the sync signal start; see specifications document
- delay = "Pulse Delay = 100 ns"
- PW = "Pulse Width = 100 ns"
- period = "Pulse Period = 300 ns" (time between the pulse start of two consecutive pulses)
- a = Gate active duration (pulses are generated during the gate active part)

For more information, refer to the specifications document.

Remote command:

`[ :SOURce<hw> ] :PULM:TRIGger:MODE` on page 637

Pulse Period

Sets the repetition rate of the generated pulse signal.

Remote command:

`[ :SOURce<hw> ] :PULM:PERiod` on page 638

Pulse Width

Sets the pulse duration of the generated pulse signal.

Note: The pulse width must be at least 20 ns less than the set pulse period.

Remote command:

`[ :SOURce<hw> ] :PULM:WIDTh` on page 638

Double Pulse Width

Sets the width of the second pulse.

Remote command:

`[ :SOURce<hw> ] :PULM:DOUBle:WIDTh` on page 639

Pulse Delay

Sets the pulse delay. The pulse delay determines the time that elapses after a trigger event before pulse modulation starts. The pulse delay is not effective for double pulse generation.

Remote command:

`[ :SOURce<hw> ] :PULM:DELay` on page 638

Double Pulse Delay

Sets the delay from the start of the first pulse to the start of the second pulse.

Remote command:

`[ :SOURce<hw> ] :PULM:DOUBle:DELay` on page 639

Pulse Repetition Frequency

Indicates the number of pulses of the repeating signal in a specific time unit.

The parameter is commonly expressed in Hz or in pulses per second (pps).

Remote command:

n.a.

Pulse Output State

Activates the output of the pulse modulation signal.

Remote command:

`[ :SOURce<hw> ] :PGENerator:OUTPut[:STATe]` on page 738

**Show/Show Connector**

Opens a dialog that displays the location of the connector on the front panel or rear panel of the instrument. A blinking rectangle shows the connector.

Pulse Output Polarity

Sets the polarity of the pulse output signal.

Remote command:

`[ :SOURce<hw> ] :PGENerator:OUTPut:POLarity` on page 738

Execute Single Trigger

If "Trigger Mode = Single", initiates a single pulse sequence manually.

Remote command:


`[ :SOURCE ] :PULM [ :INTERNAL ] [ :TRAIN ] :TRIGger:IMMediate` on page 638

5.4.4.2 Pulse generator > pulse train settings

Option: see [Section 5.1, "Required options"](#), on page 77.

Access:

1. Select "Modulation" > "Pulse Modulation > Pulse Generator" > **"Pulse Mode = Train"**.



2. Select "Pulse Train Data".
3. Select an existing file or select "New" to create one.
4. Define the filename.
Select "Edit Pulse Train Data", if the file is empty or to control and change the values.
5. In the "Edit Pulse Train Data" dialog, enter the pulse on/off times and pulse repetition values.
6. Select "Save".

A pulse train is a sequence of pulses with user-defined repetition, and pulse on and off times. Once defined, pulse train settings can be saved in a file. The filename is user-definable; the file extension (*.pulstrn) is assigned automatically. When a file is selected, the filename is indicated.

Possible ways to configure a pulse train

You can configure a pulse train in the following ways:

- **Internally**

- Use the built-in editor table editor, see in the "Pulse Generator > Pulse Train" dialog.
Once defined, pulse train settings can be saved in a file. For example, to exchange configuration between instruments or to modify the file content with an external program and reload them again.
The filename is user-definable; the file extension is *.pulstrn.
- Using the corresponding remote-control commands.
Note that you have to create a pulse train file first.
- **Externally**
Create a pulse train sequence as a CSV file with Microsoft Excel, with a Notepad or a similar tool, save it with the predefined extension. Transfer the file to and load it into the instrument.

Pulse train ASCII file format

Files describing pulse trains are simple files in text or comma-separated value (CSV) file format. The filename is user-definable; the file extension is *.csv or *.txt.

The file contains a list of pulse definition values, one row per pulse; a new line indicator separates the pulses. Pulses are defined with their pulse on time, pulse off time given in us and number of repetitions.

Example: Pulse train file content (*.txt file)

```
0.0001,0.0005,2
0.00025,0.0005,1
0.0001,0.0003,3
```

For file handling, use the standard functions in the "File Manager", see [Section 12.9, "Using the file manager"](#), on page 348.

The remote commands required to define these settings are described in [Section 15.18.1.6, "SOURCE:PULM subsystem"](#), on page 635.

Settings

Pulse Train Data	103
Edit Pulse Train Data	104
Data handling keys	104
L Go To	104
L Edit	104
L Save As/Save	104
Fill	104

Pulse Train Data

Accesses the standard "File Select" function of the instrument. The provided navigation possibilities in the dialog are self-explanatory.

Pulse train files are files with predefined file extension *.pulstrn. When a file is selected, the dialog indicates the filename.

You can create the file internally in the table editor or externally.

- To select an existing file, select "Select List > navigate to the file *.pulstrn > Select"

- Use the general editor function to create internally new file or to edit an existing one.
- Use the standard file manager function to load externally created files to the instrument.

Remote command:

`[ :SOURce<hw> ] :PULM:TRAI:n:CATalog?` on page 642

`[ :SOURce<hw> ] :PULM:TRAI:n:SElect` on page 644

`[ :SOURce<hw> ] :PULM:TRAI:n:DElete` on page 642

Edit Pulse Train Data

Accesses the build-in table editor to define a new pulse train file or edit an existing one.

"On-Time, μ s/Off-Time, μ s"

Sets the pulse on and pulse off time.

"Count"

Sets the number of repetitions of an "On-/ Off-Time" value pair.

Pulses with "Count = 0" are ignored.

Use this method to skip value pairs temporarily, without deleting them from the table.

Remote command:

`[ :SOURce<hw> ] :PULM:TRAI:n:ONTime` on page 643

`[ :SOURce<hw> ] :PULM:TRAI:n:OFFTime` on page 643

`[ :SOURce<hw> ] :PULM:TRAI:n:REPetition` on page 643

`[ :SOURce<hw> ] :PULM:TRAI:n:DElete` on page 642

Data handling keys

Standard functions for file and data handling.



Note: Save a list only after filling both columns (frequency and level), otherwise the entries are lost.

Go To ← Data handling keys

Selects a row for editing.

Edit ← Data handling keys

Enables you to insert, or delete a row or ranges within a list, and provides access to a dialog for automatic filling.

See "Fill..." on page 104.

Save As/Save ← Data handling keys

Saves the list in a file with user-defined name and predefined file extension. To save a copy or create a file, use the "Save as" function.

Fill...

Provides parameters for filling a table automatically with user-defined values.

From 0	Range 4
Column To Fill Frequency /Hz	
Start Value 2.000 000 000 000 GHz	End Value 2.600 000 000 000 GHz
Increment Value 200.000 000 000 MHz	
☒ Fill	

To fill the table, select "Fill".

Note: Once you enter a value or fill a column, the editor automatically adds preset values in the other columns. This functionality protects against data loss, otherwise incomplete rows will be lost when saving. You can simply override these values.

"From / Range"

Defines the start line and number of lines to be filled.

"Column To Fill"

Selects, if the column is filled up with frequencies in Hz, levels in dBm or dwell times in s.

"Start Value / End Value"

Sets the start value for frequency, level or dwell time. The end value is read only and depends on the increment value and the range.

"Increment Value"

Determines the step size.

"Fill"

Fills the column specified in "Column To fill".

5.4.4.3 Import/export list files

Access:

1. Select one of the following:

- "Sweep" > "List mode".
- "Level" > "User Correction".
- "Modulation > Pulse Modulation > Pulse Generator > Pulse Mode = Train".

2. Select "Import/Export".

Figure 5-1: Im-/Export dialog (example with UCOR settings)

The "Import/Export" dialog contains all functions and settings to import externally created list data or to export it accordingly. You can process and store a list in the formats `*.txt` (ASCII), or `*.csv` (plain text with identical sequence of fields). The table separators and the decimal floating point numbers are customizable.

Settings:

Mode.....	106
ASCII File Settings.....	106
Select (ASCII) Source/Select (ASCII) Destination.....	107
Select Source/Select ASCII Destination.....	107
Import / Export.....	107

Mode

Selects import or export of a data list file. The provided parameters vary according to the selected mode.

Remote command:

`[ :SOURCE<hw> ] :LIST:DEXChange:MODE` on page 735

`[ :SOURCE<hw> ] :CORRection:DEXChange:MODE` on page 697

`[ :SOURCE<hw> ] :PULM:TRAIIn:DEXChange:MODE` on page 644

ASCII File Settings

Defines the format and the separators of the associated data file.

"Extension" Selects `*.csv` or `*.txt` format.

"Decimal Point" Sets "Point" (dot) or "Comma" as the decimal separator used in the ASCII data with floating-point numerals.

"Column Separator" Sets the separator between the columns in an ASCII table.
Available are: "Tab", "Semicolon", "Comma" or "Space".

Remote command:

`[ :SOURCE<hw> ] :LIST:DEXChange:AFIle:EXTension` on page 734

`[ :SOURCE<hw> ] :LIST:DEXChange:AFIle:SEPARATOR:DECimal` on page 734

[\[:SOURce<hw>\]:LIST:DEXChange:AFILe:SEParator:COLumn](#) on page 734

[\[:SOURce<hw>\]:CORRection:DEXChange:AFILe:EXTension](#) on page 695

[\[:SOURce<hw>\]:CORRection:DEXChange:AFILe:SEParator:DECimal](#)

on page 696

[\[:SOURce<hw>\]:CORRection:DEXChange:AFILe:SEParator:COLumn](#)

on page 696

[\[:SOURce<hw>\]:PULM:TRain:DEXChange:AFILe:EXTension](#) on page 645

[\[:SOURce<hw>\]:PULM:TRain:DEXChange:AFILe:SEParator:DECimal](#)

on page 645

[\[:SOURce<hw>\]:PULM:TRain:DEXChange:AFILe:SEParator:COLumn](#)

on page 645

Select (ASCII) Source/Select (ASCII) Destination

In "Mode > Import", access the file select dialog that provides standard file handling functions.

Where:

- "Select ASCII Source": defines the file to be loaded (imported)
- "Select ASCII Destination": selects the filename under that the loaded file is saved

Remote command:

[\[:SOURce<hw>\]:LIST:DEXChange:AFILe:CATalog?](#) on page 733

[\[:SOURce<hw>\]:LIST:DEXChange:AFILe:SElect](#) on page 734

[\[:SOURce<hw>\]:CORRection:DEXChange:AFILe:CATalog?](#) on page 695

[\[:SOURce<hw>\]:CORRection:DEXChange:AFILe:SElect](#) on page 696

[\[:SOURce<hw>\]:PULM:TRain:DEXChange:AFILe:CATalog?](#) on page 645

[\[:SOURce<hw>\]:PULM:TRain:DEXChange:AFILe:SElect](#) on page 646

Select Source/Select ASCII Destination

In "Mode > Export", access the file select dialog that provides standard file handling functions.

Where:

- "Select Source": selects the file to be exported
- "Select ASCII Destination": defines the filename and the file path for the exported file

Remote command:

[\[:SOURce<hw>\]:LIST:DEXChange:SElect](#) on page 735

[\[:SOURce<hw>\]:CORRection:DEXChange:SElect](#) on page 697

[\[:SOURce<hw>\]:PULM:TRain:DEXChange:SElect](#) on page 646

Import / Export

Imports or exports the selected data list file, depending on the current mode.

Remote command:

[\[:SOURce<hw>\]:LIST:DEXChange:EXECute](#) on page 735

[\[:SOURce<hw>\]:CORRection:DEXChange:EXECute](#) on page 696

[\[:SOURce<hw>\]:PULM:TRain:DEXChange:EXECute](#) on page 646


5.4.5 Pulse graph

Option: see [Section 5.1, "Required options"](#), on page 77.

Access:

- Select "Modulation" > "Pulse Modulation > Pulse Graph".

The pulse graph is the graphical representation of the current pulse signal.



The height of the bars corresponds to the selected amplitude of the pulse signal.

The remote commands required to define these settings are described in [Section 15.18.1.6, "SOURCE:PULM subsystem"](#), on page 635.

File Name

Indicates the name of the pulse train data file.

To create or select a file, see ["Pulse Train Data"](#) on page 103.

Remote command:

`[ :SOURCE<hw> ] :PULM:TRAI:n:SElect` on page 644

Zooming


You can zoom into the diagram to visualize the graph in more detail:

- "Zoom Position": Sets the focus on the time axis where to enlarge the graph.
- "Zoom In": Enlarges the graph at the selected position.
- "Zoom Out" for the reverse operation.

5.4.6 Pulse external / trigger settings

Access:

► Select "Modulation" > "Pulse Modulation > Pulse External / Trigger".



The dialog specifies some characteristics of the Pulse Ext connector.
This connector is common for the pulse generator and the pulse modulator. For an overview, see ["Input and output connectors"](#) on page 78.

The remote commands required to define these settings are described in [Section 15.18.1.6, "SOURce:PULM subsystem"](#), on page 635.

Settings

Polarity	109
Impedance	109
Threshold	110
Show/Show Connector	110

Polarity

Sets the polarity of the active slope of a pulse input signal, that is the external pulse modulation signal.

Remote command:
[\[:SOURce<hw>\]:PULM:POLarity](#) on page 640

Impedance

Sets the input impedance.

Remote command:
[\[:SOURce<hw>\]:PULM:IMPedance](#) on page 640

Threshold
Sets the high/low threshold in volts for the signal at the [Pulse Ext] connector.
Remote command:
[\[:SOURce<hw>\]:PULM:THReshold](#) on page 641



Show/Show Connector
Opens a dialog that displays the location of the connector on the front panel or rear panel of the instrument. A blinking rectangle shows the connector.

5.4.7 FM, PhiM and AM modulation sources

- Access:
- ▶ Select "Modulation > Modulation Sources".
In the "Sources" tab, you can configure an LF modulation signal for performing analog modulations. It includes the setting parameters of the internal LF-and multi-function generators, the noise generator, and an external signal source.
 - [Source > LF generator settings](#)..... 111
 - [Source > external settings](#)..... 115
 - [Source > noise generator settings](#)..... 116

5.4.7.1 Source > LF generator settings

Access:

- Select "Modulation" > "Modulation Sources > LF Generator".

Sources		☒ FM	☐ Φ M	☒ AM	☐ Output	Overview	X
LF Generator 1		LF Generator 2		LF Generator			
LF Frequency Sweep State				External			
Off				Noise Generator			
Shape		Shape					
Sine		Pulse					
Frequency		Pulse Period					
1.000 00 kHz		1.000 00 ms					
Period		Pulse Width					
1.000 00 ms		500.00 μ s					
		Pulse Duty Cycle					
		50.000 000 %					

The internal LF signal can be the modulation signal source for any of the analog modulations. The LF signal applies to all modulations which use the internal modulation signal. Therefore, any modification of the LF signal immediately affects all currently active modulations.

The remote commands required to define these settings are described in [Section 15.18.7, "SOURCE:LFOutput subsystem"](#), on page 710.

Settings

State (LF frequency sweep).....	111
Shape.....	112
Frequency.....	114
Period.....	114
Pulse Width.....	114
Pulse Duty Cycle.....	114
Triangle Rise.....	114
Trapezoid Rise / Fall.....	114
Trapezoid High.....	114

State (LF frequency sweep)

Status of the LF frequency sweep signal.

You find this parameter in two dialogs:

- "LF Frequency Sweep" turns on/off the signal generation.
See [Sweep mode settings](#) for access.
- "Analog Modulation Sources" displays the current state (read-only). If it is turned on, this dialog provides the varying sweep frequency, see [Current Frequency](#).

Note: Active RF frequency, RF level or RF combined sweep modes deactivate the LF sweep or List mode and vice versa.

Remote command:


[\[:SOURce<hw>\]:LFOutput:FREQUENCY:MODE](#) on page 714

Shape

Option: R&S SMAB-K24.


Selects the waveform shape of the LF generator signal.

"Sine"




1 = Period

"Square"




1 = Period

"Pulse"




1 = Pulse width
2 = Pulse period

"Triangle"



1 = Triangle rise
2 = Triangle period

"Trapezoid"



1 = Trapezoid rise
2 = Trapezoid high
3 = Trapezoid fall
4 = Trapezoid period

Remote command:

[:SOURce<hw>] :LFOutput<ch>:SHApe on page 717

Frequency

Sets the frequency of the LF generator for sine signals.

Set the signal shape with the parameter [Shape](#).

Remote command:

[:SOURce] :LFOutput<ch>:FREQuency on page 713

Period

Sets the repetition rate of the generated LF signal for triangle, trapezoid or pulse shapes, see [Shape](#).

The period of sine signals is calculated from the selected [Frequency](#)

Remote command:

[:SOURce<hw>] :LFOutput<ch>:SHApe:TRAPeZe:PERiod on page 718

[:SOURce<hw>] :LFOutput<ch>:SHApe:TRIangle:PERiod on page 719

[:SOURce<hw>] :LFOutput<ch>:SHApe:PULSe:PERiod on page 717

Pulse Width

Sets the pulse duration of the generated pulse signal.

Remote command:

[:SOURce<hw>] :LFOutput<ch>:SHApe:PULSe:WIDTh on page 718

Pulse Duty Cycle

Sets the ratio between the pulse duration and the pulse period in percent.

Remote command:

[:SOURce<hw>] :LFOutput<ch>:SHApe:PULSe:DCYCLe on page 717

Triangle Rise

Sets the time required for the triangle signal to change from low level to high level.

Remote command:

[:SOURce<hw>] :LFOutput<ch>:SHApe:TRIangle:RISE on page 719

Trapezoid Rise / Fall

Sets the time required for the trapezoid signal to change from low level to high level, and vice versa.

Remote command:

[:SOURce<hw>] :LFOutput<ch>:SHApe:TRAPeZe:RISE on page 719

[:SOURce<hw>] :LFOutput<ch>:SHApe:TRAPeZe:FALL on page 718

Trapezoid High

Sets how long the trapezoid signal is at high level.

Remote command:

[:SOURce<hw>] :LFOutput<ch>:SHApe:TRAPeZe:HIGH on page 718

5.4.7.2 Source > external settings

Access:

- Select "Modulation" > "Modulation Sources > External".

Sources		FM	ΦM	AM	Output	Overview	X
External 1		External 2		LF Generator			
Coupling(AC/DC)		Coupling(AC/DC)		DC		External	
Impedance		Impedance		50 Ω		Noise Generator	
Bandwidth		Bandwidth		10 MHz			
Show Connector ...		Show Connector ...					

The "External" settings section contains all parameters required to configure the signal of an externally supplied LF signal.

The remote commands required to define these settings are described in [Section 15.18.6, "SOURce:INPut subsystem"](#), on page 709.

Settings

Coupling (AC/DC).....	115
Impedance.....	116
Bandwidth.....	116
Show/Show Connector.....	116

Coupling (AC/DC)

Selects the coupling mode (AC or DC) for the external signal.

"AC"	Disconnects the DC voltage component and uses only the AC component of the modulation signal.
"DC"	Uses the modulation signal with both components, AC and DC. For active external exponential AM, sets the coupling of the corresponding input automatically to DC.

Remote command:

[:SOURce<hw>] : INPut : MODext : COUPling<ch> on page 709

Impedance

Sets the impedance for the externally supplied signal.

Remote command:
[:SOURce<hw>]:INPut:MODext:IMPedance<ch> on page 710

Bandwidth

Displays the maximum bandwidth of the external LF signal.

Remote command:
[:SOURce]:LFOutput<ch>:BANDwidth? on page 713




Show/Show Connector

Opens a dialog that displays the location of the connector on the front panel or rear panel of the instrument. A blinking rectangle shows the connector.

5.4.7.3 Source > noise generator settings

Access:

► Select "Modulation" > "Modulation Sources > Noise Generator".



The "Noise Generator" settings contain all parameters to configure the signal of the internal noise generator.

The remote commands required to define these settings are described in [Section 15.18.9, "SOURce:NOISe subsystem"](#), on page 735.

Settings

Distribution.....	116
Bandwidth.....	117

Distribution

Selects the distribution of the noise power density.

"Gauss" Generates the noise power according to a Gaussian distribution.

"Equal" Generates an evenly distributed noise.

Remote command:

[\[:SOURce<hw>\]:NOISe:DISTriBution](#) on page 737

Bandwidth

Sets the noise bandwidth as distinct value.

You can set the bandwidth between 100 kHz and 10 MHz in 100 KHz steps.

Remote command:


[\[:SOURce<hw>\]:NOISe:BANDwidth|BWIDth](#) on page 736

[\[:SOURce<hw>\]:NOISe:BWIDth:STATe](#) on page 736

5.4.8 LF signal output settings

Access:

- Select "Modulation" > "LF Output".



In the "LF Output" tab, you can configure the signal at the LF outputs, determine the output voltage or add a DC offset. Activate both paths to output the sum signal of the two sources.

Settings

State.....	118
Source.....	118
Show/Show Connector.....	118
Output Voltage.....	118

DC-Offset.....	118
Load Impedance.....	118
Noise Level.....	119
L Noise Density.....	119
L Noise Level.....	119

State

Activates the output of the LF signal.

Remote command:

`[ :SOURce ] :LFOutput<ch> [ :STATe ]` on page 715

Source

Select the sources for the signal output at the LF connector. If you activate path 1 *and* 2, those sources are added.

Use the "Show Connector" function to find out where this connector is located.

"LF Generator 1/2"

Selects one of internally generated LF signals.

"AM"

Option: R&S SMAB-K720

Selects the AM signal.

"FM/PhiM"

Option: R&S SMAB-K720

Selects the signal also used by the frequency or phase modulations.

"Noise Generator"

Selects the internally generated noise signal.

"External 1/2"

Selects one of the externally supplied LF signals.

Remote command:

`[ :SOURce ] :LFOutput<ch> :SOURce` on page 716



Show/Show Connector

Opens a dialog that displays the location of the connector on the front panel or rear panel of the instrument. A blinking rectangle shows the connector.

Output Voltage

Sets the peak to peak voltage of the selected LF output source.

This value, e.g. +1 V to -1 V refers to 50 Ohm at the RF output with high termination impedance at the LF output.

Remote command:

`[ :SOURce ] :LFOutput<ch> :INTernal :VOLTage` on page 715

DC-Offset

Adds a DC offset to the LF output signal.

Remote command:

`[ :SOURce ] :LFOutput :OFFSet` on page 716

Load Impedance

Sets the specification of the load impedance interconnected to the LF generator output.

This parameter is available in case of activated R&S SML0x emulations only, see "Remote Access Settings" > "Instrument Emulations" > ["Language"](#) on page 429.

These signal generators come with an LF generator source impedance of 10 Ohm which is not available with the R&S SMA100B.

The set LF generator load impedance enables the R&S SMA100B to emulate the 10 Ohm LF generator source impedance of these generators by a corresponding increase of the open circuit LF generator output voltage.

The load impedance setting is not affected by an instrument preset ([Preset] key or *RST), restart or the "Save/Recall" function. It is reset to the default value of 1 MOhm by a factory preset only.


Remote command:

n.a.

Noise Level

Access:

- Select "Modulation" > "Output > Noise Level".



Noise Density ← Noise Level

Indicates the level of the noise signal for a bandwidth of 1 Hz (relative).

Remote command:

[\[:SOURCE<hw>\]:NOISE:LEVEL:RELATIVE?](#) on page 737

Noise Level ← Noise Level

Indicates the level of the noise signal per Hz within the total bandwidth (absolute).

Remote command:


[\[:SOURCE<hw>\]:NOISE:LEVEL\[:ABSOLUTE\]?](#) on page 737

5.4.9 Overview

Option: AM and FM/PM require R&S SMAB-K720

Access:

- Select "Modulation" > "Modulation Sources > Overview".



The "Overview" tab is an interactive diagram that indicates the active modulations and the signal being output.

Here you can:

- Select the output signal ("LF Out") in one or two paths; the setting acts as the parameter "LF Output Source"
 - Select the source for each modulation and modulation path; the setting acts as the parameter "Source"
 - Activate modulation in one or two paths; the setting acts as the parameter "State"
- To generate a two-tone signal composed from the two paths of the same modulation type, activate both paths.
- The "FM" box allows switching to "PhiM", but those modulations are mutually exclusive.

LFOut

Label for the LF output settings in the overview.

Remote command:

n.a.

AM

Label for the amplitude modulation settings in the overview.

Remote command:

n.a.

FM/PhiM

Selects the modulation signal to be assigned to the output. You can assign the frequency or phase modulated signal.

Remote command:

n.a.

5.5 How to generate an amplitude modulated signal

The following examples use the internal LF generator.

To set the frequency and level of the RF signal

1. Press [Preset] to start from a defined state.
2. In the status bar, set "Frequency = 2 GHz".
3. Set "Level = -20 dBm".

To configure the modulation signal (LF generator)

1. Select "Modulation" > "Modulation Source".
2. In the "Sources" tab, select "Shape > Sine".
3. Set "Frequency = 20 kHz".

The period is calculated automatically and indicates "Period = 50.00 µs".

To configure the amplitude modulation settings

1. In "Modulation" dialog, select the "AM" tab.
2. Set "Source = LF Generator1"
3. Set "Depth = 30%"
4. Select "State = I" to activate the modulation.
5. Set "Level > RF ON" to enable signal output.

5.6 How to generate a pulse modulated signal

The following example uses the internal pulse generator.

To set the frequency and level of the RF signal

1. Press [Preset].
2. In the status bar, set "Frequency = 4 GHz".
3. Set "Level = -25 dBm".

To configure the pulse generator

1. Select "Modulation" > "Pulse Generator".
2. Select "Pulse Mode = Double".
3. Set "Pulse Period = 10 us".
4. Set "Pulse Width = 2 us".
5. Set "Double Pulse Width = 1.2 us".
6. Set "Double Pulse Delay = 4.5 us".
7. Activate "Pulse Output State".
8. Set "Trigger Mode = Auto".

In the "Pulse Graph" tab, you can view the generated pulse signal graphically.

To enable pulse modulation

1. Select the "Pulse Modulation" tab.
2. Set "State = I" to activate pulse modulation.
3. Set "Level > RF ON" to enable signal output.

5.7 How to generate a pulse train modulated signal

The following example uses the internal pulse generator.

To set the frequency and level of the RF signal

1. Press [Preset].
2. In the status bar, set "Frequency = 6 GHz".
3. Set "Level = -25 dBm".

To configure the pulse generator

1. Select "Modulation" > "Pulse Generator".
2. Select "Pulse Mode = Train".
3. Select "Pulse Train Data".
Accesses the standard function for file handling.

4. Select an existing file or select "New" to create one.
5. Define the filename.
Select "Edit Pulse Train Data", if the file is empty or to control and change the values.
6. In the "Edit Pulse Train Data" dialog, enter the pulse on/off times and pulse repetition values.
For example:
 - "On-Time = 500 us", "OFF-Time = 2 ms", "Count = 2"
 - "On-Time = 100 us", "OFF-Time = 2.5 ms", "Count = 1"
 - "On-Time = 10 us", "OFF-Time = 50 us", "Count = 10"
7. "Save" the file and close the dialog.
The instrument returns to the /var/user/ where it has saved the file.
8. Select the file in the directory.
9. Confirm with "Select".
10. In the "Pulse Generator" dialog, select "Pulse Output State = On".
11. Set "Trigger Mode = Auto".

In the "Pulse Graph" tab, you can view the generated pulse signal graphically.

To enable pulse train modulation

1. Select the "Pulse Modulation" tab.
2. Set "State = I".
3. Set "Level > RF ON" to enable signal output.

6 Avionic standards

The R&S SMA100B supports avionic standards VOR, ILS and ADF.

Contents

• Required options	124
• About avionics	124
• Generating VOR signals	124
• Generating ILS signals	135
• Generating ADF signals	162

6.1 Required options

The R&S SMA100B base unit equipped with the following options:

- Signal generation for VOR, ILS and ADF (R&S SMAB-K25)

6.2 About avionics

This section summarizes information on avionics standards supported at the R&S SMA100B. Also, it links detailed information on the avionic standard supported at the R&S SMA100B.

Overview of avionics standards

- **Landing systems:** ILS (Instrument Landing System)
Landing systems are ground-based approach systems that provide precision guidance to aircraft approaching and landing on a runway.
For more information, see [Section 6.4, "Generating ILS signals"](#), on page 135.
- **Radio/Flight navigation systems:** VOR (VHF Omnidirectional Radio), ADF (Automatic Direction Finder)
The radio navigation systems are aircraft systems that support the pilots to determine the aircraft positions and stay on course.
For more information, see [Section 6.3, "Generating VOR signals"](#), on page 124 and [Section 6.5, "Generating ADF signals"](#), on page 162.

6.3 Generating VOR signals

This section provides information on very high frequency (VHF) omnidirectional radio range (VOR) signal generation with the R&S SMA100B. This information includes

required options, background information on VOR, generation of VOR signals, configuration and settings.

- [About VOR](#)..... 125
- [VOR configuration and settings](#)..... 126

6.3.1 About VOR

Very high frequency (VHF) omnidirectional radio range (VOR) is used for radio navigation and helps the aircraft to determine its position and stay on course.

A VOR system consists of a ground transmission station and a VOR receiver on the board of the aircraft.

The transmitter stations operate at VHF frequencies of 108 MHz to 118 MHz (see [Table 6-1](#)), with the code identification (COM/ID) transmitting on a modulation tone of 1.020 kHz. It emits two types of signals:

- An omnidirectional reference signal (REF) that can consist of two parts:
 - 30 Hz frequency modulated (FM) sine wave on subcarrier 9.96 kHz from amplitude modulation (AM) carrier
 - 1020 Hz AM modulated sine wave morse code
- A directional positioning signal, variable (VAR): 30 Hz AM modulated sine waves with variable phase shift.

The position of the aircraft is determined by measuring azimuth as the difference in phase of those two signals. The magnetic north is defined as the reference point, for which both signals are exactly in phase.

Related settings

For VOR settings at the R&S SMA100B, see [Section 6.3, "Generating VOR signals"](#), on page 124.

Channel frequencies

The column notations in the table below are as follows:

- **Channel** = ICAO channel number
- **Frequency** = VOR Interrogation frequency (MHz)

Table 6-1: VOR ICAO channels and frequencies (MHz)

Channel	Frequency	Channel	Frequency	Channel	Frequency	Channel	Frequency
17X	108.00	57X	112.00	87Y	114.00	107X	116.00
17Y	108.05	57Y	112.05	87Y	114.05	107Y	116.05
19X	108.20	58X	112.10	88X	114.10	108X	116.10
19Y	108.25	58Y	112.15	88Y	114.15	108Y	116.15
21X	108.40	59X	112.20	89X	114.20	109X	116.20
21Y	108.45	59Y	112.25	89Y	114.25	109Y	116.25

Channel	Frequency	Channel	Frequency	Channel	Frequency	Channel	Frequency
23X	108.60	70X	112.30	90X	114.30	110X	116.30
23Y	108.65	70Y	112.35	90Y	114.35	110Y	116.35
25X	108.80	71X	112.40	91X	114.40	111X	116.40
25Y	108.85	71Y	112.45	91Y	114.45	111Y	116.45
27X	109.00	72X	112.50	92X	114.50	112X	116.50
27Y	109.05	72Y	112.55	92Y	114.55	112Y	116.55
29X	109.20	73X	112.60	93X	114.60	113X	116.60
29Y	109.25	73Y	112.65	93Y	114.65	113Y	116.65
31X	109.40	74X	112.70	94X	114.70	114X	116.75
31Y	109.45	74Y	112.75	94Y	114.75	114Y	116.75
33X	109.60	75X	112.80	95X	114.80	115X	116.80
33Y	109.65	75Y	112.85	95Y	114.85	115Y	116.85
35X	109.80	76X	112.90	96X	114.90	116X	116.90
35Y	109.85	76Y	112.95	96Y	114.95	116Y	116.95
37X	110.00	77X	113.00	97X	115.00	117X	117.00
37Y	110.05	77Y	113.05	97Y	115.05	117Y	117.05
39X	110.20	78X	113.10	98X	115.10	118X	117.10
39Y	110.25	78Y	113.15	98Y	115.15	118Y	117.15
41X	110.40	79X	113.20	99X	115.20	119X	117.20
41Y	110.45	79Y	113.25	99Y	115.25	119Y	117.25
43X	110.60	80X	113.30	100X	115.30	120X	117.30
43Y	110.65	80Y	113.35	100Y	115.35	120Y	117.35
45X	110.80	81X	113.40	101X	115.40	121X	117.40
45Y	110.85	81Y	113.45	101Y	115.45	121Y	117.45
47X	111.00	82X	113.50	102X	115.50	122X	117.50
47Y	111.05	82Y	113.55	102Y	115.55	122Y	117.55
49X	111.20	83X	113.60	103X	115.60	123X	117.60
49Y	111.25	83Y	113.65	103Y	115.65	123Y	117.65
51X	111.40	84X	113.70	104X	115.70	124X	117.70
51Y	111.45	84Y	113.75	104Y	115.75	124Y	117.75
53X	111.60	85X	113.80	105X	115.80	125X	117.80
53Y	111.65	85Y	113.85	105Y	115.85	125Y	117.85
55X	111.80	86X	113.90	106X	115.90	126X	117.90
55Y	111.85	86Y	113.95	106Y	115.95	126Y	117.95

6.3.2 VOR configuration and settings

Option: R&S SMAB-K25

Access:

- Select "Modulation" > "Avionic Standards" > "VOR".

The remote commands required to define VOR settings are described in [Section 15.18.2.5, "SOURCE:VOR subsystem"](#), on page 680.


Settings

- [General settings](#)..... 127
- [Signal settings](#)..... 130
- [Position settings](#)..... 132
- [COM/ID settings](#)..... 133

6.3.2.1 General settings

Access:

- Select "VOR" > "General".



This dialog provides general settings of the VOR standard, the default and the "Save/Recall" settings.

By default, a VOR modulation signal is set on an RF carrier with a frequency of 108 MHz or ICAO channel 17X. The 9.96 kHz subcarrier signal is frequency modulated with a 30.00 Hz reference signal. The COM/ID signal has 1.02 kHz frequency, the variable phase signal 30.00 Hz frequency.

If enabled, the avionic standard modulation is displayed in the "Modulation" tile as follows:

- "Avionic: VOR" for enabled VOR modulation
- "Avionic ILS: Glide Slope/Localizer/Marker Bcn" for enabled ILS glide slope/localizer/marker beacons modulation
- "Avionic: ADF" for enabled ADF modulation

Settings:

State.....	128
Set To Default.....	128
Save/Recall.....	128
Carrier Frequency Mode.....	129
Carrier Frequency.....	129
ICAO Channel.....	129
EXT AM.....	129

State

Activates the avionic standard.

Activation of the standard deactivates a previously active avionic standard. The "VOR/ILS > Carrier Frequency" setting is applied automatically to the RF [Frequency](#) and displayed in the status bar.

Remote command:

[<subsystem>:STATe](#) on page 653

Set To Default

Calls the default settings. The table below lists the default values of the main parameters.

Standard	Parameter	Value
VOR/ILS/ADF	State	Not affected by "Set to default"
VOR	Carrier Frequency Mode	User Defined
	Carrier Frequency	108.000000 MHz
ILS	ILS Component	Glide Slope (GS)
	ILS GS > Carrier Frequency Mode	User Defined
	ILS GS > Carrier Frequency	334.700000 MHz
ADF	Carrier Frequency	190.000 kHz

Remote command:

[<subsystem>:PRESet](#) on page 652

Save/Recall

Opens the "Save/Recall" dialog that is the standard instrument function for saving and recalling the complete dialog-related settings in a file. The provided navigation possibilities in the dialog are self-explanatory.

The settings are saved in a file with a predefined extension. You can define the file-name and the directory, in that you want to save the file.

Remote command:

[<subsystem>:SETTing:CATalog](#) on page 652

[<subsystem>:SETTing:DELeTe](#) on page 652

[<subsystem>:SETTing:LOAD](#) on page 653

[<subsystem>:SETTing:STORe](#) on page 653

Carrier Frequency Mode

Sets the mode for the carrier frequency of the signal.

"User Defined" Activates user-defined setting of the carrier frequency.

"ICAO" Activates ICAO-conform setting of the carrier frequency via the "ICAO Channel". For standard VOR transmitting frequencies, see [Table 6-1](#).

Remote command:

[:SOURce<hw>] :VOR:FREQuency:MODE on page 686

Carrier Frequency

Requires "Carrier Frequency Mode > User Defined".

Sets the carrier frequency of the signal.

Remote command:

[:SOURce<hw>] :VOR:FREQuency on page 685

ICAO Channel

Requires "Carrier Frequency Mode" > "ICAO".

Sets the ICAO channel and the corresponding transmitting frequency.

If avionic standard modulation is activated and you change the "RF Frequency", the frequency value of the closest ICAO channel is applied automatically. The "ICAO Channel" is also updated.

For an overview of the VOR ICAO channels and frequencies, see [Table 6-1](#).

Remote command:

[:SOURce<hw>] :VOR:ICAO:CHANnel on page 686

EXT AM

Enables additional modulation from an external source. The external signal is input via the Ext connector.

"Off" Selects the internal modulation source for the avionic standard modulation.

"EXT (MOD AM)"

Selects the external source. The external signal is added to the internal signal. Switching off the internal source is not possible. The external signal is input via the Ext connector. The sensitivity is 10 mV per percent modulation depth.

Note: There can be an overmodulation as a function of the level of the external signal without a corresponding caution message being generated. To avoid an overmodulation, the peak value of the external signal is to be delimited corresponding to the sum of the modulation depths of the remaining VOR signal components.

Remote command:

[:SOURce<hw>] :VOR:SOURce on page 681

6.3.2.2 Signal settings

Access:

- Select "VOR" > "Signal".

VOR		ILS <i>Glide Slope</i>	ADF	
Operating Mode				General
Norm				
VAR/REF Frequency		VAR Depth		Signal
30.00 Hz		30.0 %		
Subcarrier Frequency		Subcarrier Depth		Position
9.960 00 kHz		30.0 %		
REF Deviation				COM/ID
480 Hz				

This dialog provides signal settings of the VOR modulation signal.

Settings:

Mode.....	130
VAR/REF Frequency.....	131
VAR Depth.....	131
Subcarrier Frequency.....	131
Subcarrier Depth.....	131
REF Deviation.....	131

Mode

Selects the operating mode for the VOR modulation signal.

"Norm"	VOR modulation is active.
"Var"	Amplitude modulation of the output signal with the VAR signal component (30Hz signal content) of the VOR signal. The modulation depth corresponds to the value set under VAR Depth .
"Subcarrier"	Amplitude modulation of the output signal with the unmodulated FM carrier (9960Hz) of the VOR signal. The modulation depth corresponds to the value set under Subcarrier Depth .
"Subcarrier + FM"	Amplitude modulation of the output signal with the frequency-modulated FM carrier (9960Hz) of the VOR signal. The frequency deviation corresponds to the value set under REF Deviation , the modulation depth corresponds to the value set under "Subcarrier Depth".

Remote command:

[:SOURCE<hw>] :VOR:MODE on page 687

VAR/REF Frequency

Sets the frequency of the VAR signal and the REF signal. As the two signals must have the same frequency, the setting is valid for both signals.

Remote command:

[\[:SOURce<hw>\]:VOR:VAR:FREQuency](#) on page 689

VAR Depth

Sets the AM modulation depth of the 30 Hz VAR signal.

Note: The sum of "Subcarrier Depth", "VAR Depth" and COM/ID "Depth" must be smaller than 100 %.

Remote command:

[\[:SOURce<hw>\]:VOR:VAR\[:DEPTh\]](#) on page 689

Subcarrier Frequency

Sets the frequency of the FM carrier.

Remote command:

[\[:SOURce<hw>\]:VOR:SUBCarrier\[:FREQuency\]](#) on page 688

Subcarrier Depth

Sets the AM modulation depth of the FM carrier.

Note: The sum of "Subcarrier Depth", "VAR Depth" and COM/ID "Depth" must be smaller than 100 %.

Remote command:

[\[:SOURce<hw>\]:VOR:SUBCarrier:DEPTh](#) on page 688

REF Deviation

Sets the frequency deviation of the reference signal on the FM carrier.

Remote command:

[\[:SOURce<hw>\]:VOR:REFerence\[:DEViation\]](#) on page 688

6.3.2.3 Position settings

Access:

- Select "VOR" > "Position".

This dialog provides position settings related to the VOR modulation signal.

Settings:

Bearing Angle.....	132
Direction.....	132

Bearing Angle

Sets the phase angle between the 30 Hz VAR signal and the 30 Hz reference signal.

The orientation of the angle depends on the set [Direction](#).

Remote command:

[\[:SOURCE<hw>\]:VOR\[:BANGLE\]](#) on page 681

Direction

Sets the reference position of the phase information.

The angle set under "Bearing Angle" corresponds to the angle between the geographic north and the connection line from beacon to airplane.

"From" Selection of the beacon as a reference position.

"To" Selection of the airplane position as a reference position.

Remote command:

[\[:SOURCE<hw>\]:VOR\[:BANGLE\]:DIRection](#) on page 682

6.3.2.4 COM/ID settings

Access:

- Select "VOR" > "COM/ID".

VOR		ILS <i>Glide Slope</i>	ADF	
COM/ID State ☐				General
Code	MUC	Period	9.000 s	Signal
Frequency	1.020 00 kHz	Depth	10.0 %	Position
Time Schema	Standard			COM/ID
Dot Length	100.0 ms			

This dialog provides COM/ID signal settings related to the VOR signal.

Settings:

COM/ID State.....	133
Code.....	133
Period.....	134
Frequency.....	134
Depth.....	134
Time Schema.....	134
Dot Length.....	134
Dash Length.....	134
Symbol Space.....	135
Letter Space.....	135

COM/ID State

Enables/disables the COM/ID signal.

See also [Section D, "Morse code settings"](#), on page 860.

Remote command:

`[ :SOURce<hw> ] :VOR:COMid [ :STATe ]` on page 685

Code

Sets the coding of the COM/ID signal by the international short name of the airport (e.g. MUC for the Munich airport).

The COM/ID tone is sent according to the selected code, see [Section D, "Morse code settings"](#), on page 860.

If no coding is set, the COM/ID tone is sent uncoded (key down).

Remote command:

[\[:SOURCE<hw>\]:VOR:COMid:CODE](#) on page 682

Period

Sets the period of the COM/ID signal.

Remote command:

[\[:SOURCE<hw>\]:VOR:COMid:PERiod](#) on page 684

Frequency

Sets the frequency of the COM/ID signal.

Remote command:

[\[:SOURCE<hw>\]:VOR:COMid:FREQuency](#) on page 683

Depth

Sets the AM modulation depth of the COM/ID signal.

Note: The sum of [Subcarrier Depth](#), [VAR Depth](#) and COM/ID > [Depth](#) must be smaller than 100 %.

Remote command:

[\[:SOURCE<hw>\]:VOR:COMid:DEPTH](#) on page 683

Time Schema

Sets the time schema of the Morse code for the COM/ID signal.

"Standard" The set dot length determines the length of the dash, the symbol space and letter space of the Morse code.

"User" You can set each length value separately.

Remote command:

[\[:SOURCE<hw>\]:VOR:COMid:TSCHEMA](#) on page 685

Dot Length

Sets the length of a Morse code dot.

If "Time Schema" > "Standard", the dot length value determines also the length of the dash (= 3 times the dot length), symbol space (= dot length) and letter space (= 3 times the dot length).

Remote command:

[\[:SOURCE<hw>\]:VOR:COMid:DOT](#) on page 683

Dash Length

Requires "Time Schema" > "User".

Sets the length of a Morse code dash.

Remote command:

[\[:SOURCE<hw>\]:VOR:COMid:DASH](#) on page 682

Symbol Space
 Requires "Time Schema" > "User".
 Sets the length of the Morse code symbol space.
 Remote command:
 [:SOURce<hw>]:VOR:COMid:SYMBol on page 684

Letter Space
 Requires "Time Schema" > "User".
 Sets the length of a Morse code letter space.
 Remote command:
 [:SOURce<hw>]:VOR:COMid:LETTer on page 684

6.4 Generating ILS signals

This section provides information on instrument landing system (ILS) signal generation with the R&S SMA100B. This information includes required options, background information on ILS, generation of ILS signals, configuration and settings.

- [About ILS](#)..... 135
- [ILS configuration and settings](#)..... 139

6.4.1 About ILS

During the landing approach, the aircraft uses the instrument landing system (ILS) to monitor the correct approach path to the runway.




Figure 6-1: Approach navigation using instrument landing system (ILS) [1MA193]

- An ILS consists of three independent components:
- The glide slope (GS) component is for vertical guidance.
 - The localizer (LOC or LLZ) component is for horizontal guidance.
 - Optionally, the marker beacons (MB) component to provide distance information from the runway.

ILS signals

ILS signals are amplitude modulated (AM) radio frequency signals. The carrier frequencies f_c range from about 100 MHz to 340 MHz, see [Table 6-2](#). The modulation signals are tones with frequencies $f_1 = 90$ Hz and $f_2 = 150$ Hz.

During operation, an ILS sends a reference signal CSB (carrier and sidebands) and a signal for comparison SBO (sidebands only). The 90 Hz tone and the 150 Hz tone typically have the same modulation depth within these signals. Note that the R&S SMA100B supports CSB signal generation only. The figures [Figure 6-2](#) and [Figure 6-3](#) illustrate the spectrum of the CSB signal and the SBO signal.




Figure 6-2: CSB signal spectrum

- 1, 5 = Lower sideband $f_c - f_2$ and upper sideband $f_c + f_2$
- 2, 4 = Lower sideband $f_c - f_1$ and upper sideband $f_c + f_1$
- 3 = Carrier f_c




Figure 6-3: SBO signal spectrum

- 1, 4 = Inverted lower sideband $f_c - f_2$ and inverted upper sideband $f_c + f_2$
- 2, 3 = Lower sideband $f_c - f_1$ and upper sideband $f_c + f_1$

Glide slope component


The glide slope transmitter is located near the end of the runway. The location is nearest to the start of the aircraft approach.

Typically, vertically aligned antennas transmit two intersecting main beams on top of one another at carrier frequencies between 329 MHz and 335 MHz, see [Table 6-2](#).

The top beam is usually modulated at 90 Hz and the beam below at 150 Hz [1MA193]. The information on position is provided after demodulation of the beam signals by evaluating the difference in depth of modulation (DDM).

The following scenarios are possible:

- A predominance of the 90 Hz beam indicates that the aircraft is too high and needs to descend.
- A predominance of the 150 Hz beam indicates that the aircraft is too low and needs to climb.
- If the signal strength from both beams is equal, the aircraft is in the center and on the right course.




Localizer component

The localizer transmitter is located near the end of the runway (nearest to the start of the aircraft approach). Typically, horizontally aligned antennas transmit two intersecting main beams beside one another at carrier frequencies between 108 MHz and 112 MHz. As seen from the approaching aircraft coming in for a landing, the left beam is usually modulated at 90 Hz and the right beam at 150 Hz [1MA193].

The information on position is provided after demodulation of the beam signals by evaluating the difference in depth of modulation (DDM). The following scenarios are possible:

- Predominance of the 90 Hz beam: the aircraft is too far to the left and must turn to the right
- Predominance of the 150 Hz beam: the aircraft is too far to the right and must turn to the left
- The signal strength from both beams is equal: the aircraft is in the center, on the right course.



Marker beacons component

Marker beacon receivers are used for a rough distance measurement. They are available only for some ILS installations [1MA193].




Figure 6-4: Marker beacon placement and distance to runway

Marker beacon receivers decode audio signals and provide output signals to identify one of the three marker beacons near the runway. They transmit a narrow beam width at 75 MHz carrier frequency in a vertical direction. Each of them has a different distinct modulation code to allow the receiver to identify which one it is flying over [1MA193].

The flight equipment typically supports both visual identification (color of the marker beacon) and audio tone identification to determine the current flight position. The audio pairing or visual pairing of marker beacons is as follows:

- The outer marker flashes BLUE in the cockpit at 400 Hz (“relaxed” tone).
- The middle marker flashes AMBER in the cockpit at 1300 Hz (“hurried” tone).
- The inner marker flashes WHITE in the cockpit at 3000 Hz (“urgent” tone).

Related Settings

- [Section 6.4.2.2, "ILS glide slope settings"](#), on page 141
- [Section 6.4.2.3, "ILS localizer settings"](#), on page 148
- [Section 6.4.2.4, "ILS marker beacons settings"](#), on page 157

ILS channel frequencies

The column notations in the table below are as follows:

- **Chan.** = ICAO channel number
- **LOC freq.** = ILS localizer frequency (MHz)
- **GS freq.** = ILS glide slope frequency (MHz)

Table 6-2: ILS ICAO channels and frequencies (MHz)

Chan.	LOC freq.	GS freq.	Chan.	LOC freq.	GS freq.	Chan.	LOC freq.	GS freq.
18X	108.10	334.70	32X	109.50	332.60	46X	110.90	330.80
18Y	108.15	334.55	32Y	109.55	332.45	46Y	110.95	330.65
20X	108.30	334.10	34X	109.70	333.20	48X	111.10	331.70
20Y	108.35	333.95	34Y	109.75	333.05	48Y	111.15	331.55
22X	108.50	329.90	36X	109.90	333.80	50X	111.30	332.30
22Y	108.55	329.75	36Y	109.95	333.65	50Y	111.35	332.15
24X	108.70	330.50	38X	110.10	334.40	52X	111.50	332.90
24Y	108.75	330.35	38Y	110.15	334.25	52Y	111.55	332.75
26X	108.90	329.30	40X	110.30	335.00	54X	111.70	333.50
26Y	108.95	329.15	40Y	110.35	334.85	54Y	111.75	333.35
28X	109.10	331.40	42X	110.50	329.60	56X	111.90	331.10
28Y	109.15	331.25	42Y	110.55	329.45	56Y	111.95	330.95
30X	109.30	332.00	44X	110.70	330.20			
30Y	109.35	331.85	44Y	110.75	330.05			

6.4.2 ILS configuration and settings

Option: R&S SMAB-K25

Access:

- Select "Modulation" > "Avionic Standards" > "ILS".

The remote commands required to define ILS settings are described in [Section 15.18.2.4, "SOURCE:ILS subsystem"](#), on page 657.

CSB signal

By default, the R&S SMA100B generates an ILS glide slope signal. This signal is a CSB (carrier and sidebands) signal with a carrier frequency of 344.7 MHz or ICAO channel 18X. The dual-tone low-frequency signal has frequencies 90 Hz and 150 Hz and a balanced modulation at SDM of 80 %.

Settings:


- [General settings](#)..... 139
- [ILS glide slope settings](#)..... 141
- [ILS localizer settings](#)..... 148
- [ILS marker beacons settings](#)..... 157

6.4.2.1 General settings

This section provides settings to configure general ILS components.

Access:

- Select "ILS" > "General".



The dialog provides general settings of the ILS standard, the default and the "Save/ Recall" settings.

If enabled, the avionic standard modulation is displayed in the "Modulation" tile as follows:

- "Avionic: VOR" for enabled VOR modulation
- "Avionic ILS: Glide Slope/Localizer/Marker Bcn" for enabled ILS glide slope/localizer/marker beacons modulation
- "Avionic: ADF" for enabled ADF modulation

Settings:

State.....	140
Set To Default.....	140
Save/Recall.....	141
ILS Component.....	141

State

Activates the avionic standard.

Activation of the standard deactivates a previously active avionic standard. The "VOR/ILS > Carrier Frequency" setting is applied automatically to the RF [Frequency](#) and displayed in the status bar.

Remote command:
`<subsystem>:STATe` on page 653

Set To Default

Calls the default settings. The table below lists the default values of the main parameters.

Standard	Parameter	Value
VOR/ILS/ADF	State	Not affected by "Set to default"
VOR	Carrier Frequency Mode	User Defined
	Carrier Frequency	108.000000 MHz
ILS	ILS Component	Glide Slope (GS)
	ILS GS > Carrier Frequency Mode	User Defined
	ILS GS > Carrier Frequency	334.700000 MHz
ADF	Carrier Frequency	190.000 kHz

Remote command:

`<subsystem>:PRESet` on page 652

Save/Recall

Opens the "Save/Recall" dialog that is the standard instrument function for saving and recalling the complete dialog-related settings in a file. The provided navigation possibilities in the dialog are self-explanatory.

The settings are saved in a file with a predefined extension. You can define the filename and the directory, in that you want to save the file.

Remote command:

`<subsystem>:SETTing:CATalog` on page 652

`<subsystem>:SETTing:DELeTe` on page 652

`<subsystem>:SETTing:LOAD` on page 653

`<subsystem>:SETTing:STORe` on page 653

ILS Component

Sets the ILS component.

"Glide slope" Enables the glide slope.

"Localizer" Enables the localizer.

"Marker Beacons" Enables the marker beacons.

Remote command:

`[ :SOURce<hw> ] : ILS : TYPE` on page 659

6.4.2.2 ILS glide slope settings

Access:

1. Select "ILS" > "General".
2. Select "ILS Component" > "Glide Slope".


Settings:

• General settings	142
• Signal settings	144
• Amplitude settings	145

General settings

Access:

- Select "ILS" > "General".



This dialog provides carrier frequency settings related to the ILS glide slope component of the ILS signal.

Settings:

Carrier Frequency Mode	142
Carrier Frequency	143
ICAO Channel	143
Sync with Glide Slope/ Sync with Localizer	143
EXT AM	143

Carrier Frequency Mode

Sets the mode for the carrier frequency of the signal.

Select "Carrier Frequency Mode > ICAO" to set a standard ILS frequency channel. If you want to couple carrier frequencies of ILS glide slope and localizer components, enable [Sync with Glide Slope/ Sync with Localizer](#).

- "User Defined" Activates user-defined variation of the carrier frequency.
- "ICAO" Activates variation in predefined steps according to standard ILS transmitting frequencies (see [Table 6-2](#)).

Remote command:

[\[:SOURce<hw> \] : ILS \[:GS | GSLope \] : FREQuency:MODE](#) on page 662

Carrier Frequency

Requires "Carrier Frequency Mode" > "User Defined".

Sets the carrier frequency of the signal.

Remote command:

`[ :SOURce<hw> ] : ILS [ :GS | GSLope ] : FREQuency` on page 662

ICAO Channel

Requires "Carrier Frequency Mode" > "ICAO".

Sets the ICAO channel and the corresponding transmitting frequency.

If avionic standard modulation is activated and you change the "RF Frequency", the frequency value of the closest ICAO channel is applied automatically. The "ICAO Channel" is also updated.

For an overview of the ILS ICAO channel frequencies, see [Table 6-2](#).

Remote command:

`[ :SOURce<hw> ] : ILS [ :GS | GSLope ] : ICAO : CHANnel` on page 663

Sync with Glide Slope/ Sync with Localizer

Activates synchronization of the ILS glide slope with the ILS localizer carrier frequency or vice versa.

If "Carrier Frequency Mode" > "User", the ILS glide slope carrier frequency is applied to the ILS localizer carrier frequency or vice versa.

If "Carrier Frequency Mode" > "ICAO", the ILS glide slope ICAO channel is applied to the ILS localizer ICAO channel or vice versa. The ILS glide slope/localizer frequency of the ICAO channel ([Table 6-2](#)) is set automatically.

Remote command:

`<subsystem> : FREQuency : SYNChronize : STATe` on page 654

EXT AM

Activates additional modulation from an external source. The input of the external signal is at the connector Ext.

"Off" Selects the internal modulation source for the avionic standard modulation.

"EXT (MOD AM)"

Selects the external source. The external signal is added to the internal signal. Switching off the internal source is not possible. The external signal is input via the Ext connector. The sensitivity is 10 mV per percent modulation depth.

Note: There can be an overmodulation as a function of the level of the external signal without a corresponding caution message being generated. To avoid an overmodulation, the peak value of the external signal is to be delimited corresponding to the sum of the modulation depths of the remaining VOR signal components.

Remote command:

`[ :SOURce<hw> ] : ILS [ :GS | GSLope ] : SOURce` on page 665

Signal settings

Access:

1. Select "ILS Component" > "Glide Slope". See [Section 6.4.2.2, "ILS glide slope settings"](#), on page 141.
2. Select "ILS" > "Signal".

VOR

ILS
Glide Slope

ADF

X

Operating Mode	DDM Polarity	General
Norm	90 Hz - 150 Hz	
Up Frequency	Down Frequency	Signal
90.00 Hz	150.00 Hz	
Up/Down Phase		Amplitude
0.00 deg		

This dialog provides modulation signal settings related to the ILS glide slope component of the ILS signal.

Settings:

Operating Mode	144
DDM Polarity	145
Up Frequency	145
Down Frequency	145
Up/Down Phase	145

Operating Mode

Selects the operating mode for the ILS glide slope modulation signal.

- | | |
|---------|---|
| "Norm" | ILS glide slope modulation is active. |
| "90 Hz" | <p>Amplitude modulation of the output signal with the upper lobe signal component (90 Hz signal content) of the ILS glide slope signal.</p> <p>The modulation depth of the 90 Hz signal results from the settings of the parameters Sum of Depth and DDM Depth according to:</p> <ul style="list-style-type: none"> • "Fly > Down"
 $AM(90\text{ Hz}) = 0.5 \times (SDM + DDM \times 100\%)$ • "Fly > Up"
 $AM(90\text{ Hz}) = 0.5 \times (SDM - DDM \times 100\%)$ |

"150 Hz"

Amplitude modulation of the output signal with the lower lobe signal component (150 Hz signal content) of the ILS glide slope signal.

The modulation depth of the 150 Hz signal results from the settings of parameters [Sum of Depth](#) and [DDM Depth](#) according to:

- "Fly > Down"

$$\text{AM (150 Hz)} = 0.5 \times (\text{SDM} + \text{DDM} \times 100 \%)$$
- "Fly > Up"

$$\text{AM (150 Hz)} = 0.5 \times (\text{SDM} - \text{DDM} \times 100 \%)$$

Remote command:

[\[:SOURce<hw>\]:ILS\[:GS|GSLope\]:MODE](#) on page 664

DDM Polarity

Defines the polarity for DDM calculation, see ["DDM Depth"](#) on page 147.

Remote command:

[\[:SOURce<hw>\]:ILS\[:GS|GSLope\]:DDM:POLarity](#) on page 661

Up Frequency

Sets the modulation frequency of the upper antenna lobe.

Remote command:

[\[:SOURce<hw>\]:ILS\[:GS|GSLope\]:ULObE\[:FREQuency\]](#) on page 666

Down Frequency

Sets the modulation frequency of the lower antenna lobe.

Remote command:

[\[:SOURce<hw>\]:ILS\[:GS|GSLope\]:LLObE\[:FREQuency\]](#) on page 664

Up/Down Phase

Sets the phase between the modulation signals of the upper and lower antenna lobe.

The zero crossing of the lower lobe (150Hz) signal serves as a reference. The angle refers to the period of the signal of the lower antenna lobe.

Remote command:

[\[:SOURce<hw>\]:ILS\[:GS|GSLope\]:PHASe](#) on page 664

Amplitude settings

Access:

1. Select "ILS Component" > "Glide Slope". See [Section 6.4.2.2, "ILS glide slope settings"](#), on page 141.

2. Select "ILS" > "Amplitude".

VOR

ILS
Glide Slope

ADF

Fly Mode		General
Up		
Sum of Depth	DDM - SDM Coupling	Signal
80.0 %	Fixed DDM	
DDM Step		Amplitude
Decimal		
DDM Current	DDM Depth	
0.0 µA	0.000 0	
DDM Logarithmic	DDM Percent	
0.000 0 dB	0.00 %	

This dialog provides amplitude settings related to the ILS glide slope component of the ILS signal.

Settings:

Sum of Depth.....	146
Fly Mode.....	146
DDM Step.....	147
DDM Current.....	147
DDM Depth.....	147
DDM Logarithmic.....	147
DDM Percent.....	147
DDM - SDM Coupling.....	148

Sum of Depth

Sets the arithmetic sum of the modulation depths of the upper lobe (90 Hz) and lower lobe (150 Hz) ILS glide slope signal contents.

The RMS modulation depth of the sum signal depends on the phase setting of both modulation tones.

Remote command:

[:SOURce<hw>] : ILS [:GS | GSLope] :SDM on page 665

Fly Mode

Selects the simulation mode for the ILS glide slope modulation signal. A change of the setting automatically changes the sign of the DDM value.

This setting simulates the direction in which the pilot has to correct the course.

"Up" The 150 Hz modulation signal is predominant, the DDM value is negative (the airplane is too low, it must climb).

"Down" The 90 Hz modulation signal is predominant, the DDM value is positive (the airplane is too high, it must descend).

Remote command:

`[ :SOURce<hw> ] : ILS [ :GS | GSLope ] : DDM : DIRection` on page 660

DDM Step

Selects the variation of the DDM values.

"Decimal" Decimal variation according to the current cursor position.

"Predifined" Variation in predefined steps according to the standardized DDM values.

Remote command:

`[ :SOURce<hw> ] : ILS [ :GS | GSLope ] : DDM : STEP` on page 661

DDM Current

Sets the current of the ILS indicating the instrument corresponding to the DDM value. The instrument current is calculated according to:

$$\text{DDM Current } \mu\text{A} = \text{DDM Depth } [\%] \times 857,125 \mu\text{A}$$

A variation of the instrument current automatically leads to a variation of the DDM value and the DDM value in dB.

Remote command:

`[ :SOURce<hw> ] : ILS [ :GS | GSLope ] : DDM : CURRent` on page 660

DDM Depth

Sets the difference in depth of modulation between the upper lobe (90 Hz) and the lower lobe (150 Hz) tone of the ILS glide slope modulation signal.

The DDM value is calculated with the formula:

- "DDM Polarity" > "90 Hz - 150 Hz":
DDM = [AM (90 Hz) - AM (150 Hz)] / 100%
- "DDM Polarity" > "150 Hz - 90 Hz":
DDM = [AM (150 Hz) - AM (90 Hz)] / 100%

A variation of the DDM value automatically leads to a variation of the value of the instrument current and the DDM value in dB.

Remote command:

`[ :SOURce<hw> ] : ILS [ :GS | GSLope ] : DDM [ : DEPT h ]` on page 662

DDM Logarithmic

Sets the DDM value in dB. The dB value is calculated according to:

$$\text{DDM dB} = 20 \times \text{LOG} [(SDM + DDM \times 100\%) / (SDM - DDM \times 100\%)]$$

A variation of the value automatically leads to a variation of the DDM value and the instrument current.

Remote command:

`[ :SOURce<hw> ] : ILS [ :GS | GSLope ] : DDM : LOGarithmic` on page 660

DDM Percent

Sets the difference in depth of modulation between the upper lobe (90 Hz) and the lower lobe (150 Hz) tone of the ILS glide slope modulation signal.

The DDM value in percent is calculated as follows:

- "DDM Polarity" > "90 Hz - 150 Hz":
DDM = [AM (90 Hz) - AM (150 Hz)]
- "DDM Polarity" > "150 Hz - 90 Hz":
DDM = [AM (150 Hz) - AM (90 Hz)]

A variation of the DDM value automatically leads to a variation of the value of the instrument current and the DDM value in dB.

Remote command:

[:SOURce<hw>] : ILS [:GS | GSLope] : DDM : PCT on page 661

DDM - SDM Coupling

Selects if the DDM value is fixed or is changed with a change of sum of modulation depths (SDM, see below).

"Fixed DDM" The absolute DDM value stays constant, if the SDM is changed.

"Coupled to SDM"

The absolute DDM value changes, if the SDM is changed. The DDM value expressed in dB stays constant.

Remote command:

[:SOURce<hw>] : ILS [:GS | GSLope] : DDM : COUPling on page 659

6.4.2.3 ILS localizer settings

Access:

1. Select "ILS" > "General".
2. Select "ILS Component" > "Localizer".


Settings:

- [General settings](#)..... 149
- [Signal settings](#)..... 151
- [Amplitude settings](#)..... 152
- [COM/ID settings](#)..... 155

General settings

Access:

- Select "ILS > General".



This dialog provides carrier frequency settings of the ILS localizer component of the ILS signal.

Settings:

Carrier Frequency Mode.....	149
Carrier Frequency.....	149
ICAO Channel.....	150
Sync with Glide Slope/ Sync with Localizer.....	150
EXT AM.....	150

Carrier Frequency Mode

Sets the mode for the carrier frequency of the signal.

"User Defined" Activates user-defined variation of the carrier frequency.

"ICAO" Activates variation in predefined steps according to standard ILS transmitting frequencies (see [Table 6-2](#)).
Select the [ICAO Channel](#) to set a standard ILS frequency channel. If you want to couple carrier frequencies of ILS glide slope and localizer components, enable [General settings](#).

Remote command:

`[ :SOURce<hw> ] :ILS:LOCalizer:FREquency:MODE` on page 672

Carrier Frequency

Requires "Carrier Frequency Mode" > "User Defined".

Sets the carrier frequency of the signal.

Remote command:

`[ :SOURce<hw> ] :ILS:LOCalizer:FREQuency` on page 672

ICAO Channel

Requires "Carrier Frequency Mode > ICAO".

Sets the ICAO channel and the corresponding transmitting frequency.

If avionic standard modulation is activated and you change the "RF Frequency", the frequency value of the closest ICAO channel is applied automatically. The "ICAO Channel" is also updated.

For an overview of the ILS ICAO channel frequencies, see [Table 6-2](#).

Remote command:

`[ :SOURce<hw> ] :ILS:LOCalizer:ICAO:CHANnel` on page 673

Sync with Glide Slope/ Sync with Localizer

Activates synchronization of the ILS glide slope with the ILS localizer carrier frequency or vice versa.

If "Carrier Frequency Mode" > "User", the ILS glide slope carrier frequency is applied to the ILS localizer carrier frequency or vice versa.

If "Carrier Frequency Mode" > "ICAO", the ILS glide slope ICAO channel is applied to the ILS localizer ICAO channel or vice versa. The ILS glide slope/localizer frequency of the ICAO channel ([Table 6-2](#)) is set automatically.

Remote command:

`<subsystem>:FREQuency:SYNChronize:STATe` on page 654

EXT AM

Activates additional modulation from an external source. The input of the external signal is at the connector Ext.

"Off" Selects the internal modulation source for the avionic standard modulation.

"EXT (MOD AM)"

Selects the external source. The external signal is added to the internal signal. Switching off the internal source is not possible. The external signal is input via the Ext connector. The sensitivity is 10 mV per percent modulation depth.

Note: There can be an overmodulation as a function of the level of the external signal without a corresponding caution message being generated. To avoid an overmodulation, the peak value of the external signal is to be delimited corresponding to the sum of the modulation depths of the remaining VOR signal components.

Remote command:

`[ :SOURce<hw> ] :ILS:LOCalizer:SOURce` on page 675

Signal settings

- Access:
- Select "ILS Component" > "Localizer". See [Section 6.4.2.3, "ILS localizer settings"](#), on page 148.
 - Select "ILS" > "Signal".

VOR

ILS
Localizer

ADF

X

Operating Mode	DDM Polarity	General
Norm	90 Hz - 150 Hz	
Left Frequency	Right Frequency	
90.00 Hz	150.00 Hz	Signal
Left/Right Phase		Amplit.
0.00 deg		COM/ID

This dialog provides audio signal and modulation settings related to the ILS localizer component of the ILS signal.

Settings:

Operating Mode	151
DDM polarity	152
Left Frequency	152
Right Frequency	152
Left/Right Phase	152

Operating Mode

Selects the operating mode for the ILS localizer modulation signal.

- "Norm" ILS localizer modulation is active.
- "90 Hz"

Amplitude modulation of the output signal with the left lobe (90 Hz) signal component of the ILS localizer signal.

The modulation depth of the 90 Hz signal results from the settings of parameters [Sum of Depth](#) and [DDM Depth](#) according to:

 - "Fly > Right"

$$\text{AM (90 Hz)} = 0.5 \times (\text{SDM} + \text{DDM} \times 100 \%)$$
 - "Fly > Left"

$$\text{AM (90 Hz)} = 0.5 \times (\text{SDM} - \text{DDM} \times 100 \%)$$

"150 Hz"

Amplitude modulation of the output signal with the right lobe (150 Hz) signal component of the ILS localizer signal.

The modulation depth of the 150 Hz signal results from the settings of parameters [Sum of Depth](#) and [DDM Depth](#) according to:

- "Fly" = "Right"

$$\text{AM (150 Hz)} = 0.5 \times (\text{SDM} + \text{DDM} \times 100 \%)$$
- "Fly" = "Left"

$$\text{AM (150 Hz)} = 0.5 \times (\text{SDM} - \text{DDM} \times 100 \%)$$

Remote command:

[\[:SOURce<hw>\]:ILS:LOCalizer:MODE](#) on page 674

DDM polarity

Defines the polarity for DDM calculation, see ["DDM Depth"](#) on page 154.

Remote command:

[\[:SOURce<hw>\]:ILS:LOCalizer:DDM:POLarity](#) on page 671

Left Frequency

Sets the modulation frequency of the antenna lobe arranged at the left viewed from the air plane.

Remote command:

[\[:SOURce<hw>\]:ILS:LOCalizer:LLOBe\[:FREQuency\]](#) on page 673

Right Frequency

Sets the modulation frequency of the antenna lobe arranged at the right viewed from the air plane.

Remote command:

[\[:SOURce<hw>\]:ILS:LOCalizer:RLOBe\[:FREQuency\]](#) on page 675

Left/Right Phase

Sets the phase between the modulation signals of the left and right antenna lobe. The zero crossing of the right lobe (150 Hz) signal serves as a reference. The angle refers to the period of the signal of the right antenna lobe.

Remote command:

[\[:SOURce<hw>\]:ILS:LOCalizer:PHASe](#) on page 674

Amplitude settings

Access:

1. Select "ILS Component" > "Localizer". See [Section 6.4.2.3, "ILS localizer settings"](#), on page 148.

2. Select "ILS" > "Amplitude".

VOR		ILS Localizer		ADF		X	
Fly Mode						General	
Left							
Sum of Depth				DDM - SDM Coupling			
40.0 %				Fixed DDM			
DDM Step				Signal			
Decimal				Amplit.			
DDM Current				COM/ID			
0.0 µA				DDM Depth			
				0.000 0			
DDM Logarithmic				DDM Percent			
0.000 0 dB				0.00 %			

This dialog provides amplitude settings related to the ILS localizer component of the ILS signal.

Settings:

Fly Mode.....	153
Sum of Depth.....	153
DDM - SDM Coupling.....	154
DDM Step.....	154
DDM Current.....	154
DDM Depth.....	154
DDM Logarithmic.....	155
DDM Percent.....	155

Fly Mode

Selects the simulation mode for the ILS localizer modulation signal. A change of the setting automatically changes the sign of the DDM value.

This setting simulates the direction in which the pilot has to correct the course.

"Left"	The 150 Hz modulation signal is predominant, the DDM value is negative (the airplane is too far to the right, it must turn to the left).
"Right"	The 90 Hz modulation signal is predominant, the DDM value is positive (the airplane is too far to the left, it must turn to the right).

Remote command:

`[ :SOURce<hw> ] :ILS:LOCalizer:DDM:DIRection` on page 670

Sum of Depth

Sets the arithmetic sum of the modulation depths of the left lobe (90 Hz) and right lobe (150 Hz) ILS localizer signal contents.

The RMS modulation depth of the sum signal depends on the phase setting of both modulation tones.

The "Sum of Depth" and "COM/ID > Depth" must be smaller than 100 %.

Remote command:

`[ :SOURce<hw> ] :ILS:LOCalizer:SDM` on page 675

DDM - SDM Coupling

Selects if the DDM value is fixed or is changed with a change of sum of modulation depths (SDM, see below).

"Fixed DDM" The absolute DDM value stays constant, if the SDM is changed.

"Coupled to SDM" The absolute DDM value changes, if the SDM is changed. The DDM value expressed in dB stays constant.

Remote command:

`[ :SOURce<hw> ] :ILS:LOCalizer:DDM:COUPling` on page 669

DDM Step

Selects the variation step of the DDM values.

"Decimal" Decimal variation according to the current cursor position.

"Predifined" Variation in predefined steps according to the standardized DDM values.

Remote command:

`[ :SOURce<hw> ] :ILS:LOCalizer:DDM:STEP` on page 671

DDM Current

Sets the current of the ILS indicating instrument corresponding to the DDM value. The instrument current is calculated according to:

$$\text{DDM } \mu\text{A} = \text{DDM} \times 967.75 \mu\text{A}$$

A variation of the instrument current automatically leads to a variation of the DDM value and the DDM value in dB.

Remote command:

`[ :SOURce<hw> ] :ILS:LOCalizer:DDM:CURRent` on page 669

DDM Depth

Sets the difference in depth of modulation (DDM) between the signal of the left lobe (90 Hz) and the right lobe (150 Hz) of the ILS localizer modulation signal.

The DDM value in percent is calculated as follows:

- "DDM Polarity > 90 Hz - 150 Hz" (default setting):

$$\text{DDM} = [\text{AM} (90 \text{ Hz}) - \text{AM} (150 \text{ Hz})] / 100 \%$$
- "DDM Polarity > 150 Hz - 90 Hz":

$$\text{DDM} = [\text{AM} (150 \text{ Hz}) - \text{AM} (90 \text{ Hz})] / 100 \%$$

A variation of the DDM value automatically leads to a variation of the DDM value in dB and the value of the instrument current.

Remote command:

`[ :SOURce<hw> ] :ILS:LOCalizer:DDM[:DEPTh]` on page 671

DDM Logarithmic

Sets the DDM value in dB. The dB value is calculated according to:

$$\text{DDM dB} = 20 \times \text{LOG} [(\text{SDM} + \text{DDM} \times 100 \%) / (\text{SDM} - \text{DDM} \times 100 \%)]$$

A variation of the value automatically leads to a variation of the DDM value and the instrument current.

Remote command:

`[ :SOURce<hw> ] :ILS:LOCalizer:DDM:LOGarithmic` on page 670

DDM Percent

Sets the difference in depth of modulation between the signal of the left lobe (90 Hz) and the right lobe (150 Hz).

The DDM value in percent is calculated by the following formulas:

- "DDM Polarity > 90 Hz - 150 Hz" (default setting):

$$\text{DDM} = [\text{AM} (90 \text{ Hz}) - \text{AM} (150 \text{ Hz})]$$

- "DDM Polarity > 150 Hz - 90 Hz":

$$\text{DDM} = [\text{AM}(150 \text{ Hz}) - \text{AM} (90 \text{ Hz})]$$

A variation of the DDM value automatically leads to a variation of the DDM value in dB and the value of the instrument current.

Remote command:

`[ :SOURce<hw> ] :ILS:LOCalizer:DDM:PCT` on page 670

COM/ID settings

Access:

1. Select "ILS Component" > "Localizer". See [Section 6.4.2.3, "ILS localizer settings"](#), on page 148.
2. Select "ILS" > "COM/ID".

VOR		ILS Localizer		ADF		X	
COM/ID State		☐				General	
Code		MUC		Period		9.000 s	
Frequency		1.020 00 kHz		Depth		10.0 %	
Time Schema		Standard				COM/ID	
Dot Length		100.0 ms					

This dialog provides COM/ID settings related to the ILS localizer component of the ILS signal.

Settings:

COM/ID State.....	156
Code.....	156
Frequency.....	156
Period.....	156
Depth.....	156
Time Schema.....	157
Dot Length.....	157
Dash Length.....	157
Symbol Space.....	157
Letter Space.....	157

COM/ID State

Enables/disables the COM/ID signal.

See also [Section D, "Morse code settings"](#), on page 860.

Remote command:

`[ :SOURce<hw> ] :ILS:LOCalizer:COMid[ :STATe ]` on page 669

Code

Sets the coding of the COM/ID signal by the international short name of the airport (e.g. MUC for the Munich airport).

The COM/ID tone is sent according to the selected code, see [Section D, "Morse code settings"](#), on page 860.

If no coding is set, the COM/ID tone is sent uncoded (key down).

Remote command:

`[ :SOURce<hw> ] :ILS:LOCalizer:COMid:CODE` on page 666

Frequency

Sets the frequency of the COM/ID signal.

Remote command:

`[ :SOURce<hw> ] :ILS:LOCalizer:COMid:FREQuency` on page 667

Period

Sets the period of the COM/ID signal.

Remote command:

`[ :SOURce<hw> ] :ILS:LOCalizer:COMid:PERiod` on page 668

Depth

Sets the AM modulation depth of the COM/ID signal.

Note: The sum of [Sum of Depth](#) and $\text{COM/ID} > \text{Depth}$ must be smaller than 100 %.

Remote command:

`[ :SOURce<hw> ] :ILS:LOCalizer:COMid:DEPTh` on page 667

Time Schema

Sets the time schema of the Morse code for the COM/ID signal.

"Standard" The set dot length determines the length of the dash, the symbol space and letter space of the Morse code.

"User" You can set each length value separately.

Remote command:

[\[:SOURce<hw>\]:ILS:LOCalizer:COMid:TSCHEMA](#) on page 668

Dot Length

Sets the length of a Morse code dot.

If "Time Schema" > "Standard", the dot length value determines also the length of the dash (= 3 times the dot length), symbol space (= dot length) and letter space (= 3 times the dot length).

Remote command:

[\[:SOURce<hw>\]:ILS:LOCalizer:COMid:DOT](#) on page 667

Dash Length

Requires "Time Schema" > "User".

Sets the length of a Morse code dash.

Remote command:

[\[:SOURce<hw>\]:ILS:LOCalizer:COMid:DASH](#) on page 666

Symbol Space

Requires "Time Schema" > "User".

Sets the length of the Morse code symbol space.

Remote command:

[\[:SOURce<hw>\]:ILS:LOCalizer:COMid:SYMBOL](#) on page 668

Letter Space

Requires "Time Schema" > "User".

Sets the length of a Morse code letter space.

Remote command:

[\[:SOURce<hw>\]:ILS:LOCalizer:COMid:LETTER](#) on page 667

6.4.2.4 ILS marker beacons settings

Access:

1. Select "ILS > General".
2. Select "ILS Component > Marker Beacons".


Settings:

• General settings	158
• Signal settings	159
• COM/ID settings	160

General settings

Access:

1. Select "ILS Component > Marker Beacons".
See [Section 6.4.2.4, "ILS marker beacons settings"](#), on page 157.
2. Select "ILS > General".



This dialog provides carrier frequency and signal settings related to the ILS marker beacons component of the ILS signal.

Settings:

Carrier Frequency Mode	158
Carrier Frequency	158

Carrier Frequency Mode

Sets the mode for the carrier frequency of the signal.

- "User Defined" Activates user-defined variation of the carrier frequency.
- "Predefined" Activates variation of the carrier frequency by integer 25 kHz steps.

Remote command:

[\[:SOURce<hw>\] \[:ILS\] :MBEacon:FREquency:MODE](#) on page 679

Carrier Frequency

Requires "Carrier Frequency Mode > User Defined".

Sets the carrier frequency of the signal.


Remote command:

[\[:SOURce<hw>\] \[:ILS\] :MBEacon:FREquency](#) on page 679

Signal settings

Access:

- 1. Select "ILS Component" > "Marker Beacons". See [Section 6.4.2.4, "ILS marker beacons settings"](#), on page 157.
- 2. Select "ILS" > "Signal".



This dialog provides signal settings related to the ILS marker beacons component of the ILS signal.

Settings:

Marker Frequency	159
Marker Depth	159
Pulsed Marker	159

Marker Frequency

Sets the modulation frequency of the marker signal.

Remote command:

`[ :SOURce<hw> ] [ :ILS ] :MBEacon:MARKer:FREQuency` on page 679

Marker Depth

Sets the modulation depth of the marker signal.

Remote command:

`[ :SOURce<hw> ] [ :ILS ] :MBEacon [ :MARKer ] :DEPTh` on page 680

Pulsed Marker

Activates the modulation of a pulsed marker signal (morse coding).

"On"

Modulation of pulsed marker signals (morse coding). The duty cycle, the marker on- and off-times depend on the frequency of the marker signal ([Table 6-3](#)).

Table 6-3: ILS marker beacons marker signals and morse coding

Signal	Freq.	On	Off	Morse rate	Duty cycle
Outer marker	400 Hz	375 ms	125 ms	2 dots/s	75 %
Middle marker	1300 Hz	1 st : 375 ms 2 nd : 83 ms	1 st : 125 ms 2 nd : 83 ms	1.5 dots/s	68.8 %
Inner marker	3000 Hz	83 ms	83 ms	6 dots/s	50 %

"Off"

Modulation of a continuous non-coded marker signal.

Remote command:

[:SOURce<hw>] [:ILS] :MBEacon [:MARKer] :PULSed on page 680

COM/ID settings

Access:

1. Select "ILS Component" > "Marker Beacons". See [Section 6.4.2.4, "ILS marker beacons settings"](#), on page 157.
2. Select "ILS" > "COM/ID".

The screenshot shows a software interface for configuring ILS Marker Beacons. At the top, there are three tabs: 'VOR', 'ILS' (which is active and labeled 'Marker Beacons'), and 'ADF'. Below the tabs, there's a 'COM/ID State' checkbox which is checked. To the right of this is a 'General' tab. Below the 'COM/ID State' checkbox, there are several input fields: 'Code' (set to 'MUC'), 'Period' (set to '9.000 s'), 'Frequency' (set to '1.020 00 kHz'), 'Depth' (set to '5.0 %'), 'Time Schema' (set to 'Standard'), and 'Dot Length' (set to '100.0 ms'). On the right side of the dialog, there are three tabs: 'General', 'Signal', and 'COM/ID' (which is selected and highlighted with an orange triangle). The 'COM/ID' tab is currently active.

This dialog provides COM/ID settings of the marker beacons component of the ILS signal.

Settings:

COM/ID State.....	161
Code.....	161
Period.....	161
Frequency.....	161
Depth.....	161
Time Schema.....	161
Dot Length.....	162
Dash Length.....	162
Symbol Space.....	162
Letter Space.....	162

COM/ID State

Enables/disables the COM/ID signal.

See also [Section D, "Morse code settings"](#), on page 860.

Remote command:

`[ :SOURce<hw> ] [ :ILS ] :MBEacon:COMid[:STATe]` on page 678

Code

Sets the coding of the COM/ID signal by the international short name of the airport (e.g. MUC for the Munich airport).

The COM/ID tone is sent according to the selected code, see [Section D, "Morse code settings"](#), on page 860.

If no coding is set, the COM/ID tone is sent uncoded (key down).

Remote command:

`[ :SOURce<hw> ] [ :ILS ] :MBEacon:COMid:CODE` on page 676

Period

Sets the period of the COM/ID signal.

Remote command:

`[ :SOURce<hw> ] [ :ILS ] :MBEacon:COMid:PERiod` on page 677

Frequency

Sets the frequency of the COM/ID signal.

Remote command:

`[ :SOURce<hw> ] [ :ILS ] :MBEacon:COMid:FREQuency` on page 677

Depth

Sets the AM modulation depth of the COM/ID signal.

Remote command:

`[ :SOURce<hw> ] [ :ILS ] :MBEacon:COMid:DEPT h` on page 676

Time Schema

Sets the time schema of the Morse code for the COM/ID signal.

"Standard" The set dot length determines the length of the dash, the symbol space and letter space of the Morse code.

"User" You can set each length value separately.

Remote command:

[\[:SOURce<hw>\]\[:ILS\]:MBEacon:COMid:TSCHEMA](#) on page 678

Dot Length

Sets the length of a Morse code dot.

If "Time Schema" > "Standard", the dot length value determines also the length of the dash (= 3 times the dot length), symbol space (= dot length) and letter space (= 3 times the dot length).

Remote command:

[\[:SOURce<hw>\]\[:ILS\]:MBEacon:COMid:DOT](#) on page 677

Dash Length

Requires "Time Schema" > "User".

Sets the length of a Morse code dash.

Remote command:

[\[:SOURce<hw>\]\[:ILS\]:MBEacon:COMid:DASH](#) on page 676

Symbol Space

Requires "Time Schema" > "User".

Sets the length of the Morse code symbol space.

Remote command:

[\[:SOURce<hw>\]\[:ILS\]:MBEacon:COMid:SYMBOL](#) on page 678

Letter Space

Requires "Time Schema" > "User".

Sets the length of a Morse code letter space.

Remote command:

[\[:SOURce<hw>\]\[:ILS\]:MBEacon:COMid:LETTER](#) on page 677

6.5 Generating ADF signals

This section provides information on automatic direction finder (ADF) signal generation with the R&S SMA100B. This information includes required options, background information on ADF, generation of ADF signals, configuration and settings.

- [About ADF](#) 162
- [ADF configuration and settings](#) 163

6.5.1 About ADF

Automatic direction finder (ADF) receivers provide the relative bearing of a basic ground-based non-directional beacon (NDB) to the fore axis or aft axis of the aircraft. The beacon signal is generated by a directional antenna assembly in the aircraft.

The ADF determines the direction to the NDB station relative to the aircraft and is used for instrument approaches (autopilot). It provides additional information to other navigation equipment, e.g. VOR.

Related Settings

For ADF settings at the R&S SMA100B, see [Section 6.5.2, "ADF configuration and settings"](#), on page 163.

6.5.2 ADF configuration and settings

Option: R&S SMAB-K25

Access:

- ▶ Select "Modulation" > "Avionic Standards" > "ADF".

The remote commands required to define ADF settings are described in [Section 15.18.2.3, "SOURCE:ADF subsystem"](#), on page 654.


Settings

- [General settings](#)..... 163
- [COM/ID settings](#)..... 165

6.5.2.1 General settings

Access:

- ▶ Select "ADF" > "General".



This dialog provides general settings of the ADF standard, the default and the "Save/Recall" settings.

By default, an ADF signal modulation is set on an RF carrier with a frequency of 190 kHz. The COM/ID signal has 1.02 kHz frequency.

If enabled, the avionic standard modulation is displayed in the "Modulation" tile as follows:

- "Avionic: VOR" for enabled VOR modulation

- "Avionic ILS: Glide Slope/Localizer/Marker Bcn" for enabled ILS glide slope/localizer/marker beacons modulation
- "Avionic: ADF" for enabled ADF modulation

ADF state and carrier frequency range

If the R&S SMA100B carrier frequency is outside the specified ADF frequency range from 190 kHz to 1750 kHz, a settings conflict is displayed. Activating ADF is not possible.

Change the carrier frequency to a value within the specified frequency range.

Settings

State.....	164
Set To Default.....	164
Save/Recall.....	164

State

Activates the avionic standard.

Activation of the standard deactivates a previously active avionic standard. The "VOR/ILS > Carrier Frequency" setting is applied automatically to the RF [Frequency](#) and displayed in the status bar.

Remote command:

[<subsystem>:STAt](#) on page 653

Set To Default

Calls the default settings. The table below lists the default values of the main parameters.

Standard	Parameter	Value
VOR/ILS/ADF	State	Not affected by "Set to default"
VOR	Carrier Frequency Mode	User Defined
	Carrier Frequency	108.000000 MHz
ILS	ILS Component	Glide Slope (GS)
	ILS GS > Carrier Frequency Mode	User Defined
	ILS GS > Carrier Frequency	334.700000 MHz
ADF	Carrier Frequency	190.000 kHz

Remote command:

[<subsystem>:PRESet](#) on page 652

Save/Recall

Opens the "Save/Recall" dialog that is the standard instrument function for saving and recalling the complete dialog-related settings in a file. The provided navigation possibilities in the dialog are self-explanatory.


The settings are saved in a file with a predefined extension. You can define the file-name and the directory, in that you want to save the file.

Remote command:

```
<subsystem>:SETting:CATalog on page 652
<subsystem>:SETting:DELeTe on page 652
<subsystem>:SETting:LOAD on page 653
<subsystem>:SETting:STORe on page 653
```

6.5.2.2 COM/ID settings

- Access:
- Select "ADF" > "COM/ID".



This dialog provides COM/ID signal settings related to the ADF signal.

Settings

COM/ID State.....	166
Code.....	166
Period.....	166
Frequency.....	166
Depth.....	166
Time Schema.....	166
Dot Length.....	166
Dash Length.....	167
Symbol Space.....	167
Letter Space.....	167

COM/ID State

Enables/disables the COM/ID signal.

Remote command:

`[ :SOURCE<hw> ] :ADF:COMid[:STATe]` on page 657

Code

Sets the coding of the COM/ID signal by the international short name of the airport (e.g. MUC for the Munich airport).

The COM/ID tone is sent according to the selected code, see [Section D, "Morse code settings"](#), on page 860.

If no coding is set, the COM/ID tone is sent uncoded (key down).

Remote command:

`[ :SOURCE<hw> ] :ADF:COMid:CODE` on page 655

Period

Sets the period of the COM/ID signal.

Remote command:

`[ :SOURCE<hw> ] :ADF:COMid:PERiod` on page 656

Frequency

Sets the frequency of the COM/ID signal.

Remote command:

`[ :SOURCE<hw> ] :ADF:COMid:FREQuency` on page 656

Depth

Sets the AM modulation depth of the COM/ID signal.

Remote command:

`[ :SOURCE<hw> ] :ADF:COMid:DEPTH` on page 655

Time Schema

Sets the time schema of the Morse code for the COM/ID signal.

"Standard" The set dot length determines the length of the dash, the symbol space and letter space of the Morse code.

"User" You can set each length value separately.

Remote command:

`[ :SOURCE<hw> ] :ADF:COMid:TSCHEMA` on page 657

Dot Length

Sets the length of a Morse code dot.

If "Time Schema" > "Standard", the dot length value determines also the length of the dash (= 3 times the dot length), symbol space (= dot length) and letter space (= 3 times the dot length).

Remote command:

`[ :SOURCE<hw> ] :ADF:COMid:DOT` on page 655

Dash Length

Requires "Time Schema" > "User".

Sets the length of a Morse code dash.

Remote command:

[\[:SOURce<hw>\]:ADF:COMid:DASH](#) on page 655

Symbol Space

Requires "Time Schema" > "User".

Sets the length of the Morse code symbol space.

Remote command:

[\[:SOURce<hw>\]:ADF:COMid:SYMBOL](#) on page 657

Letter Space

Requires "Time Schema" > "User".

Sets the length of a Morse code letter space.

Remote command:

[\[:SOURce<hw>\]:ADF:COMid:LETTER](#) on page 656

7 Multiplying RF output frequencies

7.1 About frequency multipliers

The R&S SZM multiplies the input frequency by its multiplication factor. Depending on the R&S SZM base unit, you can optionally install high output power, an attenuator or an isolator. All three options are integrated in the same housing as the frequency multiplier, which simplifies setups and the operation compared to conventional setups.

In addition, you can connect an optional external test port adapter (TPA) which is a straight waveguide and simplifies connection of the DUT. The TPA protects internal assemblies and their flange and if damaged, you can replace it.

The R&S SMA100B signal generator can communicate with an R&S SZM via USB. For the USB communication between the R&S SMA100B and the frequency multiplier R&S SZM, the R&S SMAB-K554 key must be installed on the R&S SMA100B. In case a mechanically or electronically controlled attenuator is installed, the pre-calibrated frequency response values of the multiplier are read out via USB by the R&S SMA100B. Also the multiplication factor is automatically set in the R&S SMA100B and the correct incident power of +7 dBm to the R&S SZM. Therefore, the instruments are able to provide a precise R&S SZM output signal for the DUT for a specific frequency.

Required options

- For operation of the R&S SZM with the R&S SMA100B via USB the R&S SMAB-K554 option Multiplier Control must be installed on the R&S SMA100B.
- Depending on the frequency multiplier used and its multiplication factor, different input frequency ranges are required. The R&S SMA100B must at least cover this input frequency range.
For details on the R&S SZM input frequency ranges, see the R&S SZM specifications document.

Control of the R&S SZM via USB

If the control connection between R&S SMA100B and R&S SZM is established, the following features are available:

- The right multiplication factor and incident power on the R&S SMA100B is automatically set in accordance to the connected R&S SZM.
- The connected R&S SZM is shown in the R&S SMA100B taskbar. If the mechanically controlled attenuator option is installed on the R&S SZM, the value of the micrometer screw for the correct R&S SZM output power is shown in the taskbar.
- Read out of the frequency response of the connected R&S SZM without internal attenuator option.
- Read out the calibration data of the R&S SZM if an internal attenuator option is installed
- You can correct cable losses of the connecting cable between the frequency multiplier and the R&S SMA100B.

Impact of operating modes and functions

The output level of the RF signal is determined by the operation mode that the instrument generates the signal and also by the level correction functions the generator provides to optimize the accuracy of the level.

Some of these functions affect the operation with an R&S SZM. To avoid impact, the generator automatically switches off the associated operating modes once an R&S SZM is connected via USB.

Interactions and special characteristics to the operating modes of the R&S SMA100B when an R&S SZM is connected:

- AM (amplitude modulation): blocked
- Avionic standards: blocked
- List mode: blocked
- Sweep mode: It is recommended that you use an R&S SZM with electronically controlled attenuator to generate an RF signal in frequency or level sweep mode. Also note the response times of the dwell time in the specifications document of the R&S SZM.

7.2 Operating frequency multipliers

This section provides an overview on step-by-step instructions related to connecting and configuring frequency multipliers.

It includes the following:

- [Test setup](#)..... 169
- [Connecting a frequency multiplier](#)..... 170
- [Controlling the frequency multiplier](#)..... 171
- [Generating RF output signals](#)..... 175

7.2.1 Test setup

The R&S SMA100B supports the following frequency multiplier types:

- R&S SZM

For details, see the specifications document of the R&S SMA100B.

OTA microwave test setup

Typically, mmWave signals are transmitted and received over-the-air (OTA) inside an RF shield box. The figure below illustrates a test setup with a frequency multiplier connected to a signal generator and an antenna that is mounted inside an RF shield box.

The signal generator provides the IF signal to the frequency multiplier. The frequency multiplier multiplies the IF signal from the signal generator and transmits the RF signal to the DUT.




Figure 7-1: Typical setup using a frequency multiplier

Frequency multiplier connection

You can control a frequency multiplier via USB by one R&S SMA100B that exclusively controls the frequency multiplier.

The R&S SMA100B

- Reads out the frequency multiplication factor of the R&S SZM
- Reads out the serial number of the R&S SZM
- Sets the R&S SZM incident power on the R&S SMA100B RF output

7.2.2 Connecting a frequency multiplier

This section provides step-by-step descriptions for connecting a frequency multiplier. Connecting procedures for relevant connector types are described for the R&S SZM as an example.

To connect an R&S SZM

The following procedure describes how to connect the R&S SMA100B to an R&S SZM using the "RF 50 Ω " connector as IF signal output. The R&S SZM and R&S SMA100B are connected to power and switched on.

1. Use all cables delivered with the R&S SZM. Other connections can require additional cables.
For the control connection, use the high-quality USB cable provided with the delivery.
For the IF connection, we recommend using a coaxial cable with K connectors, 50 Ω , length 1.0 m. The cable is available under order number 1348.3850.00 (see recommended extras in the R&S SZM specifications document).
See ["Cable selection to minimize electromagnetic interference"](#) on page 26.
2. **NOTICE!** Risk of SMA connector damage and cable damage. Excessive tightening can damage the connecting cable, the SMA connectors and components inside the R&S SMA100B.
Connect the "RF 50 Ω " connector of the R&S SMA100B with the "RF In" connector of the R&S SZM.
See also [Section 3.1.9, "Connecting to RF coaxial connectors"](#), on page 28.
3. Connect the "USB" connector with the "USB" connector of the R&S SZM.

See also ["To connect a frequency multiplier"](#) on page 28.

[Table 7-1](#) and [Figure 7-2](#) provide an overview on connections and a test setup.

Table 7-1: Signals and connections

Signal	R&S SMA100B	R&S SZM
Control	USB connector	"USB"
RF	"RF 50Ω"	"RF In"




Figure 7-2: Test setup with R&S SMA100B, R&S SZM and RF shield box

Signal generator = R&S SMA100B

7.2.3 Controlling the frequency multiplier

This section provides step-by-step descriptions for controlling, updating and operating a frequency multiplier with the R&S SMA100B. For controlling the frequency multiplier R&S SZM via USB, the R&S SMAB-K554 key must be installed on the R&S SMA100B.

The descriptions cover the following topics:

- ["To configure the R&S SMA100B"](#) on page 171
- ["To configure for R&S SZM with no attenuator option installed"](#) on page 173
- ["To configure for R&S SZM with electronically attenuator option installed"](#) on page 174
- ["To configure for R&S SZM with mechanically attenuator option installed"](#) on page 174

To configure the R&S SMA100B

The following procedure describes how to configure the R&S SMA100B to establish a control connection between R&S SMA100B and a frequency multiplier.

The R&S SMA100B is connected to the R&S SZM, see ["To connect an R&S SZM"](#) on page 170.

1. Select "System Configuration" tile > "System Configuration".
The "External RF" dialog opens.
2. Click "External Instrument > Config".
The "Remote Instrument" dialog for configuration of the external instrument opens.
3. Select the R&S SZM from the "External Instrument" list.

Remote Instrument Show Connector X

Clean All

External Instrument SZM75-100001 Set Symbolic Name X

Remote Channel Frontend Connection Hostname or IP Address 127.0.0.1 Device ID SZM75-100001

Apply Apply and Connect Frontend Config ...

4. Select "Apply and Connect".

A message displays if the remote connection to the external frontend is successfully established.






Figure 7-3: Message displaying an established remote connection

5. Configure the connection mode between R&S SZM frequency multiplier and R&S SMA100B:
 - a) Click "Frontend Configuration".



- b) Check the "Settings".
See [Section 7.3.3.1, "General settings"](#), on page 181.
 - c) Check the "Versions/Options".
See [Section 7.3.3.2, "Versions and options information"](#), on page 182.
 - d) If necessary, activate "Cable Correction".
See [Section 7.3.3.3, "Cable correction settings"](#), on page 184.
6. In the "System Config > System Configuration > External RF" dialog, check the control connection state.



The "RF" > "Rem Conn" field displays an active control connection:

7. Optionally, specify connection characteristics:
 - a) Select "Auto Connect > On".
If you select this setting, you do not need to execute steps 1 to 6 each time you reconnect the R&S SZM to the R&S SMA100B via USB.
 - b) Select "Preset behavior: Keep connections to external instruments > On".

To configure for R&S SZM with no attenuator option installed

When using a base instrument without the attenuator option R&S SZM-BxxE or R&S SZM-BxxM installed:

1. Enter the "Frequency" value in the "Frequency" field on the home screen.
Note: The "Level" field is grayed out and shows the output power of the R&S SZM. The R&S SMA100B reads out this number from a calibration table internally stored on the R&S SZM.
2. Switch on the RF on the front panel of the R&S SMA100B.

 SZM75-100003 Info	Frequency 75.000 000 000 000 GHz		Level -30.00 dBm
	Modulation configure AM, FM, Phase, Pulse, Avionic and Chirp Modulation Mod Off	Frequency Ref Out: 10 MHz Int Ref	Level Limit: 30.00 dBm RF Off
	System Config Host: smab-123456 IP: 10.111.0.221 GPIB Address: 28 FW: 5.10.121.26	Sweep configure RF-, LF-, Level Sweep and List Mode 	Clk Syn / FE / Pow Sens configure Clock Synthesis, Frontends and Power Sensor Applications Clock Syn Off

To configure for R&S SZM with electronically attenuator option installed

When using a base instrument with the attenuator option R&S SZM-BxxE installed:

1. Enter the "Frequency" value in the "Frequency" field on the home screen.
2. Enter the "Level" value in the "Level" field on the home screen.
3. Switch on the RF on the front panel of the R&S SMA100B.

 SZM75-100001 Info	Frequency 75.000 000 000 000 GHz		Level -15.00 dBm
	Modulation configure AM, FM, Phase, Pulse, Avionic and Chirp Modulation Mod Off	Frequency Ref Out: 10 MHz Int Ref	Level Limit: 30.00 dBm RF Off
	System Config Host: smab-123456 IP: 10.111.0.221 GPIB Address: 28 FW: 5.10.121.26	Sweep configure RF-, LF-, Level Sweep and List Mode 	Clk Syn / FE / Pow Sens configure Clock Synthesis, Frontends and Power Sensor Applications Clock Syn Off

To configure for R&S SZM with mechanically attenuator option installed

When using a base instrument with the attenuator option R&S SZM-BxxM installed:

1. Enter the "Frequency" value in the "Frequency" field on the home screen.

2. Enter the "Level" value in the "Level" field on the home screen.
3. Set the micrometer screw to the value displayed in the taskbar on the left.
After setting the micrometer screw to the displayed value, the previously set level and the corresponding frequency is output at the R&S SZM.

 0 µm SZM75-100002	Frequency 75.000 000 000 000 GHz		Level -30.00 dBm
	Modulation <i>configure</i> AM, FM, Phase, Pulse, Avionic and Chirp Modulation Mod Off	Frequency Ref Out: 10 MHz Int Ref	Level Limit: 30.00 dBm RF Off
	System Config Host: smab-123456 IP: 10.111.0.221 GPIB Address: 28 FW: 5.10.121.26	Sweep <i>configure</i> RF-, LF-, Level Sweep and List Mode 	Clk Syn / FE / Pow Sens <i>configure</i> Clock Synthesis, Frontends and Power Sensor Applications Clock Syn Off
	Info		

Note: Position 0 µm is equivalent with maximum attenuation that means minimum signal level according to the set frequency.

7.2.4 Generating RF output signals

To multiply the RF output signal frequency



This manual operation is only necessary if there is no USB connection between R&S SMA100B and R&S SZM.

To multiply the input frequency by individual factor due to the frequency range:

1. Select the "Frequency" tile.
2. Select "Frequency".
3. Enter the "Multiplier" value.

To output the external frontend RF signal

The procedure assumes, that a remote control connection between R&S SMA100B and R&S SZM is established.

See ["To configure the R&S SMA100B"](#) on page 171.

- Activate the RF output.

See "To activate the RF output signal" on page 61.


7.3 External RF configuration and settings

- External RF settings..... 176
- Remote instrument settings..... 178
- RF frontend settings..... 180

7.3.1 External RF settings

Access:

- ▶ Select "System config" tile > "System Configuration" > "External RF" tab.



In the "External RF" tab you can connect the frequency multiplier with the R&S SMA100B, see "To configure the R&S SMA100B" on page 171.

Settings:

- Connect/Disconnect..... 176
- Auto Connect..... 177
- Preset behavior: Keep connections to external instruments..... 177
- Direction..... 177
- External Instrument..... 178
- Remote Connection Status..... 178
- Instrument Name..... 178

Connect/Disconnect

Triggers the instrument to:

- Establish the remote connections to all configured external instruments.

- Terminate all existing remote connections. The external instruments are not removed from the list of external instruments. Only the remote connection status changes.

Remote connection status can be toggled with the parameter [Remote Connection Status](#).

To ensure that the remote connections to the external instruments will be automatically established after the instrument's startup or a reboot, set [Auto Connect](#) > "On".

Remote command:

[:SCONfiguration:EXTernal:REMOte:CONNect\[:ALL\]](#) on page 610

[:SCONfiguration:EXTernal:REMOte:DISConnect\[:ALL\]](#) on page 610

Auto Connect

With enabled auto connect function, the instrument automatically detects connected external instruments and establishes the required connection.

If the "Auto Connect > Off", however, after a R&S SMA100B startup you have to revise the test setup and perform the following:

- Check whether the necessary connections between the R&S SMA100B and the external instruments are still existing.
- Prove that the remote control of the particular instruments is required.
- Trigger the [Connect](#) function.

Remote command:

[:SCONfiguration:EXTernal:ACONnect](#) on page 610

Preset behavior: Keep connections to external instruments

Sets the effect of R&S SMA100B preset ([Preset] or *RST) on the following:

- The connection status between the instrument and the connected external instruments.
- The R&S SMA100B itself and the preset values.
- The connected instruments.

"Preset behavior..."	Off	On
R&S SMA100B and preset values	Standard R&S SMA100B preset See Table 12-1 .	• RF = max. frequency of the connected frequency multiplier • RF > Off
Connection status	Terminated ("Disconnect All Remote")	Unchanged
Connected instruments	External instrument preset (:DEVICE:PRESet)	External instrument preset

Remote command:

[:SCONfiguration:EXTernal:PBEHaviour](#) on page 610

Direction

Displays the connector direction as a color coded field.

"Out" The RF connector is used as output.

Remote command:

[:SCONfiguration:EXTernal:RF<ch>:DIRection?](#) on page 611

External Instrument

Accesses a dialog with settings that help you to establish the connection to the external instruments, see [Section 7.3.2, "Remote instrument settings"](#), on page 178.

Remote Connection Status

Indicates the status of the remote connection. Click the status indicator to toggle the remote connection status.

To connect/disconnect all external instruments, use the functions [Connect/Disconnect](#).

Remote command:

`:SCONfiguration:EXTernal:RF<ch>:RCONnection:STATe?` on page 611

Instrument Name

Displays useful information on the connected external instrument, like the instrument designation.

Remote command:

`:SCONfiguration:EXTernal:RF<ch>:INAME?` on page 611

7.3.2 Remote instrument settings

Access:

- Select the "System Configuration" tile > "System Configuration" > "External Instrument" > "Config".

The "Remote Instrument" tab provides settings to connect the frequency multiplier.

Settings:

Clean All.....	179
External Instrument.....	179
Set Symbolic Name.....	179
Remote Channel.....	179
Hostname or IP Address.....	179
Device ID.....	179
Apply.....	180
Apply and Connect.....	180
Frontend Configuration.....	180

Clean All

The "Clean All" function unselects the external instrument, disables the connection and removes all configured settings of the external instrument in the system configuration.

It also removes all instruments not connected via USB cable to the R&S SMA100B from the "External Instrument" list.

Remote command:

`:SCONfiguration:EXTernal:REMote:CLEan` on page 613

External Instrument

Lists all available instruments.

- Select the external instrument from the list of available instruments. The required settings are retrieved and updated automatically.
- "None": Unselects the external instrument and disables the connection.

Remote command:

`:SCONfiguration:EXTernal:REMote:LIST?` on page 611

Set Symbolic Name

Sets the alias name of the instrument.

Remote command:

`:SCONfiguration:EXTernal:RF<ch>:REMote:INFO?` on page 612

Remote Channel

Displays the hardware channel used by the remote channel to the external instrument.

Remote command:

`:SCONfiguration:EXTernal:RF<ch>:REMote:INFO?` on page 612

Hostname or IP Address

Displays the hostname or IP address of the connected external instrument.

Remote command:

`:SCONfiguration:EXTernal:RF<ch>:REMote:INFO?` on page 612

Device ID

Displays the device identifier that is a unique string with the following structure:

`<frontend type>-<serial number>`

For a defined "External Instrument", the information is read out automatically.

Remote command:

`:SCONfiguration:EXTernal:RF<ch>:REMote:INFO?` on page 612

Apply

Confirms the settings and displays the external instrument in the "External RF" dialog.

Remote command:

`:SCONfiguration:EXTernal:RF<ch>:REMote:ISElect` on page 612

Apply and Connect

Confirms the settings and triggers the connection establishment. In the connected instruments, the status of this active remote connection is displayed by the "Remote" indication.

Remote command:

`:SCONfiguration:EXTernal:RF<ch>:REMote:ICONnect` on page 612

Frontend Configuration

Requires R&S SMAB-K554.

Accesses the "RF Frontend" dialog to configure settings of the connected external instrument.


See [Section 7.3.3, "RF frontend settings"](#), on page 180.

7.3.3 RF frontend settings

Access:

- ▶ Select one of the following in the home screen:
 - Select "Clk Syn / FE / Pow Sens" tile > "RF Frontend" > "Frontend Device".

- Select "System Config" tile > "System Configuration" > "External RF > External Instrument > Config" > "Remote Instrument > Frontend Config".



The "RF Frontend" dialog provides tabs for settings and information about the external instrument.

The remote commands required to define the settings are described in [Section 15.18.4, "SOURCE:EFRontend subsystem"](#), on page 697.

To operate an external frontend with the R&S SMA100B

See [Section 7.2, "Operating frequency multipliers"](#), on page 169.


Settings:

- [General settings](#)..... 181
- [Versions and options information](#)..... 182
- [Cable correction settings](#)..... 184

7.3.3.1 General settings

- Access:
1. Select "Clk Syn / FE / Pow Sens" tile > "RF Frontend" > "Frontend Device".

2. Select "Settings".



The "Settings" tab provides information about the intermediate frequency for the connected external frontend, e.g., R&S SZM.

Settings:

Intermediate Frequency

Displays the frequency of the IF signal that is the frequency at the RF 50 Ω connector.

Remote command:

`[ :SOURCE<hw> ] :EFrontend [ :FREQUENCY ] :IFrequency [ :VALUE ] ?`
on page 698

7.3.3.2 Versions and options information

Access:

1. Select "Clk Syn / FE / Pow Sens" tile > "RF Frontend" > "Frontend Device".

2. Select "Version / Options".

	Settings	Versions / Options	Cable Correction		
SZM75-100001	Firmware				
RF Frontend	Package	Version			
	Frontend Control Server	01.01.06			
	Frontend Control Library	01.29.00			
	Hardware Config				
	Assembly	Part Number	Serial Number	Revision	
	SZM75	1443.5004.02	100001	01.01	
	SZM75-100001-Mic			00.02.1349	
	SZM75-100001-Fpga			00.00.00	
	IFC_ZM	1417.7203.02	100663	200.200	
	Options				
	Option	Designation			
Info	SZM-E	Custom Description			
	SZM-I	Custom Desc2			

The "Versions / Options" tab displays information on the firmware and hardware of the connected external frontend.

Settings:

Firmware.....	183
Hardware Config.....	183
Options.....	184

Firmware

Displays firmware information on the control server and control library of the external frontend. The information is displayed in a table and consists of installed packages and versions.

"Package" Comprises the frontend control server and frontend control library.

"Version" Denotes the version of the installed package.

Remote command:

n.a.

Hardware Config

Displays hardware information of the hardware components of the external frontend. The information is displayed in a table and consists of component name, its part number and serial number, and revision version.

"Assembly" Displays the assembly part name for hardware component.

"Part Number" Displays the part number for each hardware component.

"Serial Number"

Displays the serial number for each hardware component.

"Revision" Displays the revision version for each hardware component.

Remote command:

[:SOURce<hw>] :EFRontend:IDN? on page 698

Options

Displays the frontend options installed on the frequency multiplier.

"Option" Displays the name of the frontend option.

"Designation" Displays a short description of the frontend option.


Remote command:

[:SOURce<hw>] :EFRontend:OPT? on page 699

7.3.3.3 Cable correction settings

Access:

1. Select "Clk Syn / FE / Pow Sens" tile > "RF Frontend" > "Frontend Device".
2. Select "Cable Correction".



The "Cable Correction" tab provides settings necessary to configure the frequency response correction of the IF signal path.

You can load correction data to compensate for signal losses in the cable occurring at different IF signal frequencies. Files containing correction data have the extension *.s2p or *.uco. The following descriptions are exemplary with *.s2p files. Working with *.uco files is analogous.

Settings:

State.....	185
Load Cable Correction File.....	185
Recommended Frequency Range.....	186

State

Activates correction of the IF signal for different IF signal frequencies.

Activation requires loading of a valid cable correction file, see "[Load Cable Correction File](#)" on page 185.

Remote command:

`[ :SOURce<hw> ] :EFRontend:ALIGnment [ :STATe ]` on page 700

Load Cable Correction File

Accesses a standard file-select dialog to load correction data to compensate for signal losses in the cable occurring at different IF signal frequencies.


If a correction file is loaded, the button also displays the filename.

You can load predefined cable correction files from frontend-specific folders. The predefined cable correction files stored on the R&S SMA100B contain correction data for the recommended standard R&S IF cable, using the S-parameter S21.

Example: Displaying file correction data

The example for the *.s2p file below comprises correction data for frequencies from 0 GHz to 7.5 GHz.

```
# HZ S DB R 50.00
! Date: 2020-06-12;11:48:28
! freq[Hz] db:S11 ang:S11 db:S21 ang:S21 db:S12 ang:S12 db:S22 ang:S22
100000.0 0.001 0 -0.018267469344920073 0 -0.018267469344920073 0 0.001 0
50000000.0 0.001 0 -0.10438567392872056 0 -0.10438567392872056 0 0.001 0
100000000.0 0.001 0 -0.1402532552881901 0 -0.1402532552881901 0 0.001 0
500000000.0 0.001 0 -0.37850173705964973 0 -0.37850173705964973 0 0.001 0
1000000000.0 0.001 0 -0.5387899823157998 0 -0.5387899823157998 0 0.001 0
2500000000.0 0.001 0 -0.8994010660064706 0 -0.8994010660064706 0 0.001 0
5000000000.0 0.001 0 -1.3888357992535698 0 -1.3888357992535698 0 0.001 0
7500000000.0 0.001 0 -1.8624967962088599 0 -1.8624967962088599 0 0.001 0
```



Remote command:

`[ :SOURce<hw> ] :EFRontend:ALIGnment:FILE:CATalog?` on page 699

`[ :SOURce<hw> ] :EFRontend:ALIGnment:FILE[:SElect]` on page 699

Recommended Frequency Range

Displays the recommended frequency range of the IF signal that the external frontend requires.

We recommend that you cover this range in the cable correction file. See [Example "Displaying file correction data"](#) on page 185.

Remote command:

`[ :SOURce<hw> ] :EFRontend:ALIGnment:FILE:FREQuency:RANGe:LOWer?`
on page 699

`[ :SOURce<hw> ] :EFRontend:ALIGnment:FILE:FREQuency:RANGe:UPPer?`
on page 699

8 List and sweep mode

The operating modes "List" and "Sweep" allow you to generate an RF signal having periodically varying frequencies or amplitudes.

A signal generated with varying parameters scans a certain range of varying values of a parameter, with defined start and end points, and can be repeated cyclically.

The R&S SMA100B supports two basic methods:

- **Sweep** mode

The instrument generates an RF signal which varies its frequency or level values in discrete steps between the start and end values. The values change according to a specific shape like sawtooth or triangle. The spacing is linear or logarithmic.




Figure 8-1: Schematic representation of a signal generated in sweep mode

The main application field of the "Sweep" mode is to determine the frequency response of a DUT.

- **List** mode

The instrument generates a varying output signal, based on a previously saved list with frequency, amplitude and step width values. While in sweep mode the frequency **or** the level values change, in list mode you can vary **both parameters simultaneously**. The frequency and level values do not need to have ascending or descending order, they can vary arbitrarily.

You can use a global dwell time, which means that the time interval is constant for all steps of the list, or different dwell times for each value pair.

[Figure 8-2](#) represents the frequency and power value pairs, in this case with the dwell time set the same for all steps (global dwell time).




Figure 8-2: Schematic representation of a signal generated in list mode (global dwell time)

- 1 = RF frequency
- 2 = RF Level
- 3 = Dwell time (global)
- 4 = List index


The list mode is especially useful in high-speed measurements with fast changing frequency and level settings.



Note that the shown diagrams represent the behaviour in theory. In real signal generation, the instruments usually have a blank time when the frequency or level changes.

Interactions and characteristics of list and sweep mode

- Activating the list mode automatically deactivates all RF and LF sweeps and vice versa.
- In list processing mode, the frequency and level display in the status bar is disabled.



- The sweep modes only work with a *global* dwell time, that means the time intervals are constant during signal generation.
- If you want to hold a running sweep at a specific frequency or level value, enter the value in the status bar. The sweep stops immediately.
- We recommend that you switch off the display update for optimum sweep performance, especially with short dwell times
See [Section 13.1.2, "Display update settings"](#), on page 369.

8.1 Signal generation and triggering in the sweep and list modes

In both operating modes "List" and "Sweep", triggering and signal generation follow the same principle. The instrument generates the signal continuously (that means triggered automatically) or in individual steps (controlled manually by an internal or external trigger signal).

The instrument expects the trigger signal at the Inst Trig connector.



If the dwell time in sweep or list mode is too short or external trigger signals come too fast, the signal generation delays. As the delay increases, the R&S SMA100B signals an overrun, or even stops sweep or list mode signal generation, if the delay gets too long.

The instrument displays corresponding error messages.

The figures in this section give an overview on the signal generation in the sweep and list modes and the appropriate triggering. The figures show the signal state after activating the mode and the generation of the signal when a trigger event occurs. For each mode, the relevant parameters and settings are briefly explained.

Each "Sweep" and "List" mode dialog provides also a "Reset" function that sets the signal to the initial value or the beginning of the list. Depending on the selected trigger mode, the signal generation proceeds accordingly.



The naming of the selection parameters in manual control (GUI) sometimes deviates from the naming in the remote-control commands. In addition, the value names of the selection parameters used in the signal generator partly differ from the SCPI syntax. The instrument accepts all value names.

The correlation between the manual control and the corresponding remote control commands, including the SCPI conform syntax are explained for each mode (see the cross-reference tables).

See also the following programming examples on the sweep and list modes in remote control:

- [Example "Setting up an RF frequency or power sweep"](#) on page 762
- [Example "Setting up an LF sweep"](#) on page 710
- [Example "Create an RF list and activate the list mode"](#) on page 723

Signal generation and triggering in the sweep and list modes

Auto mode (Sweep/List)





Figure 8-3: Auto mode (Sweep/List)

- The instrument generates the signal continuously.
- Trigger mode "Auto" is prerequisite (default). It causes the continuous generation of the sweep signal.
- Starts signal generation immediately with "State = On".
- Switches automatically to the next step when the **Dwell time** has elapsed.
- Stops signal generation with "State = Off".

Table 8-1: Cross-reference between manual and remote control in Auto mode (Sweep/List)

Manual control mode: "Auto"	Remote commands Rohde & Schwarz proprietary and [SCPI conform] value name
RF frequency sweep	:TRIGger<hw>:FSweep:SOURce AUTO [IMMediate] :SOURce<hw>:SWEep:FREQuency:MODE AUTO
RF level sweep	:TRIGger<hw>:PSweep:SOURce AUTO [IMMediate] :SOURce<hw>:SWEep:POWer:MODE AUTO
LF frequency sweep	:TRIGger<hw>:LFFSweep:SOURce AUTO [IMMediate] :SOURce<hw>:LFOutput<ch>:SWEep:FREQuency:MODE AUTO
List	:SOURce<hw>:LIST:MODE AUTO :SOURce<hw>:LIST:TRIGger:SOURce AUTO

Single / Extern Single mode (Sweep/List)**Figure 8-4: Single / Extern Single mode (sweep / list)**


In single mode, you can specify, that the signal returns to the start value when a sweep cycle has been completed.

See ["The Retrace function"](#) on page 196 for details.

- The instrument generates a single sweep cycle.
- Trigger mode "Manual". A trigger event initiates one sweep from the start value to the end value.
- "State = On" sets the signal to the start value: the sweep start frequency, the sweep start power or the frequency-power value pair of the selected index in the list.
- Starts signal generation with a trigger event.
- Switches automatically to the next step when the [Dwell time](#) has elapsed.
- Stops signal generation at the set end value and waits for the subsequent trigger event.
- Trigger sources:
 - The "Execute Single Sweep" function.
 - The corresponding remote control command.
 - An externally applied trigger signal.
- "State = Off" stops the signal generation in sweep or list mode.

Table 8-2: Cross-reference between manual and remote control in Single / Extern Single modes (Sweep/List)

Manual control mode: "Single / Extern Single"	Remote commands Rohde & Schwarz proprietary and [SCPI conform] value name
RF frequency sweep	:TRIGger<hw>:FSWEEP:SOURce SINGLE [BUS] "Single" or :TRIGger<hw>:FSWEEP:SOURce EXTERNAL [EXTERNAL] "Extern Single" :SOURce<hw>:SWEep:FREQuency:MODE AUTO
RF level sweep	:TRIGger<hw>:PSWEEP:SOURce SINGLE [BUS] for "Single" or :TRIGger<hw>:PSWEEP:SOURce EXTERNAL [EXTERNAL] for "Extern Single" :SOURce<hw>:SWEep:POWer:MODE AUTO
LF frequency sweep	:TRIGger<hw>:LFFSWEEP:SOURce SINGLE [BUS] "Single" or :TRIGger<hw>:LFFSWEEP:SOURce EXTERNAL [EXTERNAL] "Extern Single" :SOURce<hw>:LFOutput<ch>:SWEep:FREQuency:MODE AUTO
List	:SOURce<hw>:LIST:TRIGger:SOURce SINGLE "Single" or :SOURce<hw>:LIST:TRIGger:SOURce EXTERNAL "Extern Single" :SOURce<hw>:LIST:MODE AUTO

Step / Extern Step mode (Sweep/List)**Figure 8-5: Step / Extern Step mode (sweep / list)**

- The instrument generates the signal step-by-step.
- Starts signal generation with "State = On".
- Switches to the next step with a manual action.
If the end value is reached, signal generation starts again from the beginning.
- Stops signal generation with "State = Off".

Signal generation and triggering in the sweep and list modes

- Trigger sources:
 - The rotary knob at the front panel.
 - The [Arrow] keys at the front panel.
 - The corresponding remote control commands.
 - An externally applied trigger signal.

To step through the sweep frequencies or levels:


- In manual mode:
 - Set the **Current Frequency** or **Current Level** values
 - Use the [Up] and [Down] keys or the rotary knob
- In remote control mode:
 - Use the commands `[ :SOURce<hw> ] :FREQuency:MANual` or `[ :SOURce<hw> ] :POWer:MANual` with the UP or DOWN parameter



Steps that would exceed the sweep range are ignored.

Table 8-3: Cross-reference between manual and remote control in Step / Extern Step modes (Sweep/List)

Manual control mode: "Step / Extern Step"	Remote commands Rohde & Schwarz proprietary and [SCPI conform] value name
RF frequency sweep	:TRIGGer<hw>:FSWEEP:SOURce SINGLE [BUS] "Step" or :TRIGGer<hw>:FSWEEP:SOURce EXTERNAL [EXTernal] for "Extern Step" :SOURce<hw>:SWEep:FREQuency:MODE STEP
RF level sweep	:TRIGGer<hw>:PSWEEP:SOURce SINGLE [BUS] "Step" or :TRIGGer<hw>:PSWEEP:SOURce EXTERNAL [EXTenal] "Extern Step" :SOURce<hw>:SWEep:POWer:MODE STEP
LF frequency sweep	:TRIGGer<hw>:LFFSWEEP:SOURce SINGLE [BUS] "Step" or :TRIGGer<hw>:LFFSWEEP:SOURce EXTERNAL [EXTenal] "Extern Step" :SOURce<hw>:LFOutput<ch>:SWEep:FREQuency:MODE STEP
List	:SOURce<hw>:LIST:TRIGGer:SOURce SINGLE "Step" or :SOURce<hw>:LIST:TRIGGer:SOURce EXTERNAL "Extern Step" :SOURce<hw>:LIST:MODE STEP

Extern Start/Stop mode (sweep)**Figure 8-6: Extern Start/Stop mode (sweep)**

- The instrument generates the signal continuously.
- Trigger mode "Auto" and "Sweep > State = On" are prerequisite.
- State "On" sets the signal to the start value, that is one of the following:
 - Sweep start frequency
 - Sweep start power
 - Frequency-power value pair of the selected index in the list
- Starts signal generation with a trigger event.
- Switches automatically to the next sweep step when the **Dwell time** has elapsed. If the end value is reached, signal generation continues with the next sweep cycle.
- Stops signal generation with the next external trigger event.
- Starts the signal generation again with the next trigger event, beginning at the start value.
- "State = Off" stops the signal generation in sweep or list mode.
- Trigger source: An externally applied trigger signal.

Table 8-4: Cross-reference between manual and remote control in Extern Start/Stop modes (sweep)

Manual control mode: "Extern Start/Stop"	Remote commands Rohde & Schwarz proprietary and [SCPI conform] value name
RF frequency sweep	:TRIGger<hw>:FSweep:SOURce EAUTO [-] :SOURce<hw>:SWEep:FREQuency:MODE AUTO
RF level sweep	:TRIGger<hw>:PSweep:SOURce EAUTO [-] :SOURce<hw>:SWEep:POWer:MODE AUTO
LF frequency sweep	:TRIGger<hw>:LFFSweep:SOURce EAUTO [-] :SOURce<hw>:LFOutput<ch>:SWEep:FREQuency:MODE AUTO

Manual mode (Sweep/List)



The **manual** mode only applies to remote control. It is not visible in the graphical user interface of the instrument and is described here for completeness.





Figure 8-7: Manual mode in remote control (sweep / list)

- The instrument generates the signal in steps.
- Starts signal generation with "State = On".
- Switches to the next step with a user defined setting via remote control. You can arbitrarily select a value within the range of the start and stop values by setting the frequency, power or index using the corresponding remote control command. There is no ascending or descending order.
- Stops signal generation with "State = Off".

Table 8-5: Remote control commands in manual mode (Sweep/List)

Remote control mode:	Remote commands
Manual	Rohde & Schwarz proprietary and [SCPI conform] value name
RF frequency sweep	:SOURce<hw>:FREQuency:MANUal <Manual>
RF level sweep	:SOURce<hw>:POWER:MANUal <Manual>
LF frequency sweep	:SOURce<hw>:LFOUtpuT:FREQuency:MANUal <Manual>
List	:SOURce<hw>:LIST:INDex <Index>

The Retrace function



Retrace is a function especially designed for "Single" sweep modes, when the sweep signal follows a sawtooth shape. Working in this mode, the instrument performs a single sweep cycle when a trigger event occurs. The signal generation stops at the set end point (stop frequency or stop level), and waits for the next trigger event.

In this state, the upper value of the signal remains at the output until the next cycle starts. In particular, if you generate a level sweep signal, the high amplitude of the signal is output for a certain time. To protect the DUT from overload, the retrace function immediately resets the signal value to the start value at the end of a sweep cycle. It returns to the start level or start frequency until the next trigger is applied.

You can use the "Retrace" function if "Sweep > Mode = Single/External Single" and "Shape = Sawtooth", see:

- ["Shape"](#) on page 207
- ["Mode"](#) on page 205

8.2 About sweep mode

In sweep mode, the signal generator scans the sweep range gradually from one point to another, using a defined step size and following a triangle or sawtooth shape. This mode also enables you to change direction, that means, it is possible to step backwards.

See [Section 8.2.2, "Sweep signal shapes"](#), on page 199.

Configuration and operation of sweep mode signals

- The R&S SMA100B generates a sweep signal by varying the following parameters: either the *RF frequency*, the *RF level* or both, the *RF frequency* and the *RF level* in combined RF sweep mode, or the *LF frequency*.
- In all sweep modes, you can perform a complete sweep cycle once, repeat the cycle continuously or step through it gradually.
- The instrument generates the sweep signal according to the sweep settings.
- The "Reset Sweep" function, provided in the sweep settings dialogs enables you to reset the sweep to its initial value and restart it.



Impact of changing the sweep mode during performance

If you change the sweep mode during the execution, the signal generator stops the sweep and starts with the next trigger event at the initial value.

Combined RF frequency / level sweep processing mode

The combined RF sweep functionality processes the signal similar to the Live list mode. The R&S SMA100B sets the frequency and level values simultaneously in the hardware. The difference to the list mode is that the values are not taken from a previously created list, but are calculated using the selected frequency and level ranges, the dwell time and the number of steps.

8.2.1 Correlating parameters in sweep mode

A sweep signal is a periodic signal that changes its frequency or level, or both, from a starting value to an ending value in a defined time.

The R&S SMA100B provides various possibilities to configure a sweep signal. For example, you can determine the sweep range by the start and end values, or based on the start value and span. In any case, related parameters are adjusted accordingly.

The formulas below show how the sweep parameters correlate and the corresponding calculation basis, by the frequency and offset settings. Apart from "Center Frequency", "Span" and "Step_lin", the values apply accordingly to the level settings.

Table 8-6: Variables that are used in the following formulas

Variable	Description
Sweep range	Defined frequency or level value range
f_{CENTer}	Defined center frequency
f_{SPAN}	Defined extend of the sweep range
f_{OFFSet}	Frequency offset
f_{START}	Start frequency of the sweep range
f_{STOP}	End frequency of the sweep range
f_1	Current sweep frequency

Variable	Description
f_2	Next, subsequent sweep frequency
step_lin	Step size in linear scaling
step_log	Step size in logarithmic scaling
POINts	Number of steps within the sweep range

Sweep range

The sweep range is defined by a start and an end value. How the remaining parameters correlate is shown below.

Offset = 0

Sweep Range = f_{START} to f_{STOP}

$$f_{\text{CENTer}} = (f_{\text{START}} + f_{\text{STOP}})/2$$

$$f_{\text{SPAN}} = (f_{\text{STOP}} - f_{\text{START}})$$

Where:

$$f_{\text{START}} = f_{\text{CENTer}} - (f_{\text{SPAN}}/2)$$

$$f_{\text{STOP}} = f_{\text{CENTer}} + (f_{\text{SPAN}}/2)$$

Offset≠0

A defined offset also affects the sweep range and the center frequency. Therefore, the set frequencies are only absolute values, if the Offset = 0. Offset ≠ 0 shifts the frequencies with the offset value:

Sweep Range = $f_{\text{START}} + f_{\text{OFFSet}}$ to $f_{\text{STOP}} + f_{\text{OFFSet}}$

$$f_{\text{CENTer}} = f_{\text{CENTer}} + f_{\text{OFFSet}}$$

$$f_{\text{SPAN}} = f_{\text{SPAN}} + f_{\text{OFFSet}}$$

The value range of the instrument is calculated as follows:

$$RF_{\text{min}} + f_{\text{OFFSet}} \text{ to } RF_{\text{max}} + f_{\text{OFFSet}}$$



It is possible to set $f_{\text{START}} > f_{\text{STOP}}$ and $f_{\text{START}} < f_{\text{STOP}}$, so that even a negative value is permitted for the "Span".

If you change the start and/or stop frequency, the span and center frequency change accordingly, and vice versa.

Sweep steps

In the following, you see how the sweep steps are calculated depending on the defined spacing mode. The formulas show a frequency sweep, but apply to the level settings in the same way.

The step size is added to the current value, to get the subsequent sweep step.

With **linear** scaling, the next frequency is calculated according to:

$$f_2 = f_1 + \text{step_lin}$$

In the **logarithmic** scaling, the step size is determined in per cent, as a constant fraction of the current frequency.

Successive frequencies are calculated as follows:

- For $f_{\text{START}} < f_{\text{STOP}}$
 $f_2 = f_1 * (1 + \text{step_log}/100)$
 If $f_2 > f_{\text{STOP}}$, then $f_2 = f_{\text{STOP}}$
- For $f_{\text{START}} > f_{\text{STOP}}$
 $f_2 = f_1 / (1 + \text{step_log}/100)$
 If $f_2 < f_{\text{STOP}}$, then $f_2 = f_{\text{STOP}}$

With "Shape = Triangle", the frequency values on the slope from f_{STOP} to f_{START} are the same as on the slope from f_{START} to f_{STOP} .

If you specify the number of steps within the sweep range, the step size is adjusted according to the following correlation:

- For **linear** sweeps and $f_{\text{START}} < f_{\text{STOP}}$
 $\text{POINTS}_{\text{frequency}} = ((f_{\text{START}} - f_{\text{STOP}})/\text{step_lin}) + 1 = (f_{\text{SPAN}}/\text{step_lin}) + 1$
- For **logarithmic** sweeps and $f_{\text{START}} < f_{\text{STOP}}$
 $\text{POINTS}_{\text{frequency}} = ((\log f_{\text{STOP}} - \log f_{\text{START}})/\log \text{step_log}) + 1$

If step_log changes, the value of POINTs is adjusted. The f_{START} and f_{STOP} values are retained.

8.2.2 Sweep signal shapes

The R&S SMA100B supports the following sweep shapes:

- **Sawtooth**
 The sweep sequence resembles a sawtooth. One sweep runs from start to stop frequency, or level value respectively. Each subsequent sweep starts again at the start value.




Figure 8-8: Sweep signal sawtooth shape

1 = Start value
 2 = Stop value
 3 = Step size

- **Triangle**
 The sweep sequence resembles a triangle. One sweep runs from start to stop value frequency and back. Each subsequent sweep starts at the start value.




Figure 8-9: Sweep signal triangle shape

1 = Start value
 2 = Stop value
 3 = Step size

The current frequency or level of an RF frequency, level or LF frequency sweep is determined by the shape (e.g. sawtooth or triangle) and the spacing (linear or logarithmic), and the step size.

8.3 About list mode

The list mode is used to generate the RF signal based on a set of predefined frequency and amplitude value pairs, with individual step times. You can define the values arbitrarily, in any order and varying step sizes, within the entire configurable value range of the instrument.

Configuration and operation of list mode signals

The parameters configuring the RF signal are defined in a list (table) and stored in a file.

Creating and handling lists

List files can be created in the following ways:

- **Internally**
 Use the build-in table editor with columns for the frequency-level values pairs and the dwell time.
 Define the values manually (row by row) or automatically, based on value range and step size.
 See [Section 8.7, "List data editor"](#), on page 223.

Lists are saved as files with user-definable filename and the predefined file extension *.lsw. To load a saved file, use the "File Manager".

See [Section 12.9, "Using the file manager"](#), on page 348.

- Lists can be exported, too. For example, to exchange configuration between instruments or to modify the file content with an external program and reload them again.
- **Externally**
Create a list file as a CSV file with Microsoft Excel, with a Notepad or a similar tool and save it with the predefined extension. Transfer the file to and load it into the instrument.

Dwell time mode

You can choose whether you want to use different dwell times or a fixed value for all steps in the list mode:

- "From List"
This mode uses the values from the data table.
See [Section 8.7, "List data editor"](#), on page 223.
- "Global"
This mode processes the list with a fixed time interval you can set with [Global Dwell Time](#).

List processing mode

See:

- ["Live list processing mode"](#) on page 203

8.4 Significant parameters and functions

This section provides some basic parameters, settings and functions that affect the operating modes CW, list and sweep, that means at all frequency and level transitions of the RF signal.

Dwell time

Dwell time is the length of time that elapses from the beginning until the end of a step in list or sweep mode.




Figure 8-10: Dwell Time vs. settling time

- 1 = "Dwell Time" (as set with the parameter)
- 2 = Settling time
- 3 = Dwell time (effective)

However, the time the instrument requires for the signal to settle reduces the set dwell time:

$$t_{\text{dwell(effective)}} = t_{\text{dwell}} - t_{\text{settling}}$$



If the dwell time in sweep or list mode is too short or external trigger signals come too fast, the signal generation delays. As the delay increases, the R&S SMA100B signals an overrun, or even stops sweep or list mode signal generation, if the delay gets too long.

The instrument displays corresponding error messages.

Hardware adjustments

The first time a list (new or modified) is processed, the instrument automatically calculates the necessary hardware settings. It can be performed during list processing, but delays the first cycle, especially with short dwell times.

With long dwell times, you can perform this calculation while the list is being processed; the entered dwell times are observed. With short dwell times, calculation of the hardware settings increases the dwell time for the initial processing cycle; the entered value is only observed from the second processing cycle onwards. In this case, a message indicates that there is a deviation between the current and set dwell times. After the first cycle, you do not need to perform additional calculations. The current dwell times do not deviate from the set dwell times.

Blanking

The instrument applies *blanking*, which temporarily turns off the RF signal when the frequency or level changes, until the signal has settled to a stable state.

Temporary blanking applies to all operating modes.

Live list processing mode

The R&S SMA100B generates the signal directly from the value pairs in the database, and adjusts the hardware settings accordingly. The current instrument state and thus any change during the signal generation directly affects the RF signal. The temporary memory is not used.

You can conveniently modify parameters like modulation settings during run-time. Learning list mode data is not required. Impacts like temperature drift are also considered immediately.

This mode is optimized for **maximum signal quality**, and is useful if dwell times higher than 2 ms are sufficient.

8.5 Sweep mode settings

This section lists the settings of **all** available sweep modes.

Access:

1. Select "Sweep" > "RF Frequency Sweep"
2. Select "Sweep" > "RF Level Sweep"
3. Select "Sweep" > "RF Combined Sweep"
4. Select "Sweep" > "LF Frequency Sweep"

The remote commands required to define these settings are described in:

- [Section 15.18.14, "SOURce:SWEep subsystem"](#), on page 760
- [Section 15.18.5, "SOURce:FREQuency subsystem"](#), on page 700
- [Section 15.18.12, "SOURce:POWer subsystem"](#), on page 740
- [Section 15.18.7, "SOURce:LFOutput subsystem"](#), on page 710

Settings



- [General sweep settings](#).....203
- [Frequency range settings](#).....210
- [Level range settings](#).....212
- [Output settings](#).....214
- [Edit marker settings](#).....215

8.5.1 General sweep settings

Access:

- Select for example "Sweep" > "RF Frequency Sweep".

Table 8-7: General settings dialog: Examples of RF Frequency and RF Combined Sweep dialogs

> "RF Frequency Sweep"	> "RF Combined Sweep"
	

Settings

Sweep Type	204
State (RF frequency sweep)	204
State (RF level sweep)	205
State (RF frequency / level sweep)	205
State (LF frequency sweep)	205
Current Frequency	205
Current Level	205
Mode	205
Retrace	206
Shape	207
Spacing	208
Sweep Time	208
Dwell Time	208
Trigger Slope	209
Show/Show Connector	209
Reset Sweep	209
Execute Single Sweep	209

Sweep Type

Selects the kind of the frequency sweep.

- "Step" Increases or decreases the frequency at each step.
To determine the frequency intervals, see [Spacing](#).
- "Ramp" Provides a synthesized continuous analog frequency sweep with the set [Sweep Time](#).

Remote command:

[\[:SOURce<hw>\]:SWEep:GENeration](#) on page 766

State (RF frequency sweep)

Activates RF frequency sweep signal generation.

Note: Active RF frequency, RF level or RF combined sweep modes deactivate the LF sweep or List mode and vice versa.

Remote command:

[:SOURce<hw>] :FREQuency:MODE on page 701

State (RF level sweep)

Activates RF level sweep signal generation.

Note: Active RF frequency, RF level or RF combined sweep modes deactivate the LF sweep or List mode and vice versa.

Remote command:

[:SOURce<hw>] :POWer:MODE on page 747

State (RF frequency / level sweep)

Activates the RF frequency / level sweep signal generation.

Note: Active RF frequency, RF level or RF combined sweep modes deactivate the LF sweep or List mode and vice versa.

Remote command:

[:SOURce<hw>] :FREQuency:MODE on page 701

[:SOURce<hw>] :POWer:MODE on page 747

State (LF frequency sweep)

Status of the LF frequency sweep signal.

You find this parameter in two dialogs:

- "LF Frequency Sweep" turns on/off the signal generation.
See [Sweep mode settings](#) for access.
- "Analog Modulation Sources" displays the current state (read-only). If it is turned on, this dialog provides the varying sweep frequency, see [Current Frequency](#).

Note: Active RF frequency, RF level or RF combined sweep modes deactivate the LF sweep or List mode and vice versa.

Remote command:

[:SOURce<hw>] :LFOutput:FREQuency:MODE on page 714

Current Frequency

Displays the current frequency sweep value for all sweep [Modes](#), except of [Mode > Step](#). In this mode, you can enter the next frequency setting manually.

Remote command:

[:SOURce<hw>] :FREQuency:MANual on page 704

[:SOURce<hw>] :LFOutput:FREQuency:MANual on page 714

Current Level

Displays the current level sweep value for all sweep [Modes](#), except of [Mode > Step](#). In this mode, you can enter the next level setting manually.

Remote command:

[:SOURce<hw>] :POWer:MANual on page 746

Mode

Selects the sweep mode.

See [Section 8.1, "Signal generation and triggering in the sweep and list modes"](#), on page 189.

"Auto" Generates a continuously repeating sweep signal directly after activating the sweep mode.
The sweep steps are performed automatically, controlled by the dwell time.

"Single / Extern Single" Generates a single sweep cycle after a trigger event.
The sweep steps within the cycle are performed automatically, controlled by the dwell time. If one cycle is completed, the instrument waits for the next trigger event.

"Step / Extern Step" Generates the sweep signal step-by-step, manually triggered.

"Extern Start/Stop" Generates a continuously repeating sweep signal that is started, stopped, and restarted by subsequent external trigger events.
The sweep steps are performed automatically, controlled by the dwell time.

Remote command:

RF frequency sweep:

[\[:SOURce<hw>\]:SWEep\[:FREQuency\]:MODE](#) on page 768
[:TRIGger<hw>:FSWEEP:SOURce](#) on page 814

RF level sweep:

[\[:SOURce<hw>\]:SWEep:POWer:MODE](#) on page 766
[:TRIGger<hw>:PSWEEP:SOURce](#) on page 814

RF combined sweep:

[\[:SOURce<hw>\]:SWEep:COMBined:MODE](#) on page 773
[:TRIGger<hw>:FPSWEEP:SOURce](#) on page 815

LF frequency sweep:

[\[:SOURce<hw>\]:LFOutput:SWEep\[:FREQuency\]:MODE](#) on page 720
[:TRIGger<hw>:LFFSWEEP:SOURce](#) on page 814

Retrace

For "Shape = Sawtooth" and "Mode = Single/External Single", enables changing the signal to the start value while it is waiting for the next trigger event. It returns to the start level or start frequency until the next trigger is applied.

Remote command:

RF frequency sweep:

[\[:SOURce<hw>\]:SWEep\[:FREQuency\]:RETRace](#) on page 770

RF level sweep:

[\[:SOURce<hw>\]:SWEep:POWer:RETRace](#) on page 770

RF combined sweep:

[\[:SOURce<hw>\]:SWEep:COMBined:RETRace](#) on page 774

LF frequency sweep:

[\[:SOURce<hw>\]:LFOutput:SWEep\[:FREQuency\]:RETRace](#) on page 721

Shape

Selects the waveform shape of the sweep signal.

"Sawtooth"

The sweep runs from start to stop frequency. The subsequent sweep starts at the start value, i.e. the shape of the sweep sequence resembles a sawtooth.




Figure 8-11: Sweep signal sawtooth shape

1 = Start value

2 = Stop value

3 = Step width

"Triangle"

The sweep runs from start to stop value and back, i.e. the shape of the sweep resembles a triangle. Each subsequent sweep starts at the start frequency.

The triangle shape is only available for [Sweep Type > Step](#).




Figure 8-12: Sweep signal triangle shape

1 = Start value

2 = Stop value

3 = Step width

Remote command:

RF frequency sweep:

[\[:SOURce<hw>\]:SWEep\[:FREQuency\]:SHApe](#) on page 769

RF level sweep:

[\[:SOURce<hw>\]:SWEep:POWer:SHApe](#) on page 769

RF combined sweep:

`[ :SOURce<hw> ] :SWEep:COMBined:SHApe` on page 774

LF frequency sweep:

`[ :SOURce<hw> ] :LFOutput:SWEep [ :FREQuency ] :SHApe` on page 722

Spacing

In "RF and LF Frequency Sweep" mode, "Spacing" selects the mode for calculating the frequency interval, which increases or decreases the current frequency at each step.

In "RF Frequency Sweep" mode and [Sweep Type > Ramp](#), the parameter automatically distributes the step intervals linearly.

To determine the step size, select the parameter [Step Linear/Step Logarithmic](#).

In "RF Combined Sweep" mode, the parameter indicates that the step intervals are linearly (straight proportional) distributed, i.e. the intervals have the same size. The frequency / level range and the [Dwell Time](#) time determine the calculated step size.

- | | |
|---------------|---|
| "Linear" | <p>The spacing depends on the selected sweep type.</p> <ul style="list-style-type: none"> • Sweep Type > Step
Takes the frequency value entered as absolute value in Hz. • Option: R&S SMAB-B28
Sweep Type > Ramp
Generates a synthesized continuous analog frequency sweep for the duration set with the parameter Sweep Time. |
| "Logarithmic" | <p>(Sweep Type > Step only)
Takes the value entered as a logarithmic value, i.e. as a constant fraction of the current frequency in %.</p> |

Remote command:

RF frequency sweep:

`[ :SOURce<hw> ] :SWEep [ :FREQuency ] :SPACing` on page 769

RF combined sweep: n.a.

LF frequency sweep:

`[ :SOURce<hw> ] :LFOutput:SWEep [ :FREQuency ] :SPACing` on page 722

Sweep Time

Option: R&S SMAB-B28

For "RF Frequency Sweep" with [Sweep Type > Ramp](#), the parameter sets the duration of a ramp sweep step.

Remote command:

`[ :SOURce<hw> ] :SWEep [ :FREQuency ] :TIME` on page 774

Dwell Time

Defines the duration of the individual sweep steps.

Note: In case of considerable overrun conditions, the R&S SMA100B turns off the sweep mode.

See also [Section 8.4, "Significant parameters and functions"](#), on page 201.

Remote command:

RF frequency sweep:

`[ :SOURce<hw> ] :SWEep [ :FREQuency ] :DWELL` on page 768

RF level sweep:

`[ :SOURce<hw> ] :SWEep:POWer:DWELl` on page 765

RF combined sweep:

`[ :SOURce<hw> ] :SWEep:COMBined:DWELl` on page 772

LF frequency sweep:

`[ :SOURce<hw> ] :LFOutput:SWEep [ :FREQuency ] :DWELl` on page 720

Trigger Slope

For "Mode = Extern Step/Single", selects the polarity of the active slope of an applied instrument trigger.

Trigger signal is expected at the Inst Trig connector.

"Positive" The rising edge of the trigger signal triggers the instrument.

"Negative" The falling edge of the trigger signal triggers the instrument.

Remote command:

`[ :SOURce ] :INPut:TRIGger:SLOPe` on page 710



Show/Show Connector

Opens a dialog that displays the location of the connector on the front panel or rear panel of the instrument. A blinking rectangle shows the connector.

Reset Sweep

Resets a sweep.

With the next trigger event, the sweep starts at the initial value.

Remote command:

`[ :SOURce<hw> ] :SWEep:RESet [ :ALL ]` on page 774

Execute Single Sweep

In "Mode = Single", starts a sweep manually.

Remote command:

RF frequency sweep:

`[ :SOURce<hw> ] :SWEep [ :FREQuency ] :EXECute` on page 769

`:TRIGger<hw>:FSweep [ :IMMediate ]` on page 816

RF level sweep:

`[ :SOURce<hw> ] :SWEep:POWer:EXECute` on page 769

`:TRIGger<hw>:PSweep [ :IMMediate ]` on page 816

RF combined sweep:

`[ :SOURce<hw> ] :SWEep:COMBined:EXECute` on page 773

LF frequency sweep:

`[ :SOURce<hw> ] :LFOutput:SWEep [ :FREQuency ] :EXECute` on page 720

`:TRIGger<hw>:LFFSweep:IMMediate` on page 816

General:

`:TRIGger<hw> [ :SWEep ] [ :IMMediate ]` on page 816

8.5.2 Frequency range settings

Access:

1. Select for example "Sweep" > "RF Frequency Sweep"
2. Select for example "Frequency Range".

Table 8-8: Range settings dialog: Examples of RF Frequency and RF Combined Sweep dialogs

> "Frequency Range"					> "Frequency / Level Range"				
General Single Frequency Range Output Edit Marker X					General Auto Frequency Level Range Output Edit Marker X				
Start Frequency			100.000 000 000 MHz		Stop Frequency			500.000 000 000 MHz	
Center Frequency			300.000 000 000 MHz		Span			400.000 000 000 MHz	
Spacing			Linear		Step Linear			1.000 000 000 MHz	

Start Frequency			100.000 000 000 MHz		Stop Frequency			500.000 000 000 MHz	
Start Level			-30.00 dBm		Stop Level			-10.00 dBm	
Step Count			501						

Settings

Start Frequency/Stop Frequency.....	210
Center Frequency.....	210
Span.....	211
Spacing.....	211
Step Linear/Step Logarithmic.....	211

Start Frequency/Stop Frequency

Defines the frequency sweep range by setting the start and end values.

See [Section 8.2.1, "Correlating parameters in sweep mode"](#), on page 197.

Remote command:

RF frequency sweep:

[:SOURce<hw>] :FREQuency:START on page 705

[:SOURce<hw>] :FREQuency:STOP on page 706

RF combined sweep:

[:SOURce<hw>] :COMBined:FREQuency:START on page 771

[:SOURce<hw>] :COMBined:FREQuency:STOP on page 771

LF frequency sweep:

[:SOURce<hw>] :LFOutput:FREQuency:START on page 715

[:SOURce<hw>] :LFOutput:FREQuency:STOP on page 715

Center Frequency

In "RF Frequency Sweep" mode, sets the RF center frequency.

See [Section 8.2.1, "Correlating parameters in sweep mode"](#), on page 197.

Remote command:

[:SOURce<hw>] :FREQuency:CENTer on page 705

Span

In "RF Frequency Sweep" mode, sets the span of the frequency sweep range.

See [Section 8.2.1, "Correlating parameters in sweep mode"](#), on page 197.

Remote command:

[:SOURce<hw>] :FREQuency:SPAN on page 705

Spacing

In "RF and LF Frequency Sweep" mode, "Spacing" selects the mode for calculating the frequency interval, which increases or decreases the current frequency at each step.

In "RF Frequency Sweep" mode and [Sweep Type > Ramp](#), the parameter automatically distributes the step intervals linearly.

To determine the step size, select the parameter [Step Linear/Step Logarithmic](#).

In "RF Combined Sweep" mode, the parameter indicates that the step intervals are linearly (straight proportional) distributed, i.e. the intervals have the same size. The frequency / level range and the [Dwell Time](#) time determine the calculated step size.

- | | |
|---------------|---|
| "Linear" | <p>The spacing depends on the selected sweep type.</p> <ul style="list-style-type: none"> • Sweep Type > Step
Takes the frequency value entered as absolute value in Hz. • Option: R&S SMAB-B28
Sweep Type > Ramp
Generates a synthesized continuous analog frequency sweep for the duration set with the parameter Sweep Time. |
| "Logarithmic" | <p>(Sweep Type > Step only)
Takes the value entered as a logarithmic value, i.e. as a constant fraction of the current frequency in %.</p> |

Remote command:

RF frequency sweep:

[:SOURce<hw>] :SWEep[:FREQuency]:SPACing on page 769

RF combined sweep: n.a.

LF frequency sweep:

[:SOURce<hw>] :LFOutput:SWEep[:FREQuency]:SPACing on page 722

Step Linear/Step Logarithmic

In "RF/LF Frequency Sweep" mode, sets the step width for the individual frequency sweep steps. The value is added at each sweep step to the current frequency.

Depending on the current [Spacing](#), you can enter either an absolute or logarithmic step width.

This parameter is only available for [Sweep Type > Step](#).

See [Section 8.2.1, "Correlating parameters in sweep mode"](#), on page 197.

"Step Linear" The step width is a constant value in Hz.

"Step Logarithmic"

The step width is determined logarithmically in %, i.e. as a constant fraction of the current frequency.

Remote command:

`[ :SOURce<hw> ] :SWEep [ :FREQuency ] :STEP [ :LINear ]`

on page 771

`[ :SOURce<hw> ] :SWEep [ :FREQuency ] :STEP:LOGarithmic`

on page 770

`[ :SOURce<hw> ] :LFOutput:SWEep [ :FREQuency ] :STEP [ :LINear ]` on page 723



`[ :SOURce<hw> ] :LFOutput:SWEep [ :FREQuency ] :STEP:LOGarithmic` on page 722

8.5.3 Level range settings

Access:

1. Select "Sweep" > "RF Level Sweep"
2. Select for example "Level Range".

Table 8-9: Range settings dialog: Examples of RF Level and RF Combined Sweep dialogs

> "Level Range"	> "Frequency / Level Range"
	

Settings

Start Level / Stop Level.....	212
Step Count.....	213
Spacing.....	213
Step.....	213
Setting Characteristics.....	213
Sweep Level Range.....	214

Start Level / Stop Level

Defines the RF level sweep range by setting the start and end values.

See [Section 8.2.1, "Correlating parameters in sweep mode"](#), on page 197.

Remote command:

RF level sweep:

`[ :SOURce<hw> ] :POWer:START` on page 748

`[ :SOURce<hw> ] :POWer:STOP` on page 748

RF combined sweep:

`[ :SOURce<hw> ] :COMBined:POWer:STARt` on page 771

`[ :SOURce<hw> ] :COMBined:POWer:STOP` on page 772

Step Count

In "RF Combined Mode", defines the number of sweeps to be executed in [Mode > Single](#).

To start the sweep cycles, select [Execute Single](#).

Remote command:

`[ :SOURce<hw> ] :SWEep:COMBined:COUNt` on page 772

Spacing

Indicates that the instrument distributes the level steps linearly (straight proportional), i.e. the level steps have the same size.

To determine the step size, use the parameter [Step](#).

Remote command:

n.a.

Step

Sets the step width for the RF level sweep in dB.

The "RF level sweep" mode increases or decreases the level value linearly by the set value.

Remote command:

`[ :SOURce<hw> ] :SWEep:POWer:STEP[:LOGarithmic]` on page 767

Setting Characteristics

Selects additional quality characteristics to optimize the behavior of the RF signal level for the specific application.

"Auto"	Sets the RF output level automatically according to the selected mode. In this mode, the instrument provides the highest dynamic range and fastest setting times. The RF signal is shortly blanked when the step attenuator is switching. For more information, refer to the specifications document.
"Uninterrupted"	Suppresses blanking at level transitions. Frequency transitions can lead to an RF level blanking due to hardware-specific switching points. This mode reduces the dynamic range of the instrument. The step attenuator is fixed.

"Strictly Monotone"

Executes signal level changes monotonically increasing or decreasing.

The setting makes sure that increasing the level value exclusively results in an increased output level, and vice versa.

All electronic switches, which can affect the monotonicity are fixed.

The operation mode is useful for applications using level searching algorithms which rely on a strictly monotonous behavior.

"Constant-VSWR"

Suppresses output impedance variations at the RF 50 Ω output connector, due to changed level settings.

"High Dyn. Uninterrupted"

R&S SMAB-K724

Provides a linear output power that is uninterrupted over a wide dynamic range.

Note: The R&S SMA100B supports this characteristic at frequencies above 52 MHz. If you select the setting at lower frequencies (≤ 52 MHz), the instrument reports a settings conflict.

"User"

Selects this entry automatically when you change one of the following parameters from the default setting:

- "Attenuator" > [Mode](#)
- "ALC" > [State](#) or [Detector Sensitivity](#)

Note: If you select another setting characteristic, the R&S SMA100B presets the modified attenuator and ALC parameters.

Remote command:

[\[:SOURce<hw>\]:POWer:LBEHaviour](#) on page 746

Sweep Level Range

Displays the RF level sweep range.

See [Section 8.2.1, "Correlating parameters in sweep mode"](#), on page 197.

Remote command:

[\[:SOURce<hw>\]:POWer:RANGe:MIN?](#) on page 754


[\[:SOURce<hw>\]:POWer:RANGe:MAX?](#) on page 754

8.5.4 Output settings

Option: R&S SMAB-B28

Access:

1. Select "Sweep" > "RF Frequency Sweep".
2. Select "Output".



Settings

V/GHz / X-Axis.....	215
Marker / User.....	215

V/GHz / X-Axis

Option: R&S SMAB-B28

Selects the mode the voltage is supplied depending on the frequency.

The R&S SMA100B supplies the signal at the V/GHz X-Axis connector.

"0,25 V/GHz" /	Supplies the voltage proportional to the set frequency, derived from
"0,5 V/GHz" /	the selected setting.
"1 V/GHz"	
"X-Axis"	Supplies a voltage range from 0 V to 10 V proportional to the frequency sweep range, set with Start Frequency/Stop Frequency .

Remote command:

[:OUTPut:FPRoportional:SCALe](#) on page 538

Marker / User

Option: R&S SMAB-B28

Selects the signal to be supplied at the Marker User1 connector.

"Marker"	Assigns a marker signal to the output. To configure and assign the marker signals, see Section 8.5.5, "Edit marker settings" , on page 215.
"User"	Intended for future use.

Remote command:

[:OUTPut:USER:MARKer](#) on page 538

8.5.5 Edit marker settings

Option: R&S SMAB-B28

Access:

1. Select "Sweep" > "RF Frequency Sweep"
2. Select "Edit Marker".

General Single	Frequency Range	Output	Edit Marker		X
Frequency 1 1.000 000 000 000 GHz	☒	Frequency 6 3.000 000 000 000 GHz	☒		
Frequency 2 4.500 000 000 000 GHz	☒	Frequency 7 1.000 000 000 000 GHz	☐		
Frequency 3 2.100 000 000 000 GHz	☐	Frequency 8 1.000 000 000 000 GHz	☐		
Frequency 4 1.000 000 000 000 GHz	☐	Frequency 9 1.000 000 000 000 GHz	☐		
Frequency 5 1.000 000 000 000 GHz	☐	Frequency 10 1.000 000 000 000 GHz	☐		
Marker Polarity Normal		Active Marker 3 - 2100000000.00 Hz			

You can define up to 10 markers, and assign one of them to the output at a time. When the sweep run has reached the marker frequency, the R&S SMA100B activates the marker signal and supplies it at the Marker User1 connector. The duration of the active signal corresponds to the dwell time of a step.

Settings

Frequency x.....	216
State.....	216
Marker Polarity.....	217
Active Marker.....	217

Frequency x

Sets the frequency that the selected marker indicates.

When the specified value is used, the polarity of the marker signal changes, as selected with the parameter .

Remote command:

[:SOURce<hw>] :SWEep [:FREQuency] :MARKer<ch>:FREQuency on page 775

State

Enables the selected marker.

A marker signal at the output connector marks the moment the specified frequency values is used.

Remote command:

[:SOURce<hw>] :SWEep [:FREQuency] :MARKer<ch>:FState on page 776

Marker Polarity

Sets the polarity of the marker signal.

The duration of the active signal is equal to the dwell time of a step.

Remote command:

`[ :SOURce<hw> ] :SWEep:MARKer:OUTPut:POLarity` on page 775

Active Marker

Boosts a specific marker signal so that it is output with higher voltage than all other markers.

Remote command:

`[ :SOURce<hw> ] :SWEep [ :FREQuency ] :MARKer:ACTive` on page 775

8.6 List mode settings

The "List Mode" dialog contains all the functions and settings for creating and handling lists with RF frequency/level pairs including the corresponding dwell times for generating the RF signal based on these values.

Access:

- Select "Sweep" > "List mode".

The dialog contains parameters for configuring the list mode processing, entering list mode data and transferring data files from or to the instrument.

The remote commands required to define these settings are described in [Section 15.18.8, "SOURce:LIST subsystem"](#), on page 723.

- [General settings](#).....218
- [List mode data settings](#).....220
- [Import/export settings](#).....221

8.6.1 General settings

Access:

- Select "Sweep" > "List mode".

The screenshot shows a dialog box titled 'List Mode Data' with a close button (X) in the top right corner. The 'General' tab is active, indicated by an orange border. Inside the dialog, there are several controls: a 'State' field with a value of '0' and a slider; a 'Mode' dropdown menu set to 'Auto'; a 'Dwell Time Mode' dropdown menu set to 'Global'; and a 'Global Dwell Time' field showing '10.000 ms'. At the bottom left, there is a 'Reset' button with a circular arrow icon.

In the "General" tab, you can configure the trigger and dwell time modes for list processing and activate signal generation.

Settings

State.....	218
Current Index.....	218
Mode.....	219
Dwell Time Mode.....	219
Global Dwell Time.....	219
Trigger Slope.....	219
Reset.....	220
Execute Single.....	220

State

Activates the list mode and processes the currently selected list.

Note: Active RF frequency, RF level or RF combined sweep modes deactivate the LF sweep or List mode and vice versa.

Remote command:

[:SOURce<hw>] :FREQuency:MODE on page 701

Current Index

Sets the list index for list processing in "Step" mode. In the other modes, the index indicates the current step.

Remote command:

[:SOURce<hw>] :LIST:INDEX on page 728

Mode

Selects the mode for list processing.

See [Section 8.1, "Signal generation and triggering in the sweep and list modes"](#), on page 189.

"Auto" Generates the signal by processing the frequency/level value pairs of the list from the beginning to the end.
The list steps are performed automatically, controlled by the dwell time. If you switch from any mode to "Auto", signal generation always starts at the top of the list.

"Single / Extern Single"

Generates the signal by processing the frequency/level value pairs of the list once from the beginning to the end after a trigger event.
The list steps are performed automatically, controlled by the dwell time. If one cycle is completed, the instrument waits for the next trigger event.

"Step / Extern Step"

Generates the signal by processing the frequency/level value pairs of the list step-by-step, manually triggered.

Remote command:

`[ :SOURce<hw> ] :LIST:TRIGger:SOURce` on page 730

`[ :SOURce<hw> ] :LIST:MODE` on page 729

Dwell Time Mode

Selects either variable dwell times or a fixed dwell time to perform signal generation in list mode.

"Global" Uses the same dwell time for all lists steps, set with [Global Dwell Time](#).

"From List" Uses the dwell times from the list.
You can define the dwell time for each frequency/level value pair individually, see [Section 8.7, "List data editor"](#), on page 223.

Remote command:

`[ :SOURce<hw> ] :LIST:DWELL:MODE` on page 726

Global Dwell Time

Sets the dwell time for [Dwell Time Mode](#) > "Global".

Note: In case of considerable overrun conditions, the R&S SMA100B turns off the list mode.

See also ["Dwell time"](#) on page 201.

Remote command:

`[ :SOURce<hw> ] :LIST:DWELL` on page 726

Trigger Slope

For "Mode = Extern Step/Single", selects the polarity of the active slope of an applied instrument trigger.

Trigger signal is expected at the Inst Trig connector.

"Positive" The rising edge of the trigger signal triggers the instrument.

"Negative" The falling edge of the trigger signal triggers the instrument.

Remote command:
[:SOURce]:INPut:TRIGger:SLOPe on page 710

Reset
Resets the list to the starting point.


Remote command:
[:SOURce<hw>]:LIST:RESet on page 732

Execute Single
Manually starts list processing in "Single" mode.

Remote command:
[:SOURce<hw>]:LIST:TRIGger:EXECute on page 730

8.6.2 List mode data settings

- Access:
- 1. Select "Sweep" > "List mode".
 - 2. Select "List Mode Data".



This dialog contains the parameters required for creating and editing lists, activating the learning function and selecting the list processing mode.

Settings

List Mode Data.....	220
Edit List Mode Data.....	221
List Range from/to.....	221

List Mode Data
Accesses the standard "Select List" dialog for selecting, creating and editing a list file. The currently loaded file is indicated.

You can create data lists with the internal editor or import externally created files, see "Creating and handling lists" on page 200.

Remote command:
[:SOURce<hw>]:LIST:CATalog? on page 731
[:SOURce<hw>]:LIST:SElect on page 733
[:SOURce<hw>]:LIST:DELeTe on page 731
[:SOURce<hw>]:LIST:DELeTe:ALL on page 732

Edit List Mode Data

Opens the build-in table editor to define a new list data table or edit an existing one.

See also: [Section 8.7, "List data editor"](#), on page 223.

You find this function also in standard file select dialog, accessed via [List Mode Data](#).

List Range from/to

Defines an index range in the current list by setting the start and stop index.

The instrument generates the signal with the values of the selected index range and ignores all other list entries.

Remote command:


[\[:SOURce<hw>\]:LIST:INDEX:START](#) on page 728

[\[:SOURce<hw>\]:LIST:INDEX:STOP](#) on page 728

8.6.3 Import/export settings

Access:

1. Select "Sweep" > "List Mode".
2. Select "List Mode Data" > "Im-/Export".



The "Im-/Export" dialog provides the parameters for importing or exporting files with user data in standard ASCII *.txt or *.csv file format.

The table separators and the decimal floating point numbers are customizable.

Settings

Mode.....	222
ASCII File Settings.....	222
Select (ASCII) Source/Select (ASCII) Destination.....	222
Select Source/Select ASCII Destination.....	223
Import / Export.....	223

Mode

Selects import or export of a data list file. The provided parameters vary according to the selected mode.

Remote command:

[:SOURce<hw>] :LIST:DEXChange:MODE on page 735
 [:SOURce<hw>] :CORRection:DEXChange:MODE on page 697
 [:SOURce<hw>] :PULM:TRAIIn:DEXChange:MODE on page 644

ASCII File Settings

Defines the format and the separators of the associated data file.

"Extension" Selects *.csv or *.txt format.
 "Decimal Sets "Point" (dot) or "Comma" as the decimal separator used in the
 Point" ASCII data with floating-point numerals.
 "Column Separator" Sets the separator between the columns in an ASCII table.
 Available are: "Tab", "Semicolon", "Comma" or "Space".

Remote command:

[:SOURce<hw>] :LIST:DEXChange:AFILe:EXTension on page 734
 [:SOURce<hw>] :LIST:DEXChange:AFILe:SEParator:DECimal on page 734
 [:SOURce<hw>] :LIST:DEXChange:AFILe:SEParator:COLumn on page 734
 [:SOURce<hw>] :CORRection:DEXChange:AFILe:EXTension on page 695
 [:SOURce<hw>] :CORRection:DEXChange:AFILe:SEParator:DECimal
 on page 696
 [:SOURce<hw>] :CORRection:DEXChange:AFILe:SEParator:COLumn
 on page 696
 [:SOURce<hw>] :PULM:TRAIIn:DEXChange:AFILe:EXTension on page 645
 [:SOURce<hw>] :PULM:TRAIIn:DEXChange:AFILe:SEParator:DECimal
 on page 645
 [:SOURce<hw>] :PULM:TRAIIn:DEXChange:AFILe:SEParator:COLumn
 on page 645

Select (ASCII) Source/Select (ASCII) Destination

In "Mode > Import", access the file select dialog that provides standard file handling functions.

Where:

- "Select ASCII Source": defines the file to be loaded (imported)
- "Select ASCII Destination": selects the filename under that the loaded file is saved

Remote command:

[:SOURce<hw>] :LIST:DEXChange:AFILe:CATalog? on page 733
 [:SOURce<hw>] :LIST:DEXChange:AFILe:SElect on page 734
 [:SOURce<hw>] :CORRection:DEXChange:AFILe:CATalog? on page 695
 [:SOURce<hw>] :CORRection:DEXChange:AFILe:SElect on page 696
 [:SOURce<hw>] :PULM:TRAIIn:DEXChange:AFILe:CATalog? on page 645
 [:SOURce<hw>] :PULM:TRAIIn:DEXChange:AFILe:SElect on page 646

Select Source/Select ASCII Destination

In "Mode > Export", access the file select dialog that provides standard file handling functions.

Where:

- "Select Source": selects the file to be exported
- "Select ASCII Destination": defines the filename and the file path for the exported file

Remote command:

[:SOURce<hw>] :LIST:DEXChange:SElect on page 735
 [:SOURce<hw>] :CORRection:DEXChange:SElect on page 697
 [:SOURce<hw>] :PULM:TRAIIn:DEXChange:SElect on page 646

Import / Export

Imports or exports the selected data list file, depending on the current mode.

Remote command:

[:SOURce<hw>] :LIST:DEXChange:EXECute on page 735
 [:SOURce<hw>] :CORRection:DEXChange:EXECute on page 696
 [:SOURce<hw>] :PULM:TRAIIn:DEXChange:EXECute on page 646

8.7 List data editor

The "List Mode" dialog provides a build-in list editor for defining the corresponding frequency and level value pairs. Prerequisite to define list mode data is that you have selected a file.

Access:

- "Sweep" > "List Mode" > "List Mode Data" > "Edit List Mode Data"

The editor for list mode provides a table with RF frequency and power values, a column for defining variable dwell times, and standard navigation functions.

Edit List Mode Data
rf_list

	Frequency (Hz)	Power (dBm)	Dwell Time (s)
0	540 000 000.000	-5.00	0.010 000
1	4 800 000 000.000	-10.00	0.010 000
2	4 200 000 000.000	-17.00	0.010 000
3	3 600 000 000.000	-25.00	0.010 000
4			

Select Row

Edit

Save As ...

Save

The remote commands required to define the list mode data are described in [Section 15.18.8, "SOURce:LIST subsystem"](#), on page 723.

- All columns in a row must contain values. Cells with missing values are therefore filled automatically, using the value of the previous row.

Once you enter a value, the editor automatically adds preset values in the other columns. This functionality protects against data loss, otherwise incomplete rows are lost when saving. You can simply override these values.

If you use **global dwell time in list mode**, consider also that the instrument uses the value set with [Global Dwell Time](#) for all list steps and not the values from the list.

Since the table and navigation functions can be assumed to be known, the following description contains a brief overview.

Settings:

Frequency (Hz).....	224
Power (dBm).....	225
Dwell Time (s).....	225
Data handling keys.....	225
L Select Row.....	225
L Edit.....	225
L Save As/Save.....	225
Fill.....	225

Frequency (Hz)

Sets the frequency values for list mode operation.

Remote command:

[:SOURce<hw>] :LIST:FREQuency on page 727

Power (dBm)

Sets the level value for the selected frequency in list mode.

Remote command:

[:SOURce<hw>] :LIST:POWer on page 729

Dwell Time (s)

Sets the dwell time values for the frequency power value pairs in list mode operation.

Remote command:

[:SOURce<hw>] :LIST:DWELL:LIST on page 727

Data handling keys

Standard functions for file and data handling.



Select Row ← Data handling keys

Selects a row for editing.

Edit ← Data handling keys

Enables you to insert, or delete a row or ranges within the table, and provides access to a dialog for automatic filling, see "Fill..." on page 104.

Save As/Save ← Data handling keys

Saves the table in a file with user-defined name and predefined file extension. To save a copy or create a file, use the "Save as" function.

Fill...

Provides parameters for filling a table automatically with user-defined values.

From	0	Range	4
Column To Fill	Frequency /Hz		
Start Value	2.000 000 000 000 GHz	End Value	2.600 000 000 000 GHz
Increment Value	200.000 000 000 MHz		
☒ Fill			

To fill the table, select "Fill".

Note: Once you enter a value or fill a column, the editor automatically adds preset values in the other columns. This functionality protects against data loss, otherwise incomplete rows will be lost when saving. You can simply override these values.

"From / Range"

Defines the start line and number of lines to be filled.

"Column To Fill"

Selects, if the column is filled up with frequencies in Hz, levels in dBm or dwell times in s.

"Start Value / End Value"

Sets the start value for frequency, level or dwell time. The end value is read only and depends on the increment value and the range.

"Increment Value"

Determines the step size.

"Fill"

Fills the column specified in "Column To fill".

8.8 How to generate a signal in list or sweep mode

This section shows you how to configure a varying RF output signal for both, the list and sweep modes.

To configure the frequency sweep signal

- For a step-by-step description, see [Section 3.3.2, "Generating an RF frequency sweep signal"](#), on page 46.

Example: Fast changing frequency and level settings in list mode

The following example shows you how to generate an amplitude modulated RF signal based on list mode data.

General workflow

Since any change of the hardware settings or list entries can affect the RF signal characteristics directly, we recommend that you proceed as follows:

1. Configure the modulation settings.
Activate the RF signal.
2. Wait until the hardware settings have settled.
3. Create a list file.
4. Configure the list mode.
5. Activate list mode.

To configure amplitude modulation and switch RF on

1. Press [Preset] to start from an initial state.

2. Select "Modulation" > "Amplitude Modulation > On".
3. Select "Level" > "RF ON" to activate RF signal generation.

To create list mode data

1. Select "Sweep" > "List Mode".
2. In the "List Mode Data" tab, select "List Mode Data > New".
3. Enter the filename `ListMode_Test` for the data list and confirm with "Ok".
The instrument creates a file and stores it in the `/var/user/` directory.
4. Select "Edit List Mode Data".
5. Enter the first values "Frequency > 2", "Power > 0" and "Dwell > 2".
6. Enter further frequency, power and dwell time values in the same way.
7. Select "Save" and close the dialog.

To configure the list mode and start signal generation

1. In the "General" tab, select "List Mode > Auto".
2. Select "Dwell Time Mode > From List".
3. Switch state to "On".
4. Select "General > State > On".

The instrument continuously generates an amplitude-modulated RF signal whose frequency and level values change according to the dwell times, as defined in the list.

With active list mode, the generator displays no frequency and level values in the status bar, but you can check the following parameters.

- In the list mode dialog, the current index indicates the steps of the signal generation.
- In remote control mode, you can query:
 - The current state with `[ :SOURCE<hw> ] :LIST:RUNNING?`
 - Current parameters with the commands `FREQ?`, `POW?` and `LIST:DWEL?`.

9 Improving level performance

To adjust the RF output signal to specific needs in your application, the R&S SMA100B offers different functions:

- **Attenuator**

The R&S SMA100B is equipped with a step attenuator that enables you to vary the amplitude of the RF signal in a wide range. It is characterized by low VSWR (voltage standing wave ratio) over the full level and frequency range, and provides highest level accuracy and noise suppression.

See ["About the attenuator"](#) on page 228.

- **Automatic Level Control (ALC)**

The automatic level control system provides stable RF signals with highest absolute level accuracy over temperature and time.

See ["About ALC"](#) on page 232.

- **User correction (UCOR)**

The user correction function allows you to compensate frequency responses of external setups (e.g. losses of cables) and achieve a stable input signal over frequency directly at the DUT.

See ["About UCOR"](#) on page 237.

- **Power sensors**

The R&S SMA100B has excellent absolute level accuracy. Since a DUT is rarely connected directly to the generator, but with cables or other components, the reference level shifts from the RF output to the DUT. To calibrate this level with high accuracy, i.e. in the tenth dB range, you can connect an R&S NRP power sensor to the generator. The power sensor transmits its readings to the generator, which indicates these measurement results in the display. Thus you can adjust the RF output power of the generator until you reach the target level at the DUT.

See [Section 9.4, "Using power sensors"](#), on page 249

9.1 Attenuator

About the attenuator

The step attenuator is either an electronic or a mechanical device. Instruments with frequency options up to 20 GHz use an electronic step attenuator, providing fast and wear free level settings. Instruments capable to generate higher frequency signals use mechanical step attenuators. Depending on the frequency range and the installed high-power option, both types of step attenuators can be built in, and you can select the type to be used below 20 GHz.

To achieve a consistent level setting behavior for all frequencies, the mechanical step attenuator is used even for lower frequencies while the electronic one is disregarded. Especially in frequency ramp sweep mode, which requires a consistent level adjustment behavior, the R&S SMA100B automatically activates the mechanical step attenuator and disables the selection of the electronic step attenuator.



However, option R&S SMAB-B36S does not support using the mechanical attenuator below 20 GHz.

According to the requirements of your application, you can select different attenuator characteristics.

The following are examples of test requirements and the corresponding configuration:

- Automatic configuration
Select standard operation mode ("Auto"), in which the generator adjusts the attenuation of the RF output signal automatically.
- DUT tests under low signal to noise conditions
Low output power is suitable to test the behavior of a DUT under low signal to noise conditions.
- Uninterrupted level settings with constant VSWR
A fix attenuation value is required for obtaining uninterrupted level settings with constant VSWR.
The configuration "RF Off Mode > Unchanged" ensures that constant VSWR is maintained if you turn the signal off and on again.
- Noise sensitive applications
The parameter "RF OFF Mode > Full Attenuation" sets maximum attenuation and thus suppresses noise when you turn off the RF signal.

9.1.1 Attenuator settings

Access:

- Select "Level" > "Level > Attenuator".

Mode	Auto	RF OFF Mode	Full Attenuation
Step Attenuator below 20GHz	Electronic		
Level Range	-30.66 ... -25.96dBm		

In the "Attenuator" dialog, you can select the operating mode of the electronic step attenuator.

The remote commands required to define these settings are described in [Section 15.14, "OUTPut subsystem"](#), on page 536 and [Section 15.18.12, "SOURce:POWER subsystem"](#), on page 740.

Settings

Mode.....	230
Step Attenuator below 20 GHz.....	230
Level Range.....	230
RF OFF Mode.....	230
Readjust.....	231

Mode

Determines the operating mode of the step attenuator.

"Auto"	Adjusts the attenuator settings automatically.
"Fixed"	Fixes the attenuator and amplifier paths for the current RF level and provides signal output with constant output VSWR. The resulting level range is indicated under "Level Range" on page 230.

Remote command:

[:OUTPut<hw>:AMODE](#) on page 537

Step Attenuator below 20 GHz

Without option R&S SMAB-B36S only

Selects the type of the step attenuator for frequencies up to 20 GHz.

This setting depends on the frequency range and the installed high power options, see ["About the attenuator"](#) on page 228.

"Mechanical"	Selects that the R&S SMA100B uses the mechanical step attenuator over the whole frequency range. The mechanical attenuator is used even for lower frequencies, to achieve a consistent level setting behavior for all frequencies. The electronic step attenuator is disregarded. Sweep Type > Ramp also requires a consistent level adjustment behavior. Therefore, the R&S SMA100B automatically activates the mechanical step attenuator and disables the selection of the electronic step attenuator.
"Electronic"	Selects that the R&S SMA100B uses the electronic attenuator as long as the frequency is below 20 GHz, providing benefits regarding setting time and wear.

Remote command:

[\[:SOURce<hw>\]:POWer:ATTenuation:PATTenuator](#) on page 745

Level Range

Shows the interruption-free range of the level that you can use in the selected mode.

Remote command:

[:OUTPut<hw>:AFIXed:RANGe:LOWer?](#) on page 539

[:OUTPut<hw>:AFIXed:RANGe:UPPer?](#) on page 539

RF OFF Mode

Determines the state of the step attenuator, when the RF signal is switched off.

The setting is not affected by an instrument preset ([Preset] key or *RST) and the "Save/Recall" function. It is reset only by factory preset.

"Unchanged" Freezes the setting of the step attenuator.
Use this mode if a constant VSWR (Voltage Standing Wave Ratio) is required.

"Full Attenuation"
Switches to the maximum attenuation.
Use this mode for applications that require a high level of noise suppression.

Remote command:

`[ :SOURce<hw> ] :POWer:ATTenuation:RFOff:MODE` on page 745

Readjust

Recalculates and adjusts the internal switch positions of the RF chain according to the current level.

The R&S SMA100B provides the "Readjust" function when you change one of the following parameters from the default setting:

- "RF Level" > [Setting Characteristics](#)
- "Attenuator" > [Mode > FixedSetting Characteristics](#)

In "External ALC" mode, "Readjust" triggers the detector offset zeroing, see [Section 9.2.2, "How to set up an external ALC"](#), on page 235.

Remote command:

`[ :SOURce<hw> ] :POWer:ALC:SONCe` on page 744

9.1.2 Reverse power protection

The instrument is equipped with a reverse power protection circuit.

The reverse power protection is tripped when the power of signals reflected from the load or external signals applied to the RF output get too high. A relay opens and interrupts the internal connection to the RF output. This condition is indicated in the status bar by the "Overload" status message.

Overload

If an "Overload" status message is indicated in the status bar, perform the following:

- Remove the cause for the overload
- Press the [RF on/off] key to reset the overload protection

The RF input is activated when the overload protection is reset.

Remote command:

`:OUTPut<hw>:PROTection:TRIPped?` on page 539

`:OUTPut<hw>:PROTection:CLEar` on page 539

9.2 Automatic level control (ALC)

The R&S SMA100B is equipped with an automatic level control (ALC) unit to obtain best RF level accuracy.

About ALC

ALC is an adaptive control system to stabilize the RF output level. It continuously monitors the current level and adjusts it to keep a steady state over temperature and time.

ALC is active in almost all applications by default. However, when **pulse modulation** with short pulses is used, the ALC uses table-based level settings with table values depending on the pulse width.

Also note that ALC can detect incorrect values in **multi-transmitter** test setups. If multiple generators are coupled, reverse power can affect the ALC readings, which leads to an incorrect RF output power.

ALC states and their effects

The following description basically explains the ALC states and their principle of operation:

- "Auto"
Adjusts the output level to the operating conditions automatically. ALC is active in almost all operating modes.
- "On"
Activates the internal level control permanently, regardless of the operating conditions.
Note: This mode is not useful for pulse modulation with narrow pulses and low repetition rates, since the automatic level control cannot settle in time. Set ALC "Auto" or "Table & On" instead.
- "Off (Table)"
Deactivates internal level control loop. The instrument calculates every level setting using the attenuation values from the internal (ALC) table. Level attenuation between two table values is done with linear interpolation. This mode enables you to perform a fast and strictly monotonic, but not quite as precise level adjustment.
- "Table & On"
Starts with the associated value of the internal level table and then activates the automatic level control. This mode achieves maximum level accuracy and fast setting times.
If pulse modulation is applied, this mode ensures fast level settings even with narrow pulses at low repetition rate.
- "External ALC"
Activates the external ALC detector mode.
This setting enables you to control the RF signal level at a specific point in the signal chain following the signal generator output with high accuracy.

The R&S SMA100B displays the level control setting as a status message in the info line.

About external ALC

Some applications require precise control of the RF signal level at a specific point in the signal chain following the signal generator output.

For this purpose, the "External ALC" function of the R&S SMA100B enables you to close the level control loop of the instrument using an external level detector diode with negative polarity and a coupler device.

The diode rectifies the signal received from the coupler and loops it back to the R&S SMA100B to control the ALC system.

As shown in [Figure 9-1](#), you must apply the feed back signal at the modulation input connector Ext1.




Figure 9-1: External ALC setup


- 1 = RF 50 Ω output connector
- 2 = Leveled output
- 3 = Negative polarity detector diode
- 4 = Ext1 input connector

How to: see [Section 9.2.2, "How to set up an external ALC"](#), on page 235.

9.2.1 ALC settings

Access:

► Select "Level" > "Automatic Level Control".



In the "ALC" dialog, you can configure the settings for the automatic level control of the RF signal to achieve optimal accuracy.

The remote commands required to define these settings are described in [Section 15.18.12, "SOURce:POWer subsystem"](#), on page 740.

Settings

State.....	234
Detector Sensitivity.....	234
Detector Coupling Factor.....	235
Required Generator Level.....	235

State

Selects the internal level control mode.

"Auto"	Selects the most appropriate ALC mode automatically.
"On"	Activates ALC permanently.
"Off (Table)"	Controls the level using the attenuation values of the internal ALC table.
"Table & On"	Starts with the attenuation setting from the internal ALC table and continues with automatic level control.
"External ALC"	Activates the external detector ALC mode.

For further details on the individual settings, an overview of the functionality and details on what is to be considered, see ["ALC states and their effects"](#) on page 232.

Remote command:
[\[:SOURce<hw>\]:POWer:ALC\[:STATe\]](#) on page 743

Detector Sensitivity

Determines the path of the internal level detector.

The level detector of the ALC has multiple paths distinguished by their sensitivity.

"Auto" Selects the detector path automatically, according to the given level. This mode is the recommended operation mode.

"Fix" Fixes the last set sensitivity setting.

Remote command:

`[ :SOURce<hw> ] :POWer:ALC:DSensitivity` on page 743

Detector Coupling Factor

Option: R&S SMAB-K726

Sets the attenuation value for the external RF coupler of the external ALC.

See [Section 9.2.2, "How to set up an external ALC"](#), on page 235

Remote command:

`[ :SOURce<hw> ] :POWer:ALC:EDETector:FACTor` on page 744

Required Generator Level

Option: R&S SMAB-K726

Sets the maximum power level at the RF output required to compensate external coupler and cable losses of the external ALC.

See [Section 9.2.2, "How to set up an external ALC"](#), on page 235

Remote command:

`[ :SOURce<hw> ] :POWer:ALC:EDETector:LEVel` on page 744

9.2.2 How to set up an external ALC

Prerequisites

- R&S SMAB-K726
- Negative polarity RF detector diode with adequate frequency range
- RF coupler with adequate frequency range

Setting up an external ALC control loop


To set up an external ALC control loop, connect the detector diode and coupler as follows, see also ["About external ALC"](#) on page 232:

1. Connect the coupled output to the detector RF input.
2. Connect the detector output to the R&S SMA100B modulation input connector Ext1.

Setting the external ALC parameters

To configure the external ALC settings:

1. Select "Level" > "Automatic Level Control" > "ALC".
2. Select "State" > "External ALC" to activate the external detector ALC mode.



The R&S SMA100B displays the parameters required for the settings in the dialog.

3. Set "Detector Coupling Factor", e.g. "16 dB", to determine the attenuation value of the RF coupler.
4. Set "Required Generator Level", e.g. "20 dBm" to configure the maximum power level at the RF output.

This value corresponds to the losses of cabling and coupler to compensate.

5. In the "RF Level" tab, select "Readjust" to execute the instrument detector offset compensation.
This function recalculates and compensates the internally detected offset voltages.
6. Set "RF" > "State" > "On".

After turning on the RF output, the system levels the coupler output power to the value set in the instrument level display

9.3 User correction

The R&S SMA100B supports a correction function to compensate external losses, caused, for example, by the RF cable, to achieve a precise target input level at the DUT.

The signal at the RF outputs of the R&S SMA100B is flat. However, the DUT is usually not connected directly to the outputs of the instrument but rather via connecting cables. Components like cables, power combiners, switches or mixers can affect the signal flatness at the DUT input.




Figure 9-2: Effect of external losses on the signal flatness at the DUT input

DUT = Device under test

Components = Designation of all components between the measurement equipment and the DUT, e.g. cables

1 = Flat signal at the outputs of the R&S SMA100B

2 = Signal received at the DUT, incl. the external losses

About UCOR

User correction (UCOR) is a method that determines the external level loss of the RF output signal over a frequency range in advance, see [Figure 9-3](#).

The difference between the generator output level and the level at the DUT determines the correction value at the respective frequency. Alternatively, the attenuation characteristics over a certain frequency range of, for example, RF cables are also specified in the associated specifications document.

For more information, refer to the specifications document.




Figure 9-3: Understanding the principle of user correction

DUT = Device under test

Components = Designation of all components between the measurement equipment and the DUT, e.g. cables

PS = Power sensor, e.g. R&S NRP, connected at the DUT's input and the USB connector of the R&S SMA100B

1 = Power sensor measures the level over a frequency range, where the collected values correspond to the losses caused by the components between the R&S SMA100B and the DUT

- 2 = Obtain the correction data by inverting the collected data; load the correction parameters in the R&S SMA100B
- 3 = In the R&S SMA100B, the RF signal is pre-processed with the correction values so that the signal at the outputs is the inverted version of the external losses
- 4 = Received at the DUT input, the pre-processed signal if flat

With active **UCOR**, the generator adds the correction value internally and thus increases the output level by exactly the amount of the loss between its output and the DUT. For frequencies which are not contained in the list, the level correction is calculated by interpolation of the closest correction values.

Possible ways for configuring the user correction values

You can configure correction values in the following ways:

- **Internally**

- Use the built-in table editor in the "UCOR > Edit User Correction Data" dialog. Once defined, user correction values can be saved in a file. Files with correction data can be exported, for example, to exchange configuration between instruments or to modify the file content with an external program and reload them again.
- Using the corresponding remote-control commands. Note that you have to create a user correction file first.

- **Externally**

Create a file with correction values as a CSV file with Microsoft Excel, with a Notepad or a similar tool and save it with the predefined extension. Transfer the file to and load it into the instrument.

UCOR file format

Files containing correction data are simple files in text or comma-separated value (CSV) file format. The filename is user-definable; the file extension is *.ucor.

The file contains a list of correction values, one row per frequency and correction value pair; a new line indicator separates the correction values.

For file handling, use the standard functions in the "File Manager", see [Section 12.9, "Using the file manager"](#), on page 348.

Collecting correction data

To fill the frequency and power values in the correction table, use one of the following options:

- **Manually**, row by row.
- Fill the table **automatically** with linearly interpolated values, calculated from value range and step size.
- Acquire the real frequency response characteristics of the used component with the **R&S NRP power sensor**, see [Understanding the principle of user correction](#).

Using a power sensor for frequency response measurements

Consider the following when using R&S NRP power sensors to measure the correction values:

- Measure the level directly at the input of the DUT.
- Use the internal correction functions of an R&S NRP power sensor to increase the measurement accuracy.
- Use S-parameter to consider the impact of any two-port device like an adapter between the signal generator and the sensor input.

For information on the various possibilities of interoperability between Rohde & Schwarz power sensors and Rohde & Schwarz signal generators, see the application note [1GP141](#).



Interactions and characteristics

You can enable user correction in all operating modes.

The RF output level (Level_{RF}) is the sum of the level value and the correction for the particular frequency:

$$\text{Level}_{\text{RF}} = \text{"Status bar > Level"} + \text{"UCOR"}$$


If enabled, the R&S SMA100B indicates user correction by the "Lev Ucor" icon in the "Level" tile.

9.3.1 User correction settings

Access:

1. Select "Level" > "User Correction".
2. If you already have created a file with user correction data:
 - a) Select "UCOR Data" > navigate to the file "*.uco" > "Select".
 - b) Proceed with [step 4](#).
3. If you need to create a file:
 - a) Select "UCOR Data" > "New".
 - b) Enter the filename `UCOR_Data` and confirm with "Ok".
 - c) Choose the file and confirm with "Select".
 - d) Select "Edit UCOR Data".
 - e) To fill the user correction data table, proceed as described in [Section 9.3.2, "Ucor data editor"](#), on page 241.
4. Select "UCOR" > "State" > "On".

5. Select "Level" > "RF State" > "On".



The "UCOR" dialog contains all settings for creating and handling files with user-defined level correction values.

The remote commands required to define these settings are described in [Section 15.18.3, "SOURce:CORRection subsystem"](#), on page 689.

Settings

State.....	240
User Correction.....	240
UCOR Data.....	240
Edit UCOR Data.....	241
UCOR Info.....	241

State

Enables user correction.

The R&S SMA100B displays the status icon "Lev Ucor" in the "Level" panel.

Remote command:

[\[:SOURce<hw>\]:CORRection\[:STATe\]](#) on page 694

User Correction

Indicates the corrected level value for a specific frequency point.

Remote command:

[\[:SOURce<hw>\]:CORRection:VALue?](#) on page 693

UCOR Data

Opens the standard "File Select" function of the instrument. The provided navigation possibilities in the dialog are self-explanatory.

Files with user correction values are files with predefined file extension *.ucor. If you select a file, the dialog indicates the filename.

You can create the file internally in the table editor or externally.

- To select an existing file, select "Select List", navigate to your user correction file and select the file.

- Use the general editor function to create a file or to edit an existing one.
- Use the standard file manager function to load externally created files to the instrument.

Remote command:

`[ :SOURce ] :CORRection:CSET:CATalog?` on page 694

`[ :SOURce<hw> ] :CORRection:CSET [ :SElect ]` on page 693

`[ :SOURce ] :CORRection:CSET:DElete` on page 695

Edit UCOR Data

Opens the build-in table editor to define a new correction table or edit an existing one.

See also:

- [Section 9.3.2, "Ucor data editor"](#), on page 241
- ["Fill..."](#) on page 104
- [Section 9.3.3, "Fill with sensor"](#), on page 244

UCOR Info

Opens a window with information on the user correction file.

The window shows the metadata of the file and the output level parameters that are relevant for user correction.

Remote command:

n.a.

9.3.2 Ucor data editor

The "User Correction" dialog provides a build-in list editor for defining the corresponding value pairs. Prerequisite to define correction values is that you have selected a file.

Access:

- "Level" > "User Correction" > "Edit UCOR Data".

	Frequency (Hz)	Correction Value (dB)
2	1 562 000 000.00	10.55
3	1 563 000 000.00	10.07
4	1 564 000 000.00	9.59
5	1 565 000 000.00	9.11
6		

The editor for user correction data provides a table with RF frequency and level values and standard navigation functions.

The remote commands required to define the user correction data are described in [Section 15.18.3, "SOURce:CORRection subsystem"](#), on page 689.



All columns in a row must contain values. Cells with missing values are therefore filled automatically, using the value of the previous row.

Once you enter a value, the editor automatically adds preset values in the other columns. This functionality protects against data loss, otherwise incomplete rows are lost when saving. You can simply override these values.

Since the table and navigation functions can be assumed to be known, the following description contains a brief overview.

Settings:

Frequency (Hz).....	243
Correction Value (dB).....	243
User correction data handling keys.....	243
L Select Row.....	243
L Edit.....	243
L Fill with Sensor.....	243
L Save As/Save.....	243
Fill.....	243

Frequency (Hz)

Sets the frequency for level correction.

Remote command:

[\[:SOURce<hw>\]:CORRection:CSET:DATA:FREQuency](#) on page 692

Correction Value (dB)


Sets the level correction value for the selected frequency.

Remote command:

[\[:SOURce<hw>\]:CORRection:CSET:DATA:POWer](#) on page 692

User correction data handling keys

Standard functions for handling user correction data and files.

**Select Row ← User correction data handling keys**

Selects a row for editing.

Edit ← User correction data handling keys

Enables you to insert, or delete a row or ranges within the table, and provides access to a dialog for automatic filling, see ["Fill..."](#) on page 104.

Fill with Sensor ← User correction data handling keys

Opens a dialog to configure the automatic filling of user correction data with an R&S NRP power sensor.

See [Section 9.3.3, "Fill with sensor"](#), on page 244

Save As/Save ← User correction data handling keys

Saves the table in a file with user-defined name and predefined file extension. To save a copy or create a file, use the "Save as" function.

Fill...

Provides parameters for filling a table automatically with user-defined values.

From 0	Range 4
Column To Fill Frequency /Hz	
Start Value 2.000 000 000 000 GHz	End Value 2.600 000 000 000 GHz
Increment Value 200.000 000 000 MHz	
☒ Fill	

To fill the table, select "Fill".

Note: Once you enter a value or fill a column, the editor automatically adds preset values in the other columns. This functionality protects against data loss, otherwise incomplete rows will be lost when saving. You can simply override these values.

"From / Range"

Defines the start line and number of lines to be filled.

"Column To Fill"

Selects, if the column is filled up with frequencies in Hz, levels in dBm or dwell times in s.

"Start Value / End Value"

Sets the start value for frequency, level or dwell time. The end value is read only and depends on the increment value and the range.

"Increment Value"

Determines the step size.

"Fill"

Fills the column specified in "Column To fill".

9.3.3 Fill with sensor

The fill with sensor function requires that you have connected a power sensor and also selected a file for user correction data before.

See:

- [Section 9.4, "Using power sensors"](#), on page 249
- ["To create user correction data with an R&S NRP and the R&S SMA100B"](#) on page 314

Access:

1. Select "Level" > "User Correction".
2. Select "UCOR Data > navigate to the file *.ucor > Select".

3. Select "Edit UCOR Data > Fill With Sensor...".

Fill User Correction Data with Sensor

List To Fill

ucor

Sensor

3: NRP33-SN-V 999006

Config ...

Include Zeroing

☒

Execute

Generator Settings used for Measurement

Modulation

Off (CW)

Amplitude

-30.00 dBm

Offset

0.00 dB

UCOR Reference Level

-30.00 dBm

This dialog contains parameters for filling a table automatically with sensor readings.

i

To fill the table, select "Execute".

For information on power sensors and how to use them, see [Section 9.5, "Improving the RF signal performance"](#), on page 313.

Settings:

Fill User Correction Data with Sensor	245
Generator Settings used for Measurement	246

Fill User Correction Data with Sensor

The "Execute" button is only enabled if a sensor is detected and the user correction list contains at least one frequency value.

"Sensor"	Displays connected sensors for selection.
"List To Fill"	Indicates the used list.
"Config"	Opens the sensor configuration dialog to set the parameters for the selected power sensor.

"Include Zeroing"

Performs a zeroing procedure before acquiring the user correction data to improve precision.

No signal is applied to the sensor during zeroing. RF output is temporarily switched off during that time.

When unchecked, the zeroing procedure is skipped. However, the RF signal level can be blanked shortly. This setting is useful if blanking of RF is undesirable or the absence of power at the sensor cannot be guaranteed.

Remote command:

`[ :SOURce<hw> ] :CORRection:ZERoing:STATe` on page 694

"Execute"

Triggers the sensor to measure and to return the data for user correction.

The "Execute" button is only enabled if a sensor is detected and the user correction list contains at least one frequency value.

Remote command:

`[ :SOURce<hw> ] :CORRection:CSET:DATA [ :SENSor<ch> ] [ :POWER ] :SONCe` on page 693

Generator Settings used for Measurement

Displays the settings relevant for the measurement.

"Modulation"

Indicates that modulation is off.

The R&S SMA100B disables modulation for the "Fill with sensor" process, even if you have enabled a modulation and if you have started "Fill with sensor".

"Amplitude"

Displays the RF level amplitude.

Remote command:

`[ :SOURce<hw> ] :POWER:POWER` on page 747

"Offset"

Displays the RF level offset.

Remote command:

`[ :SOURce<hw> ] :POWER[:LEVel] [:IMMediate]:OFFSet` on page 752

"UCOR Reference Level"

Displays the reference level for user correction.

This level is the sum of the RF level amplitude and RF level offset.

Remote command:

`[ :SOURce<hw> ] :POWER[:LEVel] [:IMMediate]:REFLevel` on page 753

9.3.4 Import/export list files

Access:

1. Select one of the following:

- "Sweep" > "List mode".
- "Level" > "User Correction".
- "Modulation > Pulse Modulation > Pulse Generator > Pulse Mode = Train".

2. Select "Import/Export".




Figure 9-4: Im-/Export dialog (example with UCOR settings)

The "Import/Export" dialog contains all functions and settings to import externally created list data or to export it accordingly. You can process and store a list in the formats *.txt (ASCII), or *.csv (plain text with identical sequence of fields). The table separators and the decimal floating point numbers are customizable.

Settings:

Mode.....	247
ASCII File Settings.....	247
Select (ASCII) Source/Select (ASCII) Destination.....	248
Select Source/Select ASCII Destination.....	248
Import / Export.....	248

Mode

Selects import or export of a data list file. The provided parameters vary according to the selected mode.

Remote command:

- [:SOURce<hw>] :LIST:DEXChange:MODE on page 735
- [:SOURce<hw>] :CORRection:DEXChange:MODE on page 697
- [:SOURce<hw>] :PULM:TRain:DEXChange:MODE on page 644

ASCII File Settings

Defines the format and the separators of the associated data file.

- "Extension" Selects *.csv or *.txt format.
- "Decimal Point" Sets "Point" (dot) or "Comma" as the decimal separator used in the ASCII data with floating-point numerals.
- "Column Separator" Sets the separator between the columns in an ASCII table.
Available are: "Tab", "Semicolon", "Comma" or "Space".

Remote command:

[:SOURce<hw>] :LIST:DEXChange:AFILe:EXTension on page 734
 [:SOURce<hw>] :LIST:DEXChange:AFILe:SEParator:DECimal on page 734
 [:SOURce<hw>] :LIST:DEXChange:AFILe:SEParator:COLumn on page 734
 [:SOURce<hw>] :CORRection:DEXChange:AFILe:EXTension on page 695
 [:SOURce<hw>] :CORRection:DEXChange:AFILe:SEParator:DECimal
 on page 696
 [:SOURce<hw>] :CORRection:DEXChange:AFILe:SEParator:COLumn
 on page 696
 [:SOURce<hw>] :PULM:TRAIIn:DEXChange:AFILe:EXTension on page 645
 [:SOURce<hw>] :PULM:TRAIIn:DEXChange:AFILe:SEParator:DECimal
 on page 645
 [:SOURce<hw>] :PULM:TRAIIn:DEXChange:AFILe:SEParator:COLumn
 on page 645

Select (ASCII) Source/Select (ASCII) Destination

In "Mode > Import", access the file select dialog that provides standard file handling functions.

Where:

- "Select ASCII Source": defines the file to be loaded (imported)
- "Select ASCII Destination": selects the filename under that the loaded file is saved

Remote command:

[:SOURce<hw>] :LIST:DEXChange:AFILe:CATalog? on page 733
 [:SOURce<hw>] :LIST:DEXChange:AFILe:SElect on page 734
 [:SOURce<hw>] :CORRection:DEXChange:AFILe:CATalog? on page 695
 [:SOURce<hw>] :CORRection:DEXChange:AFILe:SElect on page 696
 [:SOURce<hw>] :PULM:TRAIIn:DEXChange:AFILe:CATalog? on page 645
 [:SOURce<hw>] :PULM:TRAIIn:DEXChange:AFILe:SElect on page 646

Select Source/Select ASCII Destination

In "Mode > Export", access the file select dialog that provides standard file handling functions.

Where:

- "Select Source": selects the file to be exported
- "Select ASCII Destination": defines the filename and the file path for the exported file

Remote command:

[:SOURce<hw>] :LIST:DEXChange:SElect on page 735
 [:SOURce<hw>] :CORRection:DEXChange:SElect on page 697
 [:SOURce<hw>] :PULM:TRAIIn:DEXChange:SElect on page 646

Import / Export

Imports or exports the selected data list file, depending on the current mode.

Remote command:

[:SOURce<hw>] :LIST:DEXChange:EXECute on page 735
 [:SOURce<hw>] :CORRection:DEXChange:EXECute on page 696
 [:SOURce<hw>] :PULM:TRAIIn:DEXChange:EXECute on page 646

9.4 Using power sensors

The R&S SMA100B works with any of the R&S NRP power sensors and thus supports various application tasks. Using power sensors, you can for example determine attenuation characteristics of downstream equipment or cables. You can use the measured values to compensate the losses with internal control functions or with an external control circuit in real time.

For information on the various possibilities of interoperability between Rohde & Schwarz power sensors and Rohde & Schwarz signal generators, see the application note [1GP141](#).

R&S NRP power sensors are highly accurate standalone measuring devices, suitable for a wide range of applications. The power sensors communicate directly with the signal generator, calculate the average or peak power internally, include S-parameter correction and return the measurement results to the generator.

The R&S SMA100B supports up to four power sensors, allowing up to four power measurements simultaneously.

Only for the NRP power analysis function, you have to use R&S NRP power sensors that support power analysis in frequency, power and time domain, see [Section 9.4.7.1, "Required options"](#), on page 266.



Check the firmware version of the R&S NRP sensors regularly. Update the firmware, if necessary.

For updates, see the Rohde & Schwarz website www.rohde-schwarz.com in section "Power Meters & Voltmeters".

For information on working with power sensors, see the following topics:

- [Section 9.4.2, "Connecting R&S NRP power sensors to the R&S SMA100B"](#), on page 251
Overview on the supported connectors, connection options and the required accessories.
- [Section 9.4.3, "NRP power viewer"](#), on page 253
A function for measuring and monitoring the RF output power or a user-defined signal source.
- [Section 9.4.4, "NRP power control"](#), on page 254
Controls a downstream closed loop power control circuit, to compensate frequency response characteristics.
- [Section 9.4.5, "NRP sensor configuration"](#), on page 258
Parameter settings of the specific R&S NRP power sensor.
- [Section 9.4.6, "NRP sensor mapping"](#), on page 263
Shows all R&S NRP sensors connected to the instrument, or in the LAN.
- [Section 9.4.7, "NRP power analysis"](#), on page 266
Enables you to analyze the measured power of a DUT in frequency, power or time domain.

9.4.1 About

The R&S SMA100B can perform up to four power measurements simultaneously.

Depending on the signal characteristic (CW, AM, pulsed, etc.) or the parameter to be measured (average, peak, etc.) a suitable R&S power sensor must be used.

About the measuring principle, averaging filter, filter length, and achieving stable results

A sensor measures the average or peak RF power of the source continuously. The measurement results are displayed in the "NRP Power Viewer" dialog.

The power viewer function uses **averaging filters** for getting a stable readout.

Measurement results could be interfered, for instance, by too much noise in your setup, by a bad suppression of harmonics or non-harmonics or when you reach the sensitivity level of your power sensor.

Measurements are continuously repeated in a predefined time window. The measurement result is obtained by averaging the measured values for the last $2N$ time windows. This approach is referred as a **two-step averaging process**.

The factor of 2 in the formula arises because the output signals from the microwave detector are chopped at the same rate as the time windows to suppress low-frequency noise. An independent measured value can only be obtained from two consecutive values.

The variable N in the formula indicates the **filter length**. The filter length then directly influences the measurement time. The filter length can be selected automatically or it can be manually set to a fixed value.

Follow the following general recommendation to find out the **optimum filter length**:

- Always start a measurement in auto mode ("Filter > Auto").
Check if the measurement results are sufficient.
- If the power is not constant, select the filter length manually ("Filter > User").
Trigger the "Auto Once" function to search for the optimum filter length for the current measurement conditions.
The estimated value is indicated as filter length.
- If the target measurement accuracy value is known, select "Filter > Fixed Noise".
The averaging factor is selected automatically and so that the sensor's intrinsic noise (two standard deviations) does not exceed the specified noise content.
- Depending on the R&S NRP power sensor type, the manual setting of the filter length varies in resolution.
- Different sensor types achieve the same filtering result with different filter and time window lengths.
For most sensors, the time window length is fixed to 20 ms, whereas, e.g., for the R&S NRP-Z81 sensor, the time window length is 10 μ s.

For more information, refer to the specifications document.

About zeroing

Activates the auto zero function.

Zeroing calibrates the external power sensor by adjusting its reading at zero signal power. For this purpose, the RF power source must be switched off or disconnected from the sensor. If a Rohde & Schwarz power sensor receives an input power during the zeroing process, it aborts zeroing and generates an error message. Zeroing takes a few seconds, depending on the sensor model. Refer to the documentation of your power sensor for more information.

Tips for zeroing

When to perform zeroing:

- During warm up after switching on or connecting the instrument
- After a substantial change of the ambient temperature
- After fastening the power sensor module to an RF connector at high temperature
- After several hours of operation
- When low-power signals are to be measured, e.g. less than 10 dB above the lower measurement limit.
- Switch off the RF power source for zeroing, but do not disconnect it from the power sensor. This proceeding keeps the thermal equilibrium, and the zeroing process also compensates the noise that superimposes the measured signal (e.g. from a broadband amplifier).

Related settings and functions

- Measurements-related settings, like results, filter, filter length:
[Section 9.4.5, "NRP sensor configuration"](#), on page 258
- Software version of the connected power sensor:
`:SENSe<ch>[:POWER]:TYPE?` on page 608
- Acquisition of level correction data:
[Section 9.3, "User correction"](#), on page 236

Additional information

See the Rohde & Schwarz website www.rohde-schwarz.com, section "Power Meters & Voltmeters" for:

- R&S NRP power sensor manual.
- Information on the R&S NRP-Z5 sensor hub and the available accessories.
- Sensor software updates.

9.4.2 Connecting R&S NRP power sensors to the R&S SMA100B

R&S NRP sensors are connected to the R&S SMA100B in the following ways:

- Connection to the Sensor connector
 - R&S NRP-ZK8 (eight-pole interface cable) for R&S NRPxx power sensors
 - R&S NRP-ZK6 (six-pole interface cable) for R&S NRPxx power sensors

- No additional cable for R&S NRP-Zxx power sensors (cable is fixed on the sensor)
- Connection to the USB connector
Requires the following cables, depending on the used sensor type:
 - R&S NRP-ZKU (USB interface cable) for R&S NRPxx power sensors
 - R&S NRP-Z3 or R&S NRP-Z4 (USB adapter cables) for sensors of the R&S NRP-Zxx family
- Connection via R&S NRP-Z5 sensor hub
The R&S NRP-Z5 USB sensor hub (high-speed USB 2.0) can host up to 4 R&S NRP sensors.
Requires additional cables, depending on the used output connector of the hub. Choose one of the following:
 - Short extension cable R&S NRP-Z2 for connection to the sensor connector. This six-pole connection provides the external trigger capability.
 - Standard USB cable (USB type A to USB type B) to any USB type A connector of the R&S SMA100B. This connection does not support external triggering.
- Connection via USB hub with external power supply unit
Requires the following cables, depending on the used sensor type:
 - R&S NRP-ZKU (USB interface cable) for R&S NRPxx power sensors
 - R&S NRP-Z3 or R&S NRP-Z4 (USB adapter cables) for sensors of the R&S NRP-Zxx family
- Connection via LAN for R&S NRPxxxSN/xxxTN/xxxAN power sensors
Using the Ethernet interface requires PoE (Power over Ethernet) to provide the electrical power.
To establish the connection, you can use:
 - A PoE Ethernet switch, e.g. R&S NRP-ZAP1 and an RJ-45 Ethernet cable.
 - A PoE injector and an RJ-45 Ethernet cable.

For details, see the description R&S®NRP Power Sensors getting started.

Detection and mapping

The R&S SMA100B either detects a R&S NRP power sensor automatically or you can scan for available power sensors manually. The "NRP Sensor Mapping" dialog lists all detected R&S NRP power sensors, see [Section 9.4.6, "NRP sensor mapping"](#), on page 263. The dialog enables you to add, remove and map the sensors manually.

Depending on the connection interface, the R&S SMA100B detects and maps connected R&S NRP power sensors differently:

- Sensor socket
Detects a sensor automatically and maps it with index "1" by default.
If no sensor is connected to this socket, index "1" remains unassigned.
- USB interface
Detects a sensor automatically and maps it with index "2" to index "4" according to the sequence of connection.
- LAN interface

To detect sensors that are connected in the LAN, the instrument provides a scan function. When you start the function, scan searches in the LAN for available R&S NRP power sensors and adds all detected sensors to list. Assigning a mapping index activates the sensor for the measurement.



On connection, the R&S SMA100B immediately starts the measurement of the R&S NRP power sensor. If you preset the instrument ([Preset] key or *RST), the R&S SMA100B stops the measurement. The connection and the mapping of the power sensors remain.

9.4.3 NRP power viewer

The R&S SMA100B features the power viewer function for measuring or monitoring signals with R&S NRP power sensors.

9.4.3.1 NRP power viewer settings

Access:

- Select "Clk Syn / FE / Pow Sens" > "NRP Power Viewer".

Power Viewer	Power Control	Sensor Configuration	Sensor Mapping		×
1: NRP-Z81 900008	Average	-52.42	dBm	Config ...	
2: NRP18SN 101748	Average	-1.03	dBm	Config ...	
3: NRP67TN 101015	Average	-38.20	dBm	Config ...	

The "Power Viewer" tab lists the mapped R&S NRP power sensors with the measured parameter mode and the current readings. The "Config" button leads you to the configuration dialog to set the parameters for each sensor.

The remote commands required to define these settings are described in [Section 15.16, "SENSe, READ, INITiate and SLISt subsystems"](#), on page 595, including the triggering of the measurement and the retrieval of measurement results. See also [Section 9.5, "Improving the RF signal performance"](#), on page 313.

Settings

[Config](#).....254

Config

Opens the "Sensor Configuration" dialog.

See also [Section 9.4.5, "NRP sensor configuration"](#), on page 258.

9.4.4 NRP power control

The NRP power control function enables you to apply stable and accurate RF power to the DUT. For example, you can set up a downstream closed loop power control circuit to compensate spurious effects or losses caused by power amplifiers or cables.


Example: How to set up a closed loop power control

Figure 9-5: Example of a test setup with NRP power control

The signal generator applies the RF output signal to an amplifier and to the DUT. An intermediately connected coupler derives the output power from the output signal and forwards it to the power sensor. Thus, the power sensor measures a proportional power in defined time intervals, and returns the results to the signal generator. If supported, the power sensor also includes given S-parameters. The signal generator compares the measured power with the set level value and adjusts the level of the output signal accordingly.

This closed loop power control enables you to control the external signal level continuously and reliably achieve a constant input power at the DUT in real time.

**Impact of NRP power control and operating modes**

Since the frequency and level of the RF output signal are continuously adjusted during "NRP Power Control", this operating mode interferes signal generation modes with varying frequency and level values. In addition, the setting time increases. The reason is the interaction between the signal generator and the R&S NRP power sensor in the control loop.

The operating modes impact each other as follows:

- Enabling the RF frequency sweep, RF level sweep or the list mode disables a running "NRP Power Control".
- A running list or RF sweep mode blocks "NRP Power Control".
- Modulated signals can deviate from the CW signal in mean power and peak power, and thus affect the "NRP Power Control".

9.4.4.1 NRP power control settings

Access:

- Select "Clk Syn / FE / Pow Sens" > "NRP Power Control".

Power Viewer	Power Control	Sensor Configuration	Sensor Mapping	
State		☒ 		
Sensor		2: NRP18SN 101748 Average -1.31 dBm <button>Config ...</button>		
Target Level		-10.00 dBm Take Measurement as Target Level ☒		
Mode		Single Execute Single Execute		
Catch Range +/-		30.00 dB Delay Time 20 ms Set		
RF Amplitude Limit		30.00 dBm RF Setting Characteristics Auto Set		

In this dialog you can configure the parameters of the power control setup for the selected power sensor.

The remote commands required to define these settings are described in [Section 15.18.12, "SOURCE:POWER subsystem"](#), on page 740.

Settings

State.....	255
Sensor.....	256
Measured Level.....	256
Target Level.....	256
Take Measurement as Target Level.....	256
Mode.....	256
Execute Single.....	257
Catch Range +/-.....	257
Delay Time.....	257
Limit.....	257
Setting Characteristics.....	257

State

Enables power control with the selected sensor.

The control loop periodically adjusts the generator output. After switching off, the running loop is completed.

Note: If you want to use another sensor, you must disable power control before. It is not possible to switch between sensors when power control is active.

Remote command:

`[ :SOURce<hw> ] :POWer:SPC:STATe` on page 750

Sensor

Indicates the R&S NRP power sensor that is selected for power control.

To configure the power sensor parameters, see [Section 9.4.5, "NRP sensor configuration"](#), on page 258.

Remote command:

`[ :SOURce<hw> ] :POWer:SPC:SElect` on page 749

Measured Level

Indicates the current reading of the selected power sensor.

Remote command:

`:READ<ch> [ :POWer ] ?` on page 550

`:SENSe<ch>:UNIT [ :POWer ]` on page 601

Target Level

Specifies the nominal level expected at the input of the sensor. The signal generator adjusts the output power accordingly, to meet the target value at the sensor input, and thus the power required at the DUT.

Remote command:

`[ :SOURce<hw> ] :POWer:SPC:TARGet` on page 750

Take Measurement as Target Level

Uses the currently measured level as reference and applies the value as target level, see ["Target Level"](#) on page 256.

This feature simplifies setting up the control loop after manual adjustment of the measurement configuration. To assign the measured level as reference level, you must switch off "NRP Power Control". It is not possible when the control loop is running.

Remote command:

`[ :SOURce<hw> ] :POWer:SPC:MEASure` on page 749

Mode

Selects the measurement mode for acquiring the power values measured by the sensor.

"Auto"	Immediately starts and measures the power continuously.
"Single"	Starts when you manually select Execute Single , and executes one power measurement cycle. Note, that you can achieve the expected target power level at the DUT only with linear test setups. Non-linear test setups, for example, setups including an amplifier do not work.

Remote command:

`[ :SOURce<hw> ] :POWer:SPC:MODE` on page 749

Execute Single

In mode "Single", starts one measurement cycle manually.

Remote command:

`[ :SOURce<hw> ] :POWer:SPC:SINGle` on page 750

Catch Range +/-

Sets the capture range of the control system.

Within the range:

Target Level +/- Catch Range

the power control locks and tries to achieve the target level. Readings outside the range are not considered.

Remote command:

`[ :SOURce<hw> ] :POWer:SPC:CRANge` on page 748

Delay Time

Sets a waiting period between the level adjustment of the generator and the next measurement of the power sensor.

With this parameter, you can bypass idle times in the controlled system.

Remote command:

`[ :SOURce<hw> ] :POWer:SPC:DELay` on page 748

Limit

Sets an upper limit for the output power.

Note: The parameter "RF level" > "**Limit**" and "NRP power control" > "**RF Amplitude Limit**" are identical.

You can use this value to protect your DUT from damage due to high input power. If you enter an RF level above this value, the instrument limits the output power to this specified value, and generates the warning message:

"Pep value greater than the defined limit." However, the level indication in the status bar is not affected.

The setting is not affected by an instrument preset ([Preset] key or *RST) and the "Save/Recall" function. It is reset only by factory preset.

Remote command:

`[ :SOURce<hw> ] :POWer:LIMit [ :AMPLitude ]` on page 746

Setting Characteristics

Selects additional quality characteristics to optimize the behavior of the RF signal level for the specific application.

- | | |
|--------|---|
| "Auto" | <p>Sets the RF output level automatically according to the selected mode.</p> <p>In this mode, the instrument provides the highest dynamic range and fastest setting times.</p> <p>The RF signal is shortly blanked when the step attenuator is switching.</p> <p>For more information, refer to the specifications document.</p> |
|--------|---|

"Uninterrupted"

Suppresses blanking at level transitions. Frequency transitions can lead to an RF level blanking due to hardware-specific switching points.

This mode reduces the dynamic range of the instrument. The step attenuator is fixed.

"Strictly Monotone"

Executes signal level changes monotonically increasing or decreasing.

The setting makes sure that increasing the level value exclusively results in an increased output level, and vice versa.

All electronic switches, which can affect the monotonicity are fixed.

The operation mode is useful for applications using level searching algorithms which rely on a strictly monotonous behavior.

"Constant-VSWR"

Suppresses output impedance variations at the RF 50 Ω output connector, due to changed level settings.

"High Dyn. Uninterrupted"

R&S SMAB-K724

Provides a linear output power that is uninterrupted over a wide dynamic range.

Note: The R&S SMA100B supports this characteristic at frequencies above 52 MHz. If you select the setting at lower frequencies (≤ 52 MHz), the instrument reports a settings conflict.

"User"

Selects this entry automatically when you change one of the following parameters from the default setting:

- "Attenuator" > [Mode](#)
- "ALC" > [State](#) or [Detector Sensitivity](#)

Note: If you select another setting characteristic, the R&S SMA100B presets the modified attenuator and ALC parameters.

Remote command:

[\[:SOURce<hw>\]:POWer:LBEHaviour](#) on page 746

9.4.5 NRP sensor configuration

Access:

- Select "Clk Syn / FE / Pow Sens" > "NRP Sensor Configuration".

In this dialog you can configure the parameters for each mapped R&S NRP power sensor in separate tabs.

The remote commands required to define these settings are described in [Section 15.16, "SENSe, READ, INITiate and SLISt subsystems"](#), on page 595, including the triggering of the measurement and the retrieval of measurement results.

Settings:

Sensor type and serial number.....	260
Level (Peak) / Level (Average).....	260
State.....	260
Zero.....	260
Display.....	260
Display Permanent.....	260
Use Frequency Of.....	261
Frequency.....	261
Level Offset State, Level Offset.....	261
Filter.....	261
Filter Length.....	262
Auto Once.....	262
Noise/Signal Ratio.....	262
Timeout.....	262
Default Aperture Time.....	262

Aperture Time.....	262
S-Parameter.....	263
Enable Logging.....	263

Sensor type and serial number

The side tab label indicates type and serial number of an R&S NRP power sensor and its mapping index.

The **Level (Peak) / Level (Average)** values display the current readings of the sensor.

Remote command:

:SENSe<ch>[:POWER]:TYPE? on page 608

:SENSe<ch>[:POWER]:SNUMber? on page 607

Level (Peak) / Level (Average)

Indicates the measured peak or average level value.

You can also change the unit for the results display: Watt, dBm or dBμV.

Note: Peak level measurements are provided if the power sensor supports this feature.

Remote command:

:READ<ch>[:POWER]? on page 550

:SENSe<ch>:UNIT[:POWER] on page 601

State

Enables level measurement of the R&S NRP power sensor.

Remote command:

:INITiate<hw>[:POWER]:CONTinuous on page 550

To query the availability of a sensor at a given connector, use the command :

SENSe<ch>[:POWER]:STATus[:DEVice]? on page 607.

Zero

Activates the auto zeroing.

For details, see "[About zeroing](#)" on page 251.

Remote command:

:SENSe<ch>[:POWER]:ZERO on page 608

Display

Sets the display of results on mean or peak power.

Remote command:

:SENSe<ch>[:POWER]:DISPlay:PERManent:PRIority on page 602

Display Permanent

Enables the display of the power sensor with the currently measured value in the status bar of the home screen.

You can activate the permanent display for several sensors.

Remote command:

:SENSe<ch>[:POWER]:DISPlay:PERManent:STATe on page 603

Use Frequency Of

Selects the source for measurement.

"RF"	The R&S SMA100B transfers the RF frequency and level settings to the R&S power sensor automatically. Thus you achieve power readings of high accuracy, irrespective from the connected sensor type.
"User"	Sets a user defined frequency.

Example:

If you have a frequency converting device between the generator and the DUT. If the frequency converter doubles the frequency, you can set twice the frequency in the R&S SMA100B. The R&S power sensor considers this RF frequency setting.

Set the parameter [Frequency](#) to the measurement's frequency.

Remote command:

[:SENSe<ch>\[:POWer\]:SOURce](#) on page 607

Frequency

Defines the frequency value if "Source > User" is used.

Remote command:

[:SENSe<ch>\[:POWer\]:FREQuency](#) on page 605

Level Offset State,Level Offset

Activates and defines a level offset which is considered in the power measurement result. The level offset value is always expressed in dB, irrespective of the display of the measurement result.

This function allows you to consider, for example, an attenuator in the signal path.

Remote command:

[:SENSe<ch>\[:POWer\]:OFFSet](#) on page 606

[:SENSe<ch>\[:POWer\]:OFFSet:STATe](#) on page 606

Filter

Selects the way the length of the used filter is defined.

See also ["About the measuring principle, averaging filter, filter length, and achieving stable results"](#) on page 250.

"Auto"	Selects the filter length automatically and adjusts it to the measured value. The value is indicated with the parameter Filter Length. When high output power is applied, the filter length and therefore the measurement time can be short. When low output power is applied, the filter length and therefore the measurement time is increased which reduces the considered noise content in your measurement.
"User"	The filter length is defined manually, with the parameter Filter Length. As the filter length works as a multiplier for the time window, constant filter length results in a constant measurement time. Values 1 and 2N are allowed.

"Fixed Noise" The averaging factor is taken automatically in accordance to the value [Noise/Signal Ratio](#). Thus, the sensor's intrinsic noise (2 standard deviations) does not exceed the specified noise content. To avoid long measurement times when the power is too low, set a [Timeout](#).
Timeout is the maximum acceptable measurement time which limits the averaging factor and therefore leads to a more unstable readout.

Remote command:

[:SENSe<ch>\[:POWER\]:FILTer:TYPE](#) on page 605

Filter Length

Sets or indicates the filter length, depending on the selected filter mode.

- "Filter > Auto" indicates the automatically adjusted filter length.
- "Filter > User" enables you to set the filter length manually.
- "Filter > Fixed Noise" hides the setting parameter.

Remote command:

[:SENSe<ch>\[:POWER\]:FILTer:LENGTH:AUTO?](#) on page 603

[:SENSe<ch>\[:POWER\]:FILTer:LENGTH\[:USER\]](#) on page 603

Auto Once

Searches the optimum filter length for the current measurement conditions. The result is indicated with the parameter [Filter Length](#).

See also "[About the measuring principle, averaging filter, filter length, and achieving stable results](#)" on page 250.

Remote command:

[:SENSe<ch>\[:POWER\]:FILTer:SONCe](#) on page 604

Noise/Signal Ratio

For [Filter > Fixed Noise](#), sets the noise content.

Remote command:

[:SENSe<ch>\[:POWER\]:FILTer:NSRatio](#) on page 604

Timeout

Sets a time limit for the averaging process.

The setting is bound to the timeout of the connected sensor.

Remote command:

[:SENSe<ch>\[:POWER\]:FILTer:NSRatio:MTIME](#) on page 604

Default Aperture Time

The sensor default setting is sufficient. Disable this parameter to specify a user-defined aperture time per sensor, if, for example, the readings vary.

To obtain stable readings, set the [Aperture Time](#) exactly to one modulation period.

Remote command:

[:SENSe<ch>\[:POWER\]:APERTure:DEFAUlt:STATe](#) on page 601

Aperture Time

If "Use Default Aperture Time > Off", defines the acquisition time per sensor.

For example, to obtain a sufficient low average value, set the aperture time exactly to one modulation period.

Remote command:

`:SENSe<ch>[:POWer]:APERTure:TIME` on page 601

S-Parameter

Lists the S-Parameter correction data files retrieved for the connected power sensor. To activate the correction data, select the corresponding file.

S-Parameter correction is used to mathematically shift the reference plane to the DUT by considering the S-parameters for any components connected upstream of the sensor.

The S-Parameter table can be changed with the S-Parameters tool, provided as part of the free R&S NRP Toolkit software. For more information, refer to the manual of the connected R&S NRP power sensor.

Remote command:

`:SENSe<ch>[:POWer]:CORRection:SPDevice:STATe` on page 602

`:SENSe<ch>[:POWer]:CORRection:SPDevice:LIST?` on page 602

`:SENSe<ch>[:POWer]:CORRection:SPDevice:SElect` on page 602

Enable Logging

Activates recording of R&S NRP power sensor readings in a log file.

There is 1 log file per sensor. The log files are created automatically and filled in continuously. They are text files with predefined filename `SensLog<n>.txt`, where `<n>` indicates the connected sensor. Log files are stored on the internal memory, in the directory `/var/user/SensorLogging`.

Each log file contains the measured value (2 readings when you work with peak sensors), the sensor type, and the measurement time (timestamp). Logged data is not overwritten. When a new measurement is started, the collected logging data is appended in the log file.

Check the used disc space regularly and remove log files to maintain storage capacity.

Note: The logging function is intended for measurements with long time intervals. It is suitable source for data reconstructions if the connection to the sensor was interrupted.

Remote command:

`:SENSe<ch>[:POWer]:LOGGing:STATe` on page 606

9.4.6 NRP sensor mapping

The "NRP Sensor Mapping" lists the sensors detected by the instrument.

Any R&S NRP sensor that supports the USB legacy protocol and is connected to one of the USB interfaces, is detected automatically and added to the list. When you disconnect a power sensor, the R&S SMA100B removes it from the list accordingly.

R&S NRP power sensors that are connected in the LAN or use the USBTMC protocol are only detected by the scan search function.

Access:

- Select "Clk Syn / FE / Pow Sens" > "NRP Sensor Mapping".

Power Viewer	Power Control	Sensor Configuration	Sensor Mapping					✕
	Sensor	Peak	K28 Support	Revision	Protocol	Connector	Mapping	
1	NRP-Z11 900003	☒	Freq, Pow, Time, Pulse Data	01.14.95	Legacy		1	
2	NRP18SN 101699	☐	Freq, Pow, Time	02.40.22081101	Visa		2	
3	NRP18SN 101748	☐	Freq, Pow, Time	01.14.95-DU	Legacy		3	
4	NRP-Z81 000007	☒	Freq, Pow, Time	01.14.95	Visa			
Scan		Start	Clear	Add Sensor ...				

The dialog lists all detected R&S NRP sensors for selection and mapping. You can also browse the network for sensors.

The list informs on the sensor type with serial number, specific features and the revision of the sensor firmware.

For each sensor, you find the used protocol and the connector icon of the interface. In the "Mapping" column, you can assign a mapping index to enable the sensor for use. The list can contain several entries but the R&S SMA100B can only use up to four sensors simultaneously.

The remote commands required to define these settings are described in [Section 15.16, "SENSe, READ, INITiate and SLISt subsystems"](#), on page 595.

Settings

Sensor Mapping List	264
Scan	265
Clear	265
Add Sensor	265
Add LAN Sensor	265
Add USBTMC Sensor	266

Sensor Mapping List

Shows the sensors that are connected to the R&S SMA100B.

The table informs on the sensor type, specific features and the installed sensor firmware. It also shows the interface the sensor is connected to, including the communication protocol and the mapping index.

Remote command:

`:SLIST[:LIST]?` on page 598

`:SLIST:ELEMent<ch>:MAPPING` on page 600

`:SLIST:SENSor:MAP` on page 600

Scan

Scans the network and the USB connections for sensors connected using the VISA communication protocol, i.e. sensors that are addressed over LAN or USBTMC.

The instrument detects sensors communicating over the USB legacy protocol automatically.

Remote command:

`:SLIST:SCAN[:STATe]` on page 598

Clear

Removes all entries of R&S NRP power sensors using the VISA communication protocol (USB or LAN) from the sensor mapping list.

The setting does not affect sensors communicating over USB legacy protocol. To remove a USB legacy sensor from the list, disconnect it from the interface.

Note: With the remote control commands `:SLIST:CLEar:LAN`

and `:SLIST:CLEar:USB`, you can remove the power sensors of the corresponding VISA interface selectively.

Remote command:

`:SLIST:CLEar:LAN` on page 599

`:SLIST:CLEar:USB` on page 599

`:SLIST:CLEar[:ALL]` on page 600

Add Sensor

Shows or hides the "Add Sensor" dialog to configure power sensors connected to the R&S SMA100B over USB or LAN.

Add LAN Sensor

Configures settings to add sensors connected to the R&S SMA100B over LAN.

"IP Address or Host Name"

Displays the host name or the IP address of a R&S NRP power sensor.

If the R&S SMA100B does not detect a connected R&S NRP sensor, you can assign the address information manually.

"Add LAN Sensor"

Adds a detected R&S NRP sensor connected in the LAN to the list of sensors, including its device ID or name and its serial number.

Remote command:

`:SLIST:SCAN:LSensor` on page 598

Add USBTMC Sensor

Configures settings to add sensors connected to the R&S SMA100B over USB.

If the R&S SMA100B does not detect a connected R&S NRP sensor, you can assign the device ID manually.

"Sensor"

Selects the name of the R&S NRP power sensor.

If the R&S SMA100B does not contain the R&S NRP power sensor you use, select "<from Device ID". The "Device ID" entry field switches in edit mode where you can enter the ID of your product manually.

"Device ID"

Displays the device identifier of a selected R&S NRP power sensor. If you want to assign the device ID manually, get the information in the user documentation of your power sensor.

"Serial Number"

Displays the serial number of the R&S NRP power sensor.

If the R&S SMA100B does not detect a connected R&S NRP sensor, you can assign the serial number manually.

"Add USBTMC Sensor"

Adds a detected R&S NRP sensor connected at the USB interface to the list of sensors, including its device ID or name and its serial number.

Remote command:

`:SLIST:SCAN:USENsor` on page 599

9.4.7 NRP power analysis

The NRP power analysis functionality enables you to analyze the measured power of a DUT in frequency, power or time domain. The instrument provides marker, graphic and reference value functions.

9.4.7.1 Required options

The NRP power analysis function requires the power analysis option installed on your instrument, and a sensor that supports power analysis.

R&S SMA100B base unit equipped with the following option:

- Power Analysis (R&S SMAB-K28)

R&S NRP power sensors:

- R&S NRP-Z8x, referred to in the following description
- R&S NRP-Z91
- R&S NRP-Z211

For more information, refer to the specifications document.

9.4.7.2 About

Characteristics and features of the NRP power analysis function

The NRP power analysis displays the measurement data graphically. The measurement diagram covers up to four traces you can manually or automatically assign to one or more connected power sensors. For evaluation of the readings, you can save a defined reference trace or even freeze a reading temporarily on the screen. Markers and mathematic functions enable you to compare particular values.

The NRP power analysis supports three measurement modes:


- Power versus frequency (frequency response).
For this mode, all required generator settings are automatically configured except for the power level. The power level setting of the generator is used for the frequency sweep measurements.
The frequency sweep settings are transferred to the sensor to automatically calculate the correct measurement value for each frequency point.
- Power versus power (power sweep, AM/AM)
Power sweep measurements are executed using the frequency settings of the generator. Alternatively, the sensor can be adjusted to a frequency different from the generator, see [Use Separate Frequency- Power Analysis](#).
This frequency is transmitted to the sensor to automatically calculate the correct measurement value.
- Power versus time (power measurement in the time domain, e.g. R&S NRP-Z8x trace mode).
In the time mode, you can analyze the signal of the generator but also externally supplied signals. This mode requires an additional trigger event, with selectable level, hysteresis and drop time. Provided the sensor used supports the power measurement of pulse signals, you can also analyze pulse data in time domain.

Characteristics of pulse data



For R&S NRP-Z8x power sensors that support time domain analysis and automatic pulse analysis.

The power sensors enable pulse data analysis in measurement mode time. All important pulse parameters are measured after setting the threshold levels. The following graph shows most of these parameters:



The sensor calculates the pulse parameters from each measurement and delivers the results to the R&S SMA100B.

The indication state of the parameters also affects the save function. Storing the measurement diagram as hardcopy includes the parameters selected in this dialog.



A total of 6 parameters can be indicated at one time. Structured hierarchically, trace 1 features top priority and trace 4 is addressed with the lowest weighting. This means that only the first 6 checked parameters are indicated, starting with the settings of trace 1.

The pulse data is only visible for certain zoom levels of the diagram.

9.4.7.3 Accessing the NRP Power Analysis functionality

Access:

- Select "Clk Syn / FE / Pow Sens" > "NRP Power Analysis".




Figure 9-6: Power analysis window

- 1 = Softkeys for accessing the "NRP-Z" the sensor settings dialogs
- 2 = Power analysis diagram
- 3 = Reference curve, indicated when active
- 4 = Progress bar indicated during measurement
- 5 = "Start Continuous / Stop" softkey to trigger the measurement
- 6 = Softkey for accessing the measurement settings dialogs
- 7,8,9 = Softkeys for accessing the trace and marker settings dialogs

The start screen of the NRP power analysis contains the measurement diagram and labelled softkeys indicating connected power sensors. These softkeys and a configuration softkey lead you to the dialogs for setting up the measurement and sensor parameters, and for configuring the trace display in the diagram. You can start or stop your measurement directly. During the measurement, the R&S SMA100B shows the progress of the measurement in the progress bar at the bottom of the diagram.

Context-sensitive menu

A context-sensitive menu also provides access to the configuration dialogs and some additional functions.

Access:

- Touch and hold a spot in the power analysis diagram for at least 1 second to access the context-sensitive menu.




Figure 9-7: Power analysis context-sensitive menu

In the context-sensitive menu you can access:

- "Start Continuous/Stop": Triggers / stops the power analysis measurement
Note: During a measurement in the frequency domain, or the power domain respectively, the displayed frequency/power value in the status bar (home screen) does not correspond to the value applied at the output. Therefore, the R&S SMA100B displays asterisks instead of the frequency or power value during the measurement and indicates the original value again when the measurement is completed or aborted.
- "Next Window (Hardkey)": Switches between the measurement views that are enabled in the following order:
 - "Standard View"
 - "Marker View"
 - "Pulse Data View"
 - "Full Screen"

At least one viewing mode has to be selected. For details on the different view modes, see ["Window list"](#) on page 284.
- "Configure...": opens a dialog for configuring the power analysis measurement. See [Section 9.4.7.6, "NRP configure settings"](#), on page 277.
- "Trace/Markers...": opens a dialog for configuring the traces/marker. See [Section 9.4.7.5, "NRP trace/marker settings"](#), on page 271.
- "Save...(Power Analysis)": opens a dialog to save a hardcopy of the measurement. See [Section 9.4.7.7, "Creating screenshots of power analysis settings"](#), on page 302.

Power Analysis Diagram

Indicates the measurement results graphically, including configured markers, functions, etc.

Off / NRP-Zxx

Accesses the dialogs for configuring the traces and markers, see [Section 9.4.7.5, "NRP trace/marker settings"](#), on page 271

Configure...

Accesses the dialog for configuring the power analysis measurement, see [Section 9.4.7.6, "NRP configure settings"](#), on page 277.

Start Continuous / Stop

Starts and stops the power analysis measurement. Depending on the selected measurement mode, the label varies.

9.4.7.4 Test setup example

As a power meter has no built-in selection, it is measuring all signal components from nearly DC to 40 GHz and higher. Therefore, the DUT's signal must be rather pure or subjected to external filtering (harmonics, spurious) before measured.

The test setup for the power analysis in the power versus frequency or power versus power is as follows:




Figure 9-8:

DUT = Device under test


PS = Power sensor, e.g. R&S NRP-Z8x, connected at the DUT's input and the USB connector of the R&S SMA100B

1. Connect the DUT RF input to the RF output of the instrument.
2. Connect the DUT RF output to the power sensor.
3. Connect the power sensor to the signal generator.
4. Select "Clk Syn / FE / Pow Sens" > "NRP Power Analysis".
5. Select the power sensor, indicated at the bottom of the dialog to configure the trace.
6. Close the dialog.
7. Select "Start Continuous" to trigger the measurement.

9.4.7.5 NRP trace/marker settings

Access:

1. Select "Clk Syn / FE / Pow Sens" > "NRP Power Analysis".
2. Select power sensor indication located at the bottom of the dialog.
3. To access the trace settings, select the corresponding "Trace x" tab.



The measurement data can be current (sensor trace) or stored trace data. You can store data either in a file (reference trace) or in a temporary memory (hold trace). Up to four traces can be indicated at one time. On connection, the sensors are automatically detected and assigned to a trace. By default, connected sensors are assigned to the traces in ascending order, that means sensor 1 to trace 1, sensor 2 to trace 2, etc. If the default trace is already used, the sensor has to be assigned manually in the trace dialog.

Using the reference and hold traces, you can compare traces. Assign a reference curve to one trace and your measured values to a second one, and switch on the display. With this feature you can compare results directly in the graph, or show the deviations in a graph by using the ["Mathematics - Trace Power Analysis"](#) on page 274 function.

Example

The current single measurement of sensor 2 which is assigned to trace 2 is used as reference trace.

1. Select "Trace 2" with "Indication" = "2 - NRP-Z81".
2. Select "Save To Ref".
3. Select "Trace 1" > "Indication > Ref".
4. Select "Diagram".

The R&S SMA100B indicates two identical traces.
5. Select "Start single".

Triggers a new measurement cycle with sensor 2. You can compare the resulting measurement trace with the former measurement, which is displayed as reference trace.

Trace settings

Indication - Trace Power Analysis

Selects the source for the trace data.

The softkey label in the measurement diagram indicates the current selection.

"Off"	No source is selected, the trace is not indicated.
"2 - NRPxx"	The current measurement results of the selected power sensor are the source for the trace data. The index at the beginning of the sensor name indicates the used connector, for example "2" indicates that the sensor is connected over a USB interface. The data is either continuously updated (continuous measurement) or represents a single measurement cycle (single measurement).
"Ref"	Selects the reference trace. The reference trace is a static trace that was stored in a file and can be recalled. It is possible to store one reference trace at a time.
"Hold"	Freezes the current trace data. The hold trace is a temporary trace that is available until the power analysis is finished. Freezing the trace of a sensor in one trace and displaying the measurement values of the same sensor in another trace allows fast comparison between measurements.

Remote command:

:TRACe<ch>:FREQ:SWEep:SRC on page 585
 :TRACe<ch>:POW:SWEep:SRC on page 585
 :TRACe<ch>:TIME:SWEep:SRC on page 586
 :TRACe<ch>[:POWer]:SWEep:STATe on page 592
 :TRACe<ch>[:POWer]:SWEep:FEED on page 588

Color - Trace Power Analysis

Selects the color of the trace.

Remote command:

:TRACe<ch>[:POWer]:SWEep:COLor on page 586

Save to Ref - Trace Power Analysis

Saves the selected trace as reference trace. Only one reference trace is available at a time.

Remote command:

:TRACe<ch>[:POWer]:SWEep:COPY on page 587

Define Reference - Trace Power Analysis

Opens a dialog for defining a linear reference curve, see ["Define reference NRP analysis settings"](#) on page 274.

Mathematics - Trace Power Analysis

Activates the mathematic function.

The function enables you to determine the deviation of two test series, either of measurement traces, or also of traces that contain math results or stored reference curves. That means you can also assign a math result to an operand for further calculation. Various nested computation steps are possible.

The math operation follows the formula:

$$T<ch>_{\text{result}} = T<ch>_{\text{Operand1}} - T<ch>_{\text{Operand2}}$$

How to proceed:

Determine $T<ch>_{\text{Operand1}}$ in the entry field next to "Tx", and then select $T<ch>_{\text{Operand2}}$ in the second entry field right to it.

The result (" $T<ch>_{\text{result}}$ ") is assigned to the above selected "Trace". If switched on, the graph shows the resulting curve.

Note:

Depending on the type of trace, the instrument automatically sets the appropriate unit on the y-axis:

- "dBm" if it shows only measurement traces.
- "dB" for purely mathematical curves.
- "dB/dBm" ratio scale for mixed display, that means measurements and mathematical curves.

Example:

Example of a nested calculation.

- T1 shows the result of the subtraction of the trace ("Trace 1"), and the reference curve.
- Trace2 subtracts Ref from T1.

That illustrates the nested calculation, since T1 covers already a math operation.

Note: "(Ind.)" denotes the currently selected trace.

Remote command:

`:CALCulate[:POWER]:SWEep:FREQuency:MATH<ch>:STATe` on page 542

`:CALCulate[:POWER]:SWEep:FREQuency:MATH<ch>:SUBTract` on page 542

`:CALCulate[:POWER]:SWEep:POWEr:MATH<ch>:STATe` on page 544

`:CALCulate[:POWER]:SWEep:POWEr:MATH<ch>:SUBTract` on page 544

`:CALCulate[:POWER]:SWEep:TIME:MATH<ch>:STATe` on page 548

`:CALCulate[:POWER]:SWEep:TIME:MATH<ch>:SUBTract` on page 548

Define reference NRP analysis settings

Access:

1. Select "Clk Syn / FE / Pow Sens" > "NRP Power Analysis".
2. Select a power sensor at the bottom of the power analysis main screen.
The traces dialog opens.
3. Select a "Trace" tab.

4. Select "Define Reference".

Point A	
Frequency (X)	Pow (Y)
0 Hz	-40.000 0 dBm

Point B	
Frequency (X)	Pow (Y)
1 000.000 000 0 GHz	-40.000 0 dBm

Save To Ref

Figure 9-9: Defining the reference curve, e.g. in frequency mode

In this dialog, you can specify a linear reference curve for the measurement of the corresponding trace. The measurement mode, selected with [Configure measurement settings](#), determines the parameters assigned to the x-axis and the y-axis in the diagram.

The remote commands required to define these settings are described in [Section 15.16, "SENSe, READ, INITiate and SLISt subsystems"](#), on page 595.

Freq (X)

For [Configure measurement settings](#) > "Frequency", sets the frequency values for points A and B of the reference curve.

Remote command:

:SENSe[:POWER]:SWEep:FREQuency:REference:DATA:XVALues on page 562

:CALCulate[:POWER]:SWEep:FREQuency:MATH<ch>:XVAL on page 542

POW (Y)

For [Configure measurement settings](#) > "Frequency", sets the power values for points A and B of the reference curve.

Remote command:

:SENSe[:POWER]:SWEep:FREQuency:REference:DATA:YVALues on page 562

:CALCulate[:POWER]:SWEep:FREQuency:MATH<ch>:YVAL on page 543

Pow (X)

For [Configure measurement settings](#) > "Power", sets the power values for points A and B of the reference curve on the x-axis.

Remote command:

:SENSe[:POWER]:SWEep:POWer:REference:DATA:XVALues on page 574

:CALCulate[:POWER]:SWEep:POWer:MATH<ch>:XVAL on page 544

Pow (Y)

For [Configure measurement settings](#) > "Power", sets the power values for points A and B of the reference curve on the x-axis.

Remote command:

[:SENSe\[:POWER\]:SWEep:POWer:REFeRence:DATA:YVALues](#) on page 575

[:CALCulate\[:POWER\]:SWEep:POWer:MATH<ch>:YVAL](#) on page 545

Time (X)

For [Configure measurement settings](#) > "Time", sets the time values for points A and B of the reference curve on the x-axis.

Remote command:

[:SENSe\[:POWER\]:SWEep:TIME:REFeRence:DATA:XVALues](#) on page 579

[:CALCulate\[:POWER\]:SWEep:TIME:MATH<ch>:XVAL](#) on page 548

Pow (Y)

For [Configure measurement settings](#) > "Time", sets the power values for points A and B of the reference curve on the y-axis.

Remote command:

[:SENSe\[:POWER\]:SWEep:TIME:REFeRence:DATA:YVALues](#) on page 579

[:CALCulate\[:POWER\]:SWEep:TIME:MATH<ch>:YVAL](#) on page 549

Save To Ref

Saves the selected trace as reference trace. One reference trace is available at a time.

Remote command:

[:SENSe\[:POWER\]:SWEep:FREQuency:REFeRence:DATA:COpy](#) on page 561

[:SENSe\[:POWER\]:SWEep:POWer:REFeRence:DATA:COpy](#) on page 574


[:SENSe\[:POWER\]:SWEep:TIME:REFeRence:DATA:COpy](#) on page 579

Marker settings

Access:

1. Select "Clk Syn / FE / Pow Sens" > "NRP Power Analysis".
2. Select a power sensor button at the bottom power analysis main screen.
The traces dialog opens.
3. Select the "NRP Trace".

4. Select the "Markers" side tab.



In this dialog, you can assign markers to the corresponding traces and activate them for display.

Trace - Power Analysis

Selects the trace the marker is assigned to.

Remote command:

- [:CALCulate\[:POWER\]:SWEep:FREQuency:MARKer<ch>:FEED](#) on page 541
- [:CALCulate\[:POWER\]:SWEep:POWer:MARKer<ch>:FEED](#) on page 543
- [:CALCulate\[:POWER\]:SWEep:TIME:MARKer<ch>:FEED](#) on page 547

Marker x Visible - Power Analysis

Selects if the respective marker and the marker list are shown in the diagram.

Remote command:

- [:CALCulate\[:POWER\]:SWEep:FREQuency:MARKer<ch>:STATe](#) on page 541
- [:CALCulate\[:POWER\]:SWEep:POWer:MARKer<ch>:STATe](#) on page 543
- [:CALCulate\[:POWER\]:SWEep:TIME:MARKer<ch>:STATe](#) on page 547

9.4.7.6 NRP configure settings

The "Configure" dialog allows you to set measurement and sensor parameters.


- [Configure measurement settings](#)..... 278
- [Configure diagram](#).....282
- [Window list](#).....284
- [Trace settings](#).....288

• Configure sensor settings	290
• Configure time mode settings	293
• Pulse data notifications settings	293
• Trigger settings	298
• Gate mode settings	300

Configure measurement settings

Access:

1. Select "Clk Syn / FE / Pow Sens" > "NRP Power Analysis".
2. Select "Config..." > "NRP Config".
3. Select > "Measurement".



The measurement dialog provides the parameters for configuring the measurement either in frequency, power or time domain. Depending on the measurement domain, the settings vary.

The remote commands required to define the settings are described in [Section 15.15.5, "SENSe SWEEP subsystem"](#), on page 551.

Settings:

Mode	279
Min	279
Max	279
Steps	280

Timing.....	280
Average.....	280
Spacing.....	281
Execution.....	281
All Trigger Events.....	281

Mode

Selects the measurement mode.

"Frequency"	Power versus frequency measurement (frequency response).
"Power"	Power versus power measurement (power sweep, AM/AM).
"Time"	Power versus time measurement (envelope power measurement as a function of time, NRP trace mode). The R&S SMA100B samples power over a time interval and assigns the internal power values that have been determined to several points. This mode also provides gated measurement and pulse data analysis, e.g. with a connected R&S NRP-Z81, and the corresponding graphical display "Gate View" and "Pulse Data View".

Remote command:

`:SENSe[:POWER]:SWEep:MODE` on page 574

Min

Sets the minimum frequency/power/time of the measurement.

The available frequency/power range depends on the frequency/power range of the generator and the used power sensor.

The range for the start time is -1s to +1s. Value 0 defines the trigger point. By choosing a negative time value, the trace can be shifted in the diagram.

It is possible, that the measurement cannot be performed over the complete time range because of limitations due to sensor settings. In this case, the R&S SMA100B generates an error message.

If you change this value for a finished single measurement, only the scaling of the x-axis changes. This way, you can zoom the trace. However, for subsequent measurements, the measurement range is changed according to the new setting.

If you change this value during a continuous measurement, only the scaling of the x-axis changes for measurement cycles that have been triggered before the change. For subsequent measurement cycles, the measurement range changes according to the new setting.

Remote command:

`:SENSe[:POWER]:SWEep:FREQuency:STARt` on page 563

`:SENSe[:POWER]:SWEep:POWeR:STARt` on page 575

`:SENSe[:POWER]:SWEep:TIME:STARt` on page 580

Max

Sets the maximum frequency/power/time of the measurement.

The available frequency/power range depends on the frequency/power range of the instrument and the used power sensor.

The range for the stop time is 0 s to 2 s. Value 0 defines the trigger point.

It is possible, that the measurement cannot be performed over the complete time range because of limitations due to sensor settings. In this case, an error message is output.

If you change this value for a finished single measurement, only the scaling of the x-axis changes. This way, you can zoom the trace. However, for subsequent measurements the measurement range is changed according to the new setting.

If you change this value during a continuous measurement, only the scaling of the x-axis changes for measurement cycles that have been triggered before the change. For subsequent measurement cycles, the measurement range changes according to the new setting.

Remote command:

`:SENSe[:POWer]:SWEep:FREQuency:STOP` on page 563

`:SENSe[:POWer]:SWEep:POWer:START` on page 575

`:SENSe[:POWer]:SWEep:TIME:STOP` on page 581

Steps

Sets the number of steps for the sweep. The number of measured points is steps + 1. The number of steps is one of the parameters that define the measurement speed. The higher the number of steps, the longer the measurement takes (frequency and power mode).

Remote command:

`:SENSe[:POWer]:SWEep:FREQuency:STEPS` on page 563

`:SENSe[:POWer]:SWEep:POWer:STEPS` on page 576

`:SENSe[:POWer]:SWEep:TIME:STEPS` on page 581

Timing

Selects the timing mode in frequency or power domain.

This parameter is only available for [Configure measurement settings](#) > "Frequency"/"Power".

"Fast" Fast measurement with an integration time of 2 ms for each measurement step.

"Normal" A longer but more precise measurement (integration time is 20 ms/step).

Remote command:

`:SENSe[:POWer]:SWEep:FREQuency:TIMing[:MODE]` on page 564

`:SENSe[:POWer]:SWEep:POWer:TIMing[:MODE]` on page 576

Average

Selects the averaging factor in time domain.

The factor determines how many measurement cycles are used to form a measurement result. Higher averaging counts reduce noise but increase the measurement time. Averaging requires a stable trigger event so that the measurement cycles have the same timing. If factor 1 is selected, no averaging is performed.

This parameter is only available for [Configure measurement settings](#) > "Time".

Remote command:

`:SENSe[:POWer]:SWEep:TIME:AVERage[:COUNT]` on page 578

Spacing

Sets the mode for calculating the sweep steps.

In power versus frequency mode, selection between linear and logarithmic spacing is possible.

- | | |
|---------------|--|
| "Linear" | <ul style="list-style-type: none"> • Power versus frequency
In a linear sweep, the frequency is swept in equidistant steps over the continuous frequency range. The x-axis is a linear frequency axis. • Power versus power
The sweeps are performed at constant frequency but with variable generator power that is swept in linear, equidistant steps over a continuous range. The x-axis is a dB-linear power axis. • Power versus time
The sweeps are performed at constant frequency and stimulus power. The measurement is repeated over a specified period of time at constant time intervals. |
| "Logarithmic" | <p>Power versus frequency
In a logarithmic sweep, the frequency is swept in equidistant steps on a logarithmic scale. The x-axis is a logarithmic frequency axis.</p> |

Remote command:

`:SENSe[:POWER]:SWEep:FREQuency:SPACing[:MODE]` on page 563

`:SENSe[:POWER]:SWEep:POWer:SPACing[:MODE]` on page 575

`:SENSe[:POWER]:SWEep:TIME:SPACing[:MODE]` on page 580

Execution

Selects single or continuous mode in power analysis.

The measurement is started in the diagram using the "Start" button. During measurement, the "Start" button is replaced by a "Stop" button which can be used to abort the measurement. The progress bar indicates the status of the measurement.

- | | |
|----------|----------------------------------|
| "Single" | Selects single measurement. |
| "Cont." | Selects continuous measurements. |

Remote command:

`:SENSe[:POWER]:SWEep:RMODe` on page 578

`:SENSe[:POWER]:SWEep:POWer:RMODe` on page 575

`:SENSe[:POWER]:SWEep:FREQuency:RMODe` on page 562

`:SENSe[:POWER]:SWEep:TIME:RMODe` on page 580

All Trigger Events

Selects the trigger mode for measurements in the time domain.

The measurement data processing starts with a trigger event in one of the sensors (Logical OR), or when all channels are triggered (logical AND). Each sensor evaluates a trigger event according to its setting independently.


This function supports the internal or external trigger modes with multi-channel time measurements.

- | | |
|-------------|---|
| "Wired AND" | The measurement starts when all channels are triggered. |
| "Wired OR" | The measurement starts when a trigger event occurs. |

Remote command:
:SENSe[:POWER]:SWEep:TIME:TEVents on page 581

Configure diagram

- Access:
- 1. Select "Clk Syn / FE / Pow Sens" > "NRP Power Analysis".
 - 2. Select "Config..." > "NRP Config".
 - 3. Select "Diagram".



The "Configure Diagram" covers the parameters for scaling the y-axis and the appearance of the diagram.

The remote commands required to define the settings are described in [Section 15.15.5, "SENSe SWEep subsystem"](#), on page 551.

Settings:

Min - Max Level	282
Auto Scale	283
Reset Auto Scale	283
Show Grid	283
Background Color	284

Min - Max Level

Selects the minimum and maximum value of the y-axis.

Remote command:

`:SENSe[:POWER]:SWEep:FREQuency:YSCale:MAXimum` on page 565
`:SENSe[:POWER]:SWEep:FREQuency:YSCale:MINimum` on page 565
`:SENSe[:POWER]:SWEep:POWer:YSCale:MAXimum` on page 578
`:SENSe[:POWER]:SWEep:POWer:YSCale:MINimum` on page 578
`:SENSe[:POWER]:SWEep:TIME:YSCale:MAXimum` on page 582
`:SENSe[:POWER]:SWEep:TIME:YSCale:MINimum` on page 583

Auto Scale

Activates autoscaling of the y-axis of the diagram. The "Auto Scale" function adjusts the scale divisions so that the entire trace fits into the diagram area.

"Off" Auto scale is deactivated. Switching from activated to be deactivated, the scaling is maintained.

"Expand Only (Coarse/Fine)"

Auto scale is activated. Automatically selects the appropriate scaling of the y-axis so that the trace is always visible. The range is expanded when a value is out of the right or the left end-of-scale value. The step width is 5 dB for selection "Exp. (Coarse)" and variable in the range of 0.2 dB to 5 dB for selection "Exp. (Fine)".

"Float (Coarse/Fine)"

Auto scale is activated, that means this parameter automatically selects the appropriate scaling of the y-axis so that the trace is always visible. The range is either expanded, when a value is out of the right/left end-of-scale value or it is reduced when the trace fits into a smaller scale area. The step width is 5 dB for selection "Flt. (Coarse)" and variable in the range of 0.2 dB to 5 dB for selection "Flt. (Fine)".

Remote command:

`:SENSe[:POWER]:SWEep:FREQuency:YSCale:AUTO` on page 564
`:SENSe[:POWER]:SWEep:POWer:YSCale:AUTO` on page 577
`:SENSe[:POWER]:SWEep:TIME:YSCale:AUTO` on page 582

Reset Auto Scale

Resets the scaling of the y-axis to suitable values after the use of auto scaling in the expanding mode. For this mode, the Y scale can get too expanded because of temporary high-power values. The reset function resets the diagram again, to indicate smaller power values.

Remote command:

`:SENSe[:POWER]:SWEep:FREQuency:YSCale:AUTO:RESet` on page 565
`:SENSe[:POWER]:SWEep:POWer:YSCale:AUTO:RESet` on page 577
`:SENSe[:POWER]:SWEep:TIME:YSCale:AUTO:RESet` on page 582

Show Grid

Activates the indication of a grid in the diagram area.

Remote command:

`:DISPlay[:WINDow][:POWER]:SWEep:GRID:STATe` on page 549

Background Color

Sets the background color of the diagram to black or white. The background color is also effective for the hardcopy of the diagram.


Remote command:

`:DISPlay[:WINDow] [:POWer]:SWEep:BACKground:COLor` on page 549

Window list

Access:

1. Select "Clk Syn / FE / Pow Sens" > "NRP Power Analysis".
2. Select "Config..." > "NRP Config".
3. Select "Window List".



The "Window List" dialog provides functions to activate only the required "Views" on the checkboxes to the right.


The remote commands required to define the settings are described in [Section 15.15.5, "SENSe SWEep subsystem"](#), on page 551.

Settings:

Standard View	285
Marker View	285
Gate View	286
Pulse Data View	286
Full Screen	287

Standard View

Shows the graph and the button bar at the left for frequency power and level sweep measurement.



Remote command:

`:TRACe[:POWER]:SWEep:MEASurement:STANdard:DISPlay:ANNotation[:STATe]` on page 594


Marker View

Shows the graph and the corresponding marker values at the bottom for frequency power and level sweep measurement.

Up to four markers can be used to display the current power according to the position of the marker. R&S SMA100B indicates the marker values on the bottom of the diagram.

To move the marker lines, you can select them and drag them with your finger. Alternatively you can move them with the rotary knob.

For details on configuring the markers, see "[Marker settings](#)" on page 276.



Remote command:

```
:TRACe[:POWER]:SWEep:MEASurement:MARKer:DISPlay:ANNotation[:  
STATe] on page 594
```

Gate View


Shows the graph with the corresponding gate data for time trace and pulse data measurements.

Remote command:

```
:TRACe[:POWER]:SWEep:MEASurement:GATE:DISPlay:ANNotation[:STATe]  
on page 593
```

Pulse Data View

Shows the graph and the corresponding pulse data for time trace and pulse data measurements.




Remote command:

`:TRACe[:POWER]:SWEep:MEASurement:PULSe:DISPlay:ANNotation[:STATe]` on page 594

Full Screen

Shows the graph in fullscreen, and fades out buttons and list values for frequency power and level sweep measurement.



Remote command:

`:TRACe[:POWER]:SWEep:MEASurement:FULLscreen:DISPlay:ANNotation[:STATe]` on page 593

Trace settings

Access:

1. Select "Clk Syn / FE / Pow Sens" > "NRP Power Analysis".
2. Select "Config..." > "NRP Trace" > "Trace n".
3. Set "Mode" > "Time".
4. Select "Configure Time Mode"
5. Select the "Trace" tab.

Configure Measurement	Configure Sensors	Configure Diagram	Configure Time Mode	Next Window List		X
Trace		Indication		Trace		
1		1				
Pulse Analysis	☐	All Annotations Off		Pulse Data Notifications		
Thresholds				Trigger		
Base	Voltage Related					
Distal	90.00 %					
Mesial	50.00 %					
Proximal	10.00 %					
				Gate Mode		

The "Trace" tab contains the parameters for the evaluation of important pulse parameters, provided the used power sensor supports automatic pulse analysis.

Trace

Selects the trace the sensor is assigned to.

To assign a sensor to a trace, use the trace buttons, see [Off / NRP-Zxx](#).

Indication

Indicates the type of power sensor assigned to the selected trace. This field is automatically updated if the sensor is connected or disconnected. Also, this sensor is indicated on the trace button in the measurement diagram.

This parameter is only available for [Configure measurement settings](#) > "Time".

Remote command:

n.a.

Pulse Analysis

Activates pulse data analysis.

To start the automatic pulse analysis, select "Start Cont." button in the main measurement diagram.

Remote command:

`:SENSe<ch>[:POWER]:SWEep:TIME[:SENSor]:PULSe:STAtE` on page 557

All Annotations Off

Indicates the state of the annotations.

Remote command:

n.a.

Base

Selects the calculation basis for the threshold parameters.

"Voltage related"

Calculates the pulse parameters rise/fall time and pulse width by the voltage over time $U(t)$.

Voltage-related parameters represent the usual case.

"Power related"

Represents the pulse parameters as power values.

To obtain equivalent power-dependent values, the voltage-dependent threshold values are converted (squared), (see example in table below).

	Distal	Mesial	Proximal
Voltage related:	90%	50%	10%
Power related:	81%	25%	1 %
log. Scale (for example): (approximately, difference between top- base power > 30 dB)	-0.9dB	-6dB	-20dB

Remote command:

`:SENSe<ch>[:POWER]:SWEep:TIME[:SENSor]:PULSe:THReshold:BASE`

on page 557

`:TRACe<ch>[:POWER]:SWEep:PULSe:THReshold:BASE?` on page 591

Distal

Sets the upper reference level in terms of percentage of the overall pulse level (power or voltage related). The distal power defines the end of the rising edge and the start of the falling edge of the pulse.

Remote command:

`:SENSe<ch>[:POWER]:SWEep:TIME[:SENSor]:PULSe:THReshold:POWER:`

`HREFeRence` on page 557

`:TRACe<ch>[:POWER]:SWEep:PULSe:THReshold:POWER:HREFeRence`

on page 591

Medial

Sets the medial reference level in terms of percentage of the overall pulse level (power or voltage related). This level is used to define the pulse width (τ) and pulse period.

Remote command:

```
:SENSe<ch>[:POWER]:SWEep:TIME[:SENSor]:PULSe:THReshold:POWER:
REFErence on page 558
:TRACe<ch>[:POWER]:SWEep:PULSe:THReshold:POWER:REFErence
on page 592
```

Proximal

Sets the lower reference level in terms of percentage of the overall pulse level (power or voltage related).

The proximal power defines the start of the rising edge and the end of the falling edge of the pulse.

Remote command:

```
:SENSe<ch>[:POWER]:SWEep:TIME[:SENSor]:PULSe:THReshold:POWER:
LREFErence on page 558
:TRACe<ch>[:POWER]:SWEep:PULSe:THReshold:POWER:LREFErence
on page 592
```

Configure sensor settings

Access:

1. Select "Clk Syn / FE / Pow Sens" > "NRP Power Analysis".
2. Select "Config..." > "Sensors"

Configure Measurement	Configure Sensors	Configure Diagram	Configure Time Mode	Next Window List		X
2 - NRP-Z81		Zero				
Level Offset		On		3.00 dB		
S-Parameter		Unused				
Separate Frequency						
Use Separate Frequ.		☒				
1.000 000 MHz						

The "Configure Sensors" dialog provides specific parameters for the power sensor. This part of the dialog can differ from the following description depending on the sensor used. Refer to the manual of the power sensor in this case.

Mapping

Opens the "Sensor Mapping" dialog.

See [Section 9.4.6, "NRP sensor mapping"](#), on page 263.

Power Sensor - Power Analysis

Selects the power sensor to be set if more than one sensor is connected to the instrument.

Remote command:

n.a.

In remote control, the sensor is selected via the numeric suffix in the sense key word of the command, for example `SENSe2:POWer:SWEep:....`

Zero - Power Analysis

Activates the auto zero function.

Zeroing calibrates the external power sensor by adjusting its reading at zero signal power. For this purpose, the RF power source must be switched off or disconnected from the sensor. If a Rohde & Schwarz power sensor receives an input power during the zeroing process, it aborts zeroing and generates an error message. Zeroing takes a few seconds, depending on the sensor model. Refer to the documentation of your power sensor for more information.

Tips for zeroing

When to perform zeroing:

- During warm up after switching on or connecting the instrument
- After a substantial change of the ambient temperature
- After fastening the power sensor module to an RF connector at high temperature
- After several hours of operation
- When low-power signals are to be measured, e.g. less than 10 dB above the lower measurement limit.
- Switch off the RF power source for zeroing, but do not disconnect it from the power sensor. This proceeding keeps the thermal equilibrium, and the zeroing process also compensates the noise that superimposes the measured signal (e.g. from a broadband amplifier).

Pulse Data

Accesses the dialog for configuring the settings for pulse data analysis.

See ["Trace settings"](#) on page 288.

Trigger..

Accesses the dialog for configuring the trigger settings.

See ["Trigger settings"](#) on page 298

Level Offset State - Power Analysis

Activates a level offset at the sensor input. Set the offset value in the entry field on the right.

Remote command:

`:SENSe<ch>[:POWER]:SWEep:FREQuency[:SENSor]:OFFSet:STATe`

on page 553

`:SENSe<ch>[:POWER]:SWEep:TIME[:SENSor]:OFFSet:STATe` on page 556

`:SENSe<ch>[:POWER]:SWEep:TIME[:SENSor]:OFFSet:STATe` on page 556

Level Offset - Power Analysis

Sets the level offset at the sensor input. To consider the value, activate the offset.

Remote command:

`:SENSe<ch>[:POWER]:SWEep:FREQuency[:SENSor]:OFFSet` on page 553

`:SENSe<ch>[:POWER]:SWEep:POWer[:SENSor]:OFFSet` on page 555

`:SENSe<ch>[:POWER]:SWEep:TIME[:SENSor]:OFFSet` on page 556

Use S-Parameter - Power Analysis

Activates the use of the S-parameters correction data of the connected power sensor. For sensors with attenuator, this checkbox is automatically checked.

Refer also to the manual of the connected R&S power sensor for a description on how to use the S-parameters table.

Use Separate Frequency- Power Analysis

This setting is offered for measurements with DUTs that change the measurement frequency (like modulators), thus changing the input frequency of the sensor.

The parameters vary depending on the measurement modes:

- Power versus frequency measurement
Activates the use of a different frequency range other than the set signal generator frequency range for the measurement. The separate minimum and maximum frequency values are set below.
The x-scale of the diagram can be adjusted to the separate frequency range with functions "Use as X Scale" and "Map to X Scale".
- Power versus power measurement / Power versus time measurement
Activates the use of a different frequency other than the set signal generator frequency for the measurement. The separate frequency value is set in the entry window below.

Remote command:

`:SENSe<ch>[:POWER]:SWEep:FREQuency[:SENSor]:SRANge[:STATe]`

on page 554

`:SENSe<ch>[:POWER]:SWEep:POWer[:SENSor]:SFRequency:STATe`

on page 556

`:SENSe<ch>[:POWER]:SWEep:POWer[:SENSor]:SFRequency` on page 555

`:SENSe<ch>[:POWER]:SWEep:TIME[:SENSor]:SFRequency:STATe`

on page 559

`:SENSe<ch>[:POWER]:SWEep:TIME[:SENSor]:SFRequency` on page 559

Min Frequency - Power Analysis

This parameter is only available for [Configure measurement settings](#) > "Frequency" and [Use Separate Frequency- Power Analysis](#) > "Active".

Sets the minimum frequency of the measurement.

Remote command:

```
:SENSe<ch>[:POWER]:SWEep:FREQuency[:SENSor]:SRANge:STARt
```

on page 553

Max Frequency - Power Analysis

This parameter is only available for [Configure measurement settings](#) > "Frequency" and [Use Separate Frequency- Power Analysis](#) > "Active".

Sets the maximum frequency of the measurement.

Remote command:

```
:SENSe<ch>[:POWER]:SWEep:FREQuency[:SENSor]:SRANge:STOP
```

on page 554

Use as X Scale - Power Analysis

This parameter is only available for [Configure measurement settings](#) > "Frequency" and [Use Separate Frequency- Power Analysis](#) > "Active".

Activates the use of the separate frequency min and max values for the scaling of the x-axis. Thus, the trace for this sensor is visible in the diagram, especially for frequency ranges that differ substantially from the generator settings.

If more than one sensor is active, which use separate frequencies, the option is only available for one sensor. To indicate the traces of the other sensors, use function "Map to X Scale".

Remote command:

n.a.

Map to X Scale - Power Analysis

This parameter is only available for [Configure measurement settings](#) > "Frequency" and [Use Separate Frequency- Power Analysis](#) > "Active".

Maps the trace of a sensor that uses separate frequency to the current scaling of the diagram. Usually the scale is determined by the set frequency range of the generator. If more than one sensor is active, which use separate frequencies, the scale can also be determined by the separate frequency range of one of the other sensors.

Remote command:

n.a.

Configure time mode settings

The time measurement mode enables you to analyze internally generated or externally supplied signals. In time mode, the measurement requires an additional trigger event, with selectable level, hysteresis and drop time. In time domain, you can also analyze measured pulse data.

Pulse data notifications settings

Access:

1. Select "Clk Syn / FE / Pow Sens" > "NRP Power Analysis".
2. Select "Configure" > "Configure Measurement".


3. Set "Mode" > "Time".
4. Select "Configure Time Mode"
5. Select the "Pulse Data notifications" tab.

Configure Measurement	Configure Sensors	Configure Diagram	Configure Time Mode	Next Window List		×
Duty Cycle	☐	Rise Time	☒		Trace	
Pulse Width	☒	Pulse Start Time	☐		Pulse Data Notifications	
Pulse Period	☒	Overshoot (Rising Edge)	☐		Trigger	
Pulse Off Time	☒	Fall Time	☒		Gate Mode	
		Pulse Stop Time	☐			
		Overshoot (Falling Edge)	☐			
Signal Power		Pulse Power				
Peak Power	☒	Top Power	☐			
Average Power	☐	Base Power	☒			
Minimal Power	☐	Distal Power	☒			
		Mesial Power	☒			
		Proximal Power	☐			

In the "Pulse Data Notification" tab, you can determine the parameter values to be indicated on bottom of the diagram.

Notifications - Pulse Data Analysis

Selects the pulse parameters to be indicated below the measurement diagram.



Duty Cycle ← Notifications - Pulse Data Analysis

Indicates the ratio between the pulse duration (τ) and the pulse period (T) of the measured pulse signal in per cent:

$$\text{Duty Cycle} = (\text{pulse duration} / \text{pulse period}) * 100$$

Remote command:

`:TRACe<ch>[:POWER]:SWEep:MEASurement:PULSe:DCYClE?` on page 589

`:TRACe<ch>[:POWER]:SWEep:MEASurement:PULSe:DCYClE:DISPlay:ANNotation[:STATe]` on page 590

Pulse Width ← Notifications - Pulse Data Analysis

Indicates the pulse duration of the pulse data measurement in seconds.

Remote command:

`:TRACe<ch>[:POWER]:SWEep:MEASurement:PULSe:DURation?` on page 589

`:TRACe<ch>[:POWER]:SWEep:MEASurement:PULSe:DURation:DISPlay:ANNotation[:STATe]` on page 590

Pulse Period ← Notifications - Pulse Data Analysis

Indicates the time the pulse signal needs to complete one cycle.

Remote command:

`:TRACe<ch>[:POWER]:SWEep:MEASurement:PULSe:PERiod?` on page 589

`:TRACe<ch>[:POWER]:SWEep:MEASurement:PULSe:PERiod:DISPlay:ANNotation[:STATe]` on page 590

Pulse Off Time ← Notifications - Pulse Data Analysis

Determines the time the pulse signal is low, that means as long as the signal level is below the proximal value.

Remote command:

:TRACe<ch>[:POWER]:SWEep:MEASurement:PULSe:SEParation? on page 589

:TRACe<ch>[:POWER]:SWEep:MEASurement:PULSe:PERiod:DISPlay:

ANNotation[:STATe] on page 590

Transition Times - Pulse Data Analysis

Selects the transition parameters of the pulse signal to be indicated below the measurement diagram.

The R&S NRP-Z sensor searches for the first rising edge and the first falling edge in the trace.

Rise Time / Fall Time ← Transition Times - Pulse Data Analysis

Displays the time the signal requires from crossing low reference until it reaches high reference level and vice versa.

Remote command:

:TRACe<ch>[:POWER]:SWEep:MEASurement:TRANSition:NEGative:DURation? on page 589

:TRACe<ch>[:POWER]:SWEep:MEASurement:TRANSition:NEGative:DURation:DISPlay:ANNotation[:STATe] on page 590

:TRACe<ch>[:POWER]:SWEep:MEASurement:TRANSition:POSitive:DURation? on page 589

:TRACe<ch>[:POWER]:SWEep:MEASurement:TRANSition:POSitive:DURation:DISPlay:ANNotation[:STATe] on page 590

Pulse Start Time / Pulse Stop Time ← Transition Times - Pulse Data Analysis

Displays the time when the pulse signal crosses the medial reference level.

Remote command:

:TRACe<ch>[:POWER]:SWEep:MEASurement:TRANSition:NEGative:OCCurrence? on page 589

:TRACe<ch>[:POWER]:SWEep:MEASurement:TRANSition:NEGative:OCCurrence:DISPlay:ANNotation[:STATe] on page 590

:TRACe<ch>[:POWER]:SWEep:MEASurement:TRANSition:POSitive:OCCurrence? on page 589

:TRACe<ch>[:POWER]:SWEep:MEASurement:TRANSition:POSitive:OCCurrence:DISPlay:ANNotation[:STATe] on page 590

Overshoot (Rising Edge / Falling Edge) ← Transition Times - Pulse Data Analysis

Display the maximum value of the pulse signal following a rising transition and the minimum value of the signal after a falling transition, respectively.

Overshoot values are given in per cent of the pulse amplitude as shown below:

- $\text{Overshoot}(\text{pos}) = 100 \cdot (\text{maximum} - \text{top level}) / (\text{top level} - \text{base level})$
- $\text{Overshoot}(\text{neg}) = 100 \cdot (\text{base level} - \text{minimum}) / (\text{top level} - \text{base level})$

Remote command:

:TRACe<ch>[:POWER]:SWEep:MEASurement:TRANSition:POSitive:OVERshoot? on page 589

:TRACe<ch>[:POWER]:SWEep:MEASurement:TRANSition:POSitive:OVERshoot:DISPlay:ANNotation[:STATe] on page 590

`:TRACe<ch>[:POWER]:SWEep:MEASurement:TRANSition:NEGative:OVERshoot?` on page 589

`:TRACe<ch>[:POWER]:SWEep:MEASurement:TRANSition:NEGative:OVERshoot:DISPlay:ANNotation[:STATe]` on page 590

Signal Power - Pulse Data Analysis

Selects the power parameters of the pulse signal to be indicated below the measurement diagram.

Minimal / Peak / Average Power ← Signal Power - Pulse Data Analysis

Display the minimum, the maximum and the average power of the pulse signal in dBm.

Remote command:

`:TRACe<ch>[:POWER]:SWEep:MEASurement:POWER:MINimum?` on page 589

`:TRACe<ch>[:POWER]:SWEep:MEASurement:POWER:MINimum:DISPlay:ANNotation[:STATe]` on page 590

`:TRACe<ch>[:POWER]:SWEep:MEASurement:POWER:MAXimum?` on page 589

`:TRACe<ch>[:POWER]:SWEep:MEASurement:POWER:MAXimum:DISPlay:ANNotation[:STATe]` on page 590

`:TRACe<ch>[:POWER]:SWEep:MEASurement:POWER:AVERage?` on page 589

`:TRACe<ch>[:POWER]:SWEep:MEASurement:POWER:AVERage:DISPlay:ANNotation[:STATe]` on page 590

Pulse Power - Pulse Data Analysis

Selects which pulse power parameters are indicated in the diagram (pulse data view only).

Top / Base Power ← Pulse Power - Pulse Data Analysis

Indicate the pulse top and base level of the analyzed signal in dBm.

Remote command:

`:TRACe<ch>[:POWER]:SWEep:MEASurement:POWER:PULSe:BASE?` on page 589

`:TRACe<ch>[:POWER]:SWEep:MEASurement:POWER:PULSe:BASE:DISPlay:ANNotation[:STATe]` on page 590

`:TRACe<ch>[:POWER]:SWEep:MEASurement:POWER:PULSe:TOP?` on page 589

`:TRACe<ch>[:POWER]:SWEep:MEASurement:POWER:PULSe:TOP:DISPlay:ANNotation[:STATe]` on page 590

Distal / Mesial / Proximal Power ← Pulse Power - Pulse Data Analysis

Display the absolute power values of the medial, low and high reference level in dBm.

Remote command:

`:TRACe<ch>[:POWER]:SWEep:MEASurement:POWER:LREference?` on page 589

`:TRACe<ch>[:POWER]:SWEep:MEASurement:POWER:LREference:DISPlay:ANNotation[:STATe]` on page 590

`:TRACe<ch>[:POWER]:SWEep:MEASurement:POWER:HREference?` on page 589

`:TRACe<ch>[:POWER]:SWEep:MEASurement:POWER:HREference:DISPlay:ANNotation[:STATe]` on page 590

`:TRACe<ch>[:POWER]:SWEep:MEASurement:POWER:REference?` on page 589
`:TRACe<ch>[:POWER]:SWEep:MEASurement:POWER:REference:DISPlay:ANNotation[:STATe]` on page 590

Trigger settings

Access:

1. Select "Clk Syn / FE / Pow Sens" > "NRP Power Analysis".
2. Select "Configure" > "Configure Measurement".
3. Set "Mode" > "Time".
4. Select "Configure Time Mode"
5. Select the "Trigger" tab.

Configure Measurement	Configure Sensors	Configure Diagram	Configure Time Mode	Next Window List		X
Sensor		2 - NRP-Z81			Trace	
Mode		Auto			Level 1.000 dBm	
Slope		Positive			Hysteresis 0.500 dB	
Drop Out Time		200 ns			Auto Set	
					Gate Mode	

Sensor - Power Analysis

Selects the power sensor to be set if more than one sensor is connected to the instrument.

Remote command:

n.a.

In remote control, the sensor is selected via the numeric suffix in the sense key word of the command, for example `SENSe2:POWER:SWEep:....`

Mode - Power Analysis

Selects if the measurement is free running, or starts only after an internal or external trigger event.

Remote command:

`:SENSe<ch>[:POWER]:SWEep:TIME[:SENSor]:TRIGger:SOURce` on page 561

Level - Power Analysis

Sets the trigger threshold. This setting is also possible by the trigger marker on the left side of the diagram.

Remote command:

`:SENSe<ch>[:POWER]:SWEep:TIME[:SENSor]:TRIGger:LEVel` on page 560

Slope - Power Analysis

Sets the polarity of the active slope of the trigger signals.

"Positive" The rising edge of a trigger signal is active.

"Negative" The falling edge of a trigger signal is active.

Remote command:

`:SENSe<ch>[:POWER]:SWEep:TIME[:SENSor]:TRIGger:SLOPe` on page 560

Hysteresis - Power Analysis

Sets the hysteresis of the internal trigger threshold. Hysteresis is the magnitude (in dB) the trigger signal level must drop below the trigger threshold (positive trigger slope) before triggering can occur again.


Remote command:

`:SENSe<ch>[:POWER]:SWEep:TIME[:SENSor]:TRIGger:HYSTeresis`
on page 560

Drop out Time - Power Analysis

Determines the minimum time for which the signal must be below (above) the power level defined by [Level - Power Analysis](#) and [Hysteresis - Power Analysis](#) before triggering can occur again. This setting prevents the trigger system from being activated too early if the trigger threshold is temporarily underranged or exceeded.

The dropout time parameter is useful when dealing with, for example, GSM signals with several active slots. When measuring in sync with the signal, a trigger event must be generated at A, but not at B or C. As the RF power between the slots is below the threshold defined by [Level - Power Analysis](#) and [Hysteresis - Power Analysis](#), the trigger hysteresis cannot prevent triggering at B or at C. To achieve triggering at A, the value of the drop out time must be greater than the time interval between E and B and between F and C. But it must be lower than the time that elapses between G and A.



As the mechanism associated with the dropout time parameter is reactivated whenever the trigger threshold is crossed, unambiguous triggering can also be obtained for many complex signals. By contrast, all triggering is suppressed during the hold-off time. The example nevertheless shows that you can achieve stable triggering conditions with a suitable hold-off time, i.e. regular triggering at the same point. But setting a trigger that occurs at A exclusively is not possible.

it would not be possible to set exclusive triggering at A . But you cannot set a trigger that occurs exclusively at A.

Remote command:

`:SENSe<ch>[:POWer]:SWEep:TIME[:SENSor]:TRIGger:DTIME` on page 559

Auto Set - Power Analysis

Sets the trigger level, the hysteresis and the drop out time to default values.

Remote command:

`:SENSe<ch>[:POWer]:SWEep:TIME[:SENSor]:TRIGger:AUTO` on page 559

Gate mode settings



For "Time" measurement mode only.

Access:

1. Select "Clk Syn / FE / Pow Sens" > "NRP Power Analysis".
2. Select "Configure" > "Configure Measurement".
3. Set "Mode" > "Time".
4. Select "Configure Time Mode"

5. Select the "Gate Mode" tab.

Configure Measurement	Configure Diagram	Configure Gate Mode	Configure Sensors	NEXT WINDOW List		✕
Trace		2	Indication	2 - NRP-Z81		
State ● On						
Gate 1						
Start		5.000 000 µs		Stop		15.000 000 µs
Gate 2						
Start		25.000 000 µs		Stop		35.000 000 µs

The "Gate Mode" tab contains the parameters for defining the time gates for the measurement.

Almost all R&S NRP sensors also support time gated measurements of peak and average power (see the specifications document or operating manual of the respective sensor). Two user-configurable gates can be assigned to one of the traces. Both gates are active at the same time. The values are calculated from the trace data, the time resolution is determined by the resolution of the sensor. An external trigger signal or signal triggering is required for synchronization.

For more information, refer to the specifications document.

The start and stop time of the gates are indicated as gate markers, a bar between the start and stop marker shows the gate length. The indication state of the gate borders and measurement values is only available for certain diagram views which are switched with the "Next Window List" key. The "Next Window List" dialog provides a selection of views, between which is toggled (see ["Window list"](#) on page 284).

Trace - Gate

Selects the trace of the sensor assigned for the gate measurement. Both gates are assigned to the same trace.

To assign the sensor to a trace, use the trace buttons, see [Off / NRP-Zxx](#).

Remote command:

`:CALCulate[:POWER]:SWEep:TIME:GATE<ch>:FEED` on page 546

Indication

Indicates the type of power sensor assigned to the selected trace. This field is automatically updated if the sensor is connected or disconnected. Also, this sensor is indicated on the trace button in the measurement diagram.

This parameter is only available for [Configure measurement settings](#) > "Time".

Remote command:

n.a.

State - Gate

Enables time gated measurement. The measurement is started with the "Start" button in the main measurement diagram. Both gates are active at one time.

The gate borders and the measurement values (average and peak power) are indicated in/below the measurement diagram. The indication is only available for certain diagram views which are switched with the "Rearrange" key.

Remote command:

[:CALCulate\[:POWER\]:SWEep:TIME:GATE<ch>:STATe](#) on page 547

[:CALCulate\[:POWER\]:SWEep:TIME:GATE<ch>:AVERage?](#) on page 545

[:CALCulate\[:POWER\]:SWEep:TIME:GATE<ch>:MAXimum?](#) on page 546

[:TRACE\[:POWER\]:SWEep:MEASurement:GATE:DISPlay:ANNotation\[:STATe\]](#) on page 593

Start / Stop - Gate

Sets the start and the stop times for the respective gate.

Remote command:

[:CALCulate\[:POWER\]:SWEep:TIME:GATE<ch>:START](#) on page 546

[:CALCulate\[:POWER\]:SWEep:TIME:GATE<ch>:STOP](#) on page 546

9.4.7.7 Creating screenshots of power analysis settings

The power analysis save function enables you to save current settings in a file. To document the most important settings for a performed signal generation, you can also save a hardcopy of the current display.


Save (Power analysis) settings

In the "Save ..." dialog you can find the settings to store a screenshot of the current measurement diagram. The current screen shot is stored as indicated, that means with or without marker indication.

Main settings

Access:

1. Select "Clk Syn / FE / Pow Sens" > "NRP Power Analysis".
2. In the diagram window, open the context-sensitive menu.
3. In the menu, select "Save... (Power Analysis)".



File name - Power Analysis

Indicates the file name and directory.

Remote command:

:SENSe[:POWER]:SWEep:HCOPY[:EXECute] on page 573

:SENSe[:POWER]:SWEep:HCOPY:FILE[:NAME] on page 569

:SENSe[:POWER]:SWEep:HCOPY:FILE[:NAME]:AUTO:STATe on page 570

:SENSe[:POWER]:SWEep:HCOPY:FILE[:NAME]:AUTO:FILE? on page 570

Format - Power Analysis

Selects the file format.

Several bitmap graphic formats are offered. In addition, format *.csv is available which stores the measurement values as ASCII data.

You can refine the csv settings further, see "[CSV options](#)" on page 306.

Remote command:

:SENSe[:POWER]:SWEep:HCOPY:DEVIce:LANGuage on page 567

Options


Opens a dialog to select the screenshot format and also to activate and select the automatic naming settings.

Common settings

Access:

1. Select "Clk Syn / FE / Pow Sens" > "NRP Power Analysis".

2. In the diagram window, open the context-sensitive menu.
3. In the menu, select "Save... (Power Analysis)".
4. Select "Options".



Automatic Naming

If enabled, the file names are created by selected rules. The filename includes at least one number and optionally additional information.

Remote command:

[:SENSe\[:POWER\]:SWEep:HCOPY:FILE\[:NAME\]:AUTO:STATE](#) on page 570

Format - Power Analysis

Selects the file format.

Several bitmap graphic formats are offered. In addition, format *.csv is available which stores the measurement values as ASCII data.

You can refine the csv settings further, see ["CSV options"](#) on page 306.

Remote command:

[:SENSe\[:POWER\]:SWEep:HCOPY:DEVIce:LANGuage](#) on page 567

Automatic naming settings

Access:

1. Select "Clk Syn / FE / Pow Sens" > "NRP Power Analysis".
2. In the diagram window, open the context-sensitive menu.
3. In the menu, select "Save... (Power Analysis)".
4. Select "Options".
5. In the "Save NRP-Z Analysis Options" dialog, enable "Automatic Naming."

Save NRP-Z Analysis Options

Path ... C:\Users\Bozhanov\Documents

Common

Delete All Image Files In Path Clear Path Automatic Naming

Prefix ☒ smab

Year ☒ Month ☒ Day ☒

Current Auto Number 000

Resulting File Name
smab20181113000.bmp

Path

Sets the directory for saving the files.

Remote command:

`:SENSe[:POWER]:SWEep:HCOPY:FILE[:NAME]:AUTO:DIRectory` on page 569

Clear Parth

Deletes all image files with extensions "bmp", "img", "png", "xpm" and "csv" in the directory set for automatic naming.

Remote command:

`:SENSe[:POWER]:SWEep:HCOPY:FILE[:NAME]:AUTO:DIRectory:CLear`
on page 569

Prefix, Year, Month, Day, Instrument Name

A selection of the prefix, year, month, day and instrument name are included in the file name.

Remote command:

`:SENSe[:POWER]:SWEep:HCOPY:FILE[:NAME]:AUTO[:FILE]:PREFix:STAtE`
on page 572

`:SENSe[:POWER]:SWEep:HCOPY:FILE[:NAME]:AUTO[:FILE]:PREFix`
on page 572

`:SENSe[:POWER]:SWEep:HCOPY:FILE[:NAME]:AUTO[:FILE]:DAY:STAtE`
on page 571

`:SENSe[:POWER]:SWEep:HCOPY:FILE[:NAME]:AUTO[:FILE]:DAY?`
on page 571

`:SENSe[:POWer]:SWEep:HCOPY:FILE[:NAME]:AUTO[:FILE]:MONTH:STATe`

on page 571

`:SENSe[:POWer]:SWEep:HCOPY:FILE[:NAME]:AUTO[:FILE]:MONTH?`

on page 571

`:SENSe[:POWer]:SWEep:HCOPY:FILE[:NAME]:AUTO[:FILE]:YEAR:STATe`

on page 573

`:SENSe[:POWer]:SWEep:HCOPY:FILE[:NAME]:AUTO[:FILE]:YEAR?`

on page 573

Current Auto Number

Indicates the number which is used in the automatically generated file name.

Remote command:

`:SENSe[:POWer]:SWEep:HCOPY:FILE[:NAME]:AUTO[:FILE]:NUMBER?`

on page 572

Resulting File Name

Indicates the automatically generated file name.

Remote command:

`:SENSe[:POWer]:SWEep:HCOPY:FILE[:NAME]:AUTO:FILE?` on page 570

CSV options

Access:

1. Select "Clk Syn / FE / Pow Sens" > "NRP Power Analysis".
2. In the diagram window, open the context-sensitive menu.
3. In the menu, select "Save... (Power Analysis)".
4. Set "Format" > "CSV".
5. Select "Options".
6. Select the "CSV Options" tab.

Save NRP-Z Analysis Options		
Orientation	Vertical	Common
Separator	,	Automatic Naming
Decimal Point	.	CSV Options
Row Header	Off	

If file format `*.csv` is selected, the trace data is saved as an ASCII file with separated values. CSV files can be imported into the program MS Excel and then processed further. Adjust the value separator and the decimal point according to the language version, to import the data correctly.

Orientation

Defines the orientation of the X/Y value pairs:

- **Horizontal:**
 - X/Y values of trace 1 in rows 1 and 2,
 - X/Y values of trace 2 in rows 3 and 4,
 - X/Y values of trace 3 in rows 5 and 6,
 - X/Y values of trace 4 in rows 7 and 8.

Example:

```
Trace1,X[Hz]: 10000.0; 10010.0; 10020.0; 10030.0; ...
Trace1,Y[dBm]: -20.09; -19.17; -18.19; -15.43; ...
Trace2,X[Hz]: 10000.0; 10010.0; 10020.0; 10030.0; ...
Trace2,Y[dBm]: -19.09; -18.17; -17.19; -14.43; ...
Trace3,X[Hz]: 10000.0; 10010.0; 10020.0; 10030.0; ...
Trace3,Y[dBm]: -21.09; -20.17; -19.19; -16.43; ...
Trace4,X[Hz]: 10000.0; 10010.0; 10020.0; 10030.0; ...
Trace4,Y[dBm]: -22.07; -20.14; -21.56; -17.67; ...
```

- **Vertical:**
 - X/Y values of trace 1 in column 1 and 2,

X/Y values of trace 2 in column 3 and 4,
 X/Y values of trace 3 in column 5 and 6,
 X/Y values of trace 4 in column 7 and 8.

Example:

```
Trace1,X[Hz]; Trace1,Y[dBm]; Trace2,X[Hz]; Trace2,Y[dBm]; Trace3,X[Hz];
Trace3,Y[dBm]; Trace4,X[Hz]; Trace4,Y[dBm];
10000.0;-20.09;10000.0; -19.09;10000.0;21.09;10000.0;22.07;
10010.0;-19.17;10010.0;-18.17;10010.0; -20.17;10010.0; -20.14;
10020.0;-18.19;10020.0;-17.19;10020.0;-19.19;10020.0;-21.56;
10030.0; -15.43;10030.0; -14.43;10030.0;-16.43;10030.0;-17.67;...
```

Remote command:

```
:SENSe[:POWER]:SWEep:HCOPY:DEVIce:LANGuage:CSV:ORientation
on page 568
```

Separator

Defines the character to be used to separate the values: tabulator, semicolon, comma or blank.

Remote command:

```
:SENSe[:POWER]:SWEep:HCOPY:DEVIce:LANGuage:CSV[:COLUMN]:
SEParator on page 568
```

Decimal Point

Defines the character to be used as the decimal point of the values: dot or comma.

Remote command:

```
:SENSe[:POWER]:SWEep:HCOPY:DEVIce:LANGuage:CSV:DPOint on page 567
```

Row Header

Defines a header for each row or column, depending on the orientation. A header contains information on the trace, e.g. the trace index, or frequency, power or time values.

Example:


```
Trace=2;Source=detecting..;X[Hz]";"Trace=2;Source=detecting..;Y[dBm]"
```

Remote command:


```
:SENSe[:POWER]:SWEep:HCOPY:DEVIce:LANGuage:CSV:HEADer on page 567
```

How to save a hardcopy of the power analysis window

1. Select "Clk Syn / FE / Pow Sens" > "NRP Power Analysis".
2. In the diagram window, open the context-sensitive menu.
3. In the menu, select "Save... (Power Analysis)".



4. To define the output format, select "Format > JPG".
5. Select "Options...".
6. To enable the instrument to create output filenames, select "Automatic Naming > On".
- 7.



In the "Automatic Naming" tab:

- a) To change the default directory the file is saved in, select "Path" and define a path and a filename. For example, select the default directory `/var/user`.
 - b) If necessary, disable or change some of the parameters in the "Automatic Naming Settings".
 - c) Close the "Save NRP-Z Analysis Options" dialog.
8. In the "Save NRP-Z Analysis" dialog, select "Save".
- The instrument saves a hardcopy of the current instrument display as a `*.jpg` file. The filename is automatically created.
9. To print the hardcopy, connect the instrument to a LAN and:
- a) Transfer the file to a remote computer as described in [Section 12.10, "Transferring files from and to the instrument"](#), on page 354.
 - b) On the remote computer, navigate through the file system.
 - c) Print the selected file.
- For more information, refer to the online help of the operating system.

9.4.7.8 How to set up a frequency sweep measurement

Prerequisites: the sensor is connected to the instrument and configured, see [Section 9.4, "Using power sensors"](#), on page 249.

1. Select "Clk Syn / FE / Pow Sens" > "NRP Power Analysis".
2. Select "Config..." > "NRP Config".
3. Set "Mode" > "Frequency".
4. Configure the measurement:
 - a) Set "Min = 8 KHz".
 - b) Set "Max = 6 GHz".
 - c) Set "Timing = Fast"
 - d) Set "Steps = 200".
5. Select the "Configure Diagram" tab.
Ho to: see [Section 9.4.7.11, "How to configure the power analysis diagram"](#), on page 312.
6. Select the "Sensors" tab.
7. Select the connected sensor, e.g. "2: NRP-Z81".
8. If you want to configure the frequency settings of the sensor differently than the generator settings, enable "Use Separate Frequ.".
 - a) Set "Min = 1 MHz".
 - b) Set "Max = 10 MHz".
9. Select the "NRP Config" tab.
10. In the "Next Window List" side tab, enable the "Standard View".

11. Close the "NRP Config" dialog.
12. Select "Start Continuous" to start the measurement.

9.4.7.9 How to set up a power sweep measurement

Prerequisites: the sensor is connected to the instrument and configured, see [Section 9.4, "Using power sensors"](#), on page 249.

1. Select "Clk Syn / FE / Pow Sens" > "NRP Power Analysis".
2. Select "Configure" > "Configure Measurement".
3. Set "Mode" > "Power".
4. Configure the measurement:
 - a) Set "Min = -20 dBm".
 - b) Set "Max = 30 dBm".
 - c) Set "Steps = 200".
5. Select the "Configure Diagram" tab.
Ho to: see [Section 9.4.7.11, "How to configure the power analysis diagram"](#), on page 312.
6. Select the "Configure Sensors" tab.
7. Select the connected sensor, e.g. "2-NRP-Z81".
8. If you want to configure the frequency settings of the sensor differently than the generator settings, enable "Use Separate Frequ.".
 - a) Set "1 MHz".
9. In the "Next Window List" tab, enable the "Standard View".
10. Close the "Configure" dialog.
11. Press "Start Cont" to start the measurement.

9.4.7.10 How to set up a pulse measurement

Prerequisites: the sensor is connected to the instrument and configured, see [Section 9.4, "Using power sensors"](#), on page 249.

1. Select "Clk Syn / FE / Pow Sens" > "NRP Power Analysis".
2. Select "Configure" > "Configure Measurement".
3. Set "Mode" > "Time".
4. Configure the measurement:
 - a) Set "Min = -5 us".
 - b) Set "Max = 45 us".

- c) Set "Steps = 200".
5. Select the "Configure Diagram" tab.
How to: see [Section 9.4.7.11, "How to configure the power analysis diagram"](#), on page 312.
6. Select the "Configure Sensors" tab.
7. Select the connected sensor, e.g. "2-NRP-Z81".
8. In the "Next Window List" tab, enable the "Pulse Data View".
9. Close the "Configure" dialog.
10. In the diagram window, open the context-sensitive menu.
11. Select "Trace/Pulse Data Notifications/ Trigger".
12. Select the "Trace" tab.
13. Set "State > On".
14. Set the thresholds:
 - a) Set "Base > Voltage Related".
 - b) Set "Distal = 90%".
 - c) "Mesial = 50%".
 - d) "Proximal = 10%".
15. Select the "Pulse Data Notifications" tab.
16. Enable up to six parameters, for example:
 - "Duty Cycle"
 - "Pulse Width"
 - "Pulse Period"
 - "Off Time"
 - "Start Time"
17. Close the "Trace/Pulse Data Notifications/ Trigger" dialog.
18. Press "Start Cont" to start the measurement.

9.4.7.11 How to configure the power analysis diagram

1. Select "Clk Syn / FE / Pow Sens" > "NRP Power Analysis".
2. Select "Configure" > "Configure Diagram".
3. Set "Max Level = 30 dBm".
4. Set "Min Level = -40 dBm".
5. Select "Auto Scale > Expand Only (Coarse)".
6. Enable "Show Grid".

- Set "Background Color > Black."

9.5 Improving the RF signal performance

To achieve an accurate input level at the DUT, you can compensate losses, e.g. caused by cables between the RF output and the DUT over a frequency range.

Using the user correction function and e.g., a R&S NRP power sensor, the R&S SMA100B utilizes the readings of the power sensor and creates a correction value table for controlling the output level during operation.

To connect the R&S NRP to the R&S SMA100B

- Connect the power sensor.
See [Section 9.4.2, "Connecting R&S NRP power sensors to the R&S SMA100B"](#), on page 251.
- Select "Clk Syn / FE / Pow Sens" > "NRP Sensor Mapping".
- If the sensor is not detected automatically, select "Scan > Start".
The instrument scans the network and the USB connections for connected sensors and lists all detected R&S NRP sensors in the mapping table.
- In the "Mapping" column, assign the sensor to a sensor channel, see [Section 9.4.6, "NRP sensor mapping"](#), on page 263.
- Close the dialog.

To configure and calibrate the R&S NRP in the R&S SMA100B

Provided the power sensor is connected to the R&S SMA100B and is assigned to a sensor channel, we recommend that you calibrate and configure the power sensor.

- Select "Level" > "RF ON > Off"
- Select "Clk Syn / FE / Pow Sens" > "NRP Power Viewer".

Power Viewer	Power Control	Sensor Configuration	Sensor Mapping		×
1: NRP-Z81 900008	Average	-52.42	dBm	Config ...	
2: NRP18SN 101748	Average	-1.03	dBm	Config ...	
3: NRP67TN 101015	Average	-38.20	dBm	Config ...	


- To configure a sensor, select "Config".

4. Select "Zero" to start zeroing of the sensor.
Note: Always turn the RF power off or disconnect the sensor from RF before zeroing, since the function calibrates the power sensor at zero signal power.
 The zeroing process takes a few seconds, depending on the power sensor type.
5. Configure additional parameters for the selected sensor as required.
6. Select "State > On".
7. Close the dialog.

To create user correction data with an R&S NRP and the R&S SMA100B

We assume, that the power sensor is connected, assigned and ready for operation.

1. Select "Level" > "User Correction".



2. Select "UCOR Data" > "UCOR Data...."
3. Create a file: "New" > Filename and confirm with "OK".
4. Select the new file with "Select".
5. Select "Edit UCOR Data...".
6. Select "Edit" > "Fill".
 The "Fill Table" dialog enables you to fill in the values of the columns automatically.
7. To fill in the frequency column:

Fill User Correction Data ucor		✕	
From	0	Range	5
Column To Fill	Frequency (Hz)		
Start Value	11.560 000 000 00 GHz	End Value	11.564 000 000 00 GHz
Increment Value	1.000 000 00 MHz		
☒ Fill			

- Select "Select Column To Fill > Frequency / Hz".
- Select "Range > e.g. 15" to determine the number of values.
- Select "Start Value > e.g. 1.56 GHz".
- Select "Increment Value > e.g. 1 MHz", to determine the frequency steps.
- Select "Fill", to insert the frequency values.

The "Fill" function also fills the column of the "Correction Value / dB" values with a predefined value, since empty cells lead to the data loss of the entire line. If you need different values, you can change them manually, or you can use the automatic function "Fill with Sensor" as described in the next steps.

- Select "Fill with Sensor".

The "Fill User Correction Data With Sensor" dialog provides an overview of the sensor configuration.

- Select "Execute".

The R&S SMA100B successively sets each frequency point, reads the measured power of the sensor and fills in the value in the correction table.

Edit User Correction Data

ucor

	Frequency /Hz	Correction Value /dB
0	1 560 000 000.00	-11.51
1	1 561 000 000.00	-11.03
2	1 562 000 000.00	-10.58
3	1 563 000 000.00	-9.80
4	1 564 000 000.00	-9.46

Go To

Edit

Fill with Sensor ...

Save As ...

Save

10. Select "Save" to save the data in the file.

11. Close the dialog.

To calibrate the power level with user correction data

We assume that a user correction file is available in the user directory of the R&S SMA100B or on a memory stick or in a shared directory.

If you have created and saved the file immediately before this step, the file is loaded in the "User Correction" dialog automatically. Otherwise you can load a previously saved file.

1. Select "Level" > "User Correction".
2. Select "UCOR Data" > "UCOR Data...", if there is no file loaded already.
3. Select the directory and file you want to use.
4. Load the file with "Select".
5. To view the file content, select "Edit UCOR Data...".
6. Select "UCOR Data" > "State" > "On" to apply the user correction values.

When you activate the RF output, the R&S SMA100B considers the user correction data and adjusts the signal level accordingly to compensate external frequency responses.

10 Reference oscillator

The R&S SMA100B is equipped with an internal reference oscillator that generates a reference frequency of 10 MHz. It is used as internal reference source for the synthesizer.

Alternatively, you can apply an external reference signal. If equipped with the required options, the R&S SMA100B can process external reference frequency in the range 1 MHz to 100 MHz and the 1 GHz reference frequency.

Regardless of the used reference source (internal or external), the R&S SMA100B always provides the configured reference frequency at the output. You can use it, for example to synchronize several interconnected instruments, see [Section 10.5, "Using the reference frequency for instruments synchronization"](#), on page 323, for an overview of typical test situations.



The reference oscillator settings are not affected by an instrument preset ([Preset] key or *RST) and the "Save/Recall" function. They are reset only by "Set To Default" in the corresponding reference frequency dialog or by a factory preset.

10.1 Required options

R&S SMA100B base unit equipped with the following options:

- 100 MHz, 1 GHz ultra low noise reference input and output (R&S SMAB-K703)
- 1 MHz to 100 MHz flexible reference input (R&S SMAB-K704)

For more information, refer to the specifications document.

10.2 Reference frequency settings

Access:


1. Select "Frequency" > "Reference Frequency".

Reference Frequency	Reference Output	Adjustment	
Set To Default			
Source External		Show Connector ...	
Deactivate RF Output (if external reference is missing) ☐			
External Reference Frequency 10 MHz			
Synchronization Bandwidth Wide			
Nominal Synchronization Bandwidth 100 Hz		Minimum Locking Range +/- 25 ppm	

In the "Reference Frequency" tab, you can select the reference frequency signal source and the frequency and synchronization bandwidth mode of an external reference signal.

2. Observe the information on the home screen, "Frequency" tile.

The "Frequency" tile indicates the current reference oscillator configuration, incl. the reference oscillator source, external reference frequency (rounded value) and output connector. A warning symbol in the "Frequency" tile indicates a missing external source.



The remote commands required to define these settings are described in [Section 15.18.13, "SOURce:ROSCillator subsystem"](#), on page 754.

Settings:

Set to Default	319
Source	319
Show/Show Connector	319
Deactivate RF Output (if external reference is missing)	319
External Reference Frequency	319
Variable Reference Frequency	320
Synchronization Bandwidth	320
Nominal Synchronization Bandwidth	320

Minimum Locking Range.....	320
External Tuning Active.....	321
External Tuning Slope.....	321

Set to Default

Resets the reference oscillator settings to default.

Remote command:

`[ :SOURce ] :ROSCillator :PRESet` on page 756

Source

Selects the reference frequency source.

"Internal" Uses the internal reference oscillator, either with calibrated or a user-defined [Adjustment Value](#).

Note: The internal reference frequency automatically uses [Synchronization Bandwidth > Narrow](#). Thus, if you preset this parameter, or set the reference source from "External" to "Internal" manually, the R&S SMA100B sets the bandwidth to "Narrow".

"External" Uses an external reference signal.

Note: If the external reference is missing, the R&S SMA100B issues a warning message and indicates the icon  (external reference missing).

To set the frequency of the external reference, see "External Reference Frequency".

Remote command:

`[ :SOURce ] :ROSCillator :SOURce` on page 756



Show/Show Connector

Opens a dialog that displays the location of the connector on the front panel or rear panel of the instrument. A blinking rectangle shows the connector.

Deactivate RF Output (if external reference is missing)

Turns off the RF output when the external reference signal is selected, but no signal is supplied.

This function prevents that no improper RF signal due to the missing external reference signal is used for measurements. A message indicates that the RF output is deactivated.

Remote command:

`[ :SOURce ] :ROSCillator :EXTernal :RFOff [ :STATe ]` on page 757

External Reference Frequency

Selects the frequency of the external reference input signal.

"10 MHz" 10 MHz external reference frequency

"100 MHz"/"1 GHz"

Option: R&S SMAB-K703

Selects the external reference frequency.

"Variable" Requires R&S SMAB-K704.
The external reference signal has an arbitrary frequency, within the permissible range from 1 MHz to 100 MHz.

Remote command:

[\[:SOURce\]:ROSCillator:EXternal:FREQuency](#) on page 757

Variable Reference Frequency

Requires R&S SMAB-K704 and "External Reference Frequency" > "Variable".

Sets a variable value for the external reference frequency.

For more information, refer to the specifications document.

Remote command:

[\[:SOURce\]:ROSCillator:EXternal:FREQuency:VARiable](#) on page 758

Synchronization Bandwidth

Selects the synchronization bandwidth for an external reference signal, set with "Source > External".

The resulting bandwidth is indicated by the parameter [Nominal Synchronization Bandwidth](#).

"Narrow" The internal reference oscillator is synchronized to the external signal with narrow bandwidth.

This setting is recommended if the phase noise of the external signal is worse than the phase noise of the internal OCXO.

"Wide" Synchronizes the internal oscillator to the external signal with the maximum possible bandwidth.

This mode is the recommended standard mode and for precise reference sources of high spectral purity.

Note: If the frequency of the external reference signal is outside the locking range of the internal reference oscillator, spurs due to the difference of the internal and external reference frequency are generated in the reference PLL.

The R&S SMA100B issues an error message.

For more information, refer to the specifications document.

Remote command:

[\[:SOURce\]:ROSCillator:EXternal:SBANdwidth](#) on page 758

Nominal Synchronization Bandwidth

Indicates the nominal synchronization bandwidth for the selected external reference frequency and the synchronization bandwidth.

Remote command:

[\[:SOURce\]:ROSCillator:EXternal:NSBandwidth?](#) on page 759

Minimum Locking Range

Indicates the minimum locking range for the selected external reference frequency and the synchronization bandwidth.

Remote command:

[\[:SOURce\]:ROSCillator:EXternal:MLRange?](#) on page 758

External Tuning Active

For "Source > Internal", activates the EFC (external frequency control).
EFC is a function that transforms an external tuning voltage into frequency shift, where the value range of the resulting frequency is a technical characteristic listed in the specifications document.
See the specifications document also for information on the sensitivity, input voltage range, impedance and maximum bandwidth for external tuning signal.
For more information, refer to the specifications document.
Remote command:

`[ :SOURce ] :ROSCillator:INTernal:TUNing[:STATe]` on page 757


External Tuning Slope

Sets the sensitivity of the external tuning voltage.
Remote command:

`[ :SOURce ] :ROSCillator:INTernal:TUNing:SLOPe` on page 757

10.3 Reference output settings

- Access:
- 1. Select "Frequency" > "Reference Frequency".
 - 2. Select "Reference Output".



In the "Reference Output" tab, you can set the reference frequency value at the output connectors.
As a result of parameter dependencies, "Preset This Parameter" sometimes does not affect output dialogs.
The remote commands required to define these settings are described in [Section 15.18.13, "SOURce:ROSCillator subsystem"](#), on page 754.

Settings:

Reference Output/1 GHz Reference Output	321
Show/Show Connector	322

Reference Output/1 GHz Reference Output

- Selects frequency reference output signal for downstream instruments.
- "Off" Deactivates the reference signal output.
 - "10 MHz" Derives a signal with 10 MHz frequency from the internal reference oscillator and provides this signal at the output.

- "100 MHz"

Option: R&S SMAB-K703
Provides the 100 MHz reference frequency signal at the output.
- "1 GHz"

Option: R&S SMAB-K703
Provides the 1 GHz reference frequency signal at the output.
- "Input Signal (loop through)"

Option: R&S SMAB-K703/-K704
Passes the external reference frequency to the output directly.
- Remote command:

[:SOURce]:ROSCillator:OUTPut:FREQuency:MODE on page 759

[:SOURce]:ROSCillator:OUTPut:ALternate:FREQuency:MODE on page 759



Show/Show Connector

Opens a dialog that displays the location of the connector on the front panel or rear panel of the instrument. A blinking rectangle shows the connector.

10.4 Adjustment settings

- Access:
- Select "Frequency" > "Reference Frequency".
 - Select "Adjustment".

Adjustment Active

☒

Adjustment Value

0

Settings:

Adjustment Active.....	322
Adjustment Value.....	322

Adjustment Active

Selects the adjustment mode.

"Off"

Uses the calibrated internal reference frequency.

"On"

Allows you to apply a deviation to the internal reference frequency, according to your requirements.
Enter the value in the Adjustment Value field.

Remote command:

[:SOURce]:ROSCillator[:INTernal]:ADJust[:STATe] on page 760

Adjustment Value

Sets a user-defined adjustment value for the internal reference frequency. This value takes effect when it is activated with Adjustment Active.

- "0" represents the calibrated state.

- The setting range depends on the reference oscillator type and its factory calibration value.

Note:

The setting is not affected by an instrument preset ([Preset] key or *RST) and the "Save/Recall" function. It is reset only by factory preset.

Remote command:

`[ :SOURce ] :ROSCillator [ :INTernal ] :ADJust :VALue` on page 760

10.5 Using the reference frequency for instruments synchronization

Test setups with two or more instruments often require that the instruments use a common reference frequency. Depending on the availability of external reference frequency source and its quality, the instruments are connected and configured in different ways.

This section gives an overview of the possible test setups and the related settings. The following situations are considered:

- External reference source is not available or the **built-in reference oscillator** is of better quality than the external source
(see ["Distributing the internal 10 MHz reference signal to further instruments"](#) on page 323)
- **Clean external reference source** with quality exceeding the quality of the built-in reference oscillator
(see ["Using external reference source"](#) on page 324)
- **Interfered or noisy external reference signal**
(see ["Deriving 10 MHz from the external reference frequency"](#) on page 325)
- **1 GHz reference coupling** for phase coherence of the RF signals with enhanced long-term phase stability
(see ["Sharing the 1 GHz reference frequency to obtain phase-coherent signals"](#) on page 324)

Connectors overview

Use the "Show Connector" function to indicate the connector on the front/real panel:

- ["Ref In/Ref Out"](#) on page 41
- 1GHz ["Ref In/Ref Out"](#) on page 41
- ["EFC"](#) on page 41

Distributing the internal 10 MHz reference signal to further instruments

The internal reference oscillator provides the reference frequency:

- Internal $f_{\text{ref}} = 10 \text{ MHz}$ (10 MHz at connector Ref Out)
- [Source](#) = "Internal"
- [Reference Output/1 GHz Reference Output](#) = "10 MHz"
- Optional:

Using the reference frequency for instruments synchronization

- External Tuning Active = "On"
- External Tuning Slope = "Low"




Figure 10-1: Synchronizing instruments using the internal 10 MHz reference signal of the R&S SMA100B

EFC = External frequency control
 EFC, Ref In, Ref Out = Connectors

In phase noise measurement systems, for example, you can also use the EFC (external frequency control) function and shift the frequency. EFC is a function that transforms an external tuning voltage into frequency shift, where the value range of the resulting frequency is a technical characteristic. Further parameters are sensitivity, input voltage range, impedance and maximum bandwidth for external tuning signal.

Consider the following interdependency:

- EFC in combination with an external PLL
 If the EFC is applied in combination with an external PLL (phase locked loop), the PLL bandwidth must be smaller than the bandwidth of the external tuning signal.
- FM-DC mode
 If the measurement requires higher PLL bandwidth, we recommend that you use the external FM modulation (DC coupling) in low noise mode.
 The FM-DC mode yields a fixed tuning sensitivity that is independent of the RF output frequency and corresponds to the selected FM deviation.

For more information, refer to the specifications document.

Sharing the 1 GHz reference frequency to obtain phase-coherent signals

Compared to 10 MHz, a 1 GHz reference signal significantly improves the achievable phase stability between two signal sources. Because the synchronization frequency increases by a factor of 100, the relative phase fluctuations between the sources can be reduced.

1 GHz at connector Ref In 1GHz and 1 GHz at Ref Out 1GHz

- External $f_{\text{Ref}} = 1 \text{ GHz}$
- Source = "External"
- External Reference Frequency = "1 GHz"
- 1GHz Reference Output = "1 GHz"

Using external reference source

If you have a clean external reference signal with 10 MHz or 100 MHz frequency, for example, you can **directly pass it to the output**. The signal quality remains the same.

10 MHz, 100 MHz at connector Ref Out and Ref In

- External f_{Ref} = 10 MHz or 100 MHz
(earlier RF hardware versions: 5 MHz, 10 MHz, 13 MHz)
- **Source** = "External"
- **Reference Output** = "10 MHz, 100 MHz" or "Input Signal (loop through)"
(earlier RF hardware versions: 5 MHz, 10 MHz, 13 MHz)
- Set the synchronization bandwidth according to the requirements of the application.




Figure 10-2: Synchronizing instruments with a 10 MHz external reference signal

Ref. Frequency Source = e.g., Rohde & Schwarz signal analyzer

f_{Ref} = 10 MHz, 100 MHz, 1 MHz to 100 MHz external reference frequency

Ref In, Ref Out = Connectors

You can forward reference frequency between 1 MHz and 100 MHz directly to the output in the same way.

For more information, refer to the specifications document.

- External f_{Ref} = 1 MHz to 100 MHz
(**1 MHz to 100 MHz at connector Ref In and Ref Out**)
- **Source** = "External"
- **Variable Reference Frequency** = "Variable"
- **External Reference Frequency** = current external frequency
- **Reference Output** = "Input Signal (loop through)" or specify the reference frequency the synchronized instrument supports
- Set the synchronization bandwidth according to the requirements of the application.

Deriving 10 MHz from the external reference frequency

10 MHz reference frequency can be derived from the following external reference signals:

- 10 MHz from internal oscillator locked to external input
- 100 MHz and 1 GHz external reference signals
- External reference signal between 1 MHz and 100 MHz
- If the external reference signal is interfered (noisy)

Using the reference frequency for instruments synchronization




Figure 10-3: Synchronizing instruments with 10 MHz (derived from an external reference frequency)

Ref. Frequency Source = e.g., Rohde & Schwarz signal analyzer

f_{Ref} = 10 MHz, 100 MHz, 1 MHz to 100 MHz, 1 GHz** external reference frequency

** = 1 GHz uses Ref In 1 GHz connector

Ref In, Ref Out = Connectors

1 GHz, 1 MHz to 100 MHz at connector Ref In 1 GHz/Ref In and 10 MHz at Ref Out

- E.g., external Ref. $f_{\text{ref}} = 100 \text{ MHz}$
- Source = "External"
- External Reference Frequency = "100 MHz"
- Reference Output/1 GHz Reference Output = "10 MHz"
- Synchronization Bandwidth = "Narrow"

11 Clock synthesis

The clock synthesis provides a separate system clock with a freely selectable frequency for test setups that require an additional clock reference. For example, in a test setup that uses an A/D converter, the required system clock for data sampling can be provided without the need of additional signal generator.

Output connectors

The generated clock reference is synchronized to the selected reference clock of the signal generator (internal or external). The differential signal is output at the [Clk Syn] and [Clk Syn N] connectors.

Required options

- Option frequency R&S SMAB-B10x
- Option differential clock synthesis up to 3 GHz R&S SMAB-B29
- Option clock synthesis extension 6 GHz R&S SMAB-K722 (requires at least R&S SMAB-B106)

For more information, refer to the specifications document.


Settings

Access:


1. Select "Clk Syn/Power Sens > Clock Synthesis".

Clock Synthesis		User Variation	✕
State			
Output Type	Differential Sine		
Frequency	10.000 000 000 MHz	Level	-20.00 dBm
DC Offset State	☒	DC Offset	0 mV
Delta Phase	0.0 deg	Reset Delta Phase Display	

2. Select "User Variation" to set the step width to be used when setting the clock frequency using the rotary knob.



3. Observe the information on the home screen, "Clk Syn/Power Sens" tile.



The "Clk Syn/Power Sens" tile indicates that clock synthesis is activated and gives an overview of the key parameters.

Settings

State.....	328
Output Type.....	328
Frequency.....	329
Level.....	329
DC Offset State.....	329
DC Offset.....	330
Voltage.....	330
Delta Phase.....	330
Reset Delta Phase Display.....	330
User Variation.....	330
L Variation Active.....	330
L Variation Step.....	330

State

Activates/deactivates generation of a system clock.
The signal is output at the [Clk Syn] connector.
Remote command:
:CSYNthesis:STATe on page 509

Output Type

Defines the shape of the generated clock signal.

"Single-Ended/Differential Sine"

Sine signals with user-definable amplitude.

"Differential Square"

Squared signal with fixed amplitude.

"CMOS"

CMOS-like signal with user-definable amplitude and limited frequency range.

Remote command:

`:CSYNthesis:OTYPe` on page 509

Frequency

Sets the frequency of the generated clock signal.

Output Type	Min. frequency	Max. frequency
Single-ended sinus Differential sinus	100 kHz	6 GHz
Differential square	10 MHz	6 GHz
CMOS	100 kHz	200 MHz

Remote command:

`:CSYNthesis:FREQuency` on page 509

Level

For **Output Type** = "Single-Ended/Differential Sine", sets the amplitude of the generated clock signal.

Remote command:

`:CSYNthesis:POWer` on page 510

DC Offset State

Activates a DC offset for both clock synthesis signal outputs.

The DC offset can be used e.g. to shift the clock synthesis output signal into the trigger threshold of some logic elements.




Figure 11-1: Example: DC offset = 1.65V and Output Type = Differential Square

Remote command:

`:CSYNthesis:OFFSet:STATe` on page 510

DC Offset

Sets the value of the DC offset for both clock synthesis signal outputs.

Remote command:

`:CSYNthesis:OFFSet` on page 510

Voltage

For **Output Type** = "CMOS", sets the high-level of the output signal.

Remote command:

`:CSYNthesis:VOLTagE` on page 511

Delta Phase

Shifts the phase of the generated clock signal.

Remote command:

`:CSYNthesis:PHASe` on page 511

Reset Delta Phase Display

Resets the parameter **Delta Phase**.

User Variation

Defines and activates a user-defined step width for varying the frequency or level with the rotary knob.

If disabled, the step width varies in steps of one unit at the cursor position.

Variation Active ← User Variation

Activates the set user-defined step width.

Remote command:

`:CSYNthesis:FREQuency:STEP:MODE` on page 512

`:CSYNthesis:POWEr:STEP:MODE` on page 512

Variation Step ← User Variation

Sets the user-defined step width.

Remote command:

`:CSYNthesis:FREQuency:STEP` on page 512

`:CSYNthesis:POWEr:STEP[:INCRement]` on page 512

12 File and data management

The R&S SMA100B uses files to save all instrument data. The instrument allows you to save and to load instrument settings, and to import and to export user data for processing in another instrument or later. Finally, you can create a screenshot of the current settings displayed on the screen and save it as a file.

This section focuses on the functions provided for managing of user data files and covers the topics listed below.

For information on the related remote control commands, see [Section 15.5, "MMEMory subsystem"](#), on page 494.

For information on how to save the displayed setting in a file, see [Section 12.11, "Creating screenshots of current settings"](#), on page 360.

• Accessing, retrieving and handling data	331
• About the file system	332
• Restoring an instrument configuration	335
• Protecting data	340
• Saving and recalling settings	341
• Accessing files with user data	346
• Exporting and importing remote command lists	348
• Loading, importing and exporting lists	348
• Using the file manager	348
• Transferring files from and to the instrument	354
• Creating screenshots of current settings	360

12.1 Accessing, retrieving and handling data

Depending on the origin and content, this description distinguishes between the following data types:

- Operational data
- Non-operational data

Operational data (data for intended use)

Your instrument uses and generates this data because of its intended use and according to the settings and configuration you have made. Thus, this data makes up most of the data that the R&S SMA100B creates, such as user files that contain user-defined configurations or data, like instrument settings or measurement data. See also "[Types of user data](#)" on page 333.

You can access, retrieve and delete user files, see [Section 12.9, "Using the file manager"](#), on page 348.

Non-operational data (usage data)

The R&S SMA100B generates this data during and through its use. Such data is collected e.g. for troubleshooting, to help our customer support center find solutions

quickly, or if you have purchased and activated the Health and Utilization Monitoring Service (HUMS).

The R&S SMA100B does not generate this data continuously and in real-time; this data is saved on the product. You can store the data on a remote server, for example via a network connection.

The R&S SMA100B generates the following data:

- User and authentication data
- Network and communication data
- Software and firmware update data
- Diagnostic and troubleshooting data
- Environmental conditions
- Hardware component metadata
- User behavior (HUMS only)

On demand, this data is stored in a ZIP file containing files in TXT format. The volume of the non-operational data depends on the usage of the product and typically amounts to about 30 Mbyte.

You can access, retrieve and delete this data, see:

- Network and communication data, see [Section 12.5, "Saving and recalling settings"](#), on page 341.
The R&S SMA100B displays the network address data on the screen.
- Hardware component metadata, see [Section 16.8.1, "Hardware configuration settings"](#), on page 827.
- User behavior, monitored by HUMS, see [Section 14.5.8, "HUMS settings"](#), on page 432.
The R&S Health and Utilization Monitoring Service user manual is available on the Rohde & Schwarz internet.
- For all other data stored in the instrument, see [Section 16.9, "Collecting information for technical support"](#), on page 830.

For additional information on the different memory types of your product and on how to protect sensitive data, see:

- [Section 12.4, "Protecting data"](#), on page 340.
- Instrument security procedures document.

12.2 About the file system

Depending on their content, this description distinguishes between system files and user files. System files and the system directory are protected and not accessible. User files contain user-defined configurations or data.

This section focuses on user files. It provides an overview of the R&S SMA100B file system and covers the following topics:

- ["Types of user data"](#) on page 333

- ["File storage location"](#) on page 333
- ["File handling"](#) on page 334
- ["File naming conventions"](#) on page 334
- ["File extensions"](#) on page 335
- ["File contents"](#) on page 335

Types of user data

The following data types contain user data:

- Settings or configuration files, for example, you save the current instrument settings and load these settings on another instrument.
See [Section 12.5, "Saving and recalling settings"](#), on page 341.
- SCPI scripts that contain a series of commands. You can run the script to perform a task.
See [Section 12.7, "Exporting and importing remote command lists"](#), on page 348.
- Externally or internally generated lists, for example, user correction lists. You can load these list files on the instrument.
See [Section 12.8, "Loading, importing and exporting lists"](#), on page 348 and [Section 12.6, "Accessing files with user data"](#), on page 346.

Depending on the **data storage method**, user data can be:

- *Persistent*, i.e. user files that are recorded on the data storage.
Data is preserved when instrument is powered off and can be accessed and modified subsequently.
- *Temporary*, i.e. volatile data that the instrument retains while it is powered on.
Volatile data is immediately lost when the R&S SMA100B is switched off.

File storage location

Without any additional measures, the R&S SMA100B stores user files on the internal memory, the removable memory, or if connected, on a memory stick.

Both, the user directory `/var/user/` on the internal memory or the `/usb/` directory on the memory stick, can be used to **preserve** user-defined data. Any directory structure can be created.

The `/var/volatile` directory serves as a RAM drive and can be used to protect sensitive information. The data is available **temporarily**.

If option R&S SMAB-B85 is installed, the R&S SMA100B maps the user directory to the removable memory. If a memory is mounted, user data is saved there. Otherwise user data is redirected to the volatile memory.

Default storage location

The R&S SMA100B stores user data in the user directory.

Depending on the installed options, the user directory is physically located on the internal memory or on the removable memory.

In the file system, user directory is always indicated as `/var/user/`.

In manual control, you access this directory via the "File Manager", see [Section 12.9, "Using the file manager"](#), on page 348. In remote control, you can query it with the command `:SYSTem:MMEMory:PATH:USER?`.

To query and change the default directory used for mass storage, use the command `:MMEMory:CDIRectory`.

File handling

To *access files* and the file system of the instrument or to use the general file management functions such as copying and moving data, use the standard "File Manager" dialog.

See [Section 12.9, "Using the file manager"](#), on page 348.

To *transfer files* from and to the instruments or to exchange files, use one of the following alternatives:

- Connect a memory stick to one of the USB interfaces.
The instrument automatically recognizes a connected memory stick and assigns the `/usb/` drive to it.

- Connect the instrument to a LAN.

An instrument connected to a LAN supports two standard file transfer methods from a remote client:

- FTP (file transfer protocol)
- File sharing according to the SAMBA/SMB (server message block) protocol.

Both file transfer methods open the folder `/user` that is the `/var/user/` folder on the instrument.

For a step-by-step description, see [Section 12.10, "Transferring files from and to the instrument"](#), on page 354.

- Map a network folder or a computer to an instrument connected to a LAN.
A mapped network folder is indicated as `/shares/<"Local Folder">`.
For a step-by-step description, see [Section 12.9.4, "Mapping a network folder"](#), on page 352.

File naming conventions

To enable files to be used in different file systems, consider the following file naming conventions:

- The *filename* can be of any length and *is case-sensitive*, i.e it is distinguished between uppercase and lowercase letters.
- All letters and numbers are permitted (numbers are, however, not permitted at the beginning of the filename).
- Avoid using special characters.
- Do not use slashes "\" and "/". These symbols are used in file paths.
- Avoid using the following filenames: `CLOCK$`, `CON`, `COM1` to `COM4`, `LPT1` to `LPT3`, `NUL` or `PRN`
They are reserved by the operating system.

File extensions

The R&S SMA100B distinguishes the files according to their extensions; each type of file is assigned a specific file content and also a specific file extension. The extension is usually of no consequence to you since access to the files occurs in the individual dialogs where only the relevant type of file is available. For example, files with user correction data can only be saved and loaded in the "UCOR" dialog.

See [Section B, "Available user files and file extensions"](#), on page 857 for an overview of the supported file extensions.

File contents

To maintain the file size and to accelerate processing times, the instrument saves settings that deviate from their default values. Considered is also configuration data for the operating elements and lists with user data, e.g. dialog positions and a list of user correction data. However, if a list data is part of the instrument settings, a reference to this list is saved, not the list itself.

This approach ensures that the created files contain only relevant information and allows you to transfer instrument settings even between different equipped signal generators. During the recall process, the instrument interprets only the relevant settings; all non-referenced parameters are set to their preset values. Error messages indicate the settings which cannot be implemented, like referencing non-existing lists or the attempt to activate settings which are not supported by the instrument.

12.3 Restoring an instrument configuration

The R&S SMA100B has various options to set default settings. You can preset the R&S SMA100B to an initial state at any time as a known starting point for configurations. It is often useful as a first step during troubleshooting when unusual results arise.

The figure [Figure 12-1](#) shows the impact of the particular reset functions.




Figure 12-1: Preset functions for parameters and operating modes


Overview of the characteristics of the preset functions

Select the preset option that most fits to your particular application:




- [Preset]
It is the most frequent function. A preset executes a defined instrument setup to provide an initial instrument state as a basis for a new configuration. It resets all parameters and switching states including the states of inactive operating modes. Also, it resets external instruments connected to the R&S SMA100B. A preset does not change network settings, remote access settings or system settings.

► To execute a preset, press the [Preset] key at the front panel.



- "Set to Default"
This function relates to individual dialogs or tabs and resets the associated settings of the corresponding dialog. All other settings are retained.


► To reset the settings, click "Set To Default".



- "Preset this parameter"
Sets a single parameter to its default value.

1. To reset an individual parameter, open its context-sensitive menu.

2. Select "Preset This Parameter".



- "Factory Preset"
A factory preset is the most profound preset function that resets almost all instrument settings, including reference oscillator, network and remote access settings.
A factory preset does not change the following settings:
 - Security, password, and settings protected by these passwords
 - User-defined data, like setups or data lists
 - Settings that relate to an integration of the instrument in a measurement setup.
- **NOTICE!** Execute a "Factory Preset" only if it is necessary. After a "Factory Preset", the network connection to the instrument no longer exists.
To restore the factory defaults, select "System Config" > "Setup" > "Settings" > "Factory Preset".

Presetting the instrument to a user-defined state

The reset functions set the parameters and operating modes to default values predefined by the factory. Alternatively to the instrument default settings, you can preset the instrument to a user-defined state:

- Save and reload user-defined settings as preset, see [Section 12.3.3, "Presetting the instrument to a user-defined state"](#), on page 339.
- Save and reload user-defined instrument states, see [Section 12.5.2, "Saving and recalling instrument settings"](#), on page 344.

Marking parameters with non-default values

To check the current state of the settings concerning default values, the R&S SMA100B offers a feature that visually identifies deviations from the default values.

For more information, see [Section 12.3.2, "Identifying parameters with non-default values"](#), on page 338.

12.3.1 Preset, set to default and factory preset settings

Preset	337
Set To Default	338
Preset this Parameter	338
Execute Factory Preset	338

Preset

Resets all parameters and switching states, and closes all opened dialogs.

Note:

In contrast to the [Preset] key, the SCPI commands `*RST` and `:SYSTem:PRESet` do not close open dialogs in the GUI.

Consider also the following possibilities:

- You can define the settings that are restored when you preset the instrument (see [Section 12.3.3, "Presetting the instrument to a user-defined state"](#), on page 339)
- You can reset the instrument to the factory state (see ["Execute Factory Preset"](#) on page 338)

See also [Table 12-1](#) that contains the key parameters that are reset by the corresponding preset functions.

Remote command:

`*RST` on page 490

Set To Default

Resets the associated settings of the corresponding dialog or tab.

Preset this Parameter

Restores the default value of a single parameter.

Execute Factory Preset

Resets the instrument to its factory settings.

Note: "Factory Preset" retains all security settings and does not delete any user files like setups or user data.

See also [Table 12-1](#) that contains the key parameters that are reset by the corresponding preset functions.

Remote command:


`:SYSTem:FPReset` on page 493

12.3.2 Identifying parameters with non-default values

To recognize the current state of the settings related to their default values at the first glance, enable a function that visually identifies parameters in states different than preset.

To enable this display:

1. To open the context-sensitive menu, touch and hold the screen anywhere in the GUI of the R&S SMA100B.
2. Select "Mark All Parameters Changed from Preset".



If enabled, marks the parameters that deviate from their default values.

Example:

Frequency	4.000 000 000 000 GHz	
Offset	10.000 000 kHz	Multiplier 1.000
User Variation		
Variation Active	☒	Variation Step 1.000 000 000 MHz

Figure 12-2: Marked parameters show that the value deviates from its default

Frequency = changed (default = 1 GHz)
 Offset = changed (default = 0 kHz)
 Multiplier = unchanged
 Variation active = changed (default = disabled)
 Variation step = unchanged

12.3.3 Presetting the instrument to a user-defined state

You can define the settings that are restored when you preset the instrument.

Note: The preset of the instrument to a user-defined state does not include all modified settings. For information, see the corresponding description of the settings.

1. Configure the settings as required.
2. Save them as described in [Section 12.5.2, "Saving and recalling instrument settings"](#), on page 344:
 - a) Save the settings as a file with the predefined filename `UserPreset` without file extension.
The save function assigns the file extension `.savrc1.txt` automatically.
 - b) Save this file in the directory `/var/user/`.
The filename `UserPreset` and the directory `/var/user/` are mandatory.
3. Press the [Preset] key.
When operating the instrument remotely, send the `*RST` command.

The instrument restores the user-defined settings. An "Info" message appears and confirms loading of a file with user-defined preset settings.

12.3.4 Reference

See [Table 12-1](#) for an overview of the main generator settings that are affected by the corresponding preset functions. While the regular [Preset] key primarily resets the signal relevant parameters of the instrument, the "Factory Preset" affects almost all instrument settings.

For information on the default values of further parameters, see the description of the corresponding remote commands.

Table 12-1: Key parameters affected by preset and factory preset

Parameter	Preset value	Preset	Factory Preset
RF frequency	1 GHz	x	x
RF level (RF output)	off	x	x
RF level limit	30 dBm	-	x
Offsets	0	x	x
Modulation state	off	x	x
LF output state	off	x	x
Sweep state	off	x	x
List mode state	off	x	x
Reference frequency settings	-	-	x
Network settings	-	-	x
Hostname	-	-	x
GPIO address	-	-	x
Start or stop display update	-	-	x
Display and keyboard settings	-	-	x
Preset behavior: Keep connections to external instruments	off	-	x
Password and password-protected settings	-	-	-
Security settings	-	-	-
User files (setups, user correction, etc.)	-	-	-
HUMS	off	-	x

12.4 Protecting data

During operation, the R&S SMA100B saves user data permanently in the user directory, see ["File storage location"](#) on page 333.

To protect any classified data and to avoid saving any sensitive data on the R&S SMA100B permanently, you have the following options:

- Activate the **volatile mode**. This mode redirects user data to the volatile memory, see ["Volatile Mode"](#) on page 391.
The internal memory and the removable memory are write-protected.
Once you power off the instrument for at least five minutes, all volatile memory modules lose their contents.
To avoid losing this data, connect an **external memory device**, for example, a USB flash drive.

See also:

- ["Default storage location"](#) on page 333
- ["Volatile Mode"](#) on page 391
- [Section 12.10.4, "Using a USB storage device for file transfer"](#), on page 359
- If the R&S SMA100B is equipped with the **removable memory** R&S SMAB-B85 and an SD card is inserted:
 - If the volatile mode is disabled (default setting) the R&S SMA100B **saves user data permanently and only on this storage medium**.
You can access data saved on the removable memory just as data saved in the `/var/user/`.
 - If the volatile mode is enabled, the R&S SMA100B redirects user data to the **volatile memory** (SDRAM).
The volatile memory loses its contents when you power off the instrument.
- Save user files **temporarily in the `/var/volatile` directory**, which remains available only until the instrument is turned off.
You can access data in the volatile memory just as data that is saved permanently in the `/var/user/`.
See also [Section 12.9.3, "Displaying all saved files"](#), on page 352.

To remove the microSD card

This step-by-step instruction holds for R&S SMA100B microwave instruments only.

1. **NOTICE!** You can damage the instrument and loose data when removing the microSD card during operation.
Switch off the R&S SMA100B.
See ["To shut down the product"](#) on page 31.
2. Remove the microSD card from the instrument.

For detailed information on how to protect the instrument and to protect sensitive data from unauthorized access, refer to the document Instrument Security Procedures.

12.5 Saving and recalling settings

You can save and recall instrument settings, user settings and other related data for the following use cases:

- Reload or repeat a specific signal generation task on the instrument.
- Transfer a specific configuration of your instrument to another instrument, for example in multi-instrument setups.
- Save or load complete instrument settings to or from a file.

Save or recall the complete instrument settings

Two different methods are available for managing *complete instrument settings*:

- Quick (immediate) Save/Recall

A defined set of instrument settings are saved or recalled quickly in just one step, without defining a filename or storage location. This function enables a fast switching between different instrument settings.


- **Save/Recall in files with user-defined names**
The defined set of instrument settings are saved to a definable storage location. The file extension is *.savrc1txt.
Settings files created in this way are visible in the file system and accessible with the supported methods for file handling.

In the general case, a recall process replaces the instruments settings with the saved values. An exception is the frequency and level settings. During recall of the instrument settings, it is possible to retain the current settings or to overwrite them with the saved values.

12.5.1 Save/Recall settings

Access:

1. Select "System Config > Save/Recall".
2. Select "Operation Mode" > "Save" or "Recall" to open the corresponding settings.



The settings for both operation modes are similar and related.

Settings:

Operation Mode.....	343
Directory, File List and Filename.....	343
Recent files.....	343
Show SCPI List.....	343
SCPI List.....	343

Save.....	344
Quick Save x.....	344
Exclude Frequency.....	344
Exclude Level.....	344
Recall.....	344
Quick Recall x.....	344
File Manager.....	344

Operation Mode

Accesses the settings for storing ("Save") and loading ("Recall") of the instrument settings. Also, you can import SCPI-Files ("SCPI-Import") or export SCPI files ("SCPI-Export").

See [Section 12.7, "Exporting and importing remote command lists"](#), on page 348.

Directory, File List and Filename

Note:

You access this generic standard function each time you perform one of the following:

- Save or load (settings) files
- Define a folder in that these files are saved
- Navigate through the file system.

The dialog name changes depending on the context. The provided functions are self-explanatory and similar.

Use the settings for example as follows:

- To navigate through the file system, use the directory tree.
- To create a file, load and save files, use the dedicated functions ["New"](#), ["Select"](#), [Save](#), and [Recent files](#).
- To access the general data table editor, use the ["Edit"](#) button
- To perform standard file management functions, like create directories, move, copy, delete files and/or directories, use the standard "File Manager" function (see [Section 12.9, "Using the file manager"](#), on page 348).

Remote command:

To list all files in a directory:

[:MMEMory:CDIRectory](#) on page 499

[:MMEMory:CATalog?](#) on page 498

[\[:SOURce\]:CORRection:CSET:CATalog?](#) on page 694

Recent files

Displays the files last used.

Show SCPI List

Opens the "SCPI List", which lists the current settings of the R&S SMA100B as SCPI commands.

The R&S SMA100B provides this function for [Operation Mode > SCPI-Export](#).

SCPI List

Provides a list of all SCPI commands corresponding to the current instrument settings.

Save

Saves the current instrument settings under the defined filename.

Remote command:

[:MMEMory:STORe:STATe](#) on page 503

Quick Save x

Stores the current instrument setting in one of the intermediate memories.

These instrument settings are retained until a different instrument setting is stored in the intermediate memory. When the instrument is switched off, the contents of the intermediate memories are retained.

Remote command:

[*SAV](#) on page 491

Exclude Frequency

The current frequency is retained when a stored instrument setting is loaded.

Remote command:

[\[:SOURce<hw>\]:FREQuency\[:CW|FIXed\]:RCL](#) on page 703

Exclude Level

The current level is retained when a stored instrument setting is loaded.

Remote command:

[\[:SOURce<hw>\]:POWer\[:LEVel\]\[:IMMediate\]:RCL](#) on page 752

Recall

Restores the selected configuration.

During recall, the instrument considers all related settings, for example sweeps in active state or lists. An error message indicates the settings which cannot be implemented.

Remote command:

[:MMEMory:LOAD:STATe](#) on page 501

Quick Recall x

Loads the selected configuration from one of the intermediate memories. A message appears if no instrument configuration is stored in this memory.

Remote command:

[*RCL](#) on page 490

File Manager

Accesses the "File Manager" dialog, see [Section 12.9, "Using the file manager"](#), on page 348.

12.5.2 Saving and recalling instrument settings

Instrument settings can be saved to a file and loaded again later, so that you can repeat the tests with the same settings.

To access and recall instrument setups quickly

- ▶ Assign the appropriate action to the [★ (User)] key.
See [Section 13.2.2, "How to assign actions to the \[★ \(User\)\] key"](#), on page 376.

To save and recall instrument settings

1. Select "System Config > Save/Recall" > "Operation Mode" > "Save".
2. Select "Quick Save 1".
The instrument saves its settings in the intermediate memory 1. The filename and the storage location cannot be changed.
3. Adapt the instrument settings as required. Select "Quick Save 2"
4. To restore the settings, select the "Operation Mode > Recall"
5. Select "Quick Recall 1"
The instrument is restored to the previous state.
6. Select "Quick Recall 2" to switch to the settings saved in the second file.

To save complete instrument settings

1. Select "System Config > Save/Recall" > "Operation Mode" > "Save".
2. In the file selection dialog, select a filename and storage location for the settings file.
3. Select "Save".
A file with the defined name and path and the extension *.savrc1.txt is created.

To restore an instrument configuration

Save the configuration as described in ["To save complete instrument settings"](#) on page 345.

1. To restore settings, select "System Config > Save/Recall" > "Operation Mode > Recall".
2. To retain the current frequency settings, enable "Save"/"Recall" > "Exclude Frequency",
3. To retain the current level settings, enable "Save"/"Recall" > "Exclude Level",
4. In the file select dialog, select the filename and storage location of the settings file.
The settings are restored, but the frequency and level settings are retained. You can repeat the signal generation with the same settings.
See also [Section 12.3.3, "Presetting the instrument to a user-defined state"](#), on page 339.

12.6 Accessing files with user data

Signal generation in list mode, the generation of pulse train signals or applying user correction values use data from list files. Whenever a list file is required as a data source, the instrument provides direct access to the standard "File Select" function. This function enables you to select, create and edit the list files.


12.6.1 File select settings

The "File Select" dialog opens automatically each time the signal generation requires a list file as a data source.

To access a loadable data list file

1. Select "Sweep" > "List Mode Data" > "List Mode" = "Data".

A file select dialog for loading, creating and modifying a file opens.



Tip: The name of the dialog is context-sensitive and differs depending on the particular function this dialog is from. However, the provided functions are similar.

2. To load an existing file:
Navigate through the file system.
Select the file and confirm with "Select".
3. To create a file, for example if there is no data list file specified:
Navigate through the file system.
Select "New" and specify the filename.
A new empty file is created and saved in the selected folder.
4. To edit an existing or newly created file:
Navigate through the file system.
Select the file and select "Edit".
The standard "Data List Editor" dialog opens.

5. Edit the file content.
Confirm with "Save".

Settings:

Directory, File List and Filename.....	347
Functions for handling of data lists.....	347
Recent files.....	347
File Manager.....	348

Directory, File List and Filename

Note:

You access this generic standard function each time you perform one of the following:

- Save or load (settings) files
- Define a folder in that these files are saved
- Navigate through the file system.

The dialog name changes depending on the context. The provided functions are self-explanatory and similar.

Use the settings for example as follows:

- To navigate through the file system, use the directory tree.
- To create a file, load and save files, use the dedicated functions "New", "Select", Save, and Recent files.
- To access the general data table editor, use the "Edit" button
- To perform standard file management functions, like create directories, move, copy, delete files and/or directories, use the standard "File Manager" function (see [Section 12.9, "Using the file manager"](#), on page 348).

Remote command:

To list all files in a directory:

[:MMEMory:CDIRectory](#) on page 499

[:MMEMory:CATalog?](#) on page 498

[\[:SOURce\]:CORRection:CSET:CATalog?](#) on page 694

Functions for handling of data lists

Provided are the following standard functions for file handling:

"Select"	Select and load the file. Remote command: [:SOURce<hw>]:LIST:SElect on page 733 [:SOURce<hw>]:PULM:TRAI:n:SElect on page 644 [:SOURce<hw>]:CORRection:CSET[:SElect] on page 693
"New"	Creates file with the specified "Filename". To confirm, select "OK"; use "Cancel" to undo the operation. To edit the file content, select "File Select > Edit".
"Edit"	Accesses the "Data List Editor" and loads the selected file for editing

Recent files

Displays the files last used.

File Manager

Accesses the "File Manager" dialog, see [Section 12.9, "Using the file manager"](#), on page 348.

12.7 Exporting and importing remote command lists

To set specific instrument settings or perform tasks automatically, you can create scripts or import scripts that contain the settings in the form of remote control command sequences.

The R&S SMA100B also offers a SCPI macro recorder with code generator to record manual settings and create an executable script.

Completed scripts are saved in files and possibly converted to different formats, depending on the language of the source code.

The R&S SMA100B supports the following commonly used languages:

- Plain SCPI: *.txt
- MATLAB: *.m
- NICVI: *.c
- Python: *.py

It is also possible to convert the SCPI command list to a user-specific language.

How to: [Section 14.9, "Using remote command scripts"](#), on page 466

12.8 Loading, importing and exporting lists

The R&S SMA100B provides built-in editors for creating list files, for example for the list mode or lists with user correction data. You can also create or evaluate them with an external application. The instrument provides interfaces with the following functionality:

- Import and export list files in a standard ASCII format file

Lists are saved and loaded in the corresponding dialogs. For example, the user correction data list is created and saved in the "User Correction" dialog.

12.9 Using the file manager

The "File Manager" is a tool similar to a standard Windows Explorer. It helps you manage mass storage media and files saved on the R&S SMA100B.

You can perform the following tasks:


- Copying multiple files from disk to other media
See [Section 12.10, "Transferring files from and to the instrument"](#), on page 354

- Copying files into another directory
See [Cut, Copy&Paste and Delete](#)
- Renaming and deleting files
- Creating directories
See [Create New Directory](#)
- Mapping shared network folders
See [Section 12.9.4, "Mapping a network folder"](#), on page 352
- Displaying saved files
See [Section 12.9.3, "Displaying all saved files"](#), on page 352

12.9.1 File manager settings

Access:

- Select "System Config > Save/Recall" > "File Manager".
- Tip:** Each "Save/Recall" dialog and each "File Select" dialog provides a quick access to the "File Manger".



The "File Manager" dialog provides all standard functions required for file management. It displays the contents of the selected folder on the R&S SMA100B and provides functions to rename, delete, copy, or move individual files.

Settings:

Map Network Share	350
File Type	350
Directory and Filename	350
Cut, Copy&Paste and Delete	350
Rename	350
Create New Directory	350

Map Network Share

Opens a dialog where you can map one or more network folders. See [Section 12.9.2, "Map network share settings"](#), on page 350.

See also [Section 12.9.4, "Mapping a network folder"](#), on page 352.

File Type

Selects the file type to be listed. If a file type with a specific file extension is selected, only files with this extension are listed.

See [Section B, "Available user files and file extensions"](#), on page 857 for an overview of the supported file extensions.

Directory and Filename

Selects the directory in which the file to be deleted or copied is located. The dialog lists all files in this directory. Selected files are highlighted. The path is indicated above the directory tree.

Unlike the "Save/Recall" and "File Select" dialogs, the "File Manager" displays the full filenames including extensions.

Remote command:

[:MMEMory:CDIRectory](#) on page 499

Cut, Copy&Paste and Delete

Standard file management functions.

Before a file is deleted, you have to confirm the delete operation.

Remote command:

[:MMEMory:DELeTe](#) on page 501

[:MMEMory:COPI](#) on page 499

Rename

Renames the selected file or directory.

Remote command:

[:MMEMory:MOVE](#) on page 502

Create New Directory

Creates a folder and opens an edit dialog box to enter name and path (absolute or relative to the current directory) of the new folder.

Remote command:

[:MMEMory:MDIRectory](#) on page 502

12.9.2 Map network share settings

Access:

- ▶ Select "System Config > Save/Recall" > "File Manager" > "Map Network Share".

The "Map Network Share" dialog provides settings that are similar to the standard Windows Explorer function "Map network drive". These settings help you to create up to 10 "shortcuts" to shared folders or computers in the network.

The dialog displays a list of current mapped network folders. The directory tree of the "File Manager", "Save/Recall", and "File Select" dialogs indicate a mapped network folder as /shares/<"Local Folder">.

Map Network Share

Network Folder	Local Folder	User Name	Reconnect
//10.102.188.16...	setups	instrument	On

Network Folder

//10.102.188.167/user

Local Folder

setups

User Name

instrument

Password

Reconnect at Startup

☒

+

Connect

→

Change

✕

Disconnect

See also [Section 12.9.4, "Mapping a network folder"](#), on page 352.

Settings:

Network Folder	351
Local Folder	351
User Name	352
Password	352
Reconnect at Startup	352
Connect	352
Change	352
Disconnect	352

Network Folder

Enter the path of the folder or computer, e.g. //<IP Address>/user or //<server name>/user.

Local Folder

Enter a letter or an alias name to describe the folder.

In the directory tree, a mapped network folder is indicated as `/shares/`
`<"Local Folder">`.

User Name

Enter a user name of a user that has the permission to access the selected network folder.

Password

Enter the user password of the selected user.

Reconnect at Startup

Enables reconnecting every time you start up the instrument.

Connect

Triggers the instrument to prove the credential and to map (i.e. connect) the selected network folder or computer to the instrument.

You can map up to 10 network folders.

Change

Applies the changes.

Disconnect

Disconnects the network drive.

12.9.3 Displaying all saved files

To display all files on the internal memory

1. Select "System Config > Save/Recall" > "File Manager".
2. Navigate to `/var/user/`.

To display all files on a connected USB flash drive

1. Select "System Config > Save/Recall" > "File Manager".
2. Navigate to `/usb/`.

To display all files in the volatile memory

1. Select "System Config > Save/Recall" > "File Manager".
2. Navigate to `/var/volatile/`.

12.9.4 Mapping a network folder

Possibly you would like to transfer instrument or user settings to another R&S SMA100B, distribute waveform files to several instruments or you have to access

frequently the same network drive. In these cases, on a R&S SMA100B connected to a LAN you can create a shortcut to this network folder or this computer.

How to: [Section 3.1.7, "Connecting to LAN"](#), on page 27


To map a network folder, proceed as follows:

1. On the computer or the network folder you want to map, enable remote access. You can specify a list of users allowed for remote access.
Note: The remote access settings depend on the operating system the remote computer is using. For step-by-step instructions, refer to the documentation of the particular operating system.
2. On the R&S SMA100B, [enable file transfer via SMB \(samba\)](#).
3. Select "System Config" > "Setup" > "Remote Access" > "Network" to configure the following network settings:
 - a) Select "Address Mode" > "Auto (DHCP)".
 - b) Check that the "DNS Suffix" and "DNS Server" are correct.
4. In the "Save/Recall" dialog, select "File Manager" > "Map Network Share".
5. In the "Map Network Share" dialog, select:
 - a) In the "Network Folder" field, enter `//<IP Address>/user` or `//<Server Name>/user`.
 - b) In the "Local Folder" field, enter an alias name, e.g. *setups*.
 - c) Enter the "User Name" and "Password" of a user with a remote access permission to the selected network folder.
 - d) If necessary, enable "Reconnect at Startup".
 - e) Select "Connect".

The selected network folder is mapped to your instrument. The list of mapped network folders is updated.

6. Close the "Map Network Share" dialog.

The navigation tree in the "File Manager" dialog displays the mapped network folder as `/shares/Setups`.



If the connection does not succeed, consider to check the following:

- Is the network folder or computer you try to map turned on?
- Is the network folder or computer enabled for remote access?
- Does the selected user name have the necessary permissions?

See also [Section 12.10.5, "Using a file server for test files exchange"](#), on page 359.

12.10 Transferring files from and to the instrument

As explained in ["File handling"](#) on page 334, you access the file system of the R&S SMA100B via one of the following ways:

- Via the built-in "File Manager"
See [Section 12.9, "Using the file manager"](#), on page 348.
- On an instrument connected to a LAN:
 - Via one of the standard functions FTP or SMB (samba)
See [Section 12.10.2, "Accessing the file system using FTP"](#), on page 356 and [Section 12.10.3, "Accessing the R&S SMA100B file system using SMB \(Samba\)"](#), on page 357
 - Via mapped network drives
See [Section 12.9.4, "Mapping a network folder"](#), on page 352.
- Via a connected USB storage device
See [Section 12.10.4, "Using a USB storage device for file transfer"](#), on page 359

Mainly because of security reasons, the access to the file system of your R&S SMA100B can be denied, because one or all these access methods are deliberately disabled. Access to the file system via LAN and/or USB requires that the corresponding service is enabled and a write access to the file system is enabled. Refer to [Section 12.10.1, "Removing file system protection"](#), on page 355 for description of the required steps.

This section provides an introduction to the topic. For comprehensive information, refer to the application note [1GP72: Connectivity of Rohde&Schwarz Signal Generators](#).

• Removing file system protection	355
• Accessing the file system using FTP	356
• Accessing the R&S SMA100B file system using SMB (Samba)	357
• Using a USB storage device for file transfer	359
• Using a file server for test files exchange	359

12.10.1 Removing file system protection

Before you try to access the file system via FTP, SMB (samba) or USB, fulfill the following:

- Disable write protection on the file system
- Enable the corresponding service or interface

To enable write permission on the file system

1. Select "System Config" > "Setup" > "Security" > "Security".
2. Select "General" > "Disk & Memory".
3. Enable "Volatile Mode".

4. Enter the "Security Password".

The default password is 123456. For more information, see [Section 13.4, "Using the security settings"](#), on page 389.

The R&S SMA100B requests a reboot.

5. Confirm the request.

The system reboots. The enabled settings are active.

To enable file transfer over FTP

1. Select "System Config" > "Setup" > "Security" > "Security".
2. Select "LAN Services" > "Common Services" > "LAN" > "On".
3. Enable "FTP"

4. Enter the "Security Password".

The default password is 123456. For more information, refer to [Section 13.4, "Using the security settings"](#), on page 389.

5. Select "Accept".

To enable file transfer over SMB (samba)

1. Select "System Config > Setup > Security > Security > LAN Services"
2. Enable "LAN Interface"
3. Select "Samba Services".

4. Enable the "SMB 1.0/2.0 Client".
5. Enable the "SMB 1.0/2.0 Server".
6. Enter the "Security Password".
The default password is 123456. For more information, see [Section 13.4, "Using the security settings"](#), on page 389.
7. Select "Accept".

To enable file transfer over USB

1. Select "System Config > Setup > Security > Security > General"
2. Select "Disk & Memory".
3. Enable "USB Storage"
4. Enter the "Security Password".
The default password is 123456. For more information, see [Section 13.4, "Using the security settings"](#), on page 389.
5. Select "Accept".

12.10.2 Accessing the file system using FTP

If the R&S SMA100B is connected to a LAN, you can use file transfer protocol (FTP) to access the file system and to transfer files from and to the instrument.

How to: [Section 3.1.7, "Connecting to LAN"](#), on page 27

To access the file system over FTP

We assume that the instrument and the remote PC are connected to a LAN.

1. [Enable file transfer via FTP](#)
2. [Enable write permission on the file system](#)
3. On the remote PC, start the Windows Explorer.
4. In the address field, enter `ftp://<"IP Address" of the Instrument>`, e.g. `ftp://10.124.0.166`.

Tip: The R&S SMA100B indicates its IP address on the home screen.

A log-on dialog opens and requests a password.

The default user name and password is *instrument*.


Tip:**Default password**

The FTP and SAMBA file access use the user "instrument" with default password "instrument".

We recommend that you change this password in the "Setup > Security > Password Management > Change User Password" dialog before connecting the instrument to the network.

See [Section 13.4.5, "Password management"](#), on page 399.


5. Enter the password to access the `user` directory.
The `user` directory corresponds to the `/var/user/` directory of the instrument.



There, you can perform standard functions like creating directory, or saving files.

6. In the `user` directory, create a directory, e.g. `test ftp`.
7. Select "System Config > Save/Recall".
Open the `/var/user/` directory.

The dialog displays the `/var/user/test ftp` directory.



12.10.3 Accessing the R&S SMA100B file system using SMB (Samba)

The SMB (Samba) protocol is an alternative way to access the file system of the instrument from a remote PC. This protocol works if both the instrument and the PC are connected to a LAN.

How to: [Section 3.1.7, "Connecting to LAN"](#), on page 27


To access the file system over SMB

We assume that the instrument and the remote PC are connected to a LAN.

1. [Enable file transfer via FTP](#)

2. [Enable write permission on the file system](#)
3. On the remote PC, start the Windows Explorer.
4. In the address field, enter `\\<"IP Address" of the Instrument>`, e.g. `ftp://10.124.0.166`.

Tip: The R&S SMA100B indicates its IP address on the home screen.



The `user` directory corresponds to the `/var/user/` directory of the instrument; the `volatile` directory - to the `/var/volatile` directory.

To map the R&S SMA100B as a network drive to the remote PC

We assume that the instrument and the remote PC are connected to a LAN.

1. [Enable file transfer via SMB \(Samba\)](#)
2. [Enable write permission on the file system](#)
3. On the remote PC, start the Windows Explorer.
Open the "Map Network Drive" dialog.
 - a) Select a valid "Drive", e.g. *W*.
 - b) In the "Folder" field, enter `\\<"IP Address" of the Instrument>/user` or `\\<"Hostname" of the Instrument>/user`
For example: `\\10.124.0.166/user` or `\\SMA100B-102030/user`.
Tip: The R&S SMA100B indicates its IP address on the screen.
 - c) Select "Finish".

A log-on dialog opens and requests a user name and a password.

Tip:

Default password


The FTP and SAMBA file access use the user "instrument" with default password "instrument".

We recommend that you change this password in the "Setup > Security > Password Management > Change User Password" dialog before connecting the instrument to the network.

See [Section 13.4.5, "Password management"](#), on page 399.

4. Enter the user name and the password of your instrument.

The `/var/user/` directory of the instrument is mapped to and displayed as a network drive of the remote PC.



You can access the files in the `/var/user/` directory, perform standard function like creating directory, or saving files.

12.10.4 Using a USB storage device for file transfer

Alternatively to the file transfer possibility via LAN, you can use a USB storage device for direct file transfer from and to the instrument.

We recommend that you transfer files with user data (like lists or instrument setup files) to the instrument, rather than load and play them from a connected USB storage device.

To transfer a file with user data to the instrument

1. Connect a USB storage device, for example a USB memory stick to one of the USB interfaces of the instrument.

The R&S SMA100B recognizes the connected USB storage device automatically.

2. [Enable file transfer via USB](#)
3. [Enable write permission on the file system](#)
4. Select "System Config > Save/Recall".

The dialog displays the `/var/user/` directory and the `/usb/` drive.

5. In the "Save/Recall" dialog, select "File Manager".
6. In the directory tree, navigate to the `/usb/` drive.
Select the required file with user data.
7. Select "Copy".
8. In the directory tree, navigate to the `/var/user/` directory.
Select "Paste".

The file with user data is transferred to the instrument.

12.10.5 Using a file server for test files exchange

You can use a central file storage location like a file server in your company network to save setup files, SCPI scripts, application programs, or waveform files on it. Usually, you would like to distribute the files to several instruments. If the R&S SMA100Bs are connected to a LAN, you can create a shortcut on the instruments to the file server.

To access the file server

1. On each R&S SMA100B, map the required directory of the file server to the instrument.
Perform the steps described in [Section 12.9.4, "Mapping a network folder"](#), on page 352.
2. On each R&S SMA100B, use the same alias name for the directory of the file server, i.e. enter the same "Local Folder" (in this example *Setups*).

On any of the R&S SMA100B, you access the file server directly from the "File Manager" and under the same name, e.g. `/shares/Setups`.

An extra advantage in remote control is that the same application program would control the instruments.

For example, use the remote control command `MMEMory:CDIRectory "/shares/Setups"` to set the default directory for mass storage.

12.11 Creating screenshots of current settings


The save/recall function enables you to save current settings in a file. To document the most important settings for a performed signal generation, you can also save a hardcopy of the current display.

- [Hardcopy settings](#)..... 360
- [Creating a hardcopy of the display](#).....364

12.11.1 Hardcopy settings

Access:

- Select "System Config" > "Setup" > "User Interface" > "Hardcopy".



The remote commands required to define these settings are described in [Section 15.12, "HCOPY subsystem"](#), on page 529.

Settings:

File.....	361
Format.....	362
Options.....	362
Save.....	362
Hardcopy Options > Common.....	362
L Automatic Naming.....	362
L Format.....	362
L Region.....	362
Hardcopy Options > Automatic Naming.....	363
L Path.....	363
L Clear Path.....	363
L Prefix, Year, Month, Day.....	363
L Current Auto Number.....	364

File...

In "Automatic Naming > Off" mode, accesses the standard file select dialog for selecting the filename and folder the hardcopy is stored in.

If you have enabled "Automatic Naming", the instrument displays the automatically generated filename.

Remote command:

:HCOPY:FILE[:NAME] on page 531

Format

Selects the output file format, for example *.bmp, *.jpg*.xpm and *.png.

Remote command:

:HCOPY:IMAGe:FORMat on page 531

:HCOPY:DEVIce:LANGuage on page 531

Options...

Accesses [Hardcopy Options](#) dialog.

Save

Saves a hardcopy of the current display as a file.


Remote command:

:HCOPY[:EXECute] on page 532

Hardcopy Options > Common

Access: select "Hardcopy > Options... > Common".

With the provided settings, you can customize the file format and the syntax of the automatically assigned filename.

**Automatic Naming ← Hardcopy Options > Common**

If enabled, creates the output filenames automatically according to the rules set with the [Hardcopy Options > Automatic Naming](#) settings.

Remote command:

:HCOPY:FILE[:NAME]:AUTO:STATe on page 533

Format ← Hardcopy Options > Common

Selects the output file format, for example *.bmp, *.jpg*.xpm and *.png.

Remote command:

:HCOPY:IMAGe:FORMat on page 531

:HCOPY:DEVIce:LANGuage on page 531

Region ← Hardcopy Options > Common

Displays the snapshot area.

Remote command:

:HCOPY:REGion on page 531

Hardcopy Options > Automatic Naming

Access: select "Hardcopy > Options... > Automatic Naming".

The screenshot shows the 'Hardcopy Options' dialog box with the 'Automatic Naming' tab selected. The 'Path' field is highlighted with an orange box and contains the text '/var/user'. To the right of the 'Path' field is a 'Common' button. Below the 'Path' field is a 'Delete All Image Files In Path' button and a 'Clear Path' button. Further down are four checkboxes: 'Prefix' (checked), 'Year' (checked), 'Month' (checked), and 'Day' (checked). Below these is a 'Current Auto Number' field containing '000'. At the bottom, the 'Resulting File Name' field displays '<instrument>20240611000.png'.

Provided are the following settings:

Path... ← Hardcopy Options > Automatic Naming

Selects the directory.

Note: To select the destination path, specify also a filename. Otherwise an error message is displayed and selection is canceled.

Remote command:

`:HCOPY:FILE[:NAME]:AUTO:DIRectory` on page 532

Clear Path ← Hardcopy Options > Automatic Naming

Deletes all image files with extensions *.bmp, *.jpg, *.png and *.xmp in the directory set for automatic naming.

Before the command is executed, a warning message prompts you to confirm the deletion of the files.

Remote command:

`:HCOPY:FILE[:NAME]:AUTO:DIRectory:CLEAr` on page 533

Prefix, Year, Month, Day ← Hardcopy Options > Automatic Naming

Determines the rules for "Automatic Naming".

Per default, the automatically generated filename is composed of:

<Path>/<Prefix><YYYY><MM><DD><Number>.<Format>, where Y, M and D mean year, month, Day; Number is the [Current Auto Number](#).

You can activate or deactivate each component separately.

The "Resulting filename" indicates the current filename syntax.

Remote command:

`:HCOPY:FILE[:NAME]:AUTO[:FILE]:PREFIX` on page 534

`:HCOPY:FILE[:NAME]:AUTO[:FILE]:PREFIX:STATE` on page 534

`:HCOPY:FILE[:NAME]:AUTO[:FILE]:YEAR:STATE` on page 534

`:HCOPY:FILE[:NAME]:AUTO[:FILE]:MONTH:STATE` on page 534

`:HCOPY:FILE[:NAME]:AUTO[:FILE]:DAY:STATE` on page 534

Current Auto Number ← Hardcopy Options > Automatic Naming

Indicates the number which is used in the automatically generated filename.

Note: When initially switching on the instrument, the number is reset to the lowest possible value. Starting with number 0 the output directory is scanned for existing files. As long as files with the same name are existing, the number is increased by 1. The number is automatically set so that the resulting filename is unique within the selected path. The current number is not in the save/recall file but is temporarily stored within the database. At the following save operation, the number is increased.

Remote command:

`:HCOPY:FILE[:NAME]:AUTO[:FILE]:NUMBER?` on page 534

12.11.2 Creating a hardcopy of the display

To create a hardcopy

- ▶ Select "System Config" > "Setup" > "User Interface" > "Hardcopy".

Alternatively, you can use the following controls to create a hardcopy quickly:

- On the screen, select context-sensitive menu >  (print).
- On an external keyboard, press the [Print] key.
- Assign the hardcopy function to the [User] key.

See [Section 13.2.2, "How to assign actions to the \[★ \(User\)\] key"](#), on page 376.

The R&S SMA100B creates a snapshot of the screen and opens the "Hardcopy" dialog for saving it in a file.

To configure and save the hardcopy

1. To define the output format, select "Format" > "JPG".
2. To enable the instrument to create output filenames, select "Automatic Naming" > "On".
3. Select "Options ...".
4. In the "Hardcopy Options" dialog:
 - a) To change the default storage directory, select "Automatic Naming Settings" > "Path".
 - b) Define a path and a filename.
For example, select the default directory `/var/user`.

- c) If necessary, modify the parameters in the "Automatic Naming Settings".
 - d) Close the "Hardcopy Options" dialog.
5. In the "Hardcopy" dialog, select "Save".
- The instrument saves a hardcopy of the current instrument display as a *.jpg file.
Also, creates the filename automatically.

To export a hardcopy

1. Connect the instrument to the LAN.
2. Transfer the file to a remote computer
See [Section 12.10, "Transferring files from and to the instrument"](#), on page 354.
3. On the remote computer, select the file.

13 General instrument functions

The general instrument functions include basic instrument settings, regardless of the selected operating mode and measurement. Some of these settings like screen display and peripherals are initially configured at the setup of the instrument, according to personal preferences and requirements. However, you can individually adjust the settings at any time, for example, if necessary for specific applications.

The following special functions help you in service and basic system configuration:

- [Section 13.1, "Customizing the user interface"](#), on page 366
Allows you to adjust the display and keyboard language settings.
- [Section 13.2, "Organizing frequently used settings as favorites"](#), on page 372
Enables you to group user defined settings in a favorites list or to assign actions to the [★ (User)] as quick access for later retrieval.
- [Section 13.3, "Managing licenses and license keys"](#), on page 380
If you have purchased an additional option for the R&S SMA100B, you can enable it using a license key.
- [Section 12.3, "Restoring an instrument configuration"](#), on page 335
At any time, you can restore a default configuration to start a measurement at a defined instrument state, or set the instrument to factory preset.
- [Section 18.3, "Performing maintenance tasks"](#), on page 834
Special functions like calibration routines and self-tests put your instrument to an initial state.
- [Section 13.4, "Using the security settings"](#), on page 389
Special security and protection functions protect your instrument from unauthorized use or activate specific test routines.

13.1 Customizing the user interface

The R&S SMA100B provides basic alignments of instrument settings regarding the user interface, that means the touch panel (screen), the appearance of the displayed dialogs and graphics, and an external keyboard.

Start / stop display update

The operating system of the R&S SMA100B refreshes the displayed settings by default in almost real-time, to keep the display updated with the internally used values. However, you can turn off this function to reduce settling times when the instrument is remote controlled.



We recommend that you switch off the display update for optimum sweep performance with short dwell times and for fast settling times.

Consider that in this case the displayed values can differ from the operated values.

In detail described in the following paragraphs, you can:

- Set display and keyboard language, see [Section 13.1.1, "Display and keyboard settings"](#), on page 367
- Set date and time for the system clock, see [Section 18.3.2, "Date and time"](#), on page 839
- Configure and activate a [Screen Saver](#)
- Deactivate display update to improve performance, see [Section 13.1.2, "Display update settings"](#), on page 369
- Determine the state of the RF signal, and the level display in the status bar when you turn on the R&S SMA100B, see [Section 13.1.3, "Defining the RF signal state on power on"](#), on page 370.

13.1.1 Display and keyboard settings


Access:

1. Select "System Config > Setup > User Interface > Display".

Display Settings	
Screen Saver <i>is Inactive</i>	Wait time 10 Min

Brightness	
Display 14	RF Hardkey 14

2. Select "Keyboard".



In the "Display" and "Keyboard" dialogs, you can enable the screen saver function and configure the language for the key assignment of an external keyboard and the keypad.

The remote commands required to configure the display and keyboard are described in [Section 15.10, "DISPlay subsystem"](#), on page 523 and [Section 15.13, "KBOard subsystem"](#), on page 535.

Screen Saver	368
Wait Time	368
Display	368
RF Hardkey	369
Layout	369
Alphanumeric Keys	369

Screen Saver

Activates the screensaver.

If activated, the display including backlight is switched off after the selected [Wait Time](#) elapses and if no entries via touch panel, front panel, external mouse, or external keyboard are made

Remote command:
[:DISPlay:PSAVe\[:STATe\]](#) on page 524

Wait Time

Enters the idle time that must elapse before the display lamp is shut off when no entries are made.

Remote command:
[:DISPlay:PSAVe:HOLDoFF](#) on page 524

Display

Adjusts the brightness of the display.

Increase the value to turn up the display brightness.

Remote command:
[:DISPlay:BRIGhtness](#) on page 525

RF Hardkey

Adjusts the brightness of the [RF on/off] key.

Increase the value to change the contrast between the key and the front panel background color.

Remote command:

`:DISPlay:BUtTon:BRIGhtness` on page 525

Layout

Selects the language of an external keyboard connected over USB. The function assigns the corresponding keys automatically.

Remote command:

`:KBOard:LAYout` on page 535

Alphanumeric Keys

Selects the layout of the numeric keypad on the front panel.

"Digits Only" Assigns only numeric keys.

"Digits and Letters" Enables numeric and alphanumeric keys.


Remote command:

`:FPANel:KEYBoard:LAYout` on page 535

13.1.2 Display update settings

Access:

- Select "System Config > Setup > User Interface > Start/Stop Display Update".



This dialog enables you, to deactivate updating the display.

The remote command to switch off the display update is described in [Section 15.10, "DISPlay subsystem"](#), on page 523.

Display Update is

Disables the automatic refreshing of the displayed values.

Remote command:

`:DISPlay:UPDate[:STATe]` on page 525


13.1.3 Defining the RF signal state on power on

As additional functions for the level settings, you can determine the state of the RF signal, and the level display in the status bar when you turn on the R&S SMA100B.

Power-On/EMF settings

Access:

► Select "Level" > "Power-On / EMF".



The "Power-On/EMF" dialog contains all settings for configuring the power-on behavior and the level display.

Settings:

Power-On State.....	370
Display Level as Voltage of EMF.....	370

Power-On State
Determines the RF signal output state when the instrument is switched on.
You can disable the RF output signal in general, or start it in the same state as it had been when it was switched off.
Remote command:
`:OUTPut<hw>[:STATe]:PON` on page 537

Display Level as Voltage of EMF
Activates display of the signal level as voltage of the EMF (no-load voltage).
If disabled, the level is displayed as a voltage over a 50 Ohm load.
Note:
The setting is not affected by an instrument preset ([Preset] key or *RST) and the "Save/Recall" function. It is reset only by factory preset.
Remote command:
`[:SOURce<hw>]:POWer:EMF:STATe` on page 745

13.1.4 How to set the initial instrument settings


This section describes how to set up the R&S SMA100B initially.

13.1.4.1 Setting the keyboard language

You can select the language of the external keyboard connected to the instrument.

To adjust the keyboard settings

1. Press the [Setup] key.
2. Select "User Interface > Keyboard".



3. Select the "Layout".


The dialog closes and the changes take effect immediately.

13.1.4.2 Setting the screen saver

You can enable a screen saver that automatically turns off the display after a user-defined period of time. The screen saver is activated if no settings are made on the touch screen, or via keys or the rotary knob during the selected wait time.

To activate the screen saver

1. Press the [Setup] key.
2. Select "User Interface > Display"
3. Activate the "Screen Saver".



4. Define the "Wait Time" in minutes.
The instrument turns off the display after the defined period of time.
5. To reactivate the display, tap the screen or press any key on the front panel.

To deactivate the screen saver

1. Press the [Setup] key.
2. Select "User Interface > Display"
3. Disable the "Screen Saver" state.

13.2 Organizing frequently used settings as favorites

The R&S SMA100B provides two possibilities to define frequently used settings and procedures for later retrieval individually.

User menu and [★ (User)] key

These two functions work similar to the favorites function of a browser or other programs. They allow you to create a list of frequently used actions or to group frequently used settings in one dialog.

You can collect the parameters of your configuration in a favorites list, i.e. in the "User Menu", or define settings and actions with the [★ (User)] key:

- "User Menu" to group settings of specific tasks.
Similar to a favorites function, you can use this menu for:
 - Grouping the settings required for a task in one dialog.
 - Saving and recalling the settings of a task.
 - Transferring the settings for use on multiple instruments.
- [★ (User)] key, with customizable function.
You can perform the following steps using this key:
 - Open the "User Menu" (default functionality).

- Add or remove settings and functions.
- Execute actions and access functions.

Possible applications

The ★ (User) key and the "User Menu" are useful for the following situations:

- There are functions or tasks you have to perform in a defined order but the setting parameters are distributed across several dialogs.
- There are functions or tasks you have to perform frequently but they are not accessible via the front panel keys.
- The required functions are grouped in a dialog that is not directly accessible from the home screen.
- Your task involves loading and executing of SCPI scripts.
See [Section 14.9, "Using remote command scripts"](#), on page 466.
- A quick access to saved setups is required.
- There are functions and tasks you have to perform on several instruments.

Dialog identification

To identify each dialog, the instrument uses a dedicated dialog ID. The dialog ID contains the dialog position on the display and the current active tab. The action that triggers the instrument to open a dialog uses this identification.

Save/Recall vs. recall setup

If you need to restore a specific signal generation setup and perform further configurations based on this particular instrument state, the R&S SMA100B provides two options:

- "Save/Recall" function
For a detailed description, refer to [Section 12.5, "Saving and recalling settings"](#), on page 341.
- "Recall Setup" function
If the "Recall Setup" is the only user action assigned to the [★ (User)] key, pressing this key triggers the R&S SMA100B to load the user-defined preset file immediately.


13.2.1 Configuring settings quickly with the user menu

Access:



1. Press the [★ (User)] key.

The "User Menu" dialog opens.




If you execute this action for the first time, the dialog displays instructions on how to use the "User Menu".

2. If you already have a saved user menu file on the instrument, you can load with "Recall User Menu".


Creating a user menu

To create your own user dialog with settings:

1. Open a dialog with settings you frequently use.
2. Select a parameter.
3. Open the context menu and select "Add to User Menu".




A favorites icon ★ indicates that the parameter is used in the "User Menu".



The "User Menu" button in the taskbar confirms that you have created a "User Menu" with at least one entry.

4. Press the [★ (User)] key.

The "User Menu" dialog shows all parameters that you have added to the list.



You can modify the parameter settings directly in this dialog, e.g. change a state or set values, as you do in the particular dialog the parameter originally belongs to.

5. To remove an entry, select the parameter either in the "User Menu" or in the dialog where it originally belongs to.
 - a) Open the context menu and select "Remove from User Menu".



6. To remove all entries at once, select "Clear User Menu".
7. To save your individual favorites list, select "Save User Menu", and follow the file managing instructions.
The file system automatically assigns the file extension *.user_menu.
8. To recall a previously saved user menu, select "Recall User Menu" and proceed accordingly.

Providing a user menu favorites list for several instruments

To transfer files from or to an instrument:

1. Create the favorites list, as described in ["Creating a user menu"](#) on page 374.
2. Save the favorites list.
3. To transfer a file from or to an instrument, the R&S SMA100B provides several options, see ["File handling"](#) on page 334.

13.2.2 How to assign actions to the [★ (User)] key

The customizable [★ (User)] key has no predefined function assigned. You can individually define actions to be executed or functions to be accessed when pressing this key.

To assign a frequently used dialog to the [★ (User)] key:

1. Open the dialog you want to quickly access.
For example, select "Frequency" > "Reference Frequency"
2. Select "System Configuration" > "Setup" > "User Interface" > "Define User Key".
3. To create an action:
 - a) Specify the "Name".
E.g. *Open reference frequency*.
 - b) Select "Wizard" > "Open Dialog"
 - c) Select "Select Dialog" and select a settings dialog from the list

The corresponding SCPI command is automatically displayed and can be modified.

4. Select "Add" to save the new action in the list of user key actions.

Name	Action
Open reference frequency	:DISP:DIAL:OPEN "DlgKeyRf_Rosc\$t0"
Open power sensors	:DISP:DIAL:OPEN "CPowSensDlg_Overview\$t0"

Name: Open reference frequency Wizard: Open Dialog Select Dialog

SCPI: :DISP:DIAL:OPEN "DlgKeyRf_Rosc\$t0"

+ Add Change Remove Back to Exec Mode ...

5. To execute the created action, press ★ (User).
In the list of actions ("Define User Key Actions" dialog), navigate to the required action.

In this example, this is "Open reference frequency".

Define User Key Actions ✕	
Name	Action
Open reference frequency	:DISP:DIAL:OPEN "DlgKeyRf_Rosc\$t0"
Open power sensors	:DISP:DIAL:OPEN "CPowSensDlg_Overview\$t0"
Open hardcopy	:DISP:DIAL:OPEN "CSetupDlgHCopy\$tidHardcopy_general"

The R&S SMA100B opens the dialog.

Tip: If you have assigned only one action to the user key, the R&S SMA100B performs the action immediately.

13.2.3 User menu settings

The "User Menu" dialog contains function keys to organize, save and load a favorites list. You can also modify, add or delete list entries directly in the dialog.

Clear User Menu

Removes all entries from the "User Menu" at once.

Save User Menu

Saves the current "User Menu" under the defined filename.

Recall User Menu

Loads the selected "User Menu" file.

This function enables you to use the user specific favorites file on another instrument. However, if functions or parameters are not provided due to varying configuration of the instrument, the settings of these particular parameters take no effect.

13.2.4 Define user key actions settings

Access:

- Select "System Config" > "Setup" > "User Interface" > "Define User Key".

Name	Action
Open reference frequency	:DISP:DIAL:OPEN "DlgKeyRf_Rosc\$t0"

Name Open reference frequency	Wizard Open Dialog	Select Dialog
----------------------------------	-----------------------	---------------

SCPI :DISP:DIAL:OPEN "DlgKeyRf_Rosc\$t0"	
---	--

+ Add	Change	Remove	Back to Exec Mode ...
-------	--------	--------	-----------------------

The dialog displays a list of the currently enabled actions and provides functions to define new, edit or remove existing actions. If no actions have been defined, the list is empty.

See [Section 13.2.2, "How to assign actions to the \[★ \(User\)\] key"](#), on page 376.

The remote commands required to define these settings are described in [Section 15.10, "DISPlay subsystem"](#), on page 523.

Name

Enters a user-defined name for the action.

Wizard

Defines the action to be executed.

"Load SCPI Script"

Selects and executes the SCPI script.

"Recall Setup"

Opens the file dialog for selecting a saved setup with user-defined settings.

"Open Dialog"

Selects an open settings dialog or menu.

Select

Depending on the selected "Wizard", provides access to:

- the standard "File Select" function for loading an SCPI script or setup file
- a list of all currently opened dialogs.

See [SCPI](#).

SCPI

For the currently selected action, displays the corresponding SCPI command with the associated parameter for dialog identification (dialog ID). The automatically displayed SCPIs are enabled for subsequent modification.

Remote command:

[:DISPlay:DIALog:OPEN](#) on page 527

See also [:DISPlay:DIALog:ID?](#) on page 526


Add, Change, Remove

Standard functions for managing of the actions.

Back to Execute Mode

Opens the "Select Action to Execute" dialog. Select an Action form the list to execute it.

To return to the "Define User Key Actions" dialogs, select [Select Action to Execute > Define Actions](#).

Select Action to Execute > Define Actions

Opens the "Define User Key Actions" settings dialog.

13.3 Managing licenses and license keys

An option is ready to operate after it is enabled with a license keycode supplied with the option. The license key is delivered as a file or on paper. Unregistered licenses must be registered for a particular instrument before the corresponding option can be enabled for operation.



For reliable operation, a software option usually requires the latest firmware version. The required version is specified in the delivery. If your instrument works with a former firmware version, update the firmware before enabling the software option.

The firmware update is described in the release notes provided on the product page of the R&S SMA100B.

13.3.1 Manage license keys settings


The "Manage License Keys" dialog provides all information on the available licenses. Instrument-related steps guide you through the process of registering or deactivating licenses.

Access:

1. Select "System Config" > "Setup" > "Instrument Assembly" > "Manage License Keys" > "Manage License Keys".

In this tab, you can activate licenses for newly purchased or newly registered options.

2. Select "Installed License Keys".



This tab lists all active options, with information on the available number of an option, the license type and registration. You can query inactive or disabled options also.

3. Select "Open License Server".

The "Manage License Keys" dialog covers all required parameters for activating or deactivating newly purchased or newly registered options, and provides access to the onboard license server, see [Section 13.3.2, "Using the license server"](#), on page 383.

Settings:

Device ID.....	381
Enter License Key.....	381
Import License Key from File.....	382
Export Deactivation Response to File.....	382
License Installation Info.....	382
Installed License Keys.....	382
L Show Inactive.....	382
L Show Deactivated.....	382
L Installed License Keys Table.....	382
Open License Server.....	383

Device ID

Displays the instrument-specific identification number. The device ID is a unique string with the following structure:

```
<stock number>-<serial number>-<checksum>
```

Enter License Key

Type here the license key provided with the option.

For license keys delivered as a file, use [Import License Key from File...](#)

Import License Key from File...

Opens a dialog for selecting the file with the license key.

Use this function also to import the deactivation key file generated by the R&S License Manager online tool (see [How to move a portable license](#)).

Export Deactivation Response to File...

Exports the generated deactivation response key to a file and opens a file management dialog to save the file.

This key is required during the unregistration process, e.g. when you want to deinstall an option or have a portable option, which you want to register later on another instrument (see [How to move a portable license](#)).

License Installation Info

Indicates status information on the performed actions.

Installed License Keys

Access: select "System Config > Setup > Instrument Assembly > Manage License Keys > Installed License Keys".

Comprises information on the installed options.

Show Inactive ← Installed License Keys

Enables the display of the inactive (expired) licenses in the [Installed License Keys Table](#).

Show Deactivated ← Installed License Keys

Enables the display of the deactivated licenses in the [Installed License Keys Table](#).

See [How to move a portable license](#) for information on how to activate deactivated licenses.

Installed License Keys Table ← Installed License Keys

Shows information on the currently installed options.

"Export License Key to File"

Opens a dialog to save the generated license key file. This file is required during the unregistration process.

If you have a portable unregistered option, you can register it later on another instrument (see [How to move a portable license](#)).

"Option"

Displays the short designation of the option.

Note: Open the [Hardware Options/Software Options](#) dialog to retrieve more information about the installed options.

"License Count"

Displays the number of the licenses for the selected option key.

- "License Type" Displays the type of license.
A license type determines the common qualification application duration and the portability of a license. The following license types are provided: evaluation, permanent, portable, quantified, time-controlled with a duration of 1, 3, 6 or 12 months. A license can also be deactivated or expired.
For time limited licenses, the left time of applicability is displayed too.
- "Registrations" (reserved for future use)

Open License Server

Opens the R&S License Server of the R&S SMA100B, see [Section 13.3.2, "Using the license server"](#), on page 383.

13.3.2 Using the license server

The R&S SMA100B now supports handling of software licenses using the license server from Rohde & Schwarz.

The R&S License Server is a browser application you can access directly in the R&S SMA100B. The onboard license server is integrated in the instrument firmware with connection to a *local smartcard* memory. The local smartcard holds local licenses, i.e. licenses used on this specific instrument.

To open the license server

Access:

1. Select "System Config > Setup > Instrument Assembly > Manage License Keys > Installed License Keys".

Manage License Keys					
Installed License Keys					
Show Inactive ☐ Show Deactivated ☐ Open License Server					
	Export License Key To File	Option	License Count	License Type	Registrations
1 ...		<InstName>-Opt>	1	Permanent	
2 ...		<InstName>-Opt>	2	Permanent	
3 ...		<InstName>-Opt>	1	Timed (2160 h left)	

2. Select "Open License Server".

The license server browser opens in a browser window and starts initially in the "Configuration" view.




Figure 13-1: R&S license server dialog

The selection button in the status bar on the left enables you to access the "Analytics" or "Licenses" views, see ["Short glance at the main views"](#) on page 384.

The icons in the status bar on the right lead you to information on the license server:

- "About": shows the software version.
- "User Manual": opens the embedded license server user manual.
- "Help": provides the functional description on a specific dialog and its settings.

Short glance at the main views

The section provides a brief insight into the main windows of the license server. For details and handling of the application, refer to the embedded user documentation.



1. To access a view, select the menu button.

2. Select "Configuration".




Figure 13-2: Configuration menu

Accesses the license server, access lists and installed product definitions.

- a) Select "Local license server".

Hostname	Description	Server version	Main port	Public port
<hostname>		2.7.1.1702	9443	9444

Showing 1 of 1 items.

Figure 13-3: Example of a local license server view

Shows the onboard license server of the instrument. With the column selection, you can indicate or unhide characteristics of the available server. The task bar buttons provide access to the corresponding functions and access lists.

- b) Select "Product definitions".

Name	Part number	Version
<productname>	1234.5678	1.0.0.0

Showing 1 of 1 items.

Figure 13-4: Example of a product definition view

Shows installed product definitions. To view the available characteristics, use the column selection.

3. Select "Licenses".
Provides access to the available license servers.
The "License keys" view lists the license key options that are available on the selected server. To show additional information, use the column selection.
The task bar functions enable you to activate or deactivate a license, to get details on an option and export license keys or information on the selected product.
4. Select "Analytics".




Figure 13-5: Analytics menu

Provides access to the license providers, client applications and enables you to export statistics data for evaluation in external applications.

Shows information on configured client applications, license providers and license types. To show additional information, use the column selection.

To manage licenses on the R&S SMA100B

To request or return a license, proceed as follows:

1. Access: see ["To open the license server"](#) on page 383.
The browser application opens.
2. Select "Licenses"
3. Select a license server in the menu list, e.g. "R&S SMA100B".
The "License keys" view lists the enabled options available on the selected server.
4. Select "Status" > "Select all" to list also options that are currently deactivated.
The "Licenses" view shows all active, inactive and time limited options.
5. To get detailed information on a specific option:
 - a) Select the option in the list.

- b) In the task bar, select "Details".




Figure 13-6: Example of the license characteristics of an option

6. To enable a discontinued license: , select in the taskbar.
 - a) Select the license you want to activate.
 - b) In the task bar, select .
7. To return a license, proceed the same way:
 - a) Select the license.
 - b) Deactivate the license with .
8. Follow the instructions on the screen.

13.3.3 How to move a portable license

This example is intended to explain how to perform the required steps at the instrument.

Use a USB flash drive to transfer the license key files between the instruments and the browser.



We assume knowledge about the handling of the R&S License Manager online tool and the description of the whole process.

1. Open your browser. Enter <https://extranet.rohde-schwarz.com/service>.
Select "Manage Licenses > Move Portable License".
The first step requires the Device IDs of the source and target instruments.
2. To find out the Device IDs, proceed as follows:

- a) On the source instrument, select "System Config > Setup > Instrument Assembly > Manage License Keys > Manage License Keys > Device ID".

Manage License Keys	Installed License Keys		X
Device ID			
1234.1234K02-000000-ID			

- b) On the target instrument, select "System Config > Setup > Instrument Assembly > Manage License Keys".
 - c) In the "Mange License Keys" tab, select "Device ID".
 - d) In the browser, select "Manage Licenses > Move Portable License > Select Devices".
 - e) Enter the Device IDs.
3. On the source instrument, select "System Config > Setup > Instrument Assembly > Installed License Keys > License Keys Table".
 - a) Navigate to the portable license that you want to move.
 - b) Select the "Export License to File" column.

A standard file manager dialog opens.
 4. Enter a filename.
 5. Save the exported license key, e.g. k123_portable_key_to_move.xml.
 6. In the browser, select "Manage Licenses > Move Portable License > Select License (from file)":
 - a) Select the exported license key.
 - b) Check the selection.
 - c) Create the deactivation key.
 - d) Save it to file.
 7. On the source instrument, select "System Config > Setup > Instrument Assembly > Manage License Keys > Import License Keys from File".
Select the transferred deactivation key.
 8. On the source instrument, select "System Config > Setup > Instrument Assembly > Manage License Keys > Export Deactivation Response to File".
 9. In the browser, go to "Manage Licenses > Move Portable License > Install Deactivation Key (from file)".
 10. Enter the deactivation response of the instrument.
The license is deactivated for the source instrument.
 11. In the "Manage Licenses > Move Portable License", go to step "Create License" to generate a license key for this portable option and the selected target instrument.
 - a) Download the license key as a file.
 - b) Transfer it to the target instrument.

12. In the target instrument, select "System Config > Setup > Instrument Assembly > Manage License Keys > New License > Import License Keys from File".

13. Select the created license key file.

The portable option is installed on the target instrument.

13.4 Using the security settings

The protection function of the R&S SMA100B provides several levels to activate particular functions like self-test or tests for service purposes specifically.

Protection

The five protection levels are automatically active on startup that means all protected functions are locked.

To unlock a protection level:

- ▶ In the "System Config > Setup > Security > Protection" dialog, enter the correct password.

To lock a protection level:

- ▶ Clear the corresponding checkbox.

Protection levels

The following functions are protected in the respective levels:

- Protection level 1
Protects against accidental changes, like, for example, the clock and date, several internal adjustments functions and the self-test, as well as network settings or the instrument hostname.
You can access this level with the password 123456.
- Protection level 2
Unlocks protected service functions. It is accessible to authorized personnel of Rohde & Schwarz service department only.
- Protection level 3 to 5
Are reserved for internal use.

Security

The security concept of the R&S SMA100B helps you to protect your instrument against uncontrolled access and changes.



All modified security settings require that you enter the [Security Password](#) and confirm with [Accept](#).

Provided security services are:

- **General** security parameters, such as:
 - **USB storage** that secures controlled access to the mass memory of the instrument
 - **Volatile mode** that prevents information to be written to the internal memory permanently.
 - **Sanitizing** that prevents the instrument from leaving a secure environment with stored user information.
 - **Annotation** frequency and amplitude prevent reading the display.
 - **User interface** prevent manual operation and reading the display.
- **Password** management secures controlled user access to the instrument
 With the two-step password concept, you can assign a user-defined password for the operating system, and a security password for accessing the mass storage of the instrument.
 See [Section 13.4.5, "Password management"](#), on page 399.
- **LAN services** secure controlled network access
 You can individually lock and unlock supported LAN interface services, including the SMB client and SMB server that use versions 1.0 and 2.0 of the SMB protocol. Remote control over LAN requires you have enabled the interface, but you can disable not needed LAN services individually.
Note: Disabling LAN services needed for remote control over LAN locks the instrument access persistently. You cannot address the instrument any longer.
 See [Section 13.4.4, "Configuring LAN services"](#), on page 395.
- **User interface** prevents front panel operation and/or reading the display.


For more information, see the document R&S SMA100B Instrument Security Procedures.

• Disk & memory security settings	390
• Manual operation security settings	392
• Protection level settings	394
• Configuring LAN services	395
• Password management	399
• Preventing unauthorized access	402

13.4.1 Disk & memory security settings

Access:

1. Select "System Config" > "Setup" > "Security" > "Security".
2. Select "General" > "Disk & Memory".



The "Disk & Memory" tab secures controlled access to the mass memory and prevents information from leaving a secure environment.

The remote commands available to control security settings are described in [Section 15.19, "SYSTem subsystem"](#), on page 776.

USB Storage

Activates the access to external USB storage media.

To apply the change enter the security password and confirm with "Accept".

See [Section 12.10.4, "Using a USB storage device for file transfer"](#), on page 359.

Note: Remove all USB memory devices before disabling the USB storage. If any USB memory device remains connected, disabling is blocked, and the instrument returns a warning message.

The microSD card is also considered a USB memory device and must be removed. If you have sealed the SD card slot, you can not disable the USB storage.

Volatile Mode

Activates volatile mode, so that no user data can be written on the internal memory permanently.

In volatile mode:

- Data that the instrument normally stores on the internal memory is redirected to volatile memory.
- The user directory is mapped to the volatile memory. You access the temporary data just as data stored in the `/var/user/`, see [Section 12.4, "Protecting data"](#), on page 340.
- Data on the internal memory cannot be changed. It is protected against modification or erasure.
- You can only save data:
 - Temporarily in the volatile memory
 - On a connected external storage device, such as a memory stick

To apply the change enter the security password and confirm with "Accept".

Enabling the volatile mode also requires a reboot, prompted by the instrument.

The icon  indicates the enabled volatile mode.

Remote command:

`:SYSTEM:SECurity:VOLMode[:STATe]` on page 799

Sanitize

Executes the erase procedure that sanitizes the internal memory.

The sanitizing function makes sure that no user information is stored on the instrument when it leaves the secure environment.

To apply the change enter the security password and confirm with "Accept".

Note: If the instrument is subject to high security, and you have disabled volatile mode, the internal memory holds user-data, and thus poses a security risk.

See also [Section 13.4, "Using the security settings"](#), on page 389 for more information on the security concept.


Remote command:

`:SYSTEM:SECurity:SANitize[:STATe]` on page 798

13.4.2 Manual operation security settings

Access:

1. Select "System Config" > "Setup" > "Security" > "Security".
2. Select "General" > "Manual Operation".



The "Manual Operation" tab enables you to lock front panel operation and/or reading the display.

The remote commands available to control security settings are described in:

- [Section 15.10, "DISPlay subsystem"](#), on page 523
- [Section 15.19, "SYSTem subsystem"](#), on page 776.

Annotation Frequency

Enables the display of the currently used frequency in the status bar.

To apply the change enter the security password and confirm with "Accept".

How to: see ["To disable frequency and level indication in the status bar"](#) on page 405.

Remote command:

`:DISPlay:ANNotation:FREQuency` on page 526

Annotation Amplitude

Enables the display of the currently selected level in the status bar.

To apply the change enter the security password and confirm with "Accept".

How to: see ["To disable frequency and level indication in the status bar"](#) on page 405.

Remote command:

`:DISPlay:ANNotation:AMPLitude` on page 525

User Interface

Allows you to lock the controls for manual operation and the display individually.

To apply the change enter the security password and confirm with "Accept".

How to: see ["To disable the user interface"](#) on page 405.

See also [Section 13.4, "Using the security settings"](#), on page 389.

"Enabled" Enables the display and all controls for the manual operation of the instrument.

"Touchscreen Off"

Locks the touch sensitivity of the screen.

This security feature protects the instrument against unintentional change of settings by accidentally touching of the screen.

Still available controls for manual operation are:

- The keys at the front panel, including the rotary knob
- The external mouse and keyboard
- Remote operation over VNC

The instrument indicates the locked touchscreen by an icon .

Unlocking is possible via VNC, external controls or remote control.

"VNC Only"

Locks the keys at the front panel, the touchscreen and externally connected keyboard and mouse.

The display on the screen remains and shows the current settings and changes.

The instrument indicates the activated "VNC only" feature by the icon



Unlocking is possible via VNC or turning off and on again.

- "Display Only" Locks the manual operation of the instrument. The display on the screen remains and shows the current settings and changes. This security feature protects the instrument against unauthorized access, but still shows the current settings and processes, for example when you operate the instrument via remote control.
- The function disables:
- The touchscreen functionality of the display
 - The keys at the front panel of the instrument
 - The external mouse and keyboard
- The instrument indicates the locked controls by a padlock  softkey. How to unlock: see ["Unlocking \(reactivating\) the user interface for manual operation"](#) on page 405.
- "Disabled" Locks the display and all controls for the manual operation of the instrument. This security feature protects the instrument against unauthorized reading and access, for example when you operate the instrument via remote control.
- The function disables:
- The display
 - The touchscreen
 - The keys at the front panel of the instrument
 - The external mouse and keyboard
- The screen shuts off and displays a padlock symbol  instead. How to unlock: see ["Unlocking \(reactivating\) the user interface for manual operation"](#) on page 405.

Remote command:

:SYSTem:ULOCK on page 785

:SYSTem:DLOCK on page 784

:SYSTem:KLOCK on page 785

Enabling a locked user interface for manual operation

Follow the instructions listed in ["Unlocking \(reactivating\) the user interface for manual operation"](#) on page 405.

Remote command:

:SYSTem:ULOCK on page 785

:SYSTem:DLOCK on page 784

:SYSTem:KLOCK on page 785

13.4.3 Protection level settings

Access:

- Select "System Config" > "Setup" > "Security" > "Protection".

Protection Level 1	☒	Password	*****
Protection Level 2	☒	Password	*****
Protection Level 3	☒	Password	*****
Protection Level 4	☒	Password	*****
Protection Level 5	☒	Password	*****

The "Protection" dialog provides access to the unlocking of different protection levels.

Several functions in the instrument are password-protected to prevent for example accidental changes, "[Protection](#)" on page 389.

The remote commands required to unlock a protected stage are described in [Section 15.19, "SYSTem subsystem"](#), on page 776.

Protection Level/Password

Unlocks the selected level of protection, if you enter the correct password.

The default protection level 1 password is 123456.

To lock the protection level again, clear the checkbox.

Remote command:

`:SYSTem:PROTect<ch>[:STATe]` on page 787

13.4.4 Configuring LAN services

Access:

1. Select "System Config > Setup > Security > Security > LAN Services > Common Services".
2. **NOTICE!** Risk of loosing access over LAN. Disabling the LAN interface or the common services "SCPI over LAN", "VNC" and "HTTP" locks the remote access to the instrument.

Do not disable the LAN interface or LAN services needed for remote control while you operate the instrument remotely.

Proceed with step [step 4](#) for troubleshooting disabled services.

General			LAN Services	Password Management	X
LAN				Common Services	
SCPI over LAN <i>is Enabled</i>	☒	FTP <i>is Enabled</i>	☒	VNC <i>is Enabled</i>	☒
SMB (Samba) <i>is Enabled</i>	☒	SSH (SCP) <i>is Enabled</i>	☒	Remote Support <i>is Disabled</i>	☐
HTTP <i>is Enabled</i>	☒	Software Update <i>is Enabled</i>	☒	Avahi (Zeroconf) <i>is Enabled</i>	☒
Security Password				☒ Accept	

In the "Common Services" side tab, you can individually disable the supported services of the LAN interface.

3. Disable LAN services as needed.
 - a) Disable the service.
 - b) To confirm disabling, enter the security password.
 - c) Select "Accept".
4. If you have locked the access accidentally, you have the following options:
 - Update the instrument firmware using ISO image (`<instrument>_<version-number>.iso`).
Note: A firmware update with the ISO image resets the instrument. The instrument reset dismisses user-specific configurations and deletes user data. Contact the Rohde & Schwarz (<https://www.rohde-schwarz.com/support>) to get the ISO image.
 - Ship the instrument to your local service department. The service center experts can enable the remote access over LAN without losing user-specific settings and data.
 See www.services.rohde-schwarz.com.
5. Select "System Config > Setup > Security > Security > LAN Services > Samba Services".

General			LAN Services	Password Management	X
SMB 1.0/2.0 Client <i>is Disabled</i>				SMB 1.0/2.0 Server <i>is Disabled</i>	
				Common Services	
				Samba Services	

In the "Samba Services" side tab, you can activate former versions of the SMB client and SMB server.

The remote commands available to control security settings are described in [Section 15.19, "SYSTem subsystem"](#), on page 776.

How to:

- ["To disable LAN access in general"](#) on page 403
- ["To disable LAN services individually"](#) on page 403
- ["To enable SMB version 1.0/2.0 client and server"](#) on page 404

Common Services.....	397
L LAN.....	397
L LAN Services.....	397
Samba Services.....	398
L SMB 1.0/2.0 Client.....	398
L SMB 1.0/2.0 Server.....	399
Security Password.....	399
Accept.....	399

Common Services

Enables the LAN interface and supported LAN interface services.

LAN ← Common Services

Enables the LAN interface in general, and thus provides remote access over all unlocked services.

Remote command:

`:SYSTem:SECurity:NETWork[:STATe]` on page 798

LAN Services ← Common Services

Enables the supported LAN interface services individually.

"SCPI over LAN"

Access over LAN to control the instrument remotely, by using SCPI (Standard Commands for Programmable Instruments) commands. See also ["To set up the controller with R&S VISA"](#) on page 458 and ["To start remote control with R&S VISA"](#) on page 460

Remote command:

`:SYSTem:SECurity:NETWork:SOE[:STATe]` on page 797

"VNC"

Access over VNC (Virtual Network Computing) interface, a graphical desktop sharing system that uses RFB protocol to control the instrument remotely.

See also [Section 14.10, "Setting up remote operation over VNC"](#), on page 476.

Remote command:

`:SYSTem:SECurity:NETWork:VNC[:STATe]` on page 798

- "SSH (SCP)" Access over SSH (Secure Shell), a network protocol for secure data communication.
Remote command:
`:SYSTem:SECurity:NETWork:SSH[:STATe]` on page 797
- "Remote Support"
Remote support over SSH (SCP).
The service provides communication for service purposes only.
Remote command:
`:SYSTem:SECurity:NETWork:REMSupport[:STATe]`
on page 796
- "HTTP" Access with HTTP (Hyper Text Transfer Protocol), the application protocol for hypermedia information systems.
Remote command:
`:SYSTem:SECurity:NETWork:HTTP[:STATe]` on page 796
- "FTP" Access with FTP (File Transfer Protocol), used to transfer files from a host to the instrument and vice versa.
See also [Section 12.10.2, "Accessing the file system using FTP"](#), on page 356.
Remote command:
`:SYSTem:SECurity:NETWork:FTP[:STATe]` on page 795
- "SMB (Samba)" Access to SMB (Server Message Block), used for providing shared access to files, printers and serial ports of a network.
See also [Section 12.10.3, "Accessing the R&S SMA100B file system using SMB \(Samba\)"](#), on page 357.
Remote command:
`:SYSTem:SECurity:NETWork:SMB[:STATe]` on page 797
- "Avahi (Zeroconf)" Avahi, a service for automatic configuration of the instrument in a network environment.
Remote command:
`:SYSTem:SECurity:NETWork:AVAHi[:STATe]` on page 795
- "Software Update" Allows updating the software.
Remote command:
`:SYSTem:SECurity:NETWork:SWUPdate[:STATe]` on page 798

Samba Services

Enables support of SMB client and SMB server version 1.0 and 2.0 of the SMB protocol.

Support of version 1.0 and 2.0 is additional to the current SMB protocol version supported in the firmware. This firmware supports SMB protocol up to version 3.1.1.

SMB 1.0/2.0 Client ← Samba Services

Enables support of the SMB client compatible with SMB protocol versions 1.0 and 2.0.

SMB 1.0/2.0 Server ← Samba Services

Enables support of the SMB server compatible with SMB protocol versions 1.0 and 2.0.

Security Password

Enters the password that is required to enable or to disable the settings protected by a security password. Default is 123456.

How to: ["To change the security password"](#) on page 402

Accept

Applies the modified settings, provided the security password is entered and correct.

13.4.5 Password management

Access:

1. Select "System Config > Setup > Security > Security > Password Management > User Password".

In this tab, you can assign the security and a user-defined password.

2. Select "System Config > Setup > Security > Security > Password Management > Security Password".

General	LAN Services	Password Management	
Old Password		User Password	
New Password		Security Password	
Confirm Password			
		 Change Password	

How to:

- ["To change the user password of the instrument"](#) on page 402.
- ["To change the security password"](#) on page 402.

Settings:

User Name.....	400
User Password.....	400
L Old Password.....	400
L New Password.....	401
L Confirm Password.....	401
L Change Password.....	401
Security Password.....	401
L Old Password.....	401
L New Password.....	401
L Confirm Password.....	401
L Change Password.....	402

User Name

Indicates the user name used for access to the Linux operating system and valid for VNC, FTP and SMB (Samba) access.

User Password

Access: select "System Config > Setup > Security > Security > Password Management > User Password".

Allows you to change and confirm the user password.

Old Password ← User Password

Enters the current user password. The default password is "instrument".

Note: We recommend that you change the default password before connecting the instrument to a network.

How to:

- ["To change the user password of the instrument"](#) on page 402.

- ["To change the security password"](#) on page 402.

Note: Note that you cannot reset the password to factory state.

If you encounter problems with the password, contact the Rohde & Schwarz customer support, see [Section 16.10, "Contacting customer support"](#), on page 831.

New Password ← User Password

Enters the new user password.

The security password can contain decimal characters only.

Confirm Password ← User Password

Confirms the new user password by repeating.

How to:

- ["To change the user password of the instrument"](#) on page 402.
- ["To change the security password"](#) on page 402.

Change Password ← User Password

Changes the user password accordingly.

Security Password

Access: select "System Config > Setup > Security > Security > Password Management > Security Password".

Enables you to change and confirm the security password.

Old Password ← Security Password

Enters the currently used security password. The default password is '123456'.

Note: We recommend that you change the default password before connecting the instrument to a network.

How to:

- ["To change the user password of the instrument"](#) on page 402.
- ["To change the security password"](#) on page 402.

The security password is required when changing the status of the USB and LAN interface or other security settings.

Note: Note that you cannot reset the password to factory state.

If you encounter problems with the password, contact the Rohde & Schwarz customer support, see [Section 16.10, "Contacting customer support"](#), on page 831.

New Password ← Security Password

Enters the new security password.

The security password can contain decimal characters only.

Confirm Password ← Security Password

Confirms the new security password by repeating.

How to:

- ["To change the user password of the instrument"](#) on page 402.
- ["To change the security password"](#) on page 402.

Change Password ← Security Password

Changes the password accordingly.

13.4.6 Preventing unauthorized access

The default computer name and user password are *instrument*. The user password is the password required for VNC, FTP and SMB (samba) connections. If for example, the VNC service or FTP are enabled, anyone in the network who knows the computer name and user password of the instrument can access it.

The default security password is *123456*. The security password is required when changing the status of the USB and LAN interfaces.

To prevent unauthorized access, use the following configurations exclusively or complementary:

- ["To change the user password of the instrument"](#) on page 402
- ["To change the security password"](#) on page 402
- ["To disable LAN access in general"](#) on page 403
- ["To disable LAN services individually"](#) on page 403
- ["To enable SMB version 1.0/2.0 client and server"](#) on page 404
- ["To disable frequency and level indication in the status bar"](#) on page 405
- ["To disable the user interface"](#) on page 405

If security is a concern, see the document instrument security procedures for comprehensive description.

To change the user password of the instrument

- **Note:** We recommend that you change the default password before connecting the instrument to a network.

How to:

- ["To change the user password of the instrument"](#) on page 402.
 - ["To change the security password"](#) on page 402.
- a) Select "System Config > Setup > Security > Security > Password Management > User Password".
 - b) Enter the current password in the "Old Password" field.
 - c) Enter the new password in the "New Password" and "Confirm Password" fields.
 - d) Select "Change Password".

The user password is changed; the user name is displayed ("Security > Password Management > User Password > User Name").

To change the security password

- **Note:** We recommend that you change the default password before connecting the instrument to a network.

How to:

- ["To change the user password of the instrument"](#) on page 402.

- "To change the security password" on page 402.
- a) Select "System Config > Setup > Security > Security > Password Management > Security Password".
- b) Enter the current password in the "Old Password" field.
The default password is 123456.
- c) Enter the new password in the "New Password" and "Confirm Password" fields.
- d) Select "Change Password".

To disable LAN access in general

1. **NOTICE!** Risk of losing access over LAN. Disabling the LAN interface or certain services lock the remote access to the instrument.
The following services lock the remote access when disabled: "LAN", "SCPI over LAN", "VNC" and "HTTP".

If you have locked the access accidentally, you have the following options:

- Update the instrument firmware using ISO image
(`<instrument>_<version-number>.iso`).
Note: A firmware update with the ISO image resets the instrument. The instrument reset dismisses user-specific configurations and deletes user data.
Contact the Rohde & Schwarz (<https://www.rohde-schwarz.com/support>) to get the ISO image.
- Ship the instrument to your local service department. The service center experts can enable the remote access over LAN without losing user-specific settings and data.
See www.services.rohde-schwarz.com.

2. Select "System Config > Setup > Security > Security".
3. Select "LAN Services > Common Services".
4. Disable "LAN" state.
5. Enter the [Security Password](#).
6. Select "Accept".

All LAN connections are blocked, including the LAN services. Communication over LAN is not possible.

To disable LAN services individually

1. Select "System Config > Setup > Security > Security".
2. Select "LAN Services > Common Services".
3. Uncheck all services you want to block, for example "FTP > Off" or "VNC > Off".

General	LAN Services	Password Management			X
LAN 				Common Services	
SCPI over LAN <i>is Enabled</i> ☒		FTP <i>is Disabled</i> ☐		VNC <i>is Disabled</i> ☐	
SMB (Samba) <i>is Enabled</i> ☒		SSH (SCP) <i>is Disabled</i> ☐		Remote Support <i>is Disabled</i> ☐	
HTTP <i>is Disabled</i> ☐		Software Update <i>is Enabled</i> ☒		Avahi (Zeroconf) <i>is Enabled</i> ☒	
Security Password				<input checked="" type="button" value="Accept"/>	

4. Uncheck the services you want to block, for example "FTP" and "VNC".
5. Enable "LAN" state, if disabled.
6. Enter the [Security Password](#).
7. Select "Accept".

Communication over LAN is possible for the enabled services only.

To enable SMB version 1.0/2.0 client and server

By default, support of SMB client and SMB server of the SMB protocol versions 1.0 and 2.0 is disabled.

Activate support only, if needed:

1. Select "System Config > Setup > Security > Security".
2. Select "LAN Services > Samba Services".

General	LAN Services	Password Management			X
SMB 1.0/2.0 Client <i>is Enabled</i> ☒				Samba Services	
SMB 1.0/2.0 Server <i>is Disabled</i> ☐				Common Services	
Security Password				<input checked="" type="button" value="Accept"/>	

3. For example, check "SMB 1.0/2.0 Client".
4. Select "SMB 1.0/2.0 Client > On" and "SMB 1.0/2.0 Server > On".
5. Enter the [Security Password](#).
6. Select "Accept".

Enables the access for the SMB Samba client, the access for the SMB Samba server remains blocked.

To disable frequency and level indication in the status bar

These settings are useful to prevent unauthorized personnel from reading the display, when you remotely control the instrument from a different location.

1. Select "System Config > Setup > Security > General > Manual Operation".
2. Select "Annotation Frequency > Off" or "Annotation Amplitude > Off".
3. Enter the [Security Password](#).
4. Select "Accept".

To disable the user interface


1. Select "System Config > Setup > Security > General > Manual Operation".
2. Select "User Interface > Disabled".
3. Enter the [Security Password](#).
4. Select "Accept".

The screen shuts off and displays a padlock symbol  instead.

There are further possible configurations. For details, see ["User Interface"](#) on page 393.

Unlocking (reactivating) the user interface for manual operation

1. In manual operation:
 - a) On the instrument's keypad or external keyboard, press any key.
The instrument prompts you to enter the security password for unlocking.



If you press the character of the first key, the input field accepts the character immediately.

- b) Delete the entry before inserting the password.
Enter the security password **123456**.
2. In remote control mode:

- a) Send the command `SYST:ULOC ENABled` to release all locks at once.
- b) Send the command `SYST:KLOC OFF` to unlock the keyboard and touchscreen.
- c) Send the command `SYST:DLOC OFF` to release all locks.

Via remote control, there is no password required.

13.5 Undoing or restoring actions


"Undo" is a function that removes the effect of the last action on the instrument and reverts it to an older state. Conversely, "Redo" restores a previously undone action.

You can "Undo/Redo" actions according to two criteria:

- Step by step
Gradually undo/redo the actions in reverse order as previously performed. Depending on the available memory the "Undo/Redo" steps may restore all actions.
- Multiple steps at once
Select any specific action in the history list to "Undo/Redo" multiple actions in a single step.
Note: This mode requires a system restoration file on the instrument.

Access:

- Select "Setup > Settings > Undo/Redo".



The dialog contains all functions for enabling the "Undo/Redo" functionality.

Settings:

State.....	407
History List.....	407
Clear History.....	407
Apply.....	407

State

Enables the recording of the performed actions.

History List

Lists the performed actions, provided "Undo/Redo" state is "On".

Clear History

Deletes the recorded list of the performed steps.

Apply

Performs the "Undo/Redo".

If you select a previously performed action of the list, all subsequent actions are undone. The list entries remain.


If you select a subsequently executed action, you can restore all the actions undone up to this state.

13.6 Shutting down and rebooting the instrument

The [On/Standby] front panel key switches the instrument from the standby to the ready state or vice versa. In remote operation from a remote computer or in manual control, there is another possibility to shut down the instrument or to reboot the system.

Access:

- ▶ Select "System Config > Setup > Maintenance > Shut Down".



- :SYSTem:REBoot on page 805
- :SYSTem:SHUTdown on page 806

14 Network operation and remote control

As an alternative to the interactive operation directly at the instrument, you can operate the R&S SMA100B also from a remote location.

The various interfaces provide flexible access to the instrument, such as *remote control*, *remote operation* or *remote file access*. These remote access modes are fundamentally different, although they are often considered interchangeable, as described in [Section 14.1, "Overview of remote access modes"](#), on page 409.

[Figure 14-1](#) shows the possibilities of the physical connection (interfaces) for remote access.




Figure 14-1: Supported remote connections



The following descriptions provide information required for operating the R&S SMA100B remotely. The information applies to all applications and operating modes supported by the instrument. Definitions specified in the SCPI standard are not provided.

For basic knowledge on remote control operation and additional information, see the following documents, available on the Rohde & Schwarz website:

- Getting started: [Remote control via SCPI](#)
- Application note [1GP72](#): "Connectivity of Rohde&Schwarz Signal Generators"
- Application note [1MA208](#): "Fast Remote Instrument Control with HiSLIP"
- Application note [1GP98](#): "SCPI Recorder Test Automation on a Fingertip"

• Overview of remote access modes	409
• Remote control interfaces and protocols	410
• Remote control programs and libraries	415
• Status reporting system	418
• Remote access settings	421
• LXI status settings	444
• LXI browser settings	445
• Setting up remote control	452

• Using remote command scripts	466
• Setting up remote operation over VNC	476
• References	482

14.1 Overview of remote access modes

This section outlines the possible access modes and their major characteristics.

Remote control (SCPI)

- A remote PC controls the instrument, usually via VISA (Virtual Instrument Software Architecture) interfaces.
- Remote control disables the manual operation of the instrument; you can set different lock states.
- The GUI is not visible.
- Remote control commands (SCPI) perform the settings, either individually or in sequences (SCPI programs).
- Using SCPI programs is faster than the manual operation, since they automate repeating applications.

Remote operation (VNC)

- A remote device accesses the instrument via the common platform technology VNC (Virtual Network Computing).
- The protocol allows simultaneous operation from several remote devices and the instrument nevertheless remains locally operable.
- The GUI is visible.
- To perform the settings, you can operate the instrument as with the manual control.
- During remote operation via VNC, the direct control of the instrument is not disabled.
You can control the instrument from the front panel and via the remote computer alternately.
- Clients supporting remote operation depend on the used remote device, see [Table 14-1](#).
- How to: see [Section 14.10, "Setting up remote operation over VNC"](#), on page 476.

Table 14-1: Supported VNC operation modes

Remote device	VNC client	Requirements	Characteristics
Desktop (Windows, Linux, Mac™OS)	• Ultr@VNC • Other dedicated client software	<i>Ultr@VNC or Client Software</i> must be installed.	Fast, supports several options like full screen mode or auto-login.
	• Any web browser	<i>Java Runtime</i> must be installed and activated in the browser settings.	Fast and convenient - only the instrument address required. Java runtime is sometimes considered as security concern.

Remote device	VNC client	Requirements	Characteristics
	Web browser with HTML5	<i>Web sockets</i> must be supported.	Slower than the other modes. No additional installation or activation required. No security concern.
Smart device (Tablet/ smartphone)	Dedicated client App	App must be installed.	Fast, supports several options like full screen mode or auto-login.
	Web browser with HTML5	<i>Web sockets</i> must be supported.	Support of QR code scanning Slower than a dedicated App.

Remote file access (FTP, SAMBA/SMB)

- A remote client accesses the instrument's file system, using the protocols FTP (file transfer protocol) and SAMBA/SMB (server message block).
- The protocols enable you to transfer files from or to the instrument and to get direct access to its file sharing directory *share*.

How to:

[Section 12.10.2, "Accessing the file system using FTP"](#), on page 356.

[Section 12.10.3, "Accessing the R&S SMA100B file system using SMB \(Samba\)"](#), on page 357

["To enable SMB version 1.0/2.0 client and server"](#) on page 404

14.2 Remote control interfaces and protocols

The instrument supports various interfaces for remote control. [Table 14-2](#) gives an overview on the connectivity:

Table 14-2: Remote control interfaces and protocols

Interface	Protocols, VISA ¹⁾ address string and library	Remarks
Local area network (LAN)	HiSLIP High-Speed LAN Instrument Protocol (IVI-6.1) TCPIP::host address::hislip0[::INSTR] VISA VXI-11 TCPIP::host address[:: LAN device name][::INSTR] VISA Socket communication (Raw Ethernet, simple Telnet) TCPIP::host address[:: LAN device name]::<port>::SOCKET VISA or socket controller	The LAN connector is at the rear panel of the instrument. The interface is based on TCP/IP, see Section 14.2.1, "LAN interface", on page 411 for details on the address information.
USB	USBTMC USB::<vendor ID>::<product ID>:: <serial number>[::INSTR] VISA	The USB In connector is at the rear panel of the instrument. For a description of the interface, see Section 14.2.2, "USB interface", on page 413

Interface	Protocols, VISA ^{*)} address string and library	Remarks
GPIB (IEC/IEEE Bus Interface)	VISA^{*)} address string: GPIB::<address>[::INSTR] (no secondary address) VISA (optional)	The optional GPIB bus interface according to standard IEC 625.1/IEEE 488.1 is at the rear panel of the instrument. For a description of the interface, see Section 14.2.3, "GPIB interface (IEC/IEEE bus interface)", on page 414.
^{*)} VISA (Virtual Instrument Software Architecture) is a standardized software interface library providing input and output functions to communicate with instruments. A VISA installation on the controller is a prerequisite for remote control over LAN (when using VXI-11 or HiSLIP protocol), USB and serial interface. When using socket communication or the GPIB interface, VISA installation is optional. For basic information, see Remote control via SCPI.		



www.rohde-schwarz.com/rsvisa provides the standardized I/O software library R&S VISA for download at the Rohde & Schwarz website www.rohde-schwarz.com/rsvisa.

How to: [Section 14.8, "Setting up remote control"](#), on page 452 describes how to configure the remote control interfaces.

- [LAN interface](#).....411
- [USB interface](#).....413
- [GPIB interface \(IEC/IEEE bus interface\)](#).....414
- [LXI browser interface](#).....415

14.2.1 LAN interface

The LAN interface of the instrument consists of a connector, a network interface card and protocols.

For remote control, the instrument and the controller PC must be connected to a common network with TCP/IP network protocol.

There are two methods to establish a LAN connection to the instrument:

- A non-dedicated network (Ethernet) connection from the instrument to an existing network.
- A dedicated network connection (Point-to-point connection) between the instrument and a single computer.

How to: [Section 3.1.7, "Connecting to LAN"](#), on page 27



Identifying instruments in a network

If several instruments are connected to the network, each instrument has its own IP address and associated resource string. The controller identifies these instruments by the resource string.

VISA resource strings

The VISA resource string is required to establish a communication session between the controller and the instrument in the LAN. The resource string is a unique identifier,

composed of the specific IP address of the instrument and some network and VISA-specific keywords.

TCPIP::<host address>[:<LAN device name>][:INSTR]

TCPIP	= designates the network protocol
host address	= designates the IP address or hostname of the instrument
[:LAN device name]	= defines the protocol and the instance number of a subinstrument
[:INSTR]	= indicates the instrument resource class (optional)

The **IP address** (host address/computer name) is used by the programs to identify and control the instrument. It is automatically assigned by the DHCP server the first time the device is registered in the network. Optionally, you can also assign its **LAN device name**.

If assigned, the IP address is displayed in the home screen.

The following section lists the characteristics of the VISA resource strings for the corresponding interface protocols. The emphasized characters determine the protocol.



For description of the interface protocols, control commands and messages, refer to [Remote control via SCPI](#).

HiSLIP

TCPIP::<host address>::hislip0[:INSTR]

hislip0 = HiSLIP device name, designates that the interface protocol HiSLIP is used (mandatory)

hislip0 is composed of [::HiSLIP device name[,HiSLIP port]] and must be assigned.

Example:

TCPIP::192.1.2.3::hislip0

VXI-11

TCPIP::<host address>[:inst0][:INSTR]

[:inst0] = LAN device name, indicates that the VXI-11 protocol is used (optional)

inst0 currently selects the VXI-11 protocol by default and can be omitted.

Example:

TCPIP::192.1.2.3::INSTR

Socket communication

TCPIP::<host address>:<port>::SOCKET

port = determines the used port number
 SOCKET = indicates the raw network socket resource class

Socket communication requires the specification of the port (commonly referred to as port number) and of "SOCKET" to complete the resource string.

Basically, instruments from Rohde & Schwarz use port number 5025 for socket communication.

Example:

TCPIP::192.1.2.3::5025::SOCKET

14.2.2 USB interface

Option: R&S SMAB-B86

For remote control using USB, the controller PC and the instrument must be connected over the USB type B interface. Software for instrument control and the VISA program library must be installed on the controller.

The serial interface "RS232" enables you to connect the instrument over serial interface. You can connect to the interface by using the external USB/serial-adapter R&S TS1-USB and a serial crossover (null modem) cable.

For more information, refer to the specifications document.

VISA detects and configures the Rohde & Schwarz instrument automatically when the USB connection is established. You do not have to install a separate driver.

USBTMC (USB Test & Measurement Class Specification) is a protocol that is built on top of USB for communication with USB devices. It defines class code information of the instrument, that identifies its functionality to load the respective device driver. Using VISA library, the protocol supports service request, trigger, and other specific operations.

USB resource string

The resource string represents an addressing scheme that is used to establish a communication session with the instrument. It is based on the instrument address and some instrument- and vendor-specific information.

The USB resource string syntax is as follows:

USB::<vendor ID>::<product ID>::<serial number>[:INSTR]

USB = denotes the used interface
 <vendor ID> = is the manufacturer ID for Rohde & Schwarz
 <product ID> = is the product identification of the instrument
 <serial number> = is the individual serial number at the rear of the instrument
 [:INSTR] = indicates the instrument resource class (optional)

RS232 resource string

The RS232 resource string represents the addressing scheme for a device connected to the serial interface of the instrument.

The USB resource string syntax is as follows:

ASRL<port number>[:INSTR]

ASRL is the name of the serial interface

<port number> is the number of the serial interface

Example:

ASRL1::INSTR

14.2.3 GPIB interface (IEC/IEEE bus interface)

Option: R&S SMAB-B86

To control the R&S SMA100B over the GPIB bus, the instrument and the controller PC must be connected with a GPIB bus cable. A GPIB bus card, the card drivers and the program libraries for the used programming language must be installed on the controller.



For description of the characteristics, control commands and messages of the GPIB interface, refer to [Remote control via SCPI](#).

GPIB address

The controller PC addresses the instrument with the GPIB bus channel, see [Section 14.5.3, "GPIB address settings"](#), on page 426. GPIB provides channel addresses from 0 to 30.

The GPIB resource string syntax is as follows:

GPIB::/<channel>[:INSTR]

GPIB = denotes the used interface

<channel address> = the used channel

[:INSTR] = indicates the instrument resource class (optional)

Note: If the VISA implementation supports the GPIB interface, you can optionally define the VISA Instrument Control Resource (INSTR). It is used to define the basic operations and attributes for a device, such as reading, writing, or triggering.

Example:

GPIB::28::INSTR

28 is the selected GPIB bus channel

14.2.4 LXI browser interface

The LXI browser interface allows easy configuration of the LAN and remote control of the R&S SMA100B without additional installation requirements. The instrument's LXI browser interface works correctly with all W3C compliant browsers.

See [Section 14.11.1, "LXI functionality"](#), on page 482 for more about LXI.

The LAN settings are configured using the instrument's LXI browser interface described in [Section 14.7.1, "LAN configuration"](#), on page 447.

For LXI status information in the R&S SMA100B, see [Section 14.6, "LXI status settings"](#), on page 444.

14.3 Remote control programs and libraries

This section shows how the remote-control programs access the instrument, and the libraries they require for the corresponding interface protocols.






Figure 14-2: Overview of remote control interfaces, protocols and libraries

Possible setups and access functions

The following examples give an overview of dependencies between the available libraries, the possible interfaces and protocols, and whether an instrument driver is provided. For detailed information, see the application note [1GP72](#).

Example: Remote control (application) program using VISA**Figure 14-3: Application program using VISA**

Protocol	Remote control program
Socket	<pre>viOpen (... , "TCPIP:SMA100B-102030::5025::SOCKET", ...) viPrintf (... , "SOUR:FREQ 2GHz\n")</pre>
VXI-11	<pre>viOpen (... , "TCPIP:SMA100B-102030::inst0::INSTR", ...) viPrintf (... , "SOUR:FREQ 2GHz\n")</pre>
HiSLIP	<pre>viOpen (... , "TCPIP:SMA100B-102030::hislip0::INSTR", ...) viPrintf (... , "SOUR:FREQ 2GHz\n")</pre>
USBTMC	<pre>viOpen (... , "USB::0x0AAD::0x01DD::100001::INSTR", ...) viPrintf (... , "SOUR:FREQ 2GHz\n")</pre>
GPIB	<pre>viOpen (... , "GPIB::28::INSTR", ...) viPrintf (... , "SOUR:FREQ 2GHz\n")</pre>

Example: Remote control program using instrument driver (VISA available)**Figure 14-4: Application using instrument driver (VISA available)**

Protocol	Remote control program
Socket	<pre>rssma_init ("TCPIP:SMA100B-102030::5025::SOCKET", ...) rssma_SetFrequency (... , 2e9)</pre>
VXI-11	<pre>rssma_init ("TCPIP:SMA100B-102030::inst0::INSTR", ...) rssma_SetFrequency (... , 2e9)</pre>
HiSLIP	<pre>rssma_init ("TCPIP:SMA100B-102030::hislip0::INSTR", ...) rssma_SetFrequency (... , 2e9)</pre>
USBTMC	<pre>rssma_init ("USB::0x0AAD::0x01DD::100001::INSTR", ...) rssma_SetFrequency (... , 2e9)</pre>
GPIB	<pre>rssma_init ("GPIB::28::INSTR", ...) rssma_SetFrequency (... , 2e9)</pre>

Example: Remote control program using instrument driver (VISA not available)




Figure 14-5: Remote control program using instrument driver (VISA not available)

Protocol	Remote control program
Socket	<code>rssma_init ("TCPIP:SMA100B-102030::5025::SOCKET", ...)</code> <code>rssma_SetFrequency (... , 2e9)</code>
GPIB	<code>rssma_init ("GPIB::28::INSTR", ...)</code> <code>rssma_SetFrequency (... , 2e9)</code>

14.4 Status reporting system

The status reporting system stores all information on the current operating state of the instrument and on errors which have occurred. This information is stored in the status registers and in the error queue. You can query the status of the registers with the remote commands of the [Section 15.20, "STATus subsystem"](#), on page 806.

14.4.1 Overview of the status registers

The [Figure 14-6](#) shows the hierarchical structure of information in the status registers (ascending from left to right).




Figure 14-6: Graphical overview of the status registers hierarchy

OPER = Operation Status Summary Bit
 RQS/MSS = Service Request Generation
 ESB = Standard Event Status Summary Bit
 MAV = Message Available in Output Queue
 QUES = Questionable Status Summary Bit
 2 = Error- /Event-Queue
 1, 0 = not used



The following sections describe the instrument-specific bit assignments of the operation status and the questionable status registers.

For more information, see:

- [Remote control via SCPI](#): provides general information on the status reporting system of Rohde & Schwarz instruments. This document also provides information on the standard event status register and the error queue.
- SCPI standard documentation for comprehensive information on the standard

14.4.2 Instrument-specific status operation register

The condition part contains information on currently executed actions. The event part covers information on the actions performed since the last readout of the register.

To read the register, use the query commands `:STATus:OPERation:CONDition?` on page 807 and `:STATus:OPERation[:EVENT]` on page 808.

The remote commands for the status questionable register are described in [Section 15.20, "STATus subsystem"](#), on page 806.

Table 14-3: Assignment of the bits used in the operation status register

Bit No.	Meaning
0	Calibrating The bit is set during the calibration phase.
1–2	Not used
3	Sweeping This bit is set during a sweep in automatic or single mode.
4–15	Not used

14.4.3 Instrument-specific status questionable register

This status register contains information on questionable instrument states. Questionable states occur when the instrument is not operated in compliance with its specifications.

To read the register, use the query commands `:STATus:QUEStionable:CONDition` on page 809 or `:STATus:QUEStionable[:EVENT]` on page 809.

The remote commands for the status questionable register are described in [Section 15.20, "STATus subsystem"](#), on page 806.

Table 14-4: Assignment of the bits used in the questionable status register

Bit No.	Meaning
0–15	Not used

14.4.4 Reset values of the status reporting system

The following table contains the different commands and events causing the status reporting system to be reset. None of the commands, except for *RST and SYSTem:PRESet affect the functional instrument settings. In particular, DCL does not change the instrument settings.

Table 14-5: Resetting the status reporting system

Event	Switching on supply voltage Power-On-Status-Clear		DCL, SDC (Device Clear, Selected Device Clear)	*RST or SYSTem: PRESet	STATus: PRESet	*CLS
Effect	0	1				
Clear STB, ESR	-	Yes	-	-	-	Yes
Clear SRE, ESE	-	Yes	-	-	-	-
Clear PPE	-	Yes	-	-	-	-
Clear error queue	Yes	Yes	-	-	-	Yes
Clear output buffer	Yes	Yes	Yes	1)	1)	1)
Clear command processing and input buffer	Yes	Yes	Yes	-	-	-
1) The first command in a command line that immediately follows a <PROGRAM MESSAGE TERMINATOR> clears the output buffer.						

14.5 Remote access settings

This section describes the settings required for accessing and configuring the provided remote control interfaces. It includes network settings, access addresses, emulation settings for using the command sets of other generators, and the access with smart devices.

- [Network settings](#).....422
- [VISA resource strings settings](#).....425
- [GPIB address settings](#).....426
- [RS232 settings](#).....427
- [Instrument emulations settings](#).....428
- [Active remote connection settings](#).....430
- [Closed remote connection settings](#).....431
- [HUMS settings](#).....432
- [HUMS enhanced settings](#).....434
- [QR code](#).....443

14.5.1 Network settings

Access:

- Select "System Config" > "Remote Access" > "Network".

Network	Visa Resource Strings	GPIO Address	RS232	Instrument Emulations	Remote Connections	HUMS	QR-Code
Network Status ● Connected Restart Network							
Instrument Name							
Hostname INSTRUMENT		Workgroup INSTRUMENT					
Instrument Address							
Address Mode Auto (DHCP)		Show Connector ...					
IP Address 10.111.1.17		Subnet Mask 255.255.252.0		Default Gateway 10.111.0.1			
DNS Suffix rsint.net		DNS Server 10.0.2.166		MAC Address 08 00 27 55 c0 44			

The "Network" dialog provides settings of the general network environment, and specific identification parameters of the instrument in the network. If necessary, you can configure the instrument address settings manually.

How to: ["To assign the instrument address manually"](#) on page 454.

The remote commands required to configure the network remotely are described in [Section 15.19, "SYSTEM subsystem"](#), on page 776.

Settings:

Network Status	422
Restart Network	422
Hostname	423
Workgroup	423
Address Mode	423
IP Address	423
Subnet Mask	423
Default Gateway	424
DNS Suffix	424
DNS Server	424
MAC Address	424

Network Status

Indicates that the instrument is connected to the network.

Remote command:

`:SYSTEM:COMMunicate:NETWork:STATus?` on page 790

Restart Network

Terminates the network connection of the instrument and sets it up again. You can use this function to fix network problems.

Note: This function restarts only the connection of the instrument to the network. It does not impact the network itself.

Remote command:

[:SYSTem:COMMunicate:NETWork:REStart](#) on page 790

Hostname

Displays the hostname.

Each instrument is delivered with an assigned hostname, a logical name which can be used instead of the IP address. With the default network settings, the IP address is allocated by the DHCP server. This address can change each time the instrument is reconnected. Unlike the IP address, the hostname name does not change.

Note:

This function is password-protected. Unlock the protection level 1 to access it.

- We recommend that you do not change the default network settings or the host-name to avoid problems with the network connection.
If you change the hostname, be sure to use a unique name.

Remote command:

[:SYSTem:COMMunicate:NETWork\[:COMMON\]:HOSTname](#) on page 790

Workgroup

Sets the individual windows workgroup name of the R&S SMA100B. This parameter is required in case the instrument is integrated in a windows network.

This function is password-protected. Unlock the protection level 1 to access it.

Remote command:

[:SYSTem:COMMunicate:NETWork\[:COMMON\]:WORKgroup](#) on page 791

Address Mode

Selects the mode for assigning the IP address.

"Auto (DHCP)"

Assigns the IP address automatically, provided the network supports DHCP (Dynamic Host Configuration Protocol).

"Static"

Enables you to assign the IP address manually.

Remote command:

[:SYSTem:COMMunicate:NETWork:IPAddress:MODE](#) on page 789

IP Address

Displays the IP address of the instrument in the network.

To assign the IP address manually, see ["To assign the instrument address manually"](#) on page 454.

Remote command:

[:SYSTem:COMMunicate:NETWork:IPAddress](#) on page 789

Subnet Mask

Displays the bit group of the subnet in the host identifier.

The TCP/IP protocol is preinstalled with the subnet mask 255.255.255.0. If the DHCP server is available [Address Mode A AUTO \(DHCP\)](#), the setting is read-only. The subnet mask consists of four number blocks separated by dots. Each block contains 3 numbers in maximum (e.g. 100.100.100.100), but also one or two numbers are allowed in a block (as an example see the preinstalled address).

To assign the subnet mask manually, select [Address Mode > Static](#).

Note: When assigning the subnet mask manually, make sure that the address matches with the subnet mask of the controlling host interface.

How to: ["To assign the instrument address manually"](#) on page 454.

Remote command:

`:SYSTem:COMMunicate:NETWork[:IPAddress]:SUBNet:MASK` on page 791

Default Gateway

Displays the gateway address.

This address identifies the router on the same network as the instrument that is used to forward traffic to destinations beyond the local network.

To assign the gateway address manually, select [Address Mode > "Static"](#).

Remote command:

`:SYSTem:COMMunicate:NETWork[:IPAddress]:GATeway` on page 791

DNS Suffix

Displays the primary DNS (Domain Name System) suffix, that means the DNS name without the hostname part.

The DNS system uses the suffix for registration and name resolution for unique identification of the instrument in the entire network.

To assign the DNS suffix manually, select [Address Mode > "Static"](#).

Remote command:

`:SYSTem:COMMunicate:NETWork[:COMMON]:DOMain` on page 790

DNS Server

Determines the preferred server for name resolution. The DNS server contains the underlying numerical values that are required for name resolution of the hostname as part of the IP address.

To select the DNS server manually, select [Address Mode > "Static"](#).

Remote command:

`:SYSTem:COMMunicate:NETWork[:IPAddress]:DNS` on page 791

MAC Address

Indicates the MAC (Media Access Control) address, a unique identifier of the network adapter in the R&S SMA100B.


Remote command:

`:SYSTem:COMMunicate:NETWork:MACaddress` on page 789

14.5.2 VISA resource strings settings

Access:

- ▶ Select "System Config" > "Remote Access" > "Visa Resource Strings".



The "Visa Resource String" dialog displays the VISA resource strings provided for remote control over the different interfaces.

The remote commands required to query the address information remotely are described in [Section 15.19, "SYSTem subsystem"](#), on page 776.

Settings:

HISLIP	425
VXI11	425
Socket	426
GPIB	426
USB	426
SERIAL	426

HISLIP

Displays the visa resource string for remote control with HiSLIP protocol.

See also [Section 14.2.1, "LAN interface"](#), on page 411.

Remote command:

[:SYSTem:COMMunicate:HISLip:RESource?](#) on page 789

VXI11

Displays the visa resource string for remote control over LAN.

See also [Section 14.2.1, "LAN interface"](#), on page 411.

Remote command:

[:SYSTem:COMMunicate:NETWork:RESource?](#) on page 790

Socket

Displays the visa resource string for remote control over LAN, using the socket communication protocol.

See also [Section 14.2.1, "LAN interface"](#), on page 411.

Remote command:

`:SYSTem:COMMunicate:SOCKet:RESource?` on page 792

GPIB

Displays the visa resource string for remote control over the GPIB interface.

See also [Section 14.2.3, "GPIB interface \(IEC/IEEE bus interface\)"](#), on page 414.

Remote command:

`:SYSTem:COMMunicate:HISLip:RESource?` on page 789

USB

Displays the visa resource string for remote control over the USB interface.

See also [Section 14.2.2, "USB interface"](#), on page 413.

Remote command:

`:SYSTem:COMMunicate:USB:RESource?` on page 793

SERIAL

Displays the visa resource string for remote control over the serial interface.

See also [Section 14.2.2, "USB interface"](#), on page 413.


Remote command:

`:SYSTem:COMMunicate:SERial:RESource?` on page 792

14.5.3 GPIB address settings

Access:

- Select "System Config" > "Remote Access" > "GPIB Address".



The "GPIB Address" enables you to select the channel for remote control over the IEC/IEE bus interface.

The remote command to configure the setting remotely is described in [Section 15.19, "SYSTem subsystem"](#), on page 776.

Settings:

[GPIB Channel Address](#).....427

GPIB Channel Address

Sets the GPIB (IEC/IEEE bus) channel address for the connected instrument.


Remote command:

[:SYSTem:COMMunicate:GPIB\[:SELF\]:ADDRes](#) on page 788

14.5.4 RS232 settings

Access:

- Select "System Config > Remote Access > RS232".



The "RS232" dialog enables you to control the instrument over a serial interface using a USB adapter. The controller and the instrument must be connected with the external USB/serial-adapter R&S TS1-USB and a serial crossover (null modem) cable. The USB connection requires the Visa library to be installed on the controller. Visa detects and configures the R&S SMA100B automatically when the USB connection is established.

For more information, refer to the specifications document.

The remote commands required to configure the parameters remotely are described in [Section 15.19, "SYSTem subsystem"](#), on page 776.

Settings:**Baud Rate**

Sets the baudrate for the serial remote control interface.

Remote command:

[:SYSTem:COMMunicate:SERial:BAUD](#) on page 792

Parity

Sets the parity for the serial remote control interface.

Remote command:

[:SYSTem:COMMunicate:SERial:PARity](#) on page 792

Stop Bits

Sets the number of stop bits for the serial remote control interface.

Remote command:

`:SYSTem:COMMunicate:SERial:SBITs` on page 792

14.5.5 Instrument emulations settings

About instrument emulations

You can remotely control the R&S SMA100B using the command set of another signal generator. With this function you can, for example, replace a signal generator with an R&S SMA100B in an automated test setup, without adjusting the command scripts used.



The R&S SMA100B also covers command sets of Rohde & Schwarz signal generators. To achieve optimal compatibility when replacing an instrument, we recommend that you select the emulation command set for the corresponding signal generator.

You find the remote control command sets supported by the R&S SMA100B in a selection list.

The selected instrument also defines the identification string that is retrieved with query `*IDN?`. If necessary, use the parameter `Mode` and `IDN String` to change this string.

As any other parameter, the remote control command set can also be changed remotely by the command `:SYSTem:LANGuage`.


While working in an emulation mode, the R&S SMA100B specific command set is disabled and the SCPI command `:SYSTem:LANGuage` is discarded.

To return to the SCPI command set of the R&S SMA100B, use the corresponding command of the selected command set.

If for example an HP generator is emulated, the HP command `EX` returns to the instrument-specific GPIB command set.

Access:

- ▶ Select "System Config" > "Remote Access" > "Instrument Emulations".



The "Instrument Emulations" dialog enables you to emulate a remote control command set of another signal generator.

The remote commands required to configure the emulation settings remotely are described in [Section 15.19, "SYSTem subsystem"](#), on page 776.

Settings:

Language

Selects the instrument whose remote command set is emulated by the R&S SMA100B.

Remote command:

[:SYSTem:LANGuage](#) on page 795

Mode

Selects the way the instrument identification is performed.

"Automatic" Sets the "IDN String" and the "OPT String" automatically for the instrument selected with the parameter [Language](#).

"User Defined" Enables you to define the "IDN String" and the "OPT String".

Remote command:

[:SYSTem:IDENTification](#) on page 793

Set to Default

In "Mode > User Defined", resets the *IDN and *OPT strings.

Remote command:

[:SYSTem:IDENTification:PRESet](#) on page 794

IDN String

Indicates the identification string of the instrument when queried with the common command *IDN?.

In addition to the preset values, you can define your own identification string so that each generator uses an individual identification, like `My_SigGen` for instance, see [Mode](#) .

Remote command:

- `*IDN?` on page 489
- `:SYSTem:IRESpOse` on page 794

OPT String

Indicates the option string of the instrument as queried with common command `*OPT?`.

In [Mode](#) > "User Defined", you can define your own option string. A query responds with this option string instead of the automatically created option string.


Remote command:

- `*OPT?` on page 489
- `:SYSTem:ORESpOse` on page 794

14.5.6 Active remote connection settings

This dialog displays the active SCPI and TCP/IP connections.

- Access:
- Select "System Config" > "Remote Access" > "Remote Connections".
 - Select "Active".



The "Active" tab shows the currently active remote connections, and you can enable the display of the active connections in the task bar.

Settings:

Show Remote Connections in Taskbar	431
SCPI Connections	431
TCP/IP Connections	431

Show Remote Connections in Taskbar

Displays the currently active connections in the taskbar.

SCPI Connections

Displays the VISA resources strings of the remote connections currently controlling the instrument via the LAN interface.

Remote command:
n.a.

TCP/IP Connections


Displays the types and client addresses of the remote connections currently controlling the instrument via the LAN interface.

Remote command:
n.a.

14.5.7 Closed remote connection settings

Access:

- 1. Select "System Config" > "Remote Access" > "Remote Connections".
- 2. Select "Closed".



This dialog displays a history list of the connections that have accessed the instrument before.

Settings:

SCPI Connections.....432

TCP/IP Connections.....432

SCPI Connections

Lists the VISA resource strings of the last remote connections that have accessed the instrument via the LAN interface before.

Remote command:

n.a.

TCP/IP Connections

Lists the types and client addresses of the last remote connections that had accessed the instrument via the LAN interface before.

Remote command:

n.a.

14.5.8 HUMS settings

Requires R&S SMAB-K980.

About health and utilization monitoring system (HUMS)

The R&S SMA100B comes with a health and utilization monitoring system (HUMS) providing information about the R&S SMA100B. Aim is to increase the overall utilization, to avoid downtime and to increase the overall security level of a fleet of instruments.

HUMS provides, for example, information about:

- Instrument identification, hardware components, software packages, licenses
- Usage of remote control, usage via keyboard / mouse, usage of test applications
- Hardware utilization and status, including S.M.A.R.T. data of the system drive
- User-defined static information, for example, an inventory code

Interfaces and protocols

The HUMS installation on the R&S SMA100B includes an SNMP agent and a REST service with HTTP endpoints. So you can access the health and usage information via LAN, using the SNMP protocol or the REST protocol. Accessing the data does not interfere with remote control via SCPI commands or with measurement execution.

Reference information for both protocols is available on the R&S SMA100B at the address `http://<instrument>/api/hums/v1/documents?name=<interface>`.

For `<instrument>`, enter the hostname (e.g. `SMA100B-102030`) or the IP address (e.g. `10.121.0.34`) of your instrument, as for access to the GUI.

For `<interface> = snmp`, you get a `.zip` file containing the MIB files for SNMP. For `<interface> = rest`, you get a web page with the OpenAPI specification of the REST API.

Address example: `http://SMA100B-102030/api/hums/v1/documents?name=snmp`.

The following table lists the REST endpoints and the SNMP MIB file names.


REST endpoint /api/hums/v1/...	SNMP MIB	Description	Typical data
documents	---	developer information	SNMP MIB files, swagger specification of HUMS REST endpoints
greetings	RS-GREETINGS-MIB	identity information	manufacturer, model, serial number, version
equipment/bios	RS-BIOS-INFO-MIB	BIOS information	BIOS manufacturer, version and release date
date-time	RS-TIME-DATE-MIB	time and date information	UTC and local time, timezone, dst (daylight savings time)
device-history	RS-DEVICE-HISTORY-MIB	history events	instrument-specific event information and notifications
device-tags	RS-DEVICE-TAGS-MIB	customer information	user-definable key information, associated with the instrument, e.g. asset number, owner, location
equipment	RS-EQUIPMENT-MIB	footprint information	hardware and software configuration, licenses
hums-info	RS-HUMS-INFO-MIB	basic information on the HUMS service	HUMS version, counter of SNMP and REST requests, amount of collected data, HUMS database size
storage	RS-STORAGE-MIB	S.M.A.R.T. data of drive	system drive temperature, drive health
system-info	RS-SYSTEM-INFO-MIB	a system overview	OS and BIOS version, IP address, locale
system-status	RS-SYSTEM-STATUS-MIB	system status information	global system status, static notifications
utilization	RS-UTILIZATION-MIB	utilization information	instrument activity, e.g., power on time, RF on time, option utilization, remote interface traffic

For detailed information about HUMS and its applications, refer to:

- The R&S®HUMS Health and Utilization Monitoring Service user manual, available on the Rohde & Schwarz website.
- The application note [GFM336](#)

Access:

- Select "System Config" > "Remote Access" > "HUMS".



The dialog provides settings to configure the health and utilization monitoring system (HUMS) of the R&S SMA100B.

The remote commands required to define these settings are described in [Section 15.9, "HUMS remote control commands"](#), on page 516.

Settings:

State	434
Enhanced Settings	434
Delete History	434
Export History	434

State

Activates HUMS.

Data is only recorded if HUMS is enabled. If disabled, already recorded data can still be retrieved.

The setting is reset by a factory preset to "off".

Remote command:

[DIAGnostic:HUMS:STATe](#) on page 518

Enhanced Settings

Opens a dialog for configuring enhanced protocol settings, see [Section 14.5.9, "HUMS enhanced settings"](#), on page 434.

Access is only available, when HUMS is enabled, see [State](#).

Delete History

Deletes all information from the HUMS service including the device history.

Note: Regarding the instrument security, the sanitization procedure also deletes the history of the HUMS service, see [Section 13.4.1, "Disk & memory security settings"](#), on page 390.

Remote command:

[DIAGnostic:HUMS:DEvIce:HISTory:DELeTe:ALL](#) on page 517

Export History

Triggers an export of the logged data of the HUMS service into a *.zip file.

A standard file dialog opens, to save the log file. By default, the file is saved to the directory /var/user/.

Remote command:

[DIAGnostic:HUMS:DEvIce:HISTory?](#) on page 516

[DIAGnostic:HUMS:SAVE](#) on page 518

14.5.9 HUMS enhanced settings

Access:

1. Select "System Config > Remote Access > HUMS".
2. Select "State > ON".

3. Select "Enhanced Settings".

Protocol

Device Tags

X

SNMP

v1/v2c/v3

REST

☒

SNMP Configuration

Location

Contact

Read Only Community

Read&Write Community

⚙ User Settings ...

The dialog provides enhanced settings for configuring protocol settings and device tags.

The remote commands required to define these settings are described in [Section 15.9, "HUMS remote control commands"](#), on page 516.

• Protocol settings	435
• SNMP user settings	437
• Device tag settings	441

14.5.9.1 Protocol settings

The "Protocol" tab of the "Enhanced HUMS Settings" dialog provides protocol settings for SNMP or REST protocol.

Access:

1. Select "System Config > Remote Access > HUMS".
2. Select "State > ON".
3. Select "Enhanced Settings".
4. Select "Protocol".

The dialog provides enhanced settings for configuring protocol settings and device tags.

Settings:

SNMP	436
REST	436
SNMP Configuration	436
L Location	436
L Contact	436

L Read Only Community.....	436
L Read&Write Community.....	437
User Settings.....	437

SNMP

Enables the SNMP agent and selects the supported SNMP version to communicate with the service.

The setting is reset by a factory preset to "v1/v2c".

"Off"	The SNMP agent is disabled.
"v1/v2c"	Selects SNMP version 2, which also enables version v1.
"v1/v2c/v3"	Selects all SNMP version v1, v2c and v3.
"v3"	Selects SNMP version v3.

Remote command:

[SYSTem:COMMUnicate:SNMP:VERSion](#) on page 522

REST

Enables the REST API protocol.

The setting is reset by a factory preset to "On".

Remote command:

[SYSTem:COMMUnicate:REST:ENABLe](#) on page 520

SNMP Configuration

For SNMPv1 and SNMPv2c authentication, you can assign a community password for read only and/or read and write access. For SNMPv3 authentication, you can define "User" profiles.

Location ← SNMP Configuration

Defines the SNMP location information. This information complies with the server's physical location and is used for identification of the SNMP server. By default, this input field is empty.

Remote command:

[SYSTem:COMMUnicate:SNMP:LOCation](#) on page 521

Contact ← SNMP Configuration

Sets the SNMP contact information. This information complies with the person who manages the SNMP server and is used for identification of the SNMP server. By default, this input field is empty.

Remote command:

[SYSTem:COMMUnicate:SNMP:CONtact](#) on page 521

Read Only Community ← SNMP Configuration

Sets a password for read only access of SNMPv1 or SNMPv2 communities.

The setting is reset by a factory preset to the "<serial number>" of the instrument.

Remote command:

[SYSTem:COMMUnicate:SNMP:COMMunity:RO](#) on page 520

Read&Write Community ← SNMP Configuration

Sets a password for read and write access of SNMPv1 or SNMPv2 communities.
The setting is reset by a factory preset to the "<serial number>" of the instrument.

Remote command:
[SYSTem:COMMunicate:SNMP:COMMunity:RW](#) on page 520

User Settings


Accesses the "Configure SNMP Users for HUMS" dialog.

14.5.9.2 SNMP user settings

For SNMPv3 authentication, you can define user profiles.

Access:

- 1. Select "System Config > Remote Access > HUMS".
- 2. Select "State > ON".
- 3. Select "Enhanced Settings".
- 4. In the protocol tab, select SNMP communication with SNMPv3, e.g. "SNMP > v1/v2c/v3".
- 5. Select "User Settings".



The "Configure SNMP User for HUMS" dialog provides an overview of all defined SNMP users and their profiles. With the "Add" and "Delete All" controls, you can add or remove users.

Settings:

Add	438
Delete All	438
User table	438
L Edit	438
L Name	439
L Prefix	439

L Level.....	439
L Delete.....	439
Add SNMP User for HUMS.....	439
L SNMP User Name.....	440
L SNMP User Prefix.....	440
L SNMP User Level.....	440
L SNMP User Public Passphrase.....	441
L SNMP User Encrypted Passphrase.....	441
L Add / Update.....	441

Add

Accesses the "Add SNMP User for HUMS" dialog.

In this dialog, you can define a user and its profile, see ["Add SNMP User for HUMS"](#) on page 439.

Delete All

Removes all users from the list.

Remote command:

[SYSTem:COMMunicate:SNMP:USM:USER:DELeTe:ALL](#) on page 522

User table

Lists all defined SNMP users.

SNMP User Settings				
+ Add ...		X Delete All		
Edit	Name	Prefix	Level	Delete
	user1	Read Only	No Authentication & No Privacy	
	user2	Read & Write	Authentication & No Privacy	
	user3	Read & Write	Authentication & Privacy	

The table informs on the user name and its specified user profile.

Remote command:

[SYSTem:COMMunicate:SNMP:USM:USER:ALL?](#) on page 522

Edit ← User table

Accesses the "Edit SNMP Users for HUMS" dialog, where you can modify an already defined user profile.

Edit SNMP User

Name: user1

Prefix: Read Only

Level: No Authentication & No Privacy

Public Passphrase: [Empty]

Encrypted Passphrase: [Empty]

Update

For description on the entry fields, see [Add SNMP User for HUMS](#).

Name ← User table

Shows the user name of the user who should have specific user rights.

Prefix ← User table

Shows the access right of the selected user.

Level ← User table

Shows the security level of the selected user.

Delete ← User table

Removes the selected user from the list.

Remote command:

[SYSTem:COMMunicate:SNMP:USM:USER:DELeTe](#) on page 522

Add SNMP User for HUMS

Configuration dialog for defining SNMP users and their profiles.

Remote command:

[SYSTem:COMMunicate:SNMP:USM:USER](#) on page 521

SNMP User Name ← Add SNMP User for HUMS

Defines the name of the user for assigning specific user rights. Entering a user name is mandatory.

SNMP User Prefix ← Add SNMP User for HUMS

Defines the access right for a user.

"Read Only" Allows the user to only read information.

"Read & Write" Allows the user to read and modify information.

SNMP User Level ← Add SNMP User for HUMS

Defines the security level of the SNMP user. Depending on the security level, the service requests user name and passphrases for authentication and encryption.

"No Authentication & No Privacy"

Low security level. Using this level, the service queries the user name only. Password authentication and password for encrypted data transfer is not requested.

See ["SNMP User Public Passphrase"](#) on page 441 and ["SNMP User Encrypted Passphrase"](#) on page 441 for data transfer is not requested.

"Authentication & No Privacy"

Medium security level: Requests the user name and password authentication, but no data transfer encryption.

"Authentication & Privacy"

High security level: Requests the user name, and both, the password authentication and the password for data transfer encryption.

SNMP User Public Passphrase ← Add SNMP User for HUMS

Defines the password for authentication. The password must have of 8 to 12 characters with any combination of ASCII characters.

SNMP User Encrypted Passphrase ← Add SNMP User for HUMS

Defines the password for encryption. This password must have at least 8 characters with any combination of ASCII characters. When encryption is defined, the R&S SMA100B supports the DES (directed enhanced services) protocol.

Add / Update ← Add SNMP User for HUMS

Assigns the defined user with its profile to the list.

If you change an already defined user profile, the instrument provides the "Update" button to apply the modifications.

14.5.9.3 Device tag settings

The "Device Tags" tab of the "Enhanced HUMS Settings" dialogs displays the defined device tags. You can also add or delete device tags here.

A device tag is a label to assign to your instrument. You can create any device tag for your instrument and define it by a specific key and value.

Access:

1. Select "System Config > Remote Access > HUMS".
2. Select "State > ON".
3. Select "Enhanced Settings".

Protocol

Device Tags

✕

ID	Key	Value	Delete
0			✕
1			✕
2			✕

+

Add

✕

Delete All

Configures device tags for tagging user-defined information of the instrument in a table. You can define up to 32 device tags, e.g., for HUMS history evaluation. To add a device tag, define "Key" and "Value" of the device tag in the table. Click "Add" to add all device tags of the table to the HUMS history.

Settings:

ID.....	442
Key.....	442
Value.....	442
Delete.....	443
Add.....	443
Delete All.....	443

ID
Identification count of a device tag entry.

Key
Sets the identification key of a device tag.
Remote command:
`DIAGnostic:HUMS:TAGS[:VALue]` on page 519

Value
Sets the value of the identification key of a device tag.
Remote command:
`DIAGnostic:HUMS:TAGS[:VALue]` on page 519

Delete

Deletes the selected device tag from the HUMS history.

Remote command:

[DIAGnostic:HUMS:TAGS:DELeTe](#) on page 519

Add

Adds a new device tag to the HUMS service.

Remote command:

[DIAGnostic:HUMS:TAGS\[:VALue\]](#) on page 519

[DIAGnostic:HUMS:TAGS:ALL?](#) on page 518

Delete All

Removes all device tags from the HUMS history.

Remote command:

[DIAGnostic:HUMS:TAGS:DELeTe:ALL](#) on page 519

14.5.10 QR code

Access:

- Select "System Config" > "Remote Access" > "QR Code".



The "QR Code" dialog shows the current instrument address (IP address) in quick response (QR) format.

This functionality provides fast access to the instrument via VNC with, for example, a smartphone or a tablet.


See [Section 14.10.2, "Using a smart device"](#), on page 479

14.6 LXI status settings

On the R&S SMA100B, an LXI functionality is already installed and enabled. Thus, you can access he instrument using any web browser.

See [Section 14.7, "LXI browser settings"](#), on page 445.

- Access:
- ▶ Select "System Config > Setup > Remote Access > LXI Status".



The LXI "LAN Status" dialog shows the parameters of the LAN connection.

Alternatively, you can change the LAN settings using the LXI web browser interface, see [Section 14.7.1, "LAN configuration"](#), on page 447.

Settings:

LAN Status	444
Hostname / MAC Address / IP Address	444
LAN Reset	445

LAN Status

The LED indicates the LXI status.

"green"	Normal operation
"green (flashing)"	Device identification
"red"	LAN fault

Hostname / MAC Address / IP Address

See ["Hostname"](#) on page 423.

LAN Reset

Initiates the network configuration reset mechanism for the instrument and resets the hostname, MAC address, and IP address.

According to the LXI standard, a LAN reset must set the following network parameters to a default state:

Parameter	Value
TCP/IP mode	DHCP + Auto IP address
Dynamic DNS	Enabled
ICMP ping	Enabled
Password for LAN configuration	LxiWebIfc

The LAN reset also resets the following parameters for the R&S SMA100B:

Parameter	
Hostname	Instrument-specific hostname
Description	Signal Generator
Negotiation	Auto detect
VXI-11 discovery	Enabled

14.7 LXI browser settings

Accessing the R&S SMA100B over the LXI browser interface, you can perform the following tasks:


- Modifying network configurations, see [Section 14.7.1, "LAN configuration"](#), on page 447.
- Accessing the instrument remotely
- Analyzing SCPI remote diagnostics
- Monitoring the use and status of the instrument
This service requires option R&S SMAB-K980 "Health and utilization monitoring service (HUMS)".

Access:

- In the address field of the browser, enter the URL address, composed of the instrument's IP address or host name, for example *http://10.113.1.151*.

Note: Do not add the missing zeros in the IP address, while opening the instrument homepage.

The instrument homepage (welcome page) opens.



The navigation pane of the browser interface contains the following elements:

- "LXI"
 - "Home" opens the instrument homepage.
The homepage displays the device information required by the LXI standard, including the VISA resource string in read-only format.
 - "Device Indicator" activates or deactivates the LXI status indication.
When activated, the LXI LED flashes. A green LXI status symbol indicates that a LAN connection has been established; a red symbol indicates that no LAN cable is connected.
 - "Lan Configuration" allows you to configure LAN parameters and to initiate a ping, see [Section 14.7.1.3, "Ping client"](#), on page 449.
 - "Status" displays information about the LXI status of the instrument.
 - "Utilities" provides access to the LXI event logging functionality required by the LXI standard.
- "Instrument Control"
 - "Web Control" provides remote access to the instrument.
See ["To start remote control with the LXI browser"](#) on page 456.
- "Diagnostics"
 - "SCPI Remote Trace" records messages exchanged via the remote control interface, see [Section 14.7.2, "SCPI remote trace"](#), on page 449.
 - "Health & Utilization" (option: R&S SMAB-K980) enables you to monitor the use and status of an instrument, see [Section 14.7.3, "Health and utilization"](#), on page 451.
- "Datasheet"
 - Provides the Datasheet with the specification data of the instrument at the time of delivery, see [Section 14.7.4, "Datasheet"](#), on page 451.
- "Help"
 - "Glossary" explains terms related to the LXI standard.
 - www.rohde-schwarz.com opens the Rohde & Schwarz homepage.

14.7.1 LAN configuration

The "LAN Configuration" web page displays all mandatory LAN parameters and allows their modification.

It comprises the following navigation entries.

- [IP configuration](#).....447
- [Advanced config](#).....448
- [Ping client](#).....449

14.7.1.1 IP configuration

The "IP configuration" web page displays all mandatory LAN parameters and allows their modification.

The screenshot shows the 'LAN Parameters' configuration page in the LXI browser. The left sidebar contains navigation links: Home, Lan Configuration (selected), IP Configuration, Advanced Config, Ping Client, Status, Utilities, Instrument Control, Web Control, Diagnostics, SCPI Remote Trace, Health & Utilization, Datasheet, Production Version, and Help. The main content area is titled 'LAN Parameters' and contains the following fields:

- Hostname: <host name>
- DNS Hostname(s): <host name.xxx.net>
- Domain: rsint.net
- Description: <instrument>
- IP Address Mode: DHCP + Auto IP Address (dropdown)
- IP Address: 10.102.189.51
- Subnet Mask: 255.255.252.0
- Default Gateway: 10.102.188.1
- Obtain DNS Server Address automatically: ☒
- DNS Server(s): 10.0.2.166
- Register Device at DNS Server dynamically: ☐
- HiSLIP Port: 4880

A 'Submit' button is located below the HiSLIP Port field. A note on the right states: 'Attention! Changing the hostname reboots the device!'. At the bottom, a 'Status' bar shows 'No error'.

The "IP Address Mode" selects a configuration mode for the IP address of the instrument. With static configuration, the entered IP address, subnet mask, and default gateway are used. With dynamic configuration, DHCP or dynamic link local addressing (automatic IP) is used to obtain the instrument IP address.



Changing the LAN configuration

This function is password-protected. Unlock the protection level 1 to access it.

Note: We recommend that you change the default password before connecting the instrument to a network.

How to:

- ["To change the user password of the instrument"](#) on page 402.
- ["To change the security password"](#) on page 402.

See [Section 13.4.5, "Password management"](#), on page 399.

14.7.1.2 Advanced config

The "Advanced Config" web page provides LAN settings that are not declared mandatory by the LXI standard.

The following advanced parameters are available:

- "mDNS and DNS-SD": The additional protocols "multicast DNS" and "DNS service discovery" are used for device communication in zero configuration networks, working without DNS and DHCP.
- "ICMP Ping": Must be enabled to use the ping utility.
If you disable this setting, the instrument does not answer ping requests. The setting does not affect the LXI ping client. You can ping other hosts from the instrument, even if the setting is disabled.
- "VXI-11 Discovery": Must be enabled to detect the instrument in the LAN.
If you disable this setting, the instrument cannot be detected by the VXI-11 discovery protocol mechanism. The setting does not affect other detection mechanisms. Setting up a VXI-11 connection via the IP address or the host name is independent of this setting.



Changing the LAN configuration

This function is password-protected. Unlock the protection level 1 to access it.

Note: We recommend that you change the default password before connecting the instrument to a network.

How to:

- ["To change the user password of the instrument"](#) on page 402.
- ["To change the security password"](#) on page 402.

See [Section 13.4.5, "Password management"](#), on page 399.

14.7.1.3 Ping client

The "Ping Client" page provides the ping utility to verify the connection between the LXI-compliant instrument and another device.

The ping is initiated from the instrument. Using the `ICMP` echo request and echo reply packets, this function checks whether the communication with a device via LAN is working. Ping is useful for the diagnosis of IP network or router failures.

To initiate a ping at the instrument:

1. On the "Ping Client" page, enter the IP address of the host in the "Destination Address" field (for example 10.113.1.151).
2. Select "Submit".

The screenshot shows the LXI browser interface for the 'Ping Client' utility. On the left is a navigation menu with options like Home, Lan Configuration, IP Configuration, Advanced Config, Ping Client, Status, Utilities, Instrument Control, Web Control, Diagnostics, SCPI Remote Trace, Health & Utilization, Datasheet, Production Version, Help, Glossary, and www.rohde-schwarz.com. The main area is titled 'Ping Parameter' and contains a 'Destination Address' input field with the value '10.102.189.51' and 'Clear' and 'Submit' buttons. Below this, the 'Result' section displays the following text:

```
PING <host name> (10.102.189.51): 56 data bytes
64 bytes from 10.102.189.51: seq=0 ttl=64 time=0.040 ms

--- <host name> ping statistics ---
1 packets transmitted, 1 packets received, 0% packet loss
round-trip min/avg/max = 0.040/0.040/0.040 ms
```

At the bottom, the 'Status' section indicates 'No error'. A copyright notice '© 2022 ROHDE & SCHWARZ. All rights reserved.' is visible in the footer.


14.7.2 SCPI remote trace

The remote trace functionality allows you to trace input and output strings at the remote control interface of the R&S SMA100B.

See ["To activate SCPI remote trace"](#) on page 457


A recorded trace (message log) can be evaluated directly in the dialog. Use the highlighting and navigation functions provided by the lower toolbar to locate error messages and messages containing arbitrary search strings. You can also export the message log to a `*.CSV` file and evaluate the file using a suitable program.

To trace and display messages, switch on "logging" and "live mode" in the toolbar.



Toolbars

The toolbar at the top of the dialog provides basic settings and functions.



- "Live mode" / "logging": If logging is switched on, messages are traced. They are stored in an internal database and can be displayed upon request, using the refresh button (live mode off) or they can be displayed automatically (live mode on).
- "Filter": applies a filter to columns and/or rows when working (live mode off)
- "Refresh": reads the message log from the internal database and displays it
- "Download": stores the SCPI trace log to a *.csv file
- "Clear": deletes all message log entries in the database and at the screen
- "Details": displays details of the selected message, for example an SCPI command in hex format (also possible by double-clicking a message)

Columns

The following columns are available if no column filter is applied:

- "Rec": record number of the message within the message log
- "MT": indicates the type of the message. Possible values and related message contents are:
 - > = incoming command
 - < = outgoing response to a query
 - E = error message, highlighted by red color
 - T = execution time, i.e. time required by the instrument to process the command internally.
- I: number of the subinstrument

- "message": indicates the type of the message. Possible values and related message contents are:
 - > = incoming command
 - < = outgoing response to a query
 - E = error message, denoted in red
 - T = execution time, i.e. time required by the instrument to process the command internally

14.7.3 Health and utilization

Option: R&S SMAB-K980

The health and utilization monitoring service allows you to monitor the usage and status of the instrument, its options, including S.M.A.R.T. data of the system drive. You can retrieve information on remote accesses over SCPI commands, web browsers or protocols, as for example SNMP or REST.


For detailed information on R&S HUMS, see the following documents, available on the Rohde & Schwarz website:

- User manual "R&S Health and Utilization Monitoring Service" , describing how to access and use the service.
- Application note [GFM336](#), providing information on the SNMP and REST API, including a list of all SNMP variables and REST endpoints.

14.7.4 Datasheet

The datasheet functionality allows you to retrieve the specification data of the instrument at the time of delivery.

The document contains all specified value ranges and information of the datasheet, for example important as reference values for recalibration.



For more information, refer to the specifications document.

14.8 Setting up remote control

When you switch on the R&S SMA100B, it is always in manual operation state ("local" state). You can operate the instrument over the touchscreen, the front panel and an external keyboard and/or mouse.

Prerequisites

For remote control, make sure that you have fulfilled the following prerequisites:

- The instrument and the controller PC are connected for remote control.
See [Section 3.1.7, "Connecting to LAN"](#), on page 27.
- The instrument and the controller are switched on.
- The LAN interface and SCPI over LAN are enabled.
See [Section 13.4.4, "Configuring LAN services"](#), on page 395.
- A remote control program is running on the controller.



If security is a concern, see:

- Document Instrument Security Procedures.
- [Section 13.4.6, "Preventing unauthorized access"](#), on page 402.

The following sections describe how to start remote control over the available interface protocols.

- [Configuring remote access](#)..... 453
- [Starting remote control with LXI](#)..... 456
- [Starting remote control with VXI-11](#)..... 457

- [Starting remote control with socket communication](#).....462
- [Starting remote control over GPIB](#).....463
- [Starting remote control over USB](#).....464
- [Stopping remote control](#).....464

14.8.1 Configuring remote access

Depending on the network capacities, the TCP/IP address information for the instrument can be obtained in different ways.

- If the network supports dynamic TCP/IP configuration using the [DHCP](#) protocol, this service assigns all address information automatically (default setting).
- If the network does not support DHCP or if there is no server available, the instrument tries to obtain the IP address using the [Zeroconf](#)(Avahi) protocol. This protocol enables the instrument to self-configure an IP address and subnet mask. Zeroconf (Avahi) IP addresses start with the number blocks 169.254.*.*, with the subnet mask of 255.255.

The automatic address configuration establishes the physical connection to the LAN without any additional configuration.



An IP address that is assigned with the Zeroconf protocol although the network requires an IP address assigned from the DHCP server can cause network connection failures.

See [Section 16.5, "Resolving network connection failures"](#), on page 823.

If both services fail to connect, you must set the address information manually.

See also ["To assign the instrument address manually"](#) on page 454.

To find the VISA resource string

- Select "System Config > Remote Access > VISA Resource Strings".

Net-work	Visa Res. Strings	GPIB Addr.	RS232	Instrument Emulations	Remote Connections	HUMS	QR-Code	✕
HISLIP								
					TCPIP::10.102.52.36::hislip0::INSTR			
VXI11								
					TCPIP::10.102.52.36::inst0::INSTR			
Socket								
					TCPIP::10.102.52.36::5025::SOCKET			
GPIB								
						GPIB::28::INSTR		
USB								
					USB::0x0AAD::0x01e1::000000::INSTR			
SERIAL								
						ASRL1::INSTR		

The dialog shows the VISA resource strings that enable you to access the instrument for remote control.

Note: Using the RS232 serial interface via USB requires the USB serial adapter R&S TS-USB1.

To assign the instrument address manually

It is assumed that you have connected the instrument in the LAN.

1. Obtain the instrument address information for the R&S SMA100B and the IP address for the local default gateway from your network administrator. If necessary, also obtain the name of your DNS domain and the IP addresses of the DNS server on your network.
Obtain the IP address and subnet mask for the R&S SMA100B and the IP address for the local default gateway from your network administrator. If necessary, also obtain the name of your DNS domain and the IP addresses of the DNS server on your network.
2. On the instrument, select "System Config > Remote Access > Network".
3. Select "Address Mode > Static".
4. Select the "IP Address".
5. Enter the IP address, for example *192.168.0.1*.
The IP address consists of four number blocks separated by dots. Each block contains 3 numbers in maximum.
6. Select the "Subnet Mask" and enter the subnet mask, for example *255.255.255.0*.
Note: The subnet mask must be the same for both, the R&S SMA100B and the host interface, the instrument is connected to.
7. Enter the "Default Gateway", "DNS Suffix", and "DNS Server" if necessary.

Using the hostname

In a LAN that uses a [DNS](#) server, each computer or instrument connected in the LAN can be addressed with an unambiguous [Hostname](#) (also referred to as computer name) instead of the IP address. The DNS server translates the hostname to the IP address.



Using the hostname is useful in networks with dynamic TCP/IP and DHCP protocol services, that assign the address information automatically. Thus, it can be that the services assign a new IP address each time the instruments restarts, but they do not change the hostname.

Each instrument is delivered with an assigned hostname, that remains constant as long as it is not explicitly changed.

This function is password-protected. Unlock the protection level 1 to access it.

The default *hostname* name follows the syntax `<INST>-<Serial Number>`, where:

- `<INST>` is the short name of your instrument, as stated on the front panel.
- `<Serial Number>` is the individual serial number of the instrument.
You can find the serial number at the rear panel of instrument. It is the third part of the device ID printed on the barcode sticker.



To query and change the hostname

1. Select "System Config > Remote Access > Network".
Section "Instrument Name" displays the assigned "Hostname".
Note: This function is password-protected. Unlock the protection level 1 to access it.
2. Select "System Config > Setup > Security > Protection".
3. Enable the "Protection Level 1".
The default protection level 1 password is 123456.
The parameter "Hostname" in the "Network" tab is now enabled for configuration.
4. Change the "Hostname".

Configuring LAN access and services

By default, the LAN interface and the supported LAN interface services are enabled. For security reasons, for example to protect the instrument against unauthorized access, you can block either the LAN services individually, or the access over LAN in general.

For information on how you configure the remote access individually, see the following sections:

- [Section 13.4.4, "Configuring LAN services"](#), on page 395
- ["To disable LAN access in general"](#) on page 403
- ["To disable LAN services individually"](#) on page 403
- ["To enable SMB version 1.0/2.0 client and server"](#) on page 404

Configuring access over GPIB

Option: R&S SMAB-B86

To control the instrument remotely over the GPIB bus, it must be addressed using the GPIB address. The remote control address is factory-set to 28, but it can be changed if it does not fit in the network environment. For remote control, addresses 0 through 30 are allowed. The GPIB address is maintained after a reset of the instrument settings.

To change the GPIB address

1. Select "System Config" > "Remote Access" > "GPIB Address".
2. Select "GPIB Channel Address" and enter a value between 0 and 30.



Risk of losing remote connection

If the remote access and network settings had been configured to values different to the default, executing a factory preset via remote control terminates the connection to the instrument.

14.8.2 Starting remote control with LXI

Using the LXI browser interface you can access and control the R&S SMA100B instrument remotely from a controller PC without additional installation. Remote control over LXI supports file upload and download between the instrument and the controller PC.

It is assumed that the instrument is set up in the LAN.

See ["Prerequisites"](#) on page 452.

To start remote control with the LXI browser

1. On the controller PC, start a browser that supports HTML5 (W3C compliant).
2. Enter the IP address of the R&S SMA100B in the browser's address bar.

The browser displays the R&S SMA100B's welcome page.

3. In the navigation pane, select "Instrument Control" > "Web Control".

Remote access to the instrument requires the password. The default password is *instrument*.

4. Enter the password.

5. Confirm with [Enter].

The current screen of the R&S SMA100B appears in the browser window.

6. Use the mouse cursor and keyboard to access the functionality of the instrument as if you operate the instrument directly.

To activate SCPI remote trace

The remote trace functionality allows you to trace SCPI commands and messages exchanged over the LAN of the R&S SMA100B. To communicate with the instrument over SCPI, use a suitable remote control application.

1. Set up the remote control session as described under "[To start remote control with the LXI browser](#)" on page 456.
2. In the navigation pane, select "Diagnostics > SCPI Remote Trace".
3. In the toolbar bar of the "SCPI Remote Trace" page, select "live mode > on".
4. Using the remote control program, send your SCPI commands to the R&S SMA100B.

The "SCPI Remote Trace" tab displays all sent commands and responses.

5. Select "logging > on".
(Live mode and logging exclude each other).

"logging > on" displays all commands and responses, and traces messages also.

The SCPI remote trace function records all sent commands, received responses and messages, and saves them in an internal database. If "live mode" is disabled, you can display the recent traces on request, using the "refresh" button. You can also save the log in a file.

Note: The diagnostics functionality is extended in later releases, e.g. to download or upload SCPI command files from / to the instrument.

14.8.3 Starting remote control with VXI-11

This connection uses the I/O software library R&S VISA from Rohde & Schwarz to setup a LAN remote control link to the instrument.

R&S VISA is running on a controller PC with Windows operating system. You can send commands to the instrument and receive the responses.

For information installing, operating and the utility applications the software provides, see R&S VISA product page www.rohde-schwarz.com/rsvisa.


The remote control connection requires a VISA installation but no additional hardware on the controller PC. The LAN I/O channel is selected at initialization time using the VISA resource string (also referred to as "address string"). A VISA alias (short name) replaces the complete resource string. The host address is the R&S SMA100B's host-name or its IP address.

See [Section 14.2.1, "LAN interface"](#), on page 411.


To set up the controller with R&S VISA

To remote control the R&S SMA100B, we use the R&S VISA Tester application. The application communicates over the TCP/IP protocol.


1. On the controller PC, install the R&S VISA program.
See www.rohde-schwarz.com/rsvisa > "RS VISA release notes".
2. On the instrument, enable the LAN interface and "SCPI over LAN".
3. On the controller, start, e.g., "R&S VISA > Tester".



4. In the menu bar, select "Choose VISA Implementation > Rohde & Schwarz Visa"
5. Confirm with "OK".



6. In the menu bar, select "Find Resource" to search for the instrument in the LAN.




7. Select "VXI-11".
8. Select the "refresh" button to start the search.

R&S VISA scans the network for connected instruments and lists all detected instruments in the "Resource" list.

Note: The search can take some time, particularly in large networks.

9. Select the required instrument.




10. Confirm with "Ok".

The "Find and select resource" dialog closes and R&S VISA indicates the IP address in the "Resource" field of the main application window.


11. As an alternative to the IP address, you can assign an alias name to the R&S SMA100B:

- a) In the menu bar, select "RsVisaConfig".




- b) In the toolbar, select "+" to access the "VISA Resource String Composer".

- c) Fill in the "Alias" name, the "VISA Resource String" and the "Device IP Address or hostname" as shown in the figure.



R&S VISA indicates the assigned "Alias" name.



- d) Confirm with "OK".

R&S VISA identifies the R&S SMA100B and you can address it either with the resource string or the alias name.

12. In the main window, select "Connect".

R&S VISA establishes the connection to the R&S SMA100B.

You can send settings to configure the instrument and receive its responses.

Note: If the connection cannot be set up, R&S VISA displays an error in the log view.

See also [Section 16.5, "Resolving network connection failures"](#), on page 823.

To start remote control with R&S VISA


To set the instrument to remote control state, you can send any command from the controller.

1. Start the R&S VISA Tester.
Establish the connection to the R&S SMA100B.
See ["To set up the controller with R&S VISA"](#) on page 458.
2. In the R&S VISA "Basics" tab, enter a SCPI command, e.g. *IDN?.

3. Confirm with "Query".

The instrument switches to remote control when it receives a command from the controller.

4. Select "Read" to obtain the instrument response.



The instrument returns the response.

Remote control over R&S VISA is enabled.

To check remote control with VISA

You can check the communication by sending a setting command and querying the response:

1. Set, e.g. the frequency with the command:
SOUR1:FREQ 3 GHz.
2. Select "Write".
3. Enter the command SOUR:FREQ?.
4. Select "Query".

If the R&S SMA100B responds with the frequency value you entered, remote control works properly.

To monitor the remote control operation

1. Check the "Show Log" checkbox on the top right.
R&S VISA displays each VISA operation in the log-view on the left.
2. Check the "Write Log" checkbox.

R&S VISA saves all log-view entries to a log file.

You can operate the log-view in two modes:

- "Live Mode": shows only the most recent messages
- "View Mode" allows you to scroll the history

To return to manual operation, see [Section 14.8.7, "Stopping remote control"](#), on page 464.

14.8.4 Starting remote control with socket communication

This section provides an example on how to establish a remote control connection over Telnet client and a simple sockets-based program example that can be further developed.



The telnet client transmits information unencrypted. Therefore, for sensitive information we recommend that you use a client which supports secure protocols, like SSH.

To set up a Telnet connection

To control the software, only a Telnet program is required. The Telnet program is part of each operating system.

The controller PC and the instrument are connected in the same network.


1. On the instrument, enable the LAN interface and "SCPI over LAN".
See [Section 13.4.4, "Configuring LAN services"](#), on page 395.

2. On the controller PC, start the Telnet program.


3. Enter the socket address.

The socket address is a combination of the IP address or the hostname of the R&S SMA100B and the number of the port configured for remote-control via Telnet.


Tip: The R&S SMA100B uses the port number 5025 for remote connection via Telnet.



The connection to the instrument is set up and you can send remote-control commands.



4. Telnet does not reflect your first entry.
Insert a command, e.g. `*IDN` and confirm with "Enter".
5. Observe the screen.
A response on the query confirms that the connection is working. The client displays all subsequent inputs and responses.
6. Even if the cursor is not visible on the screen, just enter a remote-control command. Confirm with Enter.



14.8.5 Starting remote control over GPIB

The program example in this section is written in VISUAL BASIC. A condition for programming in VISUAL BASIC is that the modules NIGLOBAL (`Niglobal.bas`) and VBIB32 (`Vbib_32.bas`) are added to the projects.



Drivers for instrument, for example IVI-COM and LabVIEW drivers, are available for download area on the product page at:

<https://www.rohde-schwarz.com/driver/sma100b/>

To start remote control over GPIB

1. Connect instrument and controller using a GPIB cable.
Switch them on.
2. Select "System Config > Remote Access > GPIB Address" > **"GPIB Channel Address = 28"**.
The GPIB address of the instrument must be the default value of 28.

3. Execute the following commands on the controller:

- a) Open the port to the instrument.
`CALL IBFIND("DEV1", generator%)`
- b) Inform the controller about instrument address.
`CALL IBPAD(generator%, 28)`
- c) Reset the instrument.
`CALL IBWRT(generator%, "*RST;*CLS")`
- d) Set the instrument to new address.
`CALL IBWRT(generator%, "SYST:COMM:PIB:ADDR 18")`
- e) Inform the controller about new address.
`CALL IBPAD(generator%, 18)`

The GPIB address of the instrument is changed.

4. To return to manual operation, see [Section 14.8.7, "Stopping remote control"](#), on page 464.

14.8.6 Starting remote control over USB

For remote control, the PC and the instrument must be connected over the USB type B interface. A USB connection requires the VISA library to be installed. VISA detects and configures the R&S instrument automatically when the USB connection is established. You do not have to enter an address string or install a separate driver.

To start remote control over USB

1. Connect instrument and controller using USB cable. Switch them on.
2. Execute the following commands on the controller:
 - a) Open the port to the instrument.
`viOpen (... , "USB::0x0AAD::0x01DD::100001::INSTR", ...)`
 - b) Reset the instrument.
`viRST (generator%, "*RST;*CLS")`
 - c) Set 2 GHz frequency
`viPrintf (... , "SOUR:FREQ 2GHz\n")`
 - d) Set 20 dBm output level
`viPrintf (... , "SOUR:POW -20dBm\n")`

The RF frequency and signal level of the instrument are changed.

3. To return to manual operation, see [Section 14.8.7, "Stopping remote control"](#), on page 464.

14.8.7 Stopping remote control




Before returning to manual control, command processing must be completed. Otherwise, the instrument switches back to remote control immediately.

You have the following options to switch from remote control to manual operation:

- Closing the remote control session
- Using remote control commands
- Selecting the remote icon in the status bar directly on the screen
- Using the "Local" key

To find out active remote connections

- Check the indication on the taskbar:



A softkey in the taskbar indicates if and what kind of remote connections are currently set up.

See also [Section 14.5.6, "Active remote connection settings"](#), on page 430

To return to manual operation

Depending on the used remote control state, the transition from remote control to manual operation requires different actions.

- Select the corresponding transition action as shown in the table.

Table 14-6: Remote control status icons

GUI symbol	Transition to remote control state...	Remote control state characteristics	Transition to manual operation...(local state)
 	>R (controller PC)	Remote control, but usable front panel keys. The parameters are in read-only mode. The green arrows indicate a currently performed setting.	• &GTL (SCPI) If &NREN has been set before &GTL is locked. Use &GTR instead. • CALL IBLOC (generator%), (visual basic). • viGpibControlREN() (VISA function) • "Remote" icon in the status bar • [Local] (front panel or key emulation) The setting must be completed (white arrows) before you can return to manual operation.
	&LLO (controller)	Remote control with locked front panel keys to prevent user interaction. The parameters are in read-only mode. You can unlock LLO, and thus return to manual operation only over remote control commands.	• &LOCS • &REMS Changes from "Remote LLO" to "Remote" state. • CALL IBLOC (generator%) • viGpibControlREN()

14.9 Using remote command scripts

To configure a test setup quickly, or to make complex test setups or repeating measurements reproducible, you can automate the required settings with remote command scripts. A remote command script contains a sequence of SCPIs which configure the corresponding settings. When created, it is converted to an executable format, saved in a file and can be run whenever needed.

The graph shows the main steps required to create and execute a SCPI script.




Figure 14-7: Steps for performing SCPI Scripts


- [SCPI recording settings](#)..... 466
- [Creating remote command lists](#)..... 470
- [Checking and verifying a remote command list](#)..... 473
- [Converting a remote command list to a script](#)..... 474
- [Running a remote command script](#)..... 476

14.9.1 SCPI recording settings

The R&S SMA100B provides information on the required SCPI command for the available measurement settings, functions, and results in the context-sensitive menu.

Access:

1. Select a parameter.
2. Open the context-sensitive menu (tap and hold).



The context-sensitive menu provides the SCPI recording functions to help you create your script.

- [Show SCPI command settings](#).....467
- [SCPI recording list settings](#).....467
- [SCPI recording export settings](#)..... 468

14.9.1.1 Show SCPI command settings

Access:

1. Select the parameter.
2. Open the context-sensitive menu.
3. Select "Show SCPI Command".

This function provides the syntax of the remote command with the current setting.

Settings:

- [Copy](#).....467
- [Close](#).....467

Copy

Copies the command and the current setting.


Close

Exits the "SCPI Command" dialog.

14.9.1.2 SCPI recording list settings

Access:

1. Select a parameter.
2. Open the context-sensitive menu.
3. Select "Show SCPI Recording List".



The "SCPI Recording List" shows the recorded commands.

Settings:

SCPI Recording List	468
Remove All	468
Remove First	468
Remove Last	468
Export	468

SCPI Recording List

Lists the automatically or manually recorded SCPI commands.

Remove All

Deletes all entries in the SCPI command list.

Remove First

Deletes the first entry in the SCPI command list.

Remove Last

Deletes the last entry in the SCPI command list.

Export

Opens the "SCPI Recording Export" dialog for configuring the file parameters for the SCPI command script file.

See [Section 14.9.1.3, "SCPI recording export settings"](#), on page 468.


14.9.1.3 SCPI recording export settings

The R&S SMA100B displays recorded remote command lists in the "SCPI Recording Export" dialog. This dialog opens automatically, when you stop recording. To open the dialog manually, proceed as described.

Access:

1. Select a parameter.
2. Open the context-sensitive menu.
3. Select "Show SCPI Recording List".

4. Select "Export".



The "SCPI Recording Export" dialog contains all functions required for export of command lists to a file. It enables you to select the source code format, assign an individual filename and display the file content.

Settings:

Format	469
Code Template	469
File	469
Export	470
Reload	470
File content	470

Format

Selects the source code format for the command list.

"Plain SCPI" Uses SCPI syntax.

"Predefined Code Generator"

Accesses the predefined templates for common source code generators that convert the recorded settings in the programming languages MATLAB or NICVI or Python.

"User Code Generator"

Use this setting to convert a script by a user-specific code generator.

Code Template

Opens a standard file handling dialog for saving or loading predefined or user-defined code templates.

See [Section 12.6.1, "File select settings"](#), on page 346.

File

Opens a standard file handling dialog for selecting the directory and file name for the output file.

See [Section 12.6.1, "File select settings"](#), on page 346.

Export

Saves the remote command list file in the selected directory.

Reload

Reloads a remote command list file.

File content

Displays the content of the remote command list in the selected format and code template.

14.9.2 Creating remote command lists

Using the SCPI recorder functions, you can create a SCPI command list directly on the instrument and then export the list for use on the controller PC. You can also edit or write a script manually, using a suitable editor on the controller. For manual creation, you can retrieve the command corresponding to a setting directly on the instrument.

You can create a SCPI list directly on the instrument at any time of operation, in the following ways:

- Recording settings automatically
The "Start SCPI Recording" function adds the SCPI command of each step that you perform to the SCPI list. You can start, stop and resume automatic recording, and also add individual commands manually.
See ["To record settings automatically"](#) on page 471.
- Recording settings manually
The "Add SCPI Command to Recording List" function adds the SCPI command and settings value of an individual step to the SCPI list.
See ["To record settings manually"](#) on page 471.
- Generating a SCPI command list of all settings in one step
Adds the SCPI commands of the current instrument settings in one step in a SCPI list.
See ["To generate a SCPI command list of all settings in one step"](#) on page 472.
Note: This function lists all commands in alphabetical order, in contrast to the recording or manual creation, which consider the order the settings are configured. If a setting cannot be set by a SCPI command, *no SCPI command found* is entered instead of a command when generate all settings at once.
Using this function can slow down the performance or cause errors during execution.
Therefore, always check and revise a script if necessary.
See ["To display a remote command list"](#) on page 473 and ["To review a remote command list"](#) on page 473.
- Copying and pasting individual SCPI commands manually
"Show SCPI command" enables you to copy the SCPI command and the current setting and paste it into any suitable editor.
See ["To copy and paste SCPI commands"](#) on page 471.

To record settings automatically

1. On the screen, open the context-sensitive menu.
2. Select "Start SCPI recording".



The R&S SMA100B now records all steps you take.

3. To stop SCPI recording, select "Stop SCPI recording" in the context-sensitive menu.



The "SCPI Recording List" dialog opens.

4. Proceed with ["To review a remote command list"](#) on page 473.

To record settings manually

1. Select the parameter or function.
2. Set the parameter.
3. Open the context-sensitive menu.
4. Select "Add SCPI Command to Recording List".



The R&S SMA100B adds the SCPI command of the setting including the value in a temporary SCPI command list.

Tip: "Context-Sensitive > Show SCPI Recording List" opens the dialog with the recorded settings.



5. Continue with the next setting accordingly whenever you want to record it.
6. Proceed with ["To review a remote command list"](#) on page 473.

To copy and paste SCPI commands

1. On the instrument, select the parameter or function.
2. Set the parameter.
3. Open the context-sensitive menu.
4. Select "Show SCPI Command".



Show SCPI Command

The R&S SMA100B displays the syntax and the setting value of the SCPI command.

With the "Copy" function, you can copy and paste the SCPI command and setting value, e.g., in a command script on a PC.


To generate a SCPI command list of all settings in one step

Using the save/recall function, you can create a SCPI command list for all settings in one step.

1. Press the [Save/Recall] key.

The instrument opens the standard "Save/Recall" dialog.

2. Select "Operating mode" > "SCPI Export".



The dialog adjusts the entry fields for configuring the command list file. "Show SCPI List" provides access to the list of all settings the instrument has recorded.

3. Select the "/var/user" directory in which you want to save the SCPI command list.
4. In the "Format" entry field, select the source code format.
5. Enter a filename.
6. Select "Export".

The R&S SMA100B saves the SCPI command list as *.txt file.

Note: Exporting the SCPI list of the instrument state in one step usually requires postprocessing on an external PC, as this function lists all instrument states and commands in alphabetical order.

In contrast, recording or manual creation of a SCPI command list considers the order the settings are configured.

14.9.3 Checking and verifying a remote command list

Before converting a command list to an executable script, we recommend that you check if the entries are correct and complete. It can be that ...

- a parameter has not assigned a SCPI command or an element of the user interface has not an assigned parameter. In these cases, `:SYST:INF:SCPI 'SCPI command not available'` is entered in the list instead.
Such entries are also detected during execution. The instrument recognizes these incomplete commands and displays notification.
- a preset has been executed, but several standards then perform some internal settings that are also assigned to the list with "SCPI Export".
- after a preset some settings are still defined, which are then written to the list generated with "SCPI Export."

To display a remote command list

On the instrument, you have different options to access a remote command list.

1. During automatic or manual recording:
 - a) Open the context-sensitive menu.
 - b) Select "Show SCPI Recording List".
2. At the end of automatic recording:
 - a) Open the context-sensitive menu.
 - b) Select "Stop SCPI Recording".
3. After exporting a command list to a file.
 - a) Select "SCPI Recording Export" > "Show file content".

The "SCPI Recording List" opens.

To review a remote command list

To rework a remote command list, you must transfer it to a computer.

1. Export the list to a PC, using, for example, a USB flash drive.
2. Check the list, e.g. by comparing it with the modified settings in the manual mode.
Tip: To find out your settings, you can use the "Mark all parameters changed from preset" function.
See [Section 12.3.2, "Identifying parameters with non-default values"](#), on page 338.
3. Search for missing or incomplete command entries.
 - a) Add missing commands.

- b) Complete missing parts of commands.
 - c) Remove superfluous entries, e.g. `:SYST:INF:SCPI 'SCPI command not available'`.
 - d) Remove unnecessary content written after a preset.
4. Rearrange the commands to a reasonable order. For example, if you set a `STATE` command to the last position in a list, you can avoid intermediate calculations of the signal.

14.9.4 Converting a remote command list to a script

For conversion of a remote command list into an executable script, a code generator translates the commands into the source code of a proprietary programming language, based on a code template. Therefore, each programming language requires a dedicated code template.

The R&S SMA100B provides the following predefined code templates by default:

- Plain SCPI
Represents SCPI base format, that is ASCII format, saved as text file (*.txt).
- MATLAB
A programming environment, frequently used in signal processing and test and measurement applications (*.m).
You can directly use this format with MATLAB(c) Toolkit. For comprehensive information on this topic, refer to the application note [1GP60](#).
- NICVI
An ANSI C programming environment designed for measurements and tests (*.c).
You can directly use this format with National Instruments LabWindows CVI.
- Python3
A general-purpose and high-level programming language (*.py).

You can also convert a script to a user-specific format. In this case, you need a code template with the extension *.expcodetmpl.

When converted, you can save the script in a file with the extension corresponding to the programming language.

To configure a plain SCPI script file

1. Select "Show SCPI Recording List" in the context-sensitive menu.
2. Select "Export".
The "SCPI Recording Export" dialog opens.
3. Select the "Format" > "Plain SCPI".
4. Select "File".
A standard file handling dialog opens.
5. Configure filename and directory and confirm with "Ok".
6. In the "SCPI Recording Export" dialog, select "Export".

The R&S SMA100B saves the recorded data in *.txt format. The "File Content" section shows the SCPI commands of the script file.

To convert the command list to a predefined code template

1. Select "Show SCPI Recording List" in the context-sensitive menu.
2. Select "Export".
The "SCPI Recording Export" dialog opens.
3. In the "SCPI Recording Export" dialog, select "Format" > "Predefined Code Generator".
The "CodeTemplate" button appears.
4. Select "Code Template".
The "SCPI Recording Export - Select Predefined Code Template" dialog opens.
5. Select a predefined code template, e.g., "MATLAB".
6. Confirm with "Select".
The R&S SMA100B returns to the "SCPI Recording Export" dialog.
7. Select "File".
A standard file handling dialog opens.
8. Configure filename and directory and confirm with "Ok".
9. In the "SCPI Recording Export" dialog, select "Export".
The R&S SMA100B saves the recorded data in the corresponding format. The "File Content" section shows the content of the script file in the corresponding programming language.

To convert the command list to a user-defined code template

Before creating a script in a user-specific format, make sure that you have saved the code template with the file extension *.expcodetmpl in the instrument.

1. Select "Show SCPI Recording List" in the context-sensitive menu.
2. In the "SCPI Recording Export" dialog, select "Format" > "Use Code Generator".
The "CodeTemplate" button appears.
3. Select "Code Template".
The "SCPI Recording Export - Select User Code Template" dialog opens.
4. Select your user-defined code template.
5. Confirm with "Select".
The R&S SMA100B returns to the "SCPI Recording Export" dialog.
6. Select "File".
A standard file handling dialog opens.
7. Configure filename and directory and confirm with "Ok".

8. In the "SCPI Recording Export" dialog, select "Export".

The R&S SMA100B saves the recorded data in the corresponding format. The "File Content" section shows the content of the script file in the corresponding programming language.

14.9.5 Running a remote command script

An executable script automates measurement tasks on the instrument. Usually controlled by a remote PC, you can also save and run a script directly in the instrument by assigning the script to the [★ (User)] key.

See [Section 13.2.2, "How to assign actions to the \[★ \(User\)\] key"](#), on page 376.

14.10 Setting up remote operation over VNC

VNC accesses the R&S SMA100B over LAN from a remote device using a web browser or a VNC client. With the screen displayed on the controller, you can control the instrument as if you operate it directly. Establishing the access depends on the used remote device and VNC client software.

See [Section 14.1, "Overview of remote access modes"](#), on page 409.

The following examples describe how to set up remote operation with remote devices:

- Using a controller PC
 - ["To operate the instrument from a web browser over VNC"](#) on page 477
 - ["To operate the instrument from a Linux/Unix client over VNC"](#) on page 478
 - ["To operate the instrument from a Windows client over VNC"](#) on page 478
- Using a smart device
 - ["To operate the instrument using a VNC App on a smart device"](#) on page 481
 - ["To operate the instrument from a web browser over VNC"](#) on page 477
 - ["To access the instrument with QR code on a smart device"](#) on page 481

To enable VNC service on the R&S SMA100B

1. **NOTICE!** Enabled VNC service can lead to unauthorized access.
Change the computer name and password of the instrument.
See [Section 13.4.6, "Preventing unauthorized access"](#), on page 402.
2. Select "System Config > Setup > Security > Security".
3. Select "LAN Services > Common Services".
4. Enable "VNC".
5. Enter the [Security Password](#).
6. Confirm with "Accept".

• Using a controller PC	477
• Using a smart device	479
• Stopping remote operation	482

14.10.1 Using a controller PC

Prerequisites

For remote operation, make sure that you have fulfilled the following prerequisites:

- The instrument and the controller PC are connected in the same network.
See [Section 3.1.7, "Connecting to LAN"](#), on page 27.
- The instrument and the controller are switched on.
- The LAN interface and VNC LAN service is enabled.
See [Section 13.4.4, "Configuring LAN services"](#), on page 395.
- A suitable application is running on the remote device.
 - Web browser
The R&S SMA100B supports remote operation over VNC with any web browser, e.g., Windows Internet Explorer, Mozilla Firefox, or an HTML5 web browser.
 - VNC client software
The software application provides remote operation of the R&S SMA100B.



VNC client software

Linux/Unix operating systems include a VNC client software by default.

For remote devices with windows operating system a VNC client software must be installed manually. Various free-of charge programs such as Ultr@VNC or similar VNC client programs are available for download on the Internet.



If security is a concern, see:

- Document Instrument Security Procedures.
- [Section 13.4.6, "Preventing unauthorized access"](#), on page 402.

To operate the instrument from a web browser over VNC

1. Install the *JRE (Java Runtime Environment)* on the remote computer.
Note: Skip this step if you are working with an HTML5 web browser.
2. Enter the IP address of the instrument in the address field of the web browser, e.g.
http://10.113.1.151
The VNC authentication screen appears.
3. Enter the user password.
The default password is *instrument*.

4. Confirm with with "OK".

When the VNC connection is established, the screen of the signal generator appears and you can operate the instrument from the remote computer.

To operate the instrument from a Linux/Unix client over VNC

1. Start a web browser on the remote computer. Enter the IP address of the instrument.
2. Enter the following address:
`vnc://<IP-address of the instrument>`, for example `vnc://10.113.1.151`.


A dialog opens requesting the password for the remote VNC connection.

3. Enter the user password.
The default password is *instrument*.
4. Confirm with with "OK".

When the VNC connection is established, the screen of the signal generator appears and you can operate the instrument from the remote computer.

To operate the instrument from a Windows client over VNC

1. Install the VNC viewer program component on the remote computer.
 - a) Download a VNC client program from the Internet.
For example the free of charge software Ultr@VNC (`vncviewer.exe` is available, see <http://www.uvnc.com/download/index.html>).
 - b) Execute the VNC client installation.
 - c) Select the VNC viewer program component and follow the installation instructions.
2. Start VNC viewer program component on the PC.



3. Select "VNC Server"

4. Enter the IP address of the instrument.
5. Confirm with "Connect".

An authentication dialog opens.



6. Enter the user password for authentication.
The default password is *instrument*.
7. Confirm with "LogOn".

When the connection is established, the screen of the signal generator appears and you can operate the instrument from the remote computer.

14.10.2 Using a smart device

The R&S SMA100B supports remote operation over VNC from a smart device (remote client), like a tablet (tablet computer) or a smartphone. The smart device accesses the instrument over WLAN, either by a suitable App, or an HTML5 web browser with embedded *javascript*.

There are several possibilities to establish a WLAN connection between the smart device and the R&S SMA100B. This section gives an example of how a network environment can be built up, and some essential configuration steps.

For more information, see:

- [1MA216: Remote Operation of Windows Based Instruments with Apple iPad](#)
- [7BM82: Apple iPad Remote Control of Broadcasting T&M Instruments](#)


Example:

Figure 14-8: Example of a network configuration for remote operation with a smart device

As shown in the figure, the R&S SMA100B and the WLAN router are connected to the LAN router. The smart device accesses the Rohde & Schwarz instrument via the WLAN router.

The WLAN router as an additional access point enables you to operate the instrument even from a great distance.

Prerequisites

For the remote operation, you need the following equipment and configuration:

- Equipment:
 - LAN router
 - WLAN router (hot spot) for accessing the instrument
 - Smart device
- The instrument and the smart device PC are connected in the same network.
- The instrument and the smart device are switched on.
- The LAN interface and VNC LAN service is enabled.
See [Section 13.4.4, "Configuring LAN services"](#), on page 395.
- A suitable application is running on the smart device.
 - Web browser
The R&S SMA100B supports remote operation over VNC with any HTML5 compliant web browser, e.g., Internet Explorer, Firefox, Google Chrome or Safari.
 - VNC app
An application that implements the VNC functionality for remote operation. The VNC App must be suitable to the used smart device.
Refer to the manufacturer's website to find a VNC App supported for your smart device, and how it is installed.
 - QR code

If your smart device is equipped with a camera and a QR code reader, you can scan the instrument's IP address or access the instrument with the Safari web browser.

Refer to the manufacturer's website to find a QR code reader supported for your smart device, and how it is installed.

We recommend that all components in the network use DHCP, which automatically assigns the relevant address information.

To operate the instrument using a VNC App on a smart device

1. Set up the network connection as shown in [Figure 14-8](#)
2. Configure the WLAN router according to the manufacturer's instructions.
3. Install the required *VNC App* on your smart device.
4. On the smart device, start the *VNC App*.
Enter the IP address of the instrument in the address field of *VNC App*.
The VNC authentication screen appears.
5. Enter the user password.
The default password is *instrument*.
6. Enter the password to establish the remote access.
The default user name and password is *instrument*.

When the VNC connection is established, the screen of the signal generator appears and you can operate the instrument from the smart device.

To operate the instrument from a web browser over VNC

1. Install the *JRE (Java Runtime Environment)* on the remote computer.
Note: Skip this step if you are working with an HTML5 web browser.
2. Enter the IP address of the instrument in the address field of the web browser, e.g. *http://10.113.1.151*
The VNC authentication screen appears.
3. Enter the user password.
The default password is *instrument*.
4. Confirm with "OK".

When the VNC connection is established, the screen of the signal generator appears and you can operate the instrument from the remote computer.

To access the instrument with QR code on a smart device

1. Set up the network connection as shown in [Figure 14-8](#)
2. Configure the WLAN router according to the manufacturer's instructions.
3. Install the required QR code reader software on your smart device.
4. On the smart device, start the QR code reader.

5. On the R&S SMA100B, select "System Config > Remote Access".
6. Select the "QR-Code" tab.
7. Scan the QR code of the instrument with your smart device.
8. On the smart device, decode the scanned QR code and forward it to the web browser.
The VNC authentication screen appears.
9. Enter the user password.
The default password is *instrument*.

When the VNC connection is established, the screen of the signal generator appears and you can operate the instrument from the smart device.

14.10.3 Stopping remote operation

To stop remote operation

To terminate remote operation over VNC depends on the used client:

- Select the action that applies to the used client:
 - a) On an external Unix/Linux PC, close the Internet browser or the signal generator window.
 - b) On an external Windows PC, close the VNC viewer program.
 - c) On a smart device, close the application.

The connection is terminated but not disabled. It can be established again anytime.

14.11 References

14.11.1 LXI functionality

LAN Extensions for Instrumentation (LXI) is an instrumentation platform for measuring instruments and test systems that is based on standard Ethernet technology.

LXI is intended to be the LAN-based successor to GPIB, combining the advantages of Ethernet with the simplicity and familiarity of GPIB. Like GPIB, LXI determines and standardizes the way the instrument behaves in a LAN.

The LXI implementation in the R&S SMA100B allows you to change certain LAN settings, to reset the LAN connection, and to identify the instrument.



For information about the LXI standard, refer to the LXI website at <https://www.lxistandard.org>.

See also "News from Rohde & Schwarz, article 2006/II - 190".

The LXI functionality in the R&S SMA100B is characterized by a common LAN implementation, including an ICMP ping responder for diagnostics. Using a web browser, you can configure the instrument. A LAN Configuration Initialize (LCI) mechanism resets the LAN configuration. The instrument also supports automatic detection in a LAN via the VXI-11 discovery protocol and programming by IVI drivers.

In addition, the R&S SMA100B provides the following LXI-related functionality:

- Integrated "LXI Status" dialog for LXI status indication and reset of the LAN configuration, see [Section 14.6, "LXI status settings"](#), on page 444.
- "LXI Browser Interface", as described in [Section 14.7.1, "LAN configuration"](#), on page 447.
- "SCPI Remote Trace" utility, see [Section 14.7.2, "SCPI remote trace"](#), on page 449.



Firmware update

To enable the full LXI functionality after a firmware update, shut down and restart the instrument.

14.11.2 Code generator templates

This section describes the main structure of the code generator templates, and shows the method with the NICVI template.

The code generation is controlled by templates with the following blocks:

Command	Function
#EXTENSION_START #EXTENSION_END	Defines the output file extension.
#INIT_CODE_START #INIT_CODE_END	Contains initial entries, such as included files and libraries, buffer size, commands for synchronization, or creating a VISA session. All entries between start and end are written once at the beginning of the output file.
#COMMAND_CODE_START #COMMAND_CODE_END	Frame for a SCPI command. A command is accessed with %COMMAND.
#NO_COMMAND_CODE_START #NO_COMMAND_CODE_END	Frame for a parameter with no SCPI command available. A parameter is accessed with %PARAMETER.
#EXIT_CODE_START #EXIT_CODE_END	Closes the visa session. All entries between start and end are written once at the end of the output file.

Templates are created in ASCII format with file extension *.expcodetempl.

Example:

Example to the code generator template `NICVI.expcodetmpl`:

```
#EXTENSION_START
.c
#EXTENSION_END

#INIT_CODE_START
#include <ansi_c.h>
#include <visa.h>
#include <cvirte.h>

#define MAX_BUFFER_SIZE 200
static ViStatus status;
static ViSession defaultRM, handle;

static void write_command(char *command)
{
    char writeBuffer[MAX_BUFFER_SIZE];
    char readBuffer[MAX_BUFFER_SIZE];
    int length;
    int readCount;

    strcpy(writeBuffer, command);
    //append "*OPC?" to sync
    strcat(writeBuffer, "*OPC?");
    length = strlen (writeBuffer);
    writeBuffer[length]='\n';
    length = length+1;
    viWrite (handle, writeBuffer, length, VI_NULL);
    //read result
    viRead(handle, readBuffer, 100, &readCount);
}

int main (int argc, char *argv[])
{
    if (InitCVIRTE (0, argv, 0) == 0)
        return -1;    /* out of memory */
    //create a VISA session and return a handle to it
    viOpenDefaultRM (&defaultRM);
    //create a VISA session to the serial port and return a handle to it
    viOpen (defaultRM, (ViRsrc)"TCPIP::localhost::INSTR", VI_NULL, VI_NULL,
    &handle);
#INIT_CODE_END

#COMMAND_CODE_START
    write_command("%COMMAND");
#COMMAND_CODE_END

#NO_COMMAND_CODE_START
```



```
//no SCPI command available for parameter %PARAMETER !
#NO_COMMAND_CODE_END

#EXIT_CODE_START
    viClose (handle);
        viClose (defaultRM);
        return 0;
}
#EXIT_CODE_END
```

15 Remote control commands

In the following, all remote-control commands are presented in detail with their parameters and the ranges of numerical values.

For an introduction to remote control and the status registers, see [Section 14, "Network operation and remote control"](#), on page 408.

• Conventions used in SCPI command descriptions	486
• Programming examples	487
• Common commands	488
• Preset commands	492
• MMEMory subsystem	494
• CALibration subsystem	504
• CSYNthesis subsystem	508
• DIAGnostic subsystem	513
• HUMS remote control commands	516
• DISPlay subsystem	523
• FORMat subsystem	528
• HCOPy subsystem	529
• KBOard subsystem	535
• OUTPut subsystem	536
• Power sensor measurement subsystems	540
• SENSe, READ, INITiate and SLISt subsystems	595
• SCONfiguration subsystem	608
• SOURce subsystem	613
• SYSTem subsystem	776
• STATus subsystem	806
• TEST subsystem	810
• TRIGger subsystem	813
• UNIT subsystem	817

15.1 Conventions used in SCPI command descriptions

The following conventions are used in the remote command descriptions:

- *Command usage*
If not specified otherwise, commands can be used both for setting and for querying parameters.
If a command can be used for setting or querying only, or if it initiates an event, the usage is stated explicitly.
- *Parameter usage*
If not specified otherwise, a parameter can be used to set a value, and it is the result of a query.
Parameters required only for setting are indicated as "Setting parameters".
Parameters required only to refine a query are indicated as "Query parameters".
Parameters that are only returned as the result of a query are indicated as "Return values".

- *Conformity*
Commands that are taken from the SCPI standard are indicated as "SCPI confirmed". All commands used by the R&S SMA100B follow the SCPI syntax rules.
- *Asynchronous commands*
A command which does not automatically finish executing before the next command starts executing (overlapping command) is indicated as an "Asynchronous command".
- *Reset values (*RST)*
Default parameter values that are used directly after resetting the instrument (*RST command) are indicated as "*RST" values, if available.
- *Factory preset values*
Default parameter values that are reset only by factory preset.
- *Default unit*
The default unit is used for numeric values if no other unit is provided with the parameter.
- *Manual operation*
If the result of a remote command can also be achieved in manual operation, a link to the description is inserted.

15.2 Programming examples

The corresponding sections of the same title provide simple programming examples for the R&S SMA100B. The purpose of these examples is to present all commands for a given task. Real applications require application-specific sets of commands and configurations.

The programming examples have been tested with a software tool which provides an environment for the development and execution of remote tests. To keep the examples as simple as possible, only the "clean" SCPI syntax elements are reported. Non-executable command lines start with two characters `//`, for example, comments.

At the beginning of the most remote control program, an instrument preset or reset is recommended to set the R&S SMA100B to a definite state. The commands `*RST` and `SYSTem:PRESet` are equivalent for this purpose. `*CLS` also resets the status registers and clears the output buffer.

In all the examples we assume the following:

- A remote PC is connected to the instrument.
- The remote PC and the instrument are switched on.
- A connection between them is established.
- The security setting "System Config" > "Setup" > "Security" > "SCPI over LAN" is enabled.

15.3 Common commands

Common commands are described in the IEEE 488.2 (IEC 625-2) standard. These commands have the same effect and are employed in the same way on different devices. The headers of these commands consist of "*" followed by three letters. Many common commands are related to the Status Reporting System.

Available common commands:

*CLS.....	488
*ESE.....	488
*ESR?.....	488
*IDN?.....	489
*IST?.....	489
*OPC.....	489
*OPT?.....	489
*PRE.....	490
*PSC.....	490
*RCL.....	490
*RST.....	490
*SAV.....	491
*SRE.....	491
*STB?.....	491
*TRG.....	491
*TST?.....	492
*WAI.....	492

*CLS

Clear status

Sets the status byte (STB), the standard event register (ESR) and the `EVENT` part of the `QUESTIONABLE` and the `OPERATION` registers to zero. The command does not alter the mask and transition parts of the registers. It clears the output buffer.

Usage: Setting only

*ESE <Value>

Event status enable

Sets the event status enable register to the specified value. The query returns the contents of the event status enable register in decimal form.

Parameters:

<Value> Range: 0 to 255

*ESR?

Event status read

Returns the contents of the event status register in decimal form and then sets the register to zero.

Return values:

<Contents> Range: 0 to 255

Usage: Query only

***IDN?**

Identification

Returns the instrument identification.

Return values:

<ID> "Rohde&Schwarz,<device type>,<part number>/<serial number>,<firmware version>"

Example: Rohde&Schwarz,SMA100B,1419.8888K02/0,4.00.033

Usage: Query only

Manual operation: See ["IDN String"](#) on page 429

***IST?**

Individual status query

Returns the contents of the IST flag in decimal form. The IST flag is the status bit which is sent during a parallel poll.

Return values:

<ISTflag> 0 | 1

Usage: Query only

***OPC**

Operation complete

Sets bit 0 in the event status register when all preceding commands have been executed. This bit can be used to initiate a service request. The query writes a "1" into the output buffer when all preceding commands have been executed, which is useful for command synchronization.

***OPT?**

Option identification query

Queries the options included in the instrument. For a list of all available options and their description, refer to the specifications document.

Return values:

<Options> The query returns a list of options. The options are returned at fixed positions in a comma-separated string. A zero is returned for options that are not installed.

Usage:

Query only

Manual operation: See "OPT String" on page 430

***PRE <Value>**

Parallel poll register enable

Sets parallel poll enable register to the indicated value. The query returns the contents of the parallel poll enable register in decimal form.

Parameters:

<Value> Range: 0 to 255

***PSC <Action>**

Power on status clear

Determines whether the contents of the `ENABLE` registers are preserved or reset when the instrument is switched on. Thus a service request can be triggered when the instrument is switched on, if the status registers ESE and SRE are suitably configured. The query reads out the contents of the "power-on-status-clear" flag.

Parameters:

<Action> 0 | 1
0
 The contents of the status registers are preserved.
1
 Resets the status registers.

***RCL <Number>**

Recall

Loads the instrument settings from an intermediate memory identified by the specified number. The instrument settings can be stored to this memory using the command `*SAV` with the associated number.

It also activates the instrument settings which are stored in a file and loaded using the `MMEMory:LOAD <number>, <file_name.extension>` command.

Manual operation: See "Quick Recall x" on page 344

***RST**

Reset

Sets the instrument to a defined default status. The default settings are indicated in the description of commands.

The command is equivalent to `SYSTem:PRESet`.

Usage: Setting only

Manual operation: See "Preset" on page 337

***SAV** <Number>

Save

Stores the current instrument settings under the specified number in an intermediate memory. The settings can be recalled using the command `*RCL` with the associated number.

To transfer the stored instrument settings in a file, use the command `:MMEM:STOR:STAT`.

Manual operation: See "Quick Save x" on page 344

***SRE** <Contents>

Service request enable

Sets the service request enable register to the indicated value. This command determines under which conditions a service request is triggered.

Parameters:

<Contents> Contents of the service request enable register in decimal form.
Bit 6 (MSS mask bit) is always 0.
Range: 0 to 255

***STB?**

Status byte query

Reads the contents of the status byte in decimal form.

Usage: Query only

***TRG**

Trigger

Triggers all actions waiting for a trigger event. In particular, `*TRG` generates a manual trigger signal. This common command complements the commands of the `TRIGger` subsystem.

`*TRG` corresponds to the `INITiate:IMMediate` command.

Usage: Event

***TST?**

Self-test query

Initiates self-tests of the instrument and returns an error code.

Return values:

<ErrorCode>

integer > 0 (in decimal format)

An error occurred.

For details, see the Service Manual supplied with the instrument.

0

No errors occurred.

Usage:Query only

***WAI**

Wait to continue

Prevents servicing of the subsequent commands until all preceding commands have been executed and all signals have settled (see also command synchronization and [*OPC](#)).

Usage:Event

15.4 Preset commands

The preset commands are not bundled in one subsystem. Therefore, they are listed separately in this section.

Four presetting actions are available:

- Activating the default state of all internal instrument functions ([*RST](#) on page 490). Functions that concern the integration of the instrument into a measurement setup are not changed, e.g. reference oscillator source settings.
- Activating the preset state of the parameters related to the selected signal path ([:SOURce<hw>:PRESet](#) on page 493)
- Activating the preset state of all parameters that are not related to the signal path ([:DEVIce:PRESet](#) on page 493)
- Activating the original state of delivery (factory reset, [:SYSTem:FPRreset](#) on page 493). Only functions that are protected by a password remain unchanged as well as the passwords themselves.



When resetting, the following deviation between remote and manual control exists:

In contrast to the [Preset] key, the SCPI commands [*RST](#) and [:SYSTem:PRESet](#) do not close open dialogs in the GUI.

:DEVIce:PRESet.....	493
:SOURce<hw>:PRESet.....	493
:SYSTem:PRESet.....	493
:SYSTem:FPReset.....	493

:DEVIce:PRESet

Presets all parameters which are not related to the signal path, including the LF generator.

Example: DEV: PRES
Presets all instruments settings that are not related to the signal path.

Usage: Event

:SOURce<hw>:PRESet

Presets all parameters which are related to the selected signal path.

Example: SOUR: PRES
Presets all settings that are related to signal path

Usage: Event

:SYSTem:PRESet

Triggers an instrument reset. This command has the same effect as:

- The [Preset] key.
However, the command does not close open GUI dialogs like the key does.
- The *RST command

For an overview of the settings affected by the preset function, see [Table 12-1](#)

Example: SYST: PRES
All instrument settings (also the settings that are not currently active) are reset to their default values.

Usage: Setting only

:SYSTem:FPReset

Triggers an instrument reset to the original state of delivery.

Example: SYST: FPR
All instrument settings (also the settings that are not currently active) are reset to the factory values.

Usage: Event

Manual operation: See "[Execute Factory Preset](#)" on page 338

15.5 MMEMory subsystem

The MMEMory subsystem (Mass MEMory) contains the commands for managing files and directories as well as for loading and saving complete instrument settings in files.

Mass storage location

Without any additional measures, the R&S SMA100B stores user files on the internal memory, the removable memory, or if connected, on a memory stick.

Both, the user directory `/var/user/` on the internal memory or the `/usb/` directory on the memory stick, can be used to **preserve** user-defined data. Any directory structure can be created.

The `/var/volatile` directory serves as a RAM drive and can be used to protect sensitive information. The data is available **temporarily**.

If option R&S SMAB-B85 is installed, the R&S SMA100B maps the user directory to the removable memory. If a memory is mounted, user data is saved there. Otherwise user data is redirected to the volatile memory.

Default storage location

The R&S SMA100B stores user data in the user directory.

Depending on the installed options, the user directory is physically located on the internal memory or on the removable memory.

In the file system, user directory is always indicated as `/var/user/`.

In manual control, you access this directory via the "File Manager", see [Section 12.9, "Using the file manager"](#), on page 348. In remote control, you can query it with the command `:SYSTem:MMEMory:PATH:USER?`.

To query and change the default directory used for mass storage, use the command `:MMEMory:CDIRectory`.

15.5.1 File naming conventions

To enable files to be used in different file systems, consider the following file naming conventions:

- The *filename* can be of any length and *is case-sensitive*, i.e it is distinguished between uppercase and lowercase letters.
- All letters and numbers are permitted (numbers are, however, not permitted at the beginning of the filename).
- Avoid using special characters.
- Do not use slashes "\" and "/". These symbols are used in file paths.
- Avoid using the following filenames: CLOCK\$, CON, COM1 to COM4, LPT1 to LPT3, NUL or PRN
They are reserved by the operating system.

File extension

The file and the optional file *extension* are separated by a period sign. The R&S SMA100B distinguishes the files according to their extensions; each type of file is assigned a specific file content and hence a specific file extension. Refer to [Section B, "Available user files and file extensions"](#), on page 857 for an overview of the supported file extensions.

Wildcards

The two characters "*" and "?" function as "wildcards", i.e. they are used for selecting several files. The "?" character represents exactly one character, while the "*" character represents all characters up to the end of the filename. "**.*" therefore represents all files in a directory.

Filename and file path

When used in remote control commands, the parameter `<filename>` is specified as a string parameter with quotation marks. It can contain either the complete path including the root user directory `/var/user` and filename, or only the filename. The filename must include the file extension. The same applies for the directory `/var/volatile` and for the parameters `<directory_name>` and `<path>`.

Depending on how much information is provided, the values specified in the parameter or with the command `MMEM:CDIR` are used for the path and drive setting in the commands.

15.5.2 Handling files in the default or in a specified directory

For better overview and easy file handling, you may not save all user files in the user directory `/var/user` but rather organize them into subdirectories.

The command syntax defines two general ways to access files with user data in a *specific* directory:

- **Change the current default directory** for mass memory storage and then directly access the files in this default directory, like saved list files, files with user data or save/recall files.
The subsequent commands for file handling (select, delete, read out files in the directory, etc.) require only specification of the filename. File extension can be omitted; after syntax evaluation of the used command, the R&S SMA100B filters out the relevant files.
- Define the **complete file path**, including the user directory `/var/user`, created subdirectories and filename.
As a rule, whenever an complete file path is determined, it overwrites a previously specified default directory.

The following example explains this rule as a principle. Exceptions of this general rule are stated in the description of the corresponding command. The [Section 15.5.3, "Programming examples"](#), on page 496 explains the general working principle with the commands for mass memory storage.

The same rule applies to the `/var/volatile` directory, see [Example "Working with files in the volatile memory"](#) on page 498.

Example: Load file with user data from a specific directory

This example shows the principle of file handling in remote environment by using list commands. Working with the files of other subsystems is analogical. We assume that the directory `/var/user/my_files` is existing and contains the files `list_test.lsw` and `list_2.lsw`.

```
//Query files in the user diectory
SOURCE1:LIST:CATalog?
// -
// no files

// Set the default directory
MMEMory:CDIRectory "/var/user/my_files"
SOURCE1:LIST:CATalog?
// "list_test","list_2"

// Specify the complete path to select a list file (*.lsw)
// in the specific directory
SOURCE1:LIST:SElect "/var/user/my_files/list_test"
SOURCE1:LIST:DElete "/var/user/my_files/list_2"
```

15.5.3 Programming examples

Example: Saving and loading current settings

This example shows two ways of how to save the current instrument setting in the file `settings.savrc1.txt` in the directory `/var/user/savrc1`.



Before the instrument settings can be saved in a file, they have to be saved in an intermediate memory using common command `*SAV <number>`. The specified number is then used in the `:MMEMory:STORe:STATe` command.

Also, after loading a file with instrument settings with command `:MMEMory:LOAD:STATe`, these settings have to be activated with the common command `*RCL <number>`.

```
// Save the current settings in an intermediate memory with number 4
*SAV 4

// save the settings in a file in a specific directory;
// the complete path has to be specyified
MMEMory:STORe:STATe 4,"/var/user/savrc1/settings.savrc1.txt"

// save the settings in a file in the default directory;
```

```
// set the default directory; specify only the file name
MMEMory:CDIRectory  "/var/user/savrcl"
*SAV 4
MMEMory:STORE:STATE 4,"settings.savrcltxt"

// Load the saved settings in the intermediate memory 4 and activate them
MMEMory:LOAD:STATE 4,"/var/user/settings.savrcltxt"
*RCL 4
```

Example: Working with files and directories

This example shows how to list files in a directory, list the subdirectories, query the number of files in a directory, create directory, rename and delete files.

```
// Query the current default directory for mass storage,
// change the directory to the default user directory "/var/user"
// and read out the files in it
MMEMory:CDIRectory?
// "/var/user/temp"
MMEMory:CDIRectory
MMEMory:CDIRectory?
// "/var/user/"
MMEMory:CATalog?
// 1282630,8102817792,".,DIR,4096","..,DIR,4096","Log,DIR,4096",
// "settings.savrcltxt,BIN,16949","temp,DIR,4096","test,DIR,4096",
// "list.lsw,BIN,1245201"
// the directory "/var/user" contains the predefined directory "Log",
// the subdirectories "test" and "temp"
// as well as the files "settings.savrcltxt" and "list.lsw"

// query only the subdirectories of the current or specified directory
MMEMory:DCATalog? "/var/user"
// ".,", "..", "Log", "temp", "test"

// query only number of subdirectories in the current or specified directory
MMEMory:DCATalog:LENGth? "/var/user"
// 5

// query number of files in the current or specified directory
MMEMory:CATalog:LENGth? "/var/user"
// 7

// Create a new directory for mass memory storage in the specified directory
MMEMory:MDIRectory "/var/user/new"

// Copy the file "settings.savrcltxt" into the new directory
MMEMory:COPY "/var/user/settings.savrcltxt","/var/user/new/settings.savrcltxt"

// Rename the file "settings.savrcltxt" into the new directory
// and read out the files in this specific directory
MMEMory:CDIRectory  "/var/user/new"
```

```

MMEMory:MOVE "settings.savrc1txt","settings_new.savrc1txt"
MMEMory:CATalog? "/var/user/new"
// 25141,8102789120,".",DIR,4096","..,DIR,4096","settings_new.savrc1txt,BIN,16949"

// Delete an empty directory, e.g. the "test" directory
MMEMory:RDIRECTory "/var/user/test"
// Delete the entire directory, including files and subdirectories
:MMEMory:RDIRECTory:RECURSive "var/user/test"

```

Example: Working with files in the volatile memory

This example shows how to work with files in the `/var/volatile` directory.

```

// Change the default directory for mass storage,
// read out the files, load and play a file with the ARB
MMEMory:CDIRECTory "/var/volatile"
MMEMory:CDIRECTory?
// "/var/volatile"
MMEMory:CATalog?
//13928,525352960,".",DIR,60","..,DIR,4096","list.lst,BIN,9772"

SOURcel:LIST:SElect "/var/volatile/list"
SOURcel:FREQuency:MODE LIST
OUTPut1:STATe 1

```

15.5.4 Remote control commands

:MMEMory:CATalog?	498
:MMEMory:CATalog:LENGth?	499
:MMEMory:CDIRECTory	499
:MMEMory:COPY	499
:MMEMory:DATA	500
:MMEMory:DCATalog?	501
:MMEMory:DCATalog:LENGth?	501
:MMEMory:DELeTe	501
:MMEMory:LOAD:STATe	501
:MMEMory:MDIRECTory	502
:MMEMory:MOVE	502
:MMEMory:MSIS	502
:MMEMory:RDIRECTory	502
:MMEMory:RDIRECTory:RECURSive	503
:MMEMory:STORe:STATe	503
:MEMory:HFRee?	503

:MMEMory:CATalog?

Returns the content of a particular directory.

Return values:

<Catalog> string
 String parameter to specify the directory.
 If you leave out the path, the command returns the contents of the directory selected with :MMEMory:CDIRectory.
 The path may be relative or absolute.

Usage: Query only

Manual operation: See "Directory, File List and Filename" on page 343

:MMEMory:CATalog:LENGth? [<Path>]

Returns the number of files in the current or in the specified directory.

Query parameters:

<Path> string
 String parameter to specify the directory. If the directory is omitted, the command queries the content of the current directory, queried with :MMEMory:CDIRectory command.

Return values:

<FileCount> integer
 Number of files.

Usage: Query only

:MMEMory:CDIRectory <Directory>

Changes the default directory for mass memory storage. The directory is used for all subsequent MMEM commands if no path is specified with them.

Parameters:

<Directory> <directory_name>
 String containing the path to another directory. The path can be relative or absolute.
 To change to a higher directory, use two dots '..'.

Manual operation: See "Directory, File List and Filename" on page 343

:MMEMory:COpy <SourceFile>, <DestinationFile>

Copies an existing file to a new file. Instead of just a file, this command can also be used to copy a complete directory together with all its files.

Setting parameters:

<SourceFile> string
 String containing the path and file name of the source file

<DestinationFile> string
 String containing the path and name of the target file. The path can be relative or absolute.
 If **<DestinationFile>** is not specified, the **<SourceFile>** is copied to the current directory, queried with the **:MMEMory:CDIRectory** command.
Note: Existing files with the same name in the destination directory are overwritten without an error message.

Usage: Setting only

Manual operation: See ["Cut, Copy&Paste and Delete"](#) on page 350

:MMEMory:DATA <Filename>, <BinaryData>

:MMEMory:DATA? <Filename>

The setting command writes the block data **<BinaryBlock>** to the file identified by **<Filename>**.

Tip: Use this command to read/transfer stored instrument settings or waveforms directly from/to the instrument.

Parameters:

<BinaryData>

Setting parameters:

<Filename> string
 String parameter to specify the name of the file.

Query parameters:

<Filename> #<number><length_entry><data>
 #: Hash sign; always comes first in the binary block
 <number>: the first digit indicates how many digits the subsequent length entry has
 <length_entry>: indicates the number of subsequent bytes
 <data>: binary block data for the specified length.
 For files with a size with more than nine digits (gigabytes), the instrument allows the syntax #(<Length>), where <Length> is the file size in decimal format.

Example:

MMEMory:DATA '/var/user/test.txt',#15hallo

Writes the block data to the file **test.txt**.

The digit 1 indicates a length entry of one digit; the digit 5 indicate a length of the binary data (**hallo**) in bytes.

MMEMory:DATA? '/var/user/test.txt'

Sends the data of the file **test.txt** from the instrument to the controller in the form of a binary block.

Response: **#15hallo**

:MMEMory:DCATalog?

Returns the subdirectories of a particular directory.

Return values:

<DCatalog>	<file_entry>
	Names of the subdirectories separated by colons. The first two strings are related to the parent directory.

Usage:	Query only
---------------	------------

:MMEMory:DCATalog:LENGth? [<Path>]

Returns the number of subdirectories in the current or specified directory.

Query parameters:

<Path>	string
	String parameter to specify the directory. If the directory is omitted, the command queries the contents of the current directory, to be queried with :MMEMory:CDIRectory command.

Return values:

<DirectoryCount>	integer
	Number of parent and subdirectories.

Usage:	Query only
---------------	------------

:MMEMory:DELeTe <Filename>

Removes a file from the specified directory.

Setting parameters:

<Filename>	string
	String parameter to specify the name and directory of the file to be removed.

Usage:	Setting only
---------------	--------------

Manual operation:	See "Cut, Copy&Paste and Delete" on page 350
--------------------------	--

:MMEMory:LOAD:STATe <SavRclStateNumb>, <file_name>

Loads the specified file stored under the specified name in an internal memory.

After the file has been loaded, the instrument setting must be activated using an [*RCL](#) command.

Setting parameters:

<SavRclStateNumb>	Determines to the specific <number> to be used with the *RCL command, e.g. *RCL 4 .
--------------------------------	---

<file_name>	String parameter to specify the file name with extension *.savrcltxt .
--------------------------	--

Usage: Setting only

Manual operation: See ["Recall"](#) on page 344

:MMEMory:MDIRectory <Directory>

Creates a subdirectory for mass memory storage in the specified directory. If no directory is specified, a subdirectory is created in the default directory. This command can also be used to create a directory tree.

Setting parameters:

<Directory> string
String parameter to specify the new directory.

Usage: Setting only

Manual operation: See ["Create New Directory"](#) on page 350

:MMEMory:MOVE <SourceFile>, <DestinationFile>

Moves an existing file to a new location or, if no path is specified, renames an existing file.

Setting parameters:

<SourceFile> string
String parameter to specify the name of the file to be moved.

<DestinationFile> string
String parameters to specify the name of the new file.

Usage: Setting only

Manual operation: See ["Rename"](#) on page 350

:MMEMory:MSIS <Path>

Defines the drive or network resource (in the case of networks) for instruments with windows operating system, using `msis` (MSIS = Mass Storage Identification String).

Note: Instruments with Linux operating system ignore this command, since Linux does not use drive letter assignment.

:MMEMory:RDIRectory <Directory>

Removes an empty directory from the mass memory storage system. If no directory is specified, the subdirectory with the specified name is deleted in the default directory.

Setting parameters:

<Directory> string
String parameter to specify the directory to be deleted.

Example: See [Example "Working with files and directories"](#) on page 497.

Usage: Setting only

:MMEMory:RDIRectory:RECursive <Directory>

Removes the specified directory, including files and subdirectories from the mass memory storage system. If no directory is specified, the command removes the subdirectories of the default directory.

The command the entire directory without further prompt or notification.

Setting parameters:

<Directory> string
String parameter to specify the directory to be deleted.

Example: See [Example "Working with files and directories"](#) on page 497.

Usage: Setting only

:MMEMory:STORE:STATe <savrcl_state_nr>, <file_name>

Stores the current instrument setting in the specified file.

The instrument setting must first be stored in an internal memory with the same number using the common command *SAV.

Setting parameters:

<savrcl_state_nr> Corresponds to the specific <number> defined with the *SAV command, e.g. *SAV 4.

<file_name> String parameter to specify the file name with extension *.savrcltxt.

Usage: Event

Manual operation: See ["Save"](#) on page 344

:MEMory:HFRee?

Returns the used and available memory in Kb.

Return values:

<TotalPhysMemKb> integer
Total physical memory.

<ApplicMemKb> integer
Application memory.

<HeapUsedKb> integer
Used heap memory.

<HeapAvailableKb> integer
Available heap memory.

Usage: Query only

15.6 CALibration subsystem

The CALibration subsystem contains the commands needed for performing internal adjustments. This procedure is triggered by the query commands.

Common suffixes

The following common suffixes are used in the remote commands:

Suffix	Value range	Description
CALibration<hw>	[1]	Optional suffix

Understanding the query response

- 0: error-free execution of the adjustments
- 1: indicates that an error occurred; the process has been canceled

Example: Querying the most recent internal adjustments

```
CALibration:ALL:DATE?
"2024-07-16"
CALibration:ALL:INFormation?
"" // no adjustment info available
CALibration:ALL:TEMP?
"-2.0 K"
CALibration:ALL:TIME?
"17 days"
```

:CALibration:ALL[:MEASure]?	504
:CALibration<hw>:ALL:DATE?	505
:CALibration<hw>:ALL:INFormation?	505
:CALibration<hw>:ALL:TEMP?	505
:CALibration<hw>:ALL:TIME?	506
:CALibration<hw>:CONTinueonerror	506
:CALibration:DATA:EXPort	506
:CALibration:DATA:FACTory:DATE?	506
:CALibration:DElay:MINutes	507
:CALibration:DElay:SHUTdown[:STATe]	507
:CALibration:DElay[:MEASure]?	507
:CALibration<hw>:DEBug	508

:CALibration:ALL[:MEASure]?? [<Force>]

Starts all internal adjustments that do not need external measuring equipment.

NOTICE! High power at the RF output applied during internal adjustment can destroy a connected DUT (device under test).

How to: See ["Running internal adjustments"](#) on page 838.

Query parameters:

<Force> string

Return values:

<Measure> 1 | ON | 0 | OFF

Example:

```

CAL:ALL:MEAS?
// Response: "0"
// Executes the adjustments of all instrument functions.
// When completed, it indicates that the adjustment
// has been performed successfully.

```

Usage: Query only

Manual operation: See ["Adjust All"](#) on page 836

:CALibration<hw>:ALL:DATE?

Queries the date of the most recently executed full adjustment.

Suffix:

<hw> [1]
Optional suffix

Return values:

<Date> string

Example: See [Example "Querying the most recent internal adjustments"](#) on page 504.

Usage: Query only

Manual operation: See ["Last Full Adjustment"](#) on page 836

:CALibration<hw>:ALL:INformation?

Queries the current state of the internal adjustment.

Return values:

<CallInfoText> string

Example: See [Example "Querying the most recent internal adjustments"](#) on page 504.

Usage: Query only

Manual operation: See ["Information"](#) on page 836

:CALibration<hw>:ALL:TEMP?

Queries the temperature deviation compared to the calibration temperature.

Suffix:

<hw> [1]
Optional suffix

Return values:

<Temperature> string

Example:See [Example "Querying the most recent internal adjustments"](#) on page 504.**Usage:**

Query only

Manual operation:See ["Temperature Offset"](#) on page 836**:CALibration<hw>:ALL:TIME?**

Queries the time elapsed since the last full adjustment.

Return values:

<Time> string

Example:See [Example "Querying the most recent internal adjustments"](#) on page 504.**Usage:**

Query only

Manual operation:See ["Time"](#) on page 836**:CALibration<hw>:CONTinueonerror <State>**

Continues the calibration even though an error was detected. By default adjustments are aborted on error.

Suffix:<hw> [1]
Optional suffix**Parameters:**<State> 1 | ON | 0 | OFF
*RST: n.a. (factory preset: 0)**Example:**CAL:CONT ON
// Continues calibration after an error**Manual operation:**See ["Continue Adjustment on Error"](#) on page 836**:CALibration:DATA:EXPort**

Collects the internal adjustment data and provides the data for export in a zip file. You can export the data for service and evaluation purposes.

Example:

:CALibration:DATA:EXPort

Usage:

Event

:CALibration:DATA:FACTory:DATE?

Queries the date of the last factory calibration.

Return values:

<Date> string

Example:

```
CAL:DATA:FACT:DATE?  
// "2016-01-01"
```

Usage:

Query only

Manual operation: See ["Last Factory Calibration"](#) on page 828

:CALibration:DElay:MINutes <Minutes>

Sets the warm-up time to wait before internal adjustment starts automatically.

Automatic execution starts only, if you have enabled the calibration with command :
[CALibration:DElay\[:MEASure\]? ON](#).

Parameters:

<Minutes> integer

Range: 30 to 120

*RST: n.a. (no preset. default: 60)

Example:

```
:CALibration:DElay:MINutes 30  
// sets the time delay for warm-up of the instrument.
```

Manual operation: See ["Warm Up Time"](#) on page 837

:CALibration:DElay:SHUTdown[:STATe] <Shutdown>

Enables the instrument to shut down automatically after calibration.

Parameters:

<Shutdown> 1 | ON | 0 | OFF

*RST: 0

Example:

```
:CALibration:DElay:SHUTdown[:STATe] ON|1  
// inititates that the instrument shuts down when the adjustments are com
```

Manual operation: See ["Shutdown After Adjustment"](#) on page 837

:CALibration:DElay[:MEASure]?

Starts the delayed adjustment process. When the warm-up time has elapsed (see :
[CALibration:DElay:MINutes](#), it executes the internal adjustments.

If you have enabled automatic shutdown, [:CALibration:DElay:SHUTdown\[:STATe\] ON](#), the instrument shuts down when the adjustments are completed.

Return values:

<Error> 1 | ON | 0 | OFF

*RST: n.a. (no preset. default: 0)

Example:

```
:CALibration:DElay[:MEASure] ON|1  
// enables the adjustment processs to start after the warm-up time automa
```

Usage: Query only

Manual operation: See ["Adjust All Delayed"](#) on page 837

:CALibration<hw>:DEBug <State>

Activates logging of the internal adjustments.

Suffix:

<hw> [1]
Optional suffix

Setting parameters:

<State> 0 | 1 | OFF | ON

*RST: 0

Example: CALibration:DEBug 1

Usage: Setting only

Manual operation: See ["Log Debug Info"](#) on page 836

15.7 CSYNthesis subsystem

This subsystem contains the commands used to define the frequency settings for the separate clock source (clock synthesis).

Option: see ["Required options"](#) on page 327.

Example:

```
CSYNthesis:OTYPe DSIN
CSYNthesis:FREQuency 10000000
CSYNthesis:POWer -15
CSYNthesis:OFFSet:STATe 1
CSYNthesis:OFFSet 0.1
CSYNthesis:PHASe 180
CSYNthesis:PHASe:REFeRence
CSYNthesis:PHASe?
// 0
CSYNthesis:FREQuency:STEP:MODE DEC
CSYNthesis:POWer:STEP:MODE DEC
// CSYNthesis:FREQuency:STEP:MODE USER
// CSYNthesis:FREQuency:STEP 1000
// CSYNthesis:FREQuency UP
// 10001000
// CSYNthesis:POWer:STEP:MODE USER
// CSYNthesis:POWer:STEP:INCRement 0.5
CSYNthesis:STATe 1
```


:CSYNthesis:STATe.....	509
:CSYNthesis:OTYPe.....	509
:CSYNthesis:FREQuency.....	509
:CSYNthesis:POWer.....	510
:CSYNthesis:OFFSet:STATe.....	510
:CSYNthesis:OFFSet.....	510
:CSYNthesis:VOLTage.....	511
:CSYNthesis:PHASe.....	511
:CSYNthesis:PHASe:REFerence.....	511
:CSYNthesis:POWer:STEP:MODE.....	512
:CSYNthesis:FREQuency:STEP:MODE.....	512
:CSYNthesis:POWer:STEP[:INCRement].....	512
:CSYNthesis:FREQuency:STEP.....	512

:CSYNthesis:STATe <State>

Activates the clock synthesis.

Parameters:

<State> 1 | ON | 0 | OFF
 *RST: 0

Example: See [Section 15.7, "CSYNthesis subsystem"](#), on page 508.

Manual operation: See ["State"](#) on page 328

:CSYNthesis:OTYPe <Mode>

Defines the shape of the generated clock signal.

Parameters:

<Mode> SESine | DSQuare | CMOS | DSINe
 SESine = single-ended sine
 DSINe = differential sine
 DSQuare = differential square
 CMOS = CMOS
 *RST: SESine

Example: See [Section 15.7, "CSYNthesis subsystem"](#), on page 508.

Manual operation: See ["Output Type"](#) on page 328

:CSYNthesis:FREQuency <Frequency>

Sets the frequency of the generated clock signal.

Parameters:

<Frequency> float
 Numerical value
 Sets the frequency

UP|DOWN

Varies the frequency step by step.

The frequency is increased or decreased by the value set with the command `:CSYNthesis:FREQuency:STEP`.

Range: 100E3 to 1.5E9

Increment: 0.001

*RST: 10E6

Example: See [Section 15.7, "CSYNthesis subsystem"](#), on page 508.

Manual operation: See ["Frequency"](#) on page 329

:CSYNthesis:POWer <Power>

Sets the power level of the generated clock signal.

Parameters:

<Power> float

Numerical value

Sets the level

UP|DOWN

Varies the level step by step.

The level is increased or decreased by the value set with the command `:CSYNthesis:POWer:STEP[:INCRement]`.

Range: -24 to 10

Increment: 0.01

*RST: -20

Example: See [Section 15.7, "CSYNthesis subsystem"](#), on page 508.

Manual operation: See ["Level"](#) on page 329

:CSYNthesis:OFFSet:STATe <State>

Activates a DC offset.

Parameters:

<State> 1 | ON | 0 | OFF

*RST: 0

Example: See [Section 15.7, "CSYNthesis subsystem"](#), on page 508.

Manual operation: See ["DC Offset State"](#) on page 329

:CSYNthesis:OFFSet <Offset>

Sets the value of the DC offset.

Parameters:

<Offset> float
 Range: -5 to 5
 Increment: 0.001
 *RST: 0

Example: See [Section 15.7, "CSYNthesis subsystem"](#), on page 508.

Manual operation: See ["DC Offset"](#) on page 330

:CSYNthesis:VOLTage <Voltage>

Sets the voltage for the CMOS signal.

Parameters:

<Voltage> float
 Range: 0.8 to 2.7
 Increment: 0.001
 *RST: 1.8

Example:

```
CSYNthesis:OTYPe CMOS
CSYNthesis:VOLTage 1.8
CSYNthesis:FREQuency 100000000
CSYNthesis:STATe 1
```

Manual operation: See ["Voltage"](#) on page 330

:CSYNthesis:PHASe <Phase>

Shifts the phase of the generated clock signal.

Parameters:

<Phase> float
 Range: -36000 to 36000
 Increment: 0.1
 *RST: 0

Example: See [Section 15.7, "CSYNthesis subsystem"](#), on page 508.

Manual operation: See ["Delta Phase"](#) on page 330

:CSYNthesis:PHASe:REFerence

Resets the delta phase value.

Example: See [Section 15.7, "CSYNthesis subsystem"](#), on page 508.

Usage: Event

:CSYNthesis:POWer:STEP:MODE <Mode>

:CSYNthesis:FREQuency:STEP:MODE <Mode>

Defines the type of step size to vary the frequency and level at discrete steps.

Parameters:

<Mode> DECimal | USER

DECimal

Increases or decreases the level in steps of 10.

USER

Increases or decreases the value in increments, set with the command:

`:CSYNthesis:FREQuency:STEP`

`:CSYNthesis:POWer:STEP[:INCRement]`

*RST: DECimal

Example: See [Section 15.7, "CSYNthesis subsystem"](#), on page 508.

Manual operation: See ["Variation Active"](#) on page 330

:CSYNthesis:POWer:STEP[:INCRement] <Increment>

Sets the step width of the rotary knob and, in user-defined step mode, increases or decreases the level.

Parameters:

<Increment> float

Range: 0 to 35

Increment: 0.01

*RST: 1

Example: See [Section 15.7, "CSYNthesis subsystem"](#), on page 508.

Manual operation: See ["Variation Step"](#) on page 330

:CSYNthesis:FREQuency:STEP <Step>

Sets the step width of the rotary knob and, in user-defined step mode, increases or decreases the frequency.

Parameters:

<Step> float

Range: 0 to 14999E5

Increment: 0.001

*RST: 1E6

Example: See [Section 15.7, "CSYNthesis subsystem"](#), on page 508.

Manual operation: See ["Variation Step"](#) on page 330

15.8 DIAGnostic subsystem

The `DIAGnostic` subsystem contains the commands used for instrument diagnosis and servicing. SCPI does not define any `DIAGnostic` commands; the commands listed here are all device-specific. All `DIAGnostic` commands are query commands which are not affected by `*RST`.



The test functions are intended for services purposes.

They are thus password-protected functions. Unlock the corresponding protection level to access them, see `:SYSTEM:PROTect<ch>[:STATe]`.

For more information, see R&S SMA100B Service Manual.

Common suffixes

The following common suffixes are used in remote commands:

Suffix	Value range	Description
<code>DIAGnostic<hw></code>	[1]	Optional suffix

Example: Programming example

The example lists the commands required to query assemblies and test points for diagnosis purposes.

```
// Query the modules available in the instrument
// and variant and revision state of a certain assembly
DIAGnostic1:BGInfo:CATalog?
// FRONT_AF,PSU300,IFB.BV,MB2_AF,...
DIAGnostic1:BGInfo? "PSU300"
// PSU300 2118.2067.02 01.00 100000

// Query the test points available in the instrument
// and trigger the measurement in a selected test point
DIAGnostic1:POINT:CATalog?
// ATT6HP_AF_DET_N,ATT6HP_AF_DET_P,ATT6HP_AF_DET_TEMP...
DIAGnostic1:MEASure:POINT? "ATT6HP_AF_DET_N"
// 0.000000V

// Query the operating hours and number of power-on so far.
DIAGnostic:INFO:OTIME?
// 112 h
DIAGnostic:INFO:POCount?
// 14
```

Commands

<code>:DIAGnostic<hw>:BGInfo:CATalog?</code>	514
<code>:DIAGnostic<hw>:BGInfo?</code>	514
<code>:DIAGnostic:INFO:OTIME?</code>	514

:DIAGnostic:INFO:POCount?.....	515
:DIAGnostic<hw>:POINT:CATalog?.....	515
:DIAGnostic<hw>[:MEASure]:POINT?.....	515

:DIAGnostic<hw>:BGInfo:CATalog?

Queries the names of the assemblies available in the instrument.

Return values:

<Catalog> string
 List of all assemblies; the values are separated by commas
 The length of the list is variable and depends on the instrument equipment configuration.

Example: See [Example "Programming example"](#) on page 513.

Usage: Query only

:DIAGnostic<hw>:BGInfo? [<Board>]

Queries information on the modules available in the instrument, using the variant and revision state.

Query parameters:

<Board> string
 Module name, as queried with the command :
[DIAGnostic<hw>:BGInfo:CATalog?](#).
 To retrieve a complete list of all modules, omit the parameter.
 The length of the list is variable and depends on the instrument equipment configuration.

Return values:

<BgInfo> <Module name> <Module stock number incl. variant> <Module revision> <Module serial number>
 List of comma-separated entries, one entry per module.
 Each entry for one module consists of four parts that are separated by space characters.

Example: See [Example "Programming example"](#) on page 513.

Usage: Query only

Manual operation: See ["Assembly"](#) on page 827

:DIAGnostic:INFO:OTIME?

Queries the operating hours of the instrument so far.

Return values:

<OperationTime> integer
 Range: 0 to INT_MAX
 *RST: 0

Example: See [Example "Programming example"](#) on page 513.

Usage: Query only

Manual operation: See ["Operation Time / h"](#) on page 828

:DIAGnostic:INFO:POCount?

Queries how often the instrument has been turned on so far.

Return values:

<PowerOnCount> integer
 Range: 0 to INT_MAX
 *RST: 0

Example: See [Example "Programming example"](#) on page 513.

Usage: Query only

Manual operation: See ["Power On Count"](#) on page 828

:DIAGnostic<hw>:POINT:CATalog?

Queries the test points available in the instrument.

For more information, see R&S SMA100B Service Manual.

Return values:

<Catalog> string
 List of comma-separated values, each representing a test point

Example: See [Example "Programming example"](#) on page 513.

Usage: Query only

:DIAGnostic<hw>[:MEASure]:POINT? <Name>

Triggers the voltage measurement at the specified test point and returns the measured voltage.

For more information, see R&S SMA100B Service Manual.

Query parameters:

<Name> <test point identifier>
 Test point name, as queried with the command :
[DIAGnostic<hw>:POINT:CATalog?](#) on page 515

Return values:

<Value> <value><unit>

Example: See [Example "Programming example"](#) on page 513.

Usage: Query only

15.9 HUMS remote control commands

The remote control commands for the health and utilizations monitoring system (HUMS) comprise commands of the `DIAGnostic` subsystem and the commands of the `SYSTem:COMMunicate:REST` and `SYSTem:COMMunicate:REST` subsystems.

For all HUMS-related remote control commands, see refer to the "R&S®HUMS Health and Utilization Monitoring Service" User Manual on the Internet.

Commands

<code>DIAGnostic:HUMS:DELeTe:ALL</code>	516
<code>DIAGnostic:HUMS:DEViCe:HISTory?</code>	516
<code>DIAGnostic:HUMS:DEViCe:HISTory:DELeTe:ALL</code>	517
<code>DIAGnostic:HUMS:FORMat</code>	517
<code>DIAGnostic:HUMS:SAVE</code>	518
<code>DIAGnostic:HUMS:STATe</code>	518
<code>DIAGnostic:HUMS:TAgS:ALL?</code>	518
<code>DIAGnostic:HUMS:TAgS:DELeTe</code>	519
<code>DIAGnostic:HUMS:TAgS:DELeTe:ALL</code>	519
<code>DIAGnostic:HUMS:TAgS[:VALue]</code>	519
<code>SYSTem:COMMunicate:REST:ENABle</code>	520
<code>SYSTem:COMMunicate:SNMP:COMMunity:RO</code>	520
<code>SYSTem:COMMunicate:SNMP:COMMunity:RW</code>	520
<code>SYSTem:COMMunicate:SNMP:CONtAct</code>	521
<code>SYSTem:COMMunicate:SNMP:LOCation</code>	521
<code>SYSTem:COMMunicate:SNMP:USM:USER</code>	521
<code>SYSTem:COMMunicate:SNMP:USM:USER:ALL?</code>	522
<code>SYSTem:COMMunicate:SNMP:USM:USER:DELeTe</code>	522
<code>SYSTem:COMMunicate:SNMP:USM:USER:DELeTe:ALL</code>	522
<code>SYSTem:COMMunicate:SNMP:VERSion</code>	522

`DIAGnostic:HUMS:DELeTe:ALL`

Deletes the complete HUMS data. This includes device history, device tags, SCPI connections, utilization history and utilizations.

Example: `//Delete HUMS data`
 `DIAG:HUMS:DEL:ALL`

Usage: Event

`DIAGnostic:HUMS:DEViCe:HISTory?`

Queries the device history information of the connected instrument. Depending on the set data format, the queried data is either displayed in `XML` or `JSON` format. For more information about setting the data format, see `DIAGnostic:HUMS:FORMat` on page 517.

Return values:
`<HistoryInfo>` `<block_data>`

Device history information of the connected instrument as block data in a comma-separated list:

```
#blockdata[{event1},{event2},{event3}...]
```

With the following parameters:

```
<eventID>,<eventTimestamp>,<eventMessage>,<eventDetails>,<eventSeverity>
```

Binary block data with the following syntax:

```
#<Digits><Length><Binarydata>
```

#

Indicates the start of the binary block

<Digits>

Decimal value

Gives the number of decimal digits used for the <Length> value

<Length>

Decimal value

Number of bytes the follow in the <Binary data> part

<Binary data>

Binary data in ASCII format

Example:

```
//Return device history
```

```
DIAG:HUMS:DEV:HIST?
```

Returns for example:

```
#44715[{"eventId":32,"eventTimestamp":
"2021-02-02T17:25:39Z","eventMessage":
"Deviation from Self Alignment Temperature",
"eventDetails":
"Deviations resolved","eventSeverity":0}]
```

Usage:

Query only

Manual operation: See ["Export History"](#) on page 434

DIAGnostic:HUMS:DEvice:HISTory:DELeTe:ALL

Deletes the complete device history information of the connected instrument.

Example:

```
//Delete complete device history
```

```
DIAG:HUMS:DEV:HIST:DEL:ALL
```

Usage:

Event

Manual operation: See ["Delete History"](#) on page 434

DIAGnostic:HUMS:FORMat <DataFormat>

Selects the format for the queried HUMS data. You can query the HUMS data either in JSON format or XML format.

The defined format affects all other commands that return block data.

Parameters:

<DataFormat> JSON | XML

JSON

Returns the HUMS data in `JSON` format.

XML

Returns the HUMS data in `XML` format.

*RST: JSON

Example: //Return data in `JSON` format
 DIAG:HUMS:FORM JSON

DIAGnostic:HUMS:SAVE <path>

Saves the HUMS history as a `ZIP` file to your preferred path.

Setting parameters:

<path>

Example: //Save HUMS history data
 DIAG:HUMS:SAVE 'C:\HUMS\hums_2021.zip'

Usage: Setting only

Manual operation: See ["Export History"](#) on page 434

DIAGnostic:HUMS:STATe <State>

Turns the HUMS service and data collection on and off.

Parameters:

<State> ON | OFF | 1 | 0
 *RST: ON

Example: //Turn on HUMS service
 DIAG:HUMS:STAT ON

Manual operation: See ["State"](#) on page 434

DIAGnostic:HUMS:TAgS:ALL?

Queries all key-value tags that you have assigned to the instrument. Depending on the set data format, the queried data is either displayed in `XML` or `JSON` format. For more information about setting the data format, see [DIAGnostic:HUMS:FORMat](#) on page 517.

Return values:

<ID> ID number of the defined tag.
 <Key> String containing key name of the defined tag.
 <Value> String containing value of the defined tag.

Example: //Return all tags
 DIAG:HUMS:TAgS:ALL?
 1,"location","building_11",2,"time zone","CET"

Usage: Query only
Manual operation: See ["Add"](#) on page 443

DIAGnostic:HUMS:TAGS:DELeTe <ID>

Deletes a certain tag you assigned to your instrument, including its key and value.

Setting parameters:

<ID> ID number of the tag you want to delete.
 To identify the ID number, query all device tags from the system first. For more information, see [DIAGnostic:HUMS:TAGS:ALL?](#) on page 518.

Example: //Delete tag
 DIAG:HUMS:TAGS:DEL 0

Usage: Setting only
Manual operation: See ["Delete"](#) on page 443

DIAGnostic:HUMS:TAGS:DELeTe:ALL

Deletes all key-value tags you have assigned to the instrument.

Example: //Delete all tags
 DIAG:HUMS:TAGS:DEL:ALL

Usage: Event
Manual operation: See ["Delete All"](#) on page 443

DIAGnostic:HUMS:TAGS[:VALue] <ID>, <Key>, <Value>

DIAGnostic:HUMS:TAGS[:VALue]? <ID>

Adds or modifies a key-value pair (device tag).

The query returns the key-value pair for a given ID or an empty string if the ID is unknown.

Parameters:

<Key> String containing key name of the queried tag.
<Value> String containing value of the queried tag.

Parameters for setting and query:

<ID> 0 - 31
 ID number of the tag you want to modify or query.
 To identify the ID number, query all device tags from the system first. For more information, read here [DIAGnostic:HUMS:TAGS:ALL?](#) on page 518.

Example: //Add or modify a tag (tag 1)
 DIAG:HUMS:TAGS 1,'location','building_11'

Manual operation: See ["Key"](#) on page 442

SYSTem:COMMunicate:REST:ENABLE <RestState>

Turns communication via the REST API on and off.

Parameters:

<RestState> ON | OFF | 0 | 1

Example:

```
//Return REST state
SYST:COMM:REST:ENAB?
```

Manual operation: See ["REST"](#) on page 436

SYSTem:COMMunicate:SNMP:COMMunity:RO <CommunityString>

Defines the SNMP community string for read-only access.

Prerequisites for this command:

- Select an SNMP version that supports communities ([SYSTem:COMMunicate:SNMP:VERSion](#) on page 522).

Setting parameters:

<CommunityString> String containing the community name.

Example:

```
//Set community name
SYST:COMM:SNMP:VERS V12
SYST:COMM:SNMP:COMM:RO 'ABC'
```

Usage:

Setting only

Manual operation: See ["Read Only Community"](#) on page 436

SYSTem:COMMunicate:SNMP:COMMunity:RW <CommunityString>

Defines the SNMP community string for read-write access.

Prerequisites for this command:

- Select an SNMP version that supports communities ([SYSTem:COMMunicate:SNMP:VERSion](#) on page 522).

Setting parameters:

<CommunityString> String containing the community name.

Example:

```
//Set read-write access
SYST:COMM:SNMP:VERS V12
SYST:COMM:SNMP:COMM:RW 'ABC'
```

Usage:

Setting only

Manual operation: See ["Read&Write Community"](#) on page 437

SYSTem:COMMunicate:SNMP:CONtact <SnmpContact>

Defines the SNMP contact information for the administrator.

You can also set the contact information via SNMP if you do not set it via SCPI.

Parameters for setting and query:

<SnmpContact> String containing SNMP contact.
 *RST: "" (empty string)

Example: //Set SNMP contact
 SYST:COMM:SNMP:CONT 'ABC'

Manual operation: See ["Contact"](#) on page 436

SYSTem:COMMunicate:SNMP:LOCation <SnmpLocation>

Defines the SNMP location information for the administrator.

You can also set the location information via SNMP if you do not set it via SCPI.

Parameters for setting and query:

<SnmpLocation> String containing SNMP location.
 *RST: "" (empty string)

Example: //Return SNMP location
 SYST:COMM:SNMP:LOC?

Manual operation: See ["Location"](#) on page 436

SYSTem:COMMunicate:SNMP:USM:USER <Name>, <Access>, <Level>[, <Auth_pwd>[, <Priv_pwd>]]

Defines an SNMP user profile.

Prerequisites for this command:

- Select SNMPv3 ([SYSTem:COMMunicate:SNMP:VERSion](#) on page 522).

Setting parameters:

<Name> String containing name of the user.
 <Access> RO | RW
 Defines the access right a user can have.
 <Level> NOAuth | AUTH | PRIVacy
 Defines the security level.
 <Auth_pwd> String containing the authentication password.
 <Priv_pwd> String containing the privacy password.

Example: //Create user profile
 SYST:COMM:SNMP:VERS V123
 SYST:COMM:SNMP:USM:USER 'Peter', 'RO', 'PRIV',
 '1234', 'XYZ'

Usage: Setting only

Manual operation: See ["Add SNMP User for HUMS"](#) on page 439

SYSTem:COMMunicate:SNMP:USM:USER:ALL?

Queries the number of users and a list of all SNMP users for SNMPv3.

Prerequisites for this command:

- Select SNMPv3 ([SYSTem:COMMunicate:SNMP:VERsion](#) on page 522).

Return values:

<Count> Total number of registered SNMP users.

<Name> List of all user names as a comma-separated list.

Example: //Return all SNMP users
SYST:COMM:SNMP:USM:USER:ALL?

Usage: Query only

Manual operation: See ["User table"](#) on page 438

SYSTem:COMMunicate:SNMP:USM:USER:DELeTe <UserName>

Deletes a specific SNMP user profile.

Setting parameters:

<UserName> String containing name of SNMP user profile to be deleted.

Example: //Delete SNMP user profile
SYST:COMM:SNMP:USM:USER:DEL "Peter"

Usage: Setting only

Manual operation: See ["Delete"](#) on page 439

SYSTem:COMMunicate:SNMP:USM:USER:DELeTe:ALL

Deletes all SNMP user profiles.

Example: //Delete all SNMP user profiles
SYST:COMM:SNMP:USM:USER:DEL:ALL

Usage: Event

Manual operation: See ["Delete All"](#) on page 438

SYSTem:COMMunicate:SNMP:VERsion <SnmVersion>

Selects the SNMP version.

Parameters for setting and query:

<SnmVersion> OFF | V12 | V123 | V3 | DEFault

OFF

SNMP communication is off.

V12

SNMP communication with SNMPv2 or lower.

V123

SNMP communication with SNMPv2 and SNMPv3.

V3

SNMP communication with SNMPv3.

*RST: V123

Example:

```
//Select the SNMP version
SYST:COMM:SNMP:VERS V12
```

Manual operation: See ["SNMP"](#) on page 436

15.10 DISPlay subsystem

The DISPlay system contains the commands to set the power-save mode of the instrument.

Programming Examples

Example: Activating screen saver mode and display update

Use the following commands to switch on the screen saver of your instrument or to automatic display. These settings are particularly useful when you control the instrument remotely.

```
// Set the wait time interval and activate the screen saver
DISPlay:PSAVE:HOLDoff 10
DISPlay:PSAVE:STATE ON

// Disable the display of the current frequency and level values in remote control
DISPlay:ANNotation:ALL "<password>", ON
// DISPlay:ANNotation:FREQuency "<password>", ON
// DISPlay:ANNotation:AMPLitude "<password>", ON

// Enable automatic update of the display at defined time intervals
DISPlay:UPDATE[:STATE] ON
```

Example: Querying the dialog IDs, opening and closing dialogs

Use the following commands to query the dialog IDs of all currently open dialogs. The dialog ID is a prerequisite for opening and closing dialogs via the remote control.



The dialog ID is also required to define user key actions.

See [Section 13.2.2, "How to assign actions to the \[★ \(User\)\] key"](#), on page 376.

```
// Query the dialog IDs of all open dialogs
DISPlay:DIALog:ID?
// CEUtraDLGenSetDlg,_, $A DlgKeyRf_Rosc

// Open and close dialogs via remote control
DISPlay:DIALog:OPEN "CEUtraDLGenSetDlg,_, $A"
DISPlay:DIALog:OPEN "DlgKeyRf_Rosc"
DISPlay:DIALog:CLOSe "DlgKeyRf_Rosc"
DISPlay:DIALog:CLOSe:ALL

:DISPlay:PSAVe:HOLDoff..... 524
:DISPlay:PSAVe[:STATe]..... 524
:DISPlay:BRIGhtness..... 525
:DISPlay:BUTTon:BRIGhtness..... 525
:DISPlay:UPDate[:STATe]..... 525
:DISPlay:ANNotation:AMPLitude..... 525
:DISPlay:ANNotation:FREQuency..... 526
:DISPlay:ANNotation[:ALL]..... 526
:DISPlay:DIALog:ID?..... 526
:DISPlay:DIALog:OPEN..... 527
:DISPlay:DIALog:CLOSe..... 527
:DISPlay:DIALog:CLOSe:ALL..... 528
```

:DISPlay:PSAVe:HOLDoff <HoldoffTimeMin>

Sets the wait time for the screen saver mode of the display.

Parameters:

<HoldoffTimeMin> integer
 Range: 1 to 60
 *RST: n.a. (factory preset: 10)
 Default unit: minute

Example: see [Example "Activating screen saver mode and display update"](#)
 on page 523

Manual operation: See ["Wait Time"](#) on page 368

:DISPlay:PSAVe[:STATe] <State>

Activates the screen saver mode of the display.

We recommend that you use this mode to protect the display, if you operate the instrument in remote control.

To define the wait time, use the command **:DISPlay:PSAVe:HOLDoff**.

Parameters:

<State> 1 | ON | 0 | OFF
 *RST: n.a. (factory preset: 0)

Example: See [Example "Activating screen saver mode and display update"](#) on page 523

Manual operation: See ["Screen Saver"](#) on page 368

:DISPlay:BRIGhtness <BRIGhtness>

Sets the brightness of the display.

Parameters:

<BRIGhtness> float
 Range: 1.0 to 20.0
 Increment: 1.0
 *RST: 14.0

Example: DISPlay:BRIGhtness 14

Manual operation: See ["Display"](#) on page 368

:DISPlay:BUtTon:BRIGhtness <ButtonBrightnes>

Sets the brightness of the [RF on/off] key.

Parameters:

<ButtonBrightnes> integer
 Range: 1 to 20
 *RST: n.a. (no preset. default: 14)

Example: DISPlay:BUtTon:BRIGhtness 15

Manual operation: See ["RF Hardkey"](#) on page 369

:DISPlay:UPDate[:STATe] <Update>

Activates the refresh mode of the display.

Parameters:

<Update> 1 | ON | 0 | OFF
 *RST: n.a. (factory preset: 1)

Example: See [Example "Activating screen saver mode and display update"](#) on page 523

Manual operation: See ["Display Update is"](#) on page 369

:DISPlay:ANNotation:AMPLitude <SecPassword>, <State>

Indicates asterisks instead of the level values in the status bar.

Parameters:

<SecPassword> string
 <State> 1 | ON | 0 | OFF
 *RST: n.a. (factory preset: 1)

Example: See [Example "Activating screen saver mode and display update"](#) on page 523

Manual operation: See ["Annotation Amplitude"](#) on page 393

:DISPlay:ANNOtation:FREQuency <SecPassWord>, <State>

Indicates asterisks instead of the frequency values in the status bar.

Parameters:

<SecPassWord> string

<State> 1 | ON | 0 | OFF

*RST: n.a. (factory preset: 1)

Example: See [Example "Activating screen saver mode and display update"](#) on page 523

Manual operation: See ["Annotation Frequency"](#) on page 392

:DISPlay:ANNOtation[:ALL] <SecPassword>, <State>

Displays asterisks instead of the level and frequency values in the status bar of the instrument.

We recommend that you use this mode if you operate the instrument in remote control.

Parameters:

<SecPassword> string

<State> 1 | ON | 0 | OFF

*RST: 1

Example: See [Example "Activating screen saver mode and display update"](#) on page 523

:DISPlay:DIALog:ID?

Returns the dialog identifiers of the open dialogs in a string separated by blanks.

Return values:

<DialogIdList> <DialogID#1>< ><DialogID#2>< > ... < ><DialogID#n>

Dialog identifiers are string without blanks. Blanks are represented as \$\$.

Dialog identifiers <DialogID> are composed of two main parts:
<DialogName> [<OptionalParts>]

<DialogName>

Meaningful information, mandatory input parameter for the commands:

[:DISPlay:DIALog:OPEN](#) on page 527

[:DISPlay:DIALog:CLOSe](#) on page 527

<Optional parts>

String of \$<X> values, where <X> is a character, interpreted as follows:

\$q<DialogQualifier>: optional dialog qualifier, usually the letter A or B, as displayed in the dialog title.

\$i<Instances>: comma-separated list of instance indexes, given in the order h, c, s, d, g, u, 0. Default is zero; the terminating ", 0" can be omitted.

\$t<TabIds>: comma-separated indexes or tab names; required, if a dialog is composed of several tabs.

\$x<Left>\$y<Top>\$h<Left>\$w<Top>: position and size; superfluous information.

Example: See [Example "Querying the dialog IDs, opening and closing dialogs"](#) on page 523

Usage: Query only

Manual operation: See ["SCPI"](#) on page 379

:DISPlay:DIALog:OPEN <DialogId>

Opens the specified dialog.

Setting parameters:

<DialogId> string

To find out the dialog identifier, use the query [:DISPlay:DIALog:ID?](#).

The <DialogName> part of the query result is mandatory.

Example: See [Example "Querying the dialog IDs, opening and closing dialogs"](#) on page 523

Usage: Setting only

Manual operation: See ["SCPI"](#) on page 379

:DISPlay:DIALog:CLOSe <DialogId>

Closes the specified dialog.

Setting parameters:

<DialogId> string

To find out the dialog identifier, use the query [:DISPlay:DIALog:ID?](#).

The <DialogName> part of the query result is sufficient.

Example: See [Example "Querying the dialog IDs, opening and closing dialogs"](#) on page 523

Usage: Setting only

:DISPlay:DIALog:CLOSe:ALL

Closes all open dialogs.

Example: See [Example "Querying the dialog IDs, opening and closing dialogs"](#) on page 523

Usage: Event

15.11 FORMat subsystem

The commands in the FORMat subsystem determine the format of data returned by the R&S SMA100B to the controller. This affects all query commands that return a list of numerical data or block data, noted in the descriptions of the commands. The set data format applies to both paths.

Example: Configuring the format of data returned to a controller

```
// Select the format to be returned by the instrument
//
FORMat:BORDer SWAPped
// returns the most significant byte of each floating point
// number first and the least significant byte last

FORMat:SREGister: HEXadecimal
// returns the content of the status register
// as a hexadecimal number

FORMat:DATA ASCii
// transfers the data in ASCII format
```

:FORMat:BORDer	528
:FORMat:SREGister	529
:FORMat[:DATA]	529

:FORMat:BORDer <Border>

Determines the sequence of bytes within a binary block. This only affects blocks which use the IEEE754 format internally.

Parameters:

<Border> NORMal | SWAPped

NORMal

Expects/sends the *least* significant byte of each IEEE754 floating-point number first and the *most* significant byte last.

SWAPped

Expects/sends the *most* significant byte of each IEEE754 floating-point number first and the *least* significant byte last.

*RST: NORMal

Example:

:FORM:BORD SWAP

transfers the data with the most significant bit first.

:FORMat:SREGister <Format>

Determines the numeric format for responses of the status register.

Parameters:

<Format> ASCii | BINary | HEXadecimal | OCTal

ASCii

Returns the register content as a decimal number.

BINary|HEXadecimal|OCTal

Returns the register content either as a binary, hexadecimal or octal number. According to the selected format, the number starts with #B (binary), #H (hexadecimal) or #O (octal).

*RST: ASCii

Example:

:FORM:SREG HEX

returns the register content as a hexadecimal number.

:FORMat[:DATA] <Data>

Determines the data format the instrument uses to return data via the IEC/IEEE bus.

The instrument automatically detects the data format used by the controller, and assigns it accordingly. Data format determined by this SCPI command is in this case irrelevant.

Parameters:

<Data> ASCii | PACKed

ASCii

Transfers numerical data as plain text separated by commas.

PACKed

Transfers numerical data as binary block data.

The format within the binary data depends on the command.

The various binary data formats are explained in the description of the parameter types.

*RST: ASCii

Example:

:FORM ASC

transfers the data as ASCII data.

15.12 HCOPI subsystem

The HCOPI subsystem contains the commands to generate and save a hard copy of the display.



To access a stored hard copy file, use the commands of the `MEMM` subsystem.

Example: Store a hard copy of the display

The following example lists commands to configure and execute a hard copy to an automatic named file.

```
:HCOpy:DEvIce:LANGuage PNG
:HCOpy:FILE:NAME:AUTO:STATe 1
// defines the output format
// sets the instrument to automatically create output file names

// *****
// Configure hard copy options, set automatic naming rules
// An automatically generated file name consists of:
// <Prefix><YYYY><MM><DD><Number>.<Format>
// *****
:HCOpy:DEvIce:LANGuage BMP
// defines output format *.bmp
:HCOpy:REGion DIALog
// selects the region to be copied
:HCOpy:FILE:AUTO:DIR "/usb/HCOpy"
// sets destination directory of automatic named file
:HCOpy:FILE:NAME:AUTO:FILE:PREFix:STATe 1
:HCOpy:FILE:NAME:AUTO:FILE:PREFix:"hardcopy"
:HCOpy:FILE:NAME:AUTO:FILE:YEAR:STATe 1
:HCOpy:FILE:NAME:AUTO:FILE:MONTh:STATe 1
// uses automatic naming prefix
// sets automatic naming prefix to "hardcopy"
// uses automatic naming date parameters year and month

// *****
// Execute and transfer the hard copy
// *****
:HCOpy:EXECute
:HCOpy:DATA
// generates a hard copy
// transfers the hard copy to the remote client
:HCOpy:FILE:AUTO:FILE?
// queries the automatic file name
// "hardcopy1607001.bmp"
:HCOpy:FILE:AUTO:NUMBer?
// queries the number in the automatic file name
// "001"
:HCOpy:FILE:AUTO?
// queries the path and file name of the automatically generated file
// "/usb/HCOpy/hardcopy1607001.bmp"
```

15.12.1 Hard copy settings

With the following commands, you can configure the settings of a hard copy.

:HCOPY:DATA?	531
:HCOPY:IMAGe:FORMat	531
:HCOPY:DEVIce:LANGuage	531
:HCOPY:REGion	531
:HCOPY:FILE[:NAME]	531
:HCOPY[:EXECute]	532

:HCOPY:DATA?

Transfers the hard copy data directly as a NByte stream to the remote client.

Return values:

<Data> block data

Example: See [Example "Store a hard copy of the display"](#) on page 530

Usage: Query only

:HCOPY:IMAGe:FORMat <Format>

:HCOPY:DEVIce:LANGuage <Language>

Selects the graphic format for the hard copy. You can use both commands alternatively.

Parameters:

<Language> BMP | JPG | XPM | PNG
 *RST: PNG

Example: See [Example "Store a hard copy of the display"](#) on page 530

Manual operation: See ["Format"](#) on page 362

:HCOPY:REGion <Region>

Selects the area to be copied.

You can create a snapshot of the screen or an active dialog.

Parameters:

<Region> ALL | DIALog
 *RST: ALL

Example: See [Example "Store a hard copy of the display"](#) on page 530

Manual operation: See ["Region"](#) on page 362

:HCOPY:FILE[:NAME] <Name>

Determines the file name and path to save the hard copy, provided automatic naming is disabled.

Note: If you have enabled automatic naming, the instrument automatically generates the file name and directory, see [Section 15.12.2, "Automatic naming"](#), on page 532.

Parameters:

<Name> string

Example: See [Example "Store a hard copy of the display"](#) on page 530

Manual operation: See ["File..."](#) on page 361

:HCOPY[:EXECute]

Generates a hard copy of the current display. The output destination is a file.

Example: See [Example "Store a hard copy of the display"](#) on page 530

Usage: Event

Manual operation: See ["Save"](#) on page 362

15.12.2 Automatic naming

Use the following commands to automatically assign a file name.

:HCOPY:FILE[:NAME]:AUTO?	532
:HCOPY:FILE[:NAME]:AUTO:DIReCTory	532
:HCOPY:FILE[:NAME]:AUTO:DIReCTory:CLEAr	533
:HCOPY:FILE[:NAME]:AUTO:FILE?	533
:HCOPY:FILE[:NAME]:AUTO:STATe	533
:HCOPY:FILE[:NAME]:AUTO[:FILE]:DAY:STATe	534
:HCOPY:FILE[:NAME]:AUTO[:FILE]:MONTH:STATe	534
:HCOPY:FILE[:NAME]:AUTO[:FILE]:YEAR:STATe	534
:HCOPY:FILE[:NAME]:AUTO[:FILE]:NUMBer?	534
:HCOPY:FILE[:NAME]:AUTO[:FILE]:PREFix	534
:HCOPY:FILE[:NAME]:AUTO[:FILE]:PREFix:STATe	534

:HCOPY:FILE[:NAME]:AUTO?

Queries path and file name of the hardcopy file, if you have enabled *Automatic Naming*.

Return values:

<Auto> string

Example: See [Example "Store a hard copy of the display"](#) on page 530

Usage: Query only

:HCOPY:FILE[:NAME]:AUTO:DIReCTory <Directory>

Determines the path to save the hard copy, if you have enabled *Automatic Naming*.

If the directory does not yet exist, the instrument automatically creates a new directory, using the instrument name and `/var/user/` by default.

Parameters:

<Directory> string
 *RST: /var/user/

Example: See [Example "Store a hard copy of the display"](#) on page 530

Manual operation: See ["Path..."](#) on page 363

:HCOPY:FILE[:NAME]:AUTO:DIRectory:CLEar

Deletes all files with extensions `*.bmp`, `*.jpg`, `*.png` and `*.xpm` in the directory set for automatic naming.

Example: See [Example "Store a hard copy of the display"](#) on page 530

Usage: Event

Manual operation: See ["Clear Path"](#) on page 363

:HCOPY:FILE[:NAME]:AUTO:FILE?

Queries the name of the automatically named hard copy file.

An automatically generated file name consists of:

<Prefix><YYYY><MM><DD><Number>.<Format>.

You can activate each component separately, to individually design the file name.

Return values:

<File> string

Example: See [Example "Store a hard copy of the display"](#) on page 530.

Usage: Query only

:HCOPY:FILE[:NAME]:AUTO:STATe <State>

Activates automatic naming of the hard copy files.

Parameters:

<State> 1 | ON | 0 | OFF
 *RST: 1

Example: See [Example "Store a hard copy of the display"](#) on page 530

Manual operation: See ["Automatic Naming"](#) on page 362

```
:HCOPY:FILE[:NAME]:AUTO[:FILE]:DAY:STATe <State>
:HCOPY:FILE[:NAME]:AUTO[:FILE]:MONTH:STATe <State>
:HCOPY:FILE[:NAME]:AUTO[:FILE]:YEAR:STATe <State>
```

Uses the date parameters (year, month or day) for the automatic naming. You can activate each of the date parameters separately.

Parameters:

```
<State>          1 | ON | 0 | OFF
*RST:           1
```

Example: See [Example "Store a hard copy of the display"](#) on page 530

Manual operation: See ["Prefix, Year, Month, Day"](#) on page 363

```
:HCOPY:FILE[:NAME]:AUTO[:FILE]:NUMBER?
```

Queries the number that is used as part of the file name for the next hard copy in automatic mode.

At the beginning, the count starts at 0. The R&S SMA100B searches the specified output directory for the highest number in the stored files. It increases this number by one to achieve a unique name for the new file.

The resulting auto number is appended to the resulting file name with at least three digits.

Return values:

```
<Number>         integer
Range:           0 to 999999
*RST:            0
```

Example: See [Example "Store a hard copy of the display"](#) on page 530

Usage: Query only

Manual operation: See ["Current Auto Number"](#) on page 364

```
:HCOPY:FILE[:NAME]:AUTO[:FILE]:PREFIX <Prefix>
:HCOPY:FILE[:NAME]:AUTO[:FILE]:PREFIX:STATe <State>
```

Uses the prefix for the automatic generation of the file name, provided `PREF:STAT` is activated.

Parameters:

```
<State>          1 | ON | 0 | OFF
*RST:           1
```

Example: See [Example "Store a hard copy of the display"](#) on page 530

Manual operation: See ["Prefix, Year, Month, Day"](#) on page 363

15.13 KBOard subsystem

The KBOard subsystem contains the commands to set a connected keyboard.

Example: Configuring the keypad

```
KBOard:LAYout US
// sets the American keyboard assignment

FPANel:KEYBoard:LAYout LETTers
// enables the alphanumerical and the
// numerical assignment of the front panel keys.
```

```
:FPANel:KEYBoard:LAYout..... 535
:KBOard:LAYout.....535
```

:FPANel:KEYBoard:LAYout <Layout>

Selects the layout of the front panel keypad.

Parameters:

<Layout> DIGits | LETTers

DIGits
Enables numerical keys only.

LETTers
Enables numerical and alphanumerical keys.

*RST: n.a. (factory preset: DIGits)

Example:

```
:FPANel:KEYBoard:LAYout LETTers
// enables the alphanumerical additional
// and the numerical assignment of the keys.
```

Manual operation: See "[Alphanumeric Keys](#)" on page 369

:KBOard:LAYout <Layout>

Selects the language for an external keyboard and assigns the keys accordingly.

Parameters:

<Layout> CHINese | DANish | DUTCh | ENGLish | ENGUK | FINNish |
FRENch | FREBe | FRECa | GERMan | ITALian | JAPANese |
KOREan | NORWegian | PORTuguese | RUSSian | SPANish |
SWEDish | ENGUS

*RST: n.a. (factory preset: ENGLish)

Example:

```
:KBOard:LAYout US
// activates American keyboard
```

Manual operation: See "[Layout](#)" on page 369

15.14 OUTPut subsystem

In the OUTPut subsystem, you can configure the output signals.

The LF output signal is defined with the commands of the [Section 15.18.7](#), "SOURce:LFOutput subsystem", on page 710 system.

Common suffixes

The following common suffixes are used in remote commands:

Suffix	Value range	Description
OUTPut<hw>	[1]	Optional suffix

:OUTPut:ALL[:STATe].....	536
:OUTPut<hw>[:STATe].....	536
:OUTPut<hw>[:STATe]:PON.....	537
:OUTPut<hw>:AMODE.....	537
:OUTPut<hw>:FILTer:MODE.....	537
:OUTPut<hw>:IMPedance?.....	538
:OUTPut:FPRoportional:SCALE.....	538
:OUTPut:USER:MARKer.....	538
:OUTPut<hw>:AFIXed:RANGe:LOWer?.....	539
:OUTPut<hw>:AFIXed:RANGe:UPPer?.....	539
:OUTPut<hw>:PROTection:CLEar.....	539
:OUTPut<hw>:PROTection:TRIPped?.....	539

:OUTPut:ALL[:STATe] <State>

Enables the RF output signal of the instrument.

Parameters:

<State> 1 | ON | 0 | OFF
 *RST: n.a. (factory preset: 0)

Example: OUTPut:ALL:STATe 0
 Disables the RF output signal.

:OUTPut<hw>[:STATe] <State>

Activates the RF output signal.

Parameters:

<State> 1 | ON | 0 | OFF
 *RST: 0

Example: :OUTPut1 ON
 Activates the RF output.

Manual operation: See "RF State/RF ON" on page 61

:OUTPut<hw>[:STATe]:PON <Pon>

Defines the state of the RF output signal when the instrument is switched on.

Parameters:

<Pon> OFF | UNCHanged
 *RST: n.a. (factory preset: UNCHanged)

Example:

:OUTPut1:PON OFF
 The RF output is deactivated when the instrument is switched on.

Manual operation: See ["Power-On State"](#) on page 370

:OUTPut<hw>:AMODE <AMode>

Sets the step attenuator mode at the RF output.

Parameters:

<AMode> AUTO | FIXed | NORMal | HPOWer

AUTO

The step attenuator adjusts the level settings automatically, within the full variation range.

FIXed

The step attenuator and amplifier stages are fixed at the current position, providing level settings with constant output VSWR. The resulting variation range is calculated according to the position.

*RST: AUTO

Example:

:SOURce1:POWer:ALC:STATe 1
 :OUTPut1:AMODE FIXed

Manual operation: See ["Mode"](#) on page 230

:OUTPut<hw>:FILTER:MODE <Mode>

Activates low harmonic filter or enables its automatic switching.

Parameters:

<Mode> ON | AUTO | 1

ON|1

Ensures best low harmonics performance but decreases the level range

AUTO

Applies an automatically selected harmonic filter that fits to the current level setting.

*RST: AUTO

Example:

:OUTPut1:FILTER:MODE AUTO

Manual operation: See ["Harmonic Filter"](#) on page 73

:OUTPut<hw>:IMPedance?

Queries the impedance of the RF outputs.

Return values:

<Impedance> G1K | G50 | G10K
*RST: G50

Example:

:OUTPut1:IMP?
queries the impedance of RF output.
Response: 50
the impedance is 50 ohms

Usage: Query only

Manual operation: See ["RF output impedance"](#) on page 61

:OUTPut:FPRoportional:SCALE <OutpSelScale>

Selects the mode the voltage is supplied depending on the frequency.

The R&S SMA100B supplies the signal at the V/GHz X-Axis connector.

Parameters:

<OutpSelScale> S0V25 | S0V5 | S1V0 | XAXis

S0V25|S0V5|S1V0

Supplies the voltage proportional to the set frequency, derived from the selected setting.

XAXis

Supplies a voltage range from 0 V to 10 V proportional to the frequency sweep range, set with [\[:SOURce<hw>\]:FREQuency:START](#) and [\[:SOURce<hw>\]:FREQuency:STOP](#).

*RST: S0V25

Options: R&S SMAB-B28

Manual operation: See ["V/GHz / X-Axis"](#) on page 215

:OUTPut:USER:MARKer <SelUserMarker>

Selects the signal for output at the Marker User1 connector.

Parameters:

<SelUserMarker> MARK | USER

MARK

Assigns a marker signal to the output.

USER

Intended for future use.

*RST: MARK

Options: R&S SMAB-B28

Manual operation: See ["Marker / User"](#) on page 215

:OUTPut<hw>:AFIXed:RANGe:LOWer?
:OUTPut<hw>:AFIXed:RANGe:UPPer?

Queries the settable minimum/maximum value in mode :OUTPut:AMODE FIXed, i.e. when the attenuator is not being adjusted.

See :OUTPut<hw>:AMODE on page 537

Return values:

<Upper> float
Increment: 0.01
Default unit: dBm

Example:

```
:OUTPut1:AMODE FIXed
:OUTPut1:AFIXed:RANGe:UPPer?
// -27
:OUTPut1:AFIXed:RANGe:LOW?
// -50
```

Usage: Query only

Manual operation: See "Level Range" on page 230

:OUTPut<hw>:PROTection:CLEar

Resets the protective circuit after it has been tripped.

To define the output state, use the command :OUTPut<hw>[:STATE].

Example:

```
:OUTPut1:PROT:CLE
Resets the protective circuit of the RF output.
```

Usage: Event

Manual operation: See "Overload" on page 231

:OUTPut<hw>:PROTection:TRIPped?

Queries the state of the protective circuit.

Return values:

<Tripped> 1 | ON | 0 | OFF
*RST: 0

Example:

```
:OUTPut1:PROT:TRIP
queries the state of the protective circuit of the RF output.
Response: 0
the protective circuit has not tripped.
```

Usage: Query only

Manual operation: See "Overload" on page 231

15.15 Power sensor measurement subsystems

The power sensor measurement uses several subsystems:

- The `CALCulate` subsystem is used to configure the time gated measurements in power analysis.
- The `DISPlay` subsystem is used to configure the diagram appearance.
- The `INITiate` command switches the local state of the continuous power measurement on and off.
- The `READ` system is used to start and to retrieve the measurement result of the power viewer measurement.
- The `SENSe` subsystem contains the commands for configuring the power viewer and power analysis measurements with power sensors connected to the generator. Up to four sensors can be connected to the signal generator.
- The `TRACe` subsystem is used to configure the traces in power analysis and to retrieve the measurement results.

Power Viewer

The power viewer measurement is started with the `READ` command, this command also retrieves the measurement results.

The sensors are distinguished by the suffix under `SENSe`:

- Power sensor connected to the `SENSOR` port = `SENSe[1]`
- First Power sensor connected to the USB interface = `SENSe2`
- Second Power sensor connected to the USB interface = `SENSe3`
- Third Power sensor connected to the USB interface = `SENSe4`

Power and Pulse Data Analysis, Gated Measurements (option R&S SMA100B-K28)

The power analysis measurement commands are subsumed under the `SENSe[:POWER]:SWEep:...` commands. Three measurement modes are available: Frequency, Power and Time.

The power analysis measurement is started with the `SENSe[:POWER]:SWEep:INITiate` command and the measurement result retrieved with the `TRACe[:POWER]:SWEep:...` commands.

The four sensors are distinguished by the suffix at the second key word `SENSe`.

The time gate settings are performed using the `CALCulate[:POWER]:SWEep:...` commands.

The measurement diagram and results can be stored in a hardcopy with the `SENSe[:POWER]:SWEep:HCOPY:...` commands.

General parameter and measurement settings are valid for all connected sensors, therefore, no suffix is used in these commands.

15.15.1 CALCulate subsystem

:CALCulate[:POWer]:SWEep:FREQuency:MARKer<ch>:FEED.....	541
:CALCulate[:POWer]:SWEep:FREQuency:MARKer<ch>:STATe.....	541
:CALCulate[:POWer]:SWEep:FREQuency:MATH<ch>:STATe.....	542
:CALCulate[:POWer]:SWEep:FREQuency:MATH<ch>:SUBTract.....	542
:CALCulate[:POWer]:SWEep:FREQuency:MATH<ch>:XVAL.....	542
:CALCulate[:POWer]:SWEep:FREQuency:MATH<ch>:YVAL.....	543
:CALCulate[:POWer]:SWEep:POWer:MARKer<ch>:FEED.....	543
:CALCulate[:POWer]:SWEep:POWer:MARKer<ch>:STATe.....	543
:CALCulate[:POWer]:SWEep:POWer:MATH<ch>:STATe.....	544
:CALCulate[:POWer]:SWEep:POWer:MATH<ch>:SUBTract.....	544
:CALCulate[:POWer]:SWEep:POWer:MATH<ch>:XVAL.....	544
:CALCulate[:POWer]:SWEep:POWer:MATH<ch>:YVAL.....	545
:CALCulate[:POWer]:SWEep:TIME:GATE<ch>:AVERAge?.....	545
:CALCulate[:POWer]:SWEep:TIME:GATE<ch>:FEED.....	546
:CALCulate[:POWer]:SWEep:TIME:GATE<ch>:MAXimum?.....	546
:CALCulate[:POWer]:SWEep:TIME:GATE<ch>:START.....	546
:CALCulate[:POWer]:SWEep:TIME:GATE<ch>:STOP.....	546
:CALCulate[:POWer]:SWEep:TIME:GATE<ch>:STATe.....	547
:CALCulate[:POWer]:SWEep:TIME:MARKer<ch>:FEED.....	547
:CALCulate[:POWer]:SWEep:TIME:MARKer<ch>:STATe.....	547
:CALCulate[:POWer]:SWEep:TIME:MATH<ch>:STATe.....	548
:CALCulate[:POWer]:SWEep:TIME:MATH<ch>:SUBTract.....	548
:CALCulate[:POWer]:SWEep:TIME:MATH<ch>:XVAL.....	548
:CALCulate[:POWer]:SWEep:TIME:MATH<ch>:YVAL.....	549

:CALCulate[:POWer]:SWEep:FREQuency:MARKer<ch>:FEED <MarkerBinding>

Selects the marker for frequency measurement. Each marker is bound to one of the traces.

Parameters:

<MarkerBinding> TRAC1 | TRAC2 | TRAC3 | TRACe1 | TRACe2 | TRACe3 |
 TRAC4 | TRACe4
 *RST: TRAC1

Example:

```
CALCulate:SWEep:FREQuency:MARKer1:FEED TRACe4
// Assigns the marker to trace 4.
```

Manual operation: See "Trace - Power Analysis" on page 277

:CALCulate[:POWer]:SWEep:FREQuency:MARKer<ch>:STATe <MarkerState>

Enables the frequency marker for the selected trace.

Parameters:

<MarkerState> 1 | ON | 0 | OFF
 *RST: 1

Example: `CALCulate:SWEep:FREQuency:MARKer1:STATe 1`
 // enables marker 1 for frequency measurement

Manual operation: See ["Marker x Visible - Power Analysis"](#) on page 277

:CALCulate[:POWer]:SWEep:FREQuency:MATH<ch>:STATe <State>

Activates the trace mathematics mode for "Frequency" measurement. This feature enables you to calculate the difference between the measurement values of two traces. For further calculation, a math result can also be assigned to a trace.

Parameters:

<State> 1 | ON | 0 | OFF
 *RST: 0

Example: `CALC:POW:SWE:FREQ:MATH2:STATe`
 Switches on math mode in trace 2.

Options: Option R&S SMAB-K28

Manual operation: See ["Mathematics - Trace Power Analysis"](#) on page 274

:CALCulate[:POWer]:SWEep:FREQuency:MATH<ch>:SUBTract <Subtract>

Subtracts the operands 1 and 2 and assigns the result to the selected trace in "Frequency" measurement mode.

Parameters:

<Subtract> T1T1 | T1T2 | T1T3 | T1T4 | T1REf | T2T1 | T2T2 | T2T3 | T2T4 |
 T2REf | T3T1 | T3T2 | T3T3 | T3T4 | T3REf | T4T1 | T4T2 |
 T4T3 | T4T4 | T4REf

Example: `CALC:POW:SWE:FREQ:MATH4:SUBT T2REF`
 Subtracts the Reference and Trace 2, and assigns the result to Trace 4. The resulting curve is shown in the diagram.

Options: Option R&S SMAB-K28

Manual operation: See ["Mathematics - Trace Power Analysis"](#) on page 274

:CALCulate[:POWer]:SWEep:FREQuency:MATH<ch>:XVAL <XVal>

Sets the x-axis values for calculating the reference curve in frequency measurement mode.

To determine two points ("Point A"/"Point B"), set suffix 1 and 2 in keyword `MATH<ch>`.

Parameters:

<XVal> float
 Range: 0 to 1E12
 Increment: 1
 *RST: 1E12

Example: `CALCulate:POWer:SWEep:FREQuency:MATH1:XVAL 8000`
`CALCulate:POWer:SWEep:FREQuency:MATH2:XVAL`
`1000000000`
 Sets the frequency points to calculate the reference curve.

Manual operation: See "[Freq \(X\)](#)" on page 275

:CALCulate[:POWer]:SWEep:FREQuency:MATH<ch>:YVAL <YVal>

Sets the y-axis values for calculating the reference curve in frequency measurement mode.

To determine two points ("Point A"/"Point B"), set suffix 1 and 2 in keyword `MATH<ch>`.

Parameters:

<YVal> float
 Range: 200 to 100
 Increment: 0.0001
 *RST: -40

Example: `CALCulate:POWer:SWEep:FREQuency:MATH1:YVAL -20`
`CALCulate:POWer:SWEep:FREQuency:MATH2:YVAL -20`
 Sets the power values for the two frequency points to calculate the reference curve.

Manual operation: See "[POW \(Y\)](#)" on page 275

:CALCulate[:POWer]:SWEep:POWer:MARKer<ch>:FEED <MarkerBinding>

Selects the marker for power measurement. Each marker is bound to one of the traces.

Parameters:

<MarkerBinding> TRAC1 | TRAC2 | TRAC3 | TRACe1 | TRACe2 | TRACe3 |
 TRAC4 | TRACe4
 *RST: TRAC1

Example: `CALCulate:SWEep:POWer:MARKer:FEED TRACe2`
`// Assigns the marker to trace 2.`

Manual operation: See "[Trace - Power Analysis](#)" on page 277

:CALCulate[:POWer]:SWEep:POWer:MARKer<ch>:STATe <MarkerState>

Enables the power marker for the selected trace.

Parameters:

<MarkerState> 1 | ON | 0 | OFF
 *RST: 1

Example: `CALCulate:SWEep:POWer:MARKer2:STATe 1`
`// enables marker 2 for power measurement`

Manual operation: See ["Marker x Visible - Power Analysis"](#) on page 277

:CALCulate[:POWer]:SWEep:POWer:MATH<ch>:STATe <State>

Activates the trace mathematics mode for "Power" measurement. This feature enables you to calculate the difference between the measurement values of two traces. For further calculation, a math result can also be assigned to a trace.

Parameters:

<State> 1 | ON | 0 | OFF
*RST: 0

Example: CALC:POW:SWE:POW:MATH2:STATe
Switches on math mode in trace 2.

Options: Option R&S SMAB-K28

Manual operation: See ["Mathematics - Trace Power Analysis"](#) on page 274

:CALCulate[:POWer]:SWEep:POWer:MATH<ch>:SUBTract <Subtract>

Subtracts the operands 1 and 2 and assigns the result to the selected trace in "Power" measurement mode.

Parameters:

<Subtract> T1T1 | T1T2 | T1T3 | T1T4 | T1REF | T2T1 | T2T2 | T2T3 | T2T4 |
T2REF | T3T1 | T3T2 | T3T3 | T3T4 | T3REF | T4T1 | T4T2 |
T4T3 | T4T4 | T4REF

Example: CALC:POW:SWE:POW:MATH4:SUBT T2REF
Subtracts the Reference and Trace 2, and assigns the result to Trace 4. The resulting curve is shown in the diagram.

Options: Option R&S SMAB-K28

Manual operation: See ["Mathematics - Trace Power Analysis"](#) on page 274

:CALCulate[:POWer]:SWEep:POWer:MATH<ch>:XVAL <XVal>

Sets the x-axis values for calculating the reference curve in power measurement mode.

To determine two points ("Point A"/"Point B"), set suffix 1 and 2 in keyword MATH<ch>.

Parameters:

<XVal> float
Range: -145 to 20
Increment: 0.01
*RST: 20

Example: `CALCulate:POWer:SWEep:POWer:MATH1:XVAL 8000`
`CALCulate:POWer:SWEep:POWer:MATH2:XVAL`
`1000000000`
 Sets the power points of the x-axis to calculate the reference curve.

Manual operation: See "[Pow \(X\)](#)" on page 275

:CALCulate[:POWer]:SWEep:POWer:MATH<ch>:YVAL <YVal>

Sets the y-axis values for calculating the reference curve in power measurement mode.

To determine two points ("Point A"/"Point B"), set suffix 1 and 2 in keyword `MATH<ch>`.

Parameters:

<YVal> float
 Range: -200 to 100
 Increment: 0.0001
 *RST: -40

Example: `CALCulate:POWer:SWEep:POWer:MATH1:YVAL 20`
`CALCulate:POWer:SWEep:POWer:MATH2:YVAL -30`
 Sets the power values on the y-axis for the two values defined for the x-axis to calculate the reference curve.

Manual operation: See "[Pow \(Y\)](#)" on page 276

:CALCulate[:POWer]:SWEep:TIME:GATE<ch>:AVERage?

Queries the average power value of the time gated measurement.

Return values:

<Average> float
 Range: -1000 to 1000
 Increment: 1E-12
 *RST: 0

Example: `SENS:SWE:MODE TIME`
 Activates time mode for power analysis.
`CALC:SWE:TIME:GATE:STAT ON`
 Activates time gated measurement.
`SENS:SWE:INIT`
 Activates a single power analysis measurement.
`CALC:SWE:TIME:GATE2:AVER?`
 Queries the average power in time gate 2 for trace 1 (=default).

Usage: Query only

Options: Option R&S SMAB-K28

Manual operation: See "[State - Gate](#)" on page 302

:CALCulate[:POWER]:SWEep:TIME:GATE<ch>:FEED <Feed>

Selects the trace for time gated measurement. Both gates are assigned to the same trace.

Parameters:

<Feed> TRAC1 | TRAC2 | TRAC3 | TRACe1 | TRACe2 | TRACe3 |
TRAC4 | TRACe4
*RST: TRAC1

Example:

CALC:SWE:TIME:GATE:FEED TRAC2
Assigns the gates to trace 2.

Manual operation: See "[Trace - Gate](#)" on page 301

:CALCulate[:POWER]:SWEep:TIME:GATE<ch>:MAXimum?

Queries the average power value of the time gated measurement.

Return values:

<Maximum> float
Range: -1000 to 1000
Increment: 1E-12
*RST: 0

Example:

SENS:SWE:MODE TIME
Activates time mode for power analysis.
CALC:SWE:TIME:GATE:STAT ON
Activates time gated measurement.
SENS:SWE:INIT
Activates a single power analysis measurement.
CALC:SWE:TIME:GATE2:MAX?
Queries the peak power in time gate 2 for trace 1 (=default).

Usage: Query only

Options: Option R&S SMAB-K28

Manual operation: See "[State - Gate](#)" on page 302

:CALCulate[:POWER]:SWEep:TIME:GATE<ch>:START <Start>**:CALCulate[:POWER]:SWEep:TIME:GATE<ch>:STOP <Stop>**

Sets the start time of the selected gate. Insert value and unit.

Parameters:

<Stop> float
Increment: 1E-12
*RST: Start/Stop: 5/15 (Gate1), 25/35 (Gate2)

Example: `CALC:SWE:TIME:GATE2:STAR 20us`
Sets a start time of 20 us for gate 2.
`CALC:SWE:TIME:GATE2:STOP 30us`
Sets a stop time of 30us for gate 2.

Options: Option R&S SMAB-K28

Manual operation: See ["Start / Stop - Gate"](#) on page 302

:CALCulate[:POWER]:SWEep:TIME:GATE<ch>:STATe <State>

Activates the gate settings for the selected trace. The measurement is started with command `SENS:POW:INIT`. Both gates are active at one time.

Parameters:

<State> 1 | ON | 0 | OFF
*RST: 0

Example: `CALC:SWE:TIME:GATE:STAT ON`
Enables time gated measurement.

Manual operation: See ["State - Gate"](#) on page 302

:CALCulate[:POWER]:SWEep:TIME:MARKer<ch>:FEED <MarkerBinding>

Selects the marker for time measurement. Each marker is bound to one of the traces.

Parameters:

<MarkerBinding> TRAC1 | TRAC2 | TRAC3 | TRACe1 | TRACe2 | TRACe3 |
TRAC4 | TRACe4
*RST: TRAC1

Example: `CALCulate:SWEep:TIME:MARKer:FEED TRACe3`
// Assigns the marker to trace 2.

Manual operation: See ["Trace - Power Analysis"](#) on page 277

:CALCulate[:POWER]:SWEep:TIME:MARKer<ch>:STATe <MarkerState>

Enables the time marker for the selected trace.

Parameters:

<MarkerState> 1 | ON | 0 | OFF
*RST: 1

Example: `CALCulate:SWEep:Power:MARKer2:STATe 1`
// enables marker 2 for power measurement

Manual operation: See ["Marker x Visible - Power Analysis"](#) on page 277

:CALCulate[:POWER]:SWEep:TIME:MATH<ch>:STATe <State>

Activates the trace mathematics mode for "Time" measurement. This feature enables you to calculate the difference between the measurement values of two traces. For further calculation, a math result can also be assigned to a trace.

Parameters:

<State> 1 | ON | 0 | OFF
*RST: 0

Example:

CALC:POW:SWE:TIME:MATH1:STATe
Switches on math mode.

Options:

Option R&S SMAB-K28

Manual operation: See ["Mathematics - Trace Power Analysis"](#) on page 274

:CALCulate[:POWER]:SWEep:TIME:MATH<ch>:SUBTract <Subtract>

Subtracts the operands 1 and 2 and assigns the result to the selected trace in "Time" measurement mode.

Parameters:

<Subtract> T1T1 | T1T2 | T1T3 | T1T4 | T1REf | T2T1 | T2T2 | T2T3 | T2T4 |
T2REf | T3T1 | T3T2 | T3T3 | T3T4 | T3REf | T4T1 | T4T2 |
T4T3 | T4T4 | T4REf

Example:

CALC:POW:SWE:TIME:MATH4:SUBT T2REF
Subtracts the Reference and Trace 2, and assigns the result to Trace 4. The resulting curve is shown in the diagram.

Options:

Option R&S SMAB-K28

Manual operation: See ["Mathematics - Trace Power Analysis"](#) on page 274

:CALCulate[:POWER]:SWEep:TIME:MATH<ch>:XVAL <XVal>

Sets the x-axis values for calculating the reference curve in time measurement mode.

To determine two points ("Point A"/"Point B"), set suffix 1 and 2 in keyword MATH<ch>.

Parameters:

<XVal> float
Range: 0 to 2
Increment: 1E-12
*RST: -5E-6

Example:

CALCulate:POWer:SWEep:TIME:MATH1:XVAL -0.000005
CALCulate:POWer:SWEep:TIME:MATH2:XVAL 0.000045
Sets the time points to calculate the reference curve.

Manual operation: See ["Time \(X\)"](#) on page 276

:CALCulate[:POWer]:SWEep:TIME:MATH<ch>:YVAL <YVal>

Sets the y-axis values for calculating the reference curve in time measurement mode.

To determine two points ("Point A"/"Point B"), set suffix 1 and 2 in keyword **MATH<ch>**.

Parameters:

<YVal> float
 Range: -200 to 100
 Increment: 0.0001
 *RST: -40

Example:

CALCulate:POWer:SWEep:TIME:MATH1:YVAL 20
 CALCulate:POWer:SWEep:TIME:MATH2:YVAL -30
 Sets the power values for the two time points to calculate the reference curve.

Manual operation: See "[Pow \(Y\)](#)" on page 276

15.15.2 DISPlay subsystem

:DISPlay[:WINDow][:POWer]:SWEep:BACKground:COLor.....549
 :DISPlay[:WINDow][:POWer]:SWEep:GRID:STATe.....549

:DISPlay[:WINDow][:POWer]:SWEep:BACKground:COLor <Color>

Defines the background color of the measurement diagram. The selected color applies also to the hardcopy of the diagram.

Parameters:

<Color> BLACK | WHITE
 *RST: BLACK

Example:

DISP:SWE:BACK:COL WHIT
 The measurement is indicated with a white background.

Manual operation: See "[Background Color](#)" on page 284

:DISPlay[:WINDow][:POWer]:SWEep:GRID:STATe <State>

Indicates a grid in the diagram.

Parameters:

<State> 1 | ON | 0 | OFF
 *RST: 1

Example:

DISP:SWE:GRID:STAT OFF
 Deactivates the indication of a grid in the diagram area.

Manual operation: See "[Show Grid](#)" on page 283

15.15.3 INITiate command

:INITiate<hw>[:POWER]:CONTinuous <Continuous>

Switches the local state of the continuous power measurement by R&S NRP power sensors on and off. Switching off local state enhances the measurement performance during remote control.

The remote measurement is triggered with **:READ<ch>[:POWER]?**. This command also returns the measurement results. The local state is not affected, measurement results can be retrieved with local state on or off.

Parameters:

<Continuous> 1 | ON | 0 | OFF
*RST: 0

Example: **INIT1:CONT ON**
Switches on the local state of continuous power measurement.

Manual operation: See "State" on page 260

15.15.4 READ subsystem

:READ<ch>[:POWER]?

Triggers power measurement and displays the results.

Note: This command does not affect the local state, i.e. you can get results with local state on or off. For long measurement times, we recommend that you use an SRQ for command synchronization (MAV bit).

Suffix:

<ch> 1 to 3

Return values:

<Power> float or float,float

The sensor returns the result in the unit set with command **:SENSe<ch>:UNIT[:POWER]**

Certain power sensors, such as the R&S NRP-Z81, return two values, first the value of the average level and - separated by a comma - the peak value.

Example: **:SENS1:UNIT DBM**
Selects unit dBm for presentation of measurement result.
:READ1?
Queries the measurement result of the sensor.
-45.6246576745440230
-45.6 dBm were measured at the given frequency.

Example: R&S NRP-Z81
:READ1?
-55.62403263352178,-22.419472478812476
-55.6 dBm is the measured average level, -22.4 dBm is the measured peak level at the given frequency.

Usage: Query only

Manual operation: See "Measured Level" on page 256

15.15.5 SENSE SWEEP subsystem

:SENSe<ch>[:POWer]:SWEep:FREQUency[:SENSor]:OFFSet	553
:SENSe<ch>[:POWer]:SWEep:FREQUency[:SENSor]:OFFSet:STATe	553
:SENSe<ch>[:POWer]:SWEep:FREQUency[:SENSor]:SRANge:START	553
:SENSe<ch>[:POWer]:SWEep:FREQUency[:SENSor]:SRANge:STOP	554
:SENSe<ch>[:POWer]:SWEep:FREQUency[:SENSor]:SRANge[:STATe]	554
:SENSe<ch>[:POWer]:SWEep:POWer[:SENSor]:OFFSet	555
:SENSe<ch>[:POWer]:SWEep:POWer[:SENSor]:OFFSet:STATe	555
:SENSe<ch>[:POWer]:SWEep:POWer[:SENSor]:SFRequency	555
:SENSe<ch>[:POWer]:SWEep:POWer[:SENSor]:SFRequency:STATe	556
:SENSe<ch>[:POWer]:SWEep:TIME[:SENSor]:OFFSet	556
:SENSe<ch>[:POWer]:SWEep:TIME[:SENSor]:OFFSet:STATe	556
:SENSe<ch>[:POWer]:SWEep:TIME[:SENSor]:PULSe:STATe	557
:SENSe<ch>[:POWer]:SWEep:TIME[:SENSor]:PULSe:THReshold:BASE	557
:SENSe<ch>[:POWer]:SWEep:TIME[:SENSor]:PULSe:THReshold:POWer:HREFerence	557
:SENSe<ch>[:POWer]:SWEep:TIME[:SENSor]:PULSe:THReshold:POWer:LREFerence	558
:SENSe<ch>[:POWer]:SWEep:TIME[:SENSor]:PULSe:THReshold:POWer:REFerence	558
:SENSe<ch>[:POWer]:SWEep:TIME[:SENSor]:SFRequency	559
:SENSe<ch>[:POWer]:SWEep:TIME[:SENSor]:SFRequency:STATe	559
:SENSe<ch>[:POWer]:SWEep:TIME[:SENSor]:TRIGger:AUTO	559
:SENSe<ch>[:POWer]:SWEep:TIME[:SENSor]:TRIGger:DTIME	559
:SENSe<ch>[:POWer]:SWEep:TIME[:SENSor]:TRIGger:HYSTeresis	560
:SENSe<ch>[:POWer]:SWEep:TIME[:SENSor]:TRIGger:LEVel	560
:SENSe<ch>[:POWer]:SWEep:TIME[:SENSor]:TRIGger:SLOPe	560
:SENSe<ch>[:POWer]:SWEep:TIME[:SENSor]:TRIGger:SOURce	561
:SENSe<ch>[:POWer]:ZERO	561
:SENSe[:POWer]:SWEep:ABORT	561
:SENSe[:POWer]:SWEep:FREQUency:REFerence:DATA:COPI	561
:SENSe[:POWer]:SWEep:FREQUency:REFerence:DATA:POINts?	562
:SENSe[:POWer]:SWEep:FREQUency:REFerence:DATA:XVALues	562
:SENSe[:POWer]:SWEep:FREQUency:REFerence:DATA:YVALues	562
:SENSe[:POWer]:SWEep:FREQUency:RMODE	562
:SENSe[:POWer]:SWEep:FREQUency:SPACing[:MODE]	563
:SENSe[:POWer]:SWEep:FREQUency:START	563
:SENSe[:POWer]:SWEep:FREQUency:STEPS	563
:SENSe[:POWer]:SWEep:FREQUency:STOP	563
:SENSe[:POWer]:SWEep:FREQUency:TIMing[:MODE]	564

Power sensor measurement subsystems

:SENSe[:POWER]:SWEep:FREQuency:YSCale:AUTO.....	564
:SENSe[:POWER]:SWEep:FREQuency:YSCale:AUTO:RESet.....	565
:SENSe[:POWER]:SWEep:FREQuency:YSCale:MAXimum.....	565
:SENSe[:POWER]:SWEep:FREQuency:YSCale:MINimum.....	565
:SENSe[:POWER]:SWEep:HCOPy:DATA?.....	565
:SENSe[:POWER]:SWEep:HCOPy:DEVIce.....	566
:SENSe[:POWER]:SWEep:HCOPy:DEVIce:LANGuage.....	567
:SENSe[:POWER]:SWEep:HCOPy:DEVIce:LANGuage:CSV:DPOint.....	567
:SENSe[:POWER]:SWEep:HCOPy:DEVIce:LANGuage:CSV:HEADer.....	567
:SENSe[:POWER]:SWEep:HCOPy:DEVIce:LANGuage:CSV:ORlentation.....	568
:SENSe[:POWER]:SWEep:HCOPy:DEVIce:LANGuage:CSV[:COLUMn]:SEPArator.....	568
:SENSe[:POWER]:SWEep:HCOPy:DEVIce:SIZE.....	568
:SENSe[:POWER]:SWEep:HCOPy:FILE[:NAME].....	569
:SENSe[:POWER]:SWEep:HCOPy:FILE[:NAME]:AUTO:DIRectory.....	569
:SENSe[:POWER]:SWEep:HCOPy:FILE[:NAME]:AUTO:DIRectory:CLear.....	569
:SENSe[:POWER]:SWEep:HCOPy:FILE[:NAME]:AUTO:FILE?.....	570
:SENSe[:POWER]:SWEep:HCOPy:FILE[:NAME]:AUTO:STATe.....	570
:SENSe[:POWER]:SWEep:HCOPy:FILE[:NAME]:AUTO[:FILE]:DAY?.....	571
:SENSe[:POWER]:SWEep:HCOPy:FILE[:NAME]:AUTO[:FILE]:DAY:STATe.....	571
:SENSe[:POWER]:SWEep:HCOPy:FILE[:NAME]:AUTO[:FILE]:MONTH?.....	571
:SENSe[:POWER]:SWEep:HCOPy:FILE[:NAME]:AUTO[:FILE]:MONTH:STATe.....	571
:SENSe[:POWER]:SWEep:HCOPy:FILE[:NAME]:AUTO[:FILE]:NUMBER?.....	572
:SENSe[:POWER]:SWEep:HCOPy:FILE[:NAME]:AUTO[:FILE]:PREFIX.....	572
:SENSe[:POWER]:SWEep:HCOPy:FILE[:NAME]:AUTO[:FILE]:PREFIX:STATe.....	572
:SENSe[:POWER]:SWEep:HCOPy:FILE[:NAME]:AUTO[:FILE]:YEAR?.....	573
:SENSe[:POWER]:SWEep:HCOPy:FILE[:NAME]:AUTO[:FILE]:YEAR:STATe.....	573
:SENSe[:POWER]:SWEep:HCOPy[:EXECute].....	573
:SENSe[:POWER]:SWEep:INITiate.....	573
:SENSe[:POWER]:SWEep:MODE.....	574
:SENSe[:POWER]:SWEep:POWer:REFerence:DATA:COPI.....	574
:SENSe[:POWER]:SWEep:POWer:REFerence:DATA:POINts?.....	574
:SENSe[:POWER]:SWEep:POWer:REFerence:DATA:XVALues.....	574
:SENSe[:POWER]:SWEep:POWer:REFerence:DATA:YVALues.....	575
:SENSe[:POWER]:SWEep:POWer:RMODE.....	575
:SENSe[:POWER]:SWEep:POWer:SPACing[:MODE].....	575
:SENSe[:POWER]:SWEep:POWer:START.....	575
:SENSe[:POWER]:SWEep:POWer:STEPS.....	576
:SENSe[:POWER]:SWEep:POWer:STOP.....	576
:SENSe[:POWER]:SWEep:POWer:TIMing[:MODE].....	576
:SENSe[:POWER]:SWEep:POWer:YSCale:AUTO.....	577
:SENSe[:POWER]:SWEep:POWer:YSCale:AUTO:RESet.....	577
:SENSe[:POWER]:SWEep:POWer:YSCale:MAXimum.....	578
:SENSe[:POWER]:SWEep:POWer:YSCale:MINimum.....	578
:SENSe[:POWER]:SWEep:RMODE.....	578
:SENSe[:POWER]:SWEep:TIME:AVERage[:COUNT].....	578
:SENSe[:POWER]:SWEep:TIME:REFerence:DATA:COPI.....	579
:SENSe[:POWER]:SWEep:TIME:REFerence:DATA:POINts?.....	579
:SENSe[:POWER]:SWEep:TIME:REFerence:DATA:XVALues.....	579
:SENSe[:POWER]:SWEep:TIME:REFerence:DATA:YVALues.....	579
:SENSe[:POWER]:SWEep:TIME:RMODE.....	580

:SENSe[:POWer]:SWEep:TIME:SPACing[:MODE]	580
:SENSe[:POWer]:SWEep:TIME:START	580
:SENSe[:POWer]:SWEep:TIME:STEPS	581
:SENSe[:POWer]:SWEep:TIME:STOP	581
:SENSe[:POWer]:SWEep:TIME:TEVents	581
:SENSe[:POWer]:SWEep:TIME:YScale:AUTO	582
:SENSe[:POWer]:SWEep:TIME:YScale:AUTO:RESet	582
:SENSe[:POWer]:SWEep:TIME:YScale:MAXimum	582
:SENSe[:POWer]:SWEep:TIME:YScale:MINimum	583

:SENSe<ch>[:POWer]:SWEep:FREQuency[:SENSor]:OFFSet <Offset>

Defines the level offset at the sensor input in dB. Activate the offset with the command :SENSe<ch>[:POWer]:SWEep:FREQuency[:SENSor]:OFFSet:STATe on page 553.

Parameters:

<Offset> float
 Range: -100 to 100
 Increment: 0.01
 *RST: 0

Example:

SENS2:SWE:FREQ:OFFS -3dB
 Defines a level offset of -3 dB.
 SENS2:SWE:FREQ:OFFS:STAT ON
 Activates the specified level offset.

Options: Option R&S SMAB-K28

Manual operation: See "Level Offset - Power Analysis" on page 292

:SENSe<ch>[:POWer]:SWEep:FREQuency[:SENSor]:OFFSet:STATe <State>

Activates a level offset at the sensor input. Define the appropriate value with the command :SENSe<ch>[:POWer]:SWEep:FREQuency[:SENSor]:OFFSet on page 553.

Parameters:

<State> 1 | ON | 0 | OFF
 *RST: 0

Example:

SENS2:SWE:FREQ:OFFS:STAT ON
 Activates the specified level offset.

Options: Option R&S SMAB-K28

Manual operation: See "Level Offset State - Power Analysis" on page 291

:SENSe<ch>[:POWer]:SWEep:FREQuency[:SENSor]:SRANge:START <Start>

Sets the start frequency for the frequency power analysis with separate frequencies.

Parameters:

<Start> integer
 Range: 0 to 1E12
 *RST: 1E6

Example:

SENS2:SWE:FREQ:SENS:SRAN:STAT ON

Activates use of a separate frequency range for frequency versus power measurement for sensor 2.

SENS2:SWE:FREQ:SENS:STAR 2.0GHZ

Sets a sweep start at 2 GHz irrespective of the current signal generator frequency settings.

Manual operation: See ["Min Frequency - Power Analysis"](#) on page 292

:SENSe<ch>[:POWer]:SWEep:FREQuency[:SENSor]:SRANge:STOP <Stop>

Sets the stop frequency for the frequency power analysis with separate frequencies.

Parameters:

<Stop> integer
 Range: 0 to 1E12
 *RST: 10E6

Example:

SENS:SWE:FREQ:SENS2:SRAN:STAT ON

Activates use of a separate frequency range for frequency versus power measurement.

SENS:SWE:FREQ:SENS2:STAR 2.0GHZ

Sets a sweep start at 2 GHz irrespective of the current signal generator frequency settings.

SENS:SWE:FREQ:SENS2:STOP 2.9GHZ

Sets a sweep stop at 2.9 GHz irrespective of the current signal generator frequency settings.

Manual operation: See ["Max Frequency - Power Analysis"](#) on page 293

:SENSe<ch>[:POWer]:SWEep:FREQuency[:SENSor]:SRANge:STATe <State>

Activates the use of a frequency range for the power measurement that is different to the set signal generator frequency range. The separate frequency range is entered with commands [:SENSe<ch>\[:POWer\]:SWEep:FREQuency\[:SENSor\]:SRANge:START](#) on page 553 and [:SENSe<ch>\[:POWer\]:SWEep:FREQuency\[:SENSor\]:SRANge:STOP](#) on page 554.

Parameters:

<State> 1 | ON | 0 | OFF
 *RST: 0

Example:

```
SENS2:SWE:FREQ:SENS:SRAN ON
```

Activates use of a separate frequency range for frequency versus power measurement for sensor 2.

```
SENS2:SWE:FREQ:SENS:STAR 2.0GHZ
```

Sets a sweep start at 2 GHz irrespective of the current signal generator frequency settings.

```
SENS2:SWE:FREQ:SENS:STOP 2.9GHZ
```

Sets a sweep stop at 2.9 GHz irrespective of the current signal generator frequency settings.

Manual operation: See ["Use Separate Frequency- Power Analysis"](#) on page 292

:SENSe<ch>[:POWer]:SWEep:POWer[:SENSor]:OFFSet <Offset>

Defines the level offset at the sensor input in dB. Activate the offset with the command [:SENSe<ch>\[:POWer\]:SWEep:POWer\[:SENSor\]:OFFSet:STATe](#) on page 555.

Parameters:

<Offset> float
 Range: -100 to 100
 Increment: 0.01
 *RST: 0

Example:

```
SENS2:SWE:POW:OFFS -5dB
```

Defines a level offset of -5 dB.

```
SENS2:SWE:POW:OFFS:STAT ON
```

Activates that the specified level offset is considered.

Options: Option R&S SMAB-K28

Manual operation: See ["Level Offset - Power Analysis"](#) on page 292

:SENSe<ch>[:POWer]:SWEep:POWer[:SENSor]:OFFSet:STATe <State>

Activates a level offset at the sensor input. Define the appropriate value with the command [:SENSe<ch>\[:POWer\]:SWEep:POWer\[:SENSor\]:OFFSet](#) on page 555.

Parameters:

<State> 1 | ON | 0 | OFF
 *RST: 0

Example:

```
SENS2:SWE:POW:OFFS:STAT ON
```

Activates the specified level offset.

Options: Option R&S SMAB-K28

:SENSe<ch>[:POWer]:SWEep:POWer[:SENSor]:SFRequency <SFRequency>

Defines the separate frequency used for power vs. power measurement.

Parameters:

<SFRrequency> float
 Range: 0 to 1E12
 Increment: 1
 *RST: 1E6

Example:

SENS1:SWE:POW:SENS:SFR 2GHz
 The measurement is performed at 2 GHz

Manual operation: See ["Use Separate Frequency- Power Analysis"](#) on page 292

:SENSe<ch>[:POWer]:SWEep:POWer[:SENSor]:SFRrequency:STATe <State>

Activates the use of a different frequency for the power measurement.

Parameters:

<State> 1 | ON | 0 | OFF
 *RST: 0

Example:

SENS1:SWE:POW:SENS:SFR:STAT ON
 Activates the use of a separate frequency than the generator frequency for power analysis

Manual operation: See ["Use Separate Frequency- Power Analysis"](#) on page 292

:SENSe<ch>[:POWer]:SWEep:TIME[:SENSor]:OFFSet <Offset>

Defines the level offset at the sensor input in dB. Activate the offset with the command [:SENSe<ch>\[:POWer\]:SWEep:TIME\[:SENSor\]:OFFSet:STATe](#) on page 556.

Parameters:

<Offset> float
 Range: -100 to 100
 Increment: 0.01
 *RST: 0

Example:

SENS2:SWE:TIME:OFFS -7dB
 Defines a level offset of -7 dB.
 SENS2:SWE:TIME:OFFS:STAT ON
 The specified level offset is considered.

Options: Option R&S SMAB-K28

Manual operation: See ["Level Offset - Power Analysis"](#) on page 292

:SENSe<ch>[:POWer]:SWEep:TIME[:SENSor]:OFFSet:STATe <State>

Activates a level offset at the sensor input. Define the appropriate value with the command [:SENSe<ch>\[:POWer\]:SWEep:TIME\[:SENSor\]:OFFSet](#) on page 556.

Parameters:

<State> 1 | ON | 0 | OFF
 *RST: 0

Example:

SENS2:SWE:POW:TIME:STAT ON
 Activates the specified level offset.

Options:

Option R&S SMAB-K28

Manual operation: See ["Level Offset State - Power Analysis"](#) on page 291

:SENSe<ch>[:POWer]:SWEep:TIME[:SENSor]:PULSe:STATe <State>

Enables pulse data analysis. The measurement is started with command INITiate.

Note: The command is only available in time measurement mode and with R&S NRP-Z81 power sensors.

Parameters:

<State> 1 | ON | 0 | OFF
 *RST: 0

Example:

SENS1:SWE:TIM:PULS:STAT ON
 Enables pulse data analysis.

Options:

Option R&S SMAB-K28

Manual operation: See ["Pulse Analysis"](#) on page 289

:SENSe<ch>[:POWer]:SWEep:TIME[:SENSor]:PULSe:THReshold:BASE <Base>

Selects how the threshold parameters for pulse analysis are calculated.

Note: The command is only available in time measurement mode and with R&S NRPZ81 power sensors.

Parameters:

<Base> VOLTage | POWer
 *RST: VOLTage

Example:

SENS1:SWE:TIME:PULS:THR:BASE POW
 Activates threshold calculation related to power.

Options:

Option R&S SMAB-K28

Manual operation: See ["Base"](#) on page 289

:SENSe<ch>[:POWer]:SWEep:TIME[:SENSor]:PULSe:THReshold:POWER: HREFerence <HReference>

Sets the upper reference level in terms of percentage of the overall pulse level (power or voltage). The distal power defines the end of the rising edge and the start of the falling edge of the pulse.

Note: The command is only available in time measurement mode and with R&S NRPZ81 power sensors.

Parameters:

<HReference> float
 Range: 0 to 100
 Increment: 0.01
 *RST: 90

Options: Option R&S SMAB-K28

Manual operation: See "[Distal](#)" on page 289

**:SENSe<ch>[:POWer]:SWEep:TIME[:SENSor]:PULSe:THReshold:POWer:
 LREference <LReference>**

Sets the lower reference level in terms of percentage of the overall pulse level. The proximal power defines the start of the rising edge and the end of the falling edge of the pulse.

Note: This parameter is only available in time measurement mode and R&S NRP-Z81 power sensors.

Parameters:

<LReference> float
 Range: 0.0 to 100.0
 Increment: 0.01
 *RST: 10.0

Example: SENS:SWE:TIM:PULS:THR:LREF 10
 Sets the lower reference level to 10%.

Options: Option R&S SMAB-K28

Manual operation: See "[Proximal](#)" on page 290

**:SENSe<ch>[:POWer]:SWEep:TIME[:SENSor]:PULSe:THReshold:POWer:
 REFERENCE <Reference>**

Sets the medial reference level in terms of percentage of the overall pulse level (power or voltage related). This level is used to define pulse width and pulse period.

Note: The command is only available in time measurement mode and with R&S NRPZ81 power sensors.

Parameters:

<Reference> float
 Range: 0.0 to 100.0
 Increment: 0.01
 *RST: 50.0

Example: SENS1:SWE:TIM:PULS:THR:REF 40
 Sets the medial reference level to 40% of the overall pulse level.

Options: Option R&S SMAB-K28

Manual operation: See ["Mesial"](#) on page 290

:SENSe<ch>[:POWer]:SWEep:TIME[:SENSor]:SFRequency <SFrequency>

Defines the separate frequency used for power vs. time measurement.

Parameters:

<SFrequency> float
 Range: 0 to 1E12
 Increment: 1
 *RST: 1E6

Example: SENS1:SWE:TIME:SENS:SFR 2GHz
 The measurement is performed at 2 GHz

Manual operation: See ["Use Separate Frequency- Power Analysis"](#) on page 292

:SENSe<ch>[:POWer]:SWEep:TIME[:SENSor]:SFRequency:STATe <State>

Activates the use of a different frequency for the power measurement.

Parameters:

<State> 1 | ON | 0 | OFF
 *RST: 0

Example: SENS1:SWE:TIME:SENS:SFR:STAT ON
 Activates the use of a separate frequency than the generator frequency for power analysis

Manual operation: See ["Use Separate Frequency- Power Analysis"](#) on page 292

:SENSe<ch>[:POWer]:SWEep:TIME[:SENSor]:TRIGger:AUTO <Auto>

Sets the trigger level, the hysteresis and the dropout time to default values.

Parameters:

<Auto> ONCE
 *RST: ---

Example: SENS1:SWE:TIME:SENS:TRIG:AUTO ONCE
 The trigger level is automatically determined

Manual operation: See ["Auto Set - Power Analysis"](#) on page 300

:SENSe<ch>[:POWer]:SWEep:TIME[:SENSor]:TRIGger:DTIME <DTime>

Determines the minimum time for which the signal must be below (above) the power level defined by level and hysteresis before triggering can occur again.

Parameters:

<DTime> float
 Range: 0 to 10
 *RST: 200E-9

Example:

SENS1:SWE:TIME:SENS:TRIG:DTIM 10 us
 The drop out time is 10 us

Manual operation: See ["Drop out Time - Power Analysis"](#) on page 299

:SENSe<ch>[:POWer]:SWEep:TIME[:SENSor]:TRIGger:HYSTeresis <Hysteresis>

Sets the hysteresis of the internal trigger threshold. Hysteresis is the magnitude (in dB) the trigger signal level must drop below the trigger threshold (positive trigger slope) before triggering can occur again.

Parameters:

<Hysteresis> float
 Range: 0 to 10
 Increment: 0.001
 *RST: 0.5

Example:

SENS1:SWE:TIME:SENS:TRIG:HYST 0.5 dB
 The hysteresis is 0.5 dB

Manual operation: See ["Hysteresis - Power Analysis"](#) on page 299

:SENSe<ch>[:POWer]:SWEep:TIME[:SENSor]:TRIGger:LEVel <Level>

Sets the trigger threshold.

Parameters:

<Level> float
 Range: -200 to 100
 Increment: 0.001
 *RST: 1

Example:

SENS1:SWE:TIME:SENS:TRIG:LEV -20 dBm
 Sets the trigger level to -20 dBm.

Manual operation: See ["Level - Power Analysis"](#) on page 299

:SENSe<ch>[:POWer]:SWEep:TIME[:SENSor]:TRIGger:SLOPe <TriggerSlope>

Sets the polarity of the active slope for the trigger signals.

Parameters:

<TriggerSlope> POSitive | NEGative
 *RST: POSitive

Example:

SENS1:SWE:TIME:TRIG:SLOP POS
 The positive edge of a trigger signal is active.

Options: Option R&S SMAB-K28

Manual operation: See ["Slope - Power Analysis"](#) on page 299

:SENSe<ch>[:POWer]:SWEep:TIME[:SENSor]:TRIGger:SOURce <Source>

Selects if the measurement is free running (FREE) or starts only after a trigger event. The trigger can be applied internally or externally.

Parameters:

<Source> FREE | AUTO | INTERNAL | EXTERNAL
*RST: AUTO

Example: SENS1:SWE:TIME:SENS:TRIG:SOUR FREE
The power versus time measurement is performed free running

Manual operation: See ["Mode - Power Analysis"](#) on page 298

:SENSe<ch>[:POWer]:ZERO

The command activates the autozero function. Zeroing is required in regular interval (at least once a day) and if the temperature has varied more than about 5 °C, if the sensor has been replaced or if measurements of signals with very low power are to be performed. The RF power source must be switched off or disconnected from the sensor before starting the autozero function.

Example: SENS:ZERO
activates autozero function.

Usage: Event

:SENSe[:POWer]:SWEep:ABORt

Aborts the power analysis with NRP power sensors.

Example: SENS:SWE:ABOR;*OPC?
Aborts the current power measurement.

Usage: Setting only

:SENSe[:POWer]:SWEep:FREQuency:REFeRence:DATA:COpy

Generates a reference curve for "Frequency" measurement.

Example: SENS:POW:SWE:FREQ:REF:DATA:COpy
Generates a reference curve in frequency mode.

Usage: Event

Manual operation: See ["Save To Ref"](#) on page 276

:SENSe[:POWer]:SWEep:FREQuency:REFerence:DATA:POINts?

Queries the number of points from the reference curve in "Frequency" measurement.

Return values:

<Points> integer
Range: 10 to 1000

Example: SENS:POW:SWE:FREQ:REF:DATA:POIN?
Queries the number of points from the reference curve in frequency mode.

Usage: Query only

:SENSe[:POWer]:SWEep:FREQuency:REFerence:DATA:XVALues <XValues>

Sets the x values of the two reference points, i.e. "Frequency X (Point A)" and "Frequency X (Point B)" in "Frequency" measurement.

Parameters:

<XValues> string

Example: SENSE:POW:SWE:FREQ:REF:DATA:XVAL 100MHZ,22GHZ
Sets the x value of reference "Point A" to 10 MHz, and the value of "Point B" to 10 GHz.

Manual operation: See "[Freq \(X\)](#)" on page 275

:SENSe[:POWer]:SWEep:FREQuency:REFerence:DATA:YVALues <YValues>

Sets or queries the y values of the two reference points, i.e. "Pow Y (Point A)" and "Power Y (Point B)" in "Frequency" measurement.

Parameters:

<YValues> string

Example: SENSE:POW:SWE:FREQ:REF:DATA:YVAL -10,25
Sets the y value of reference "Point A" to -10 dBm, and the value of "Point B" to -25 dBm.

Manual operation: See "[POW \(Y\)](#)" on page 275

:SENSe[:POWer]:SWEep:FREQuency:RMODe <RMode>

Selects single or continuous mode for measurement mode frequency in power analysis.

Parameters:

<RMode> SINGle | CONTInuous
*RST: CONTInuous

Example: SENS:SWE:FREQ:RMOD SING
Selects single measurement

Manual operation: See ["Execution"](#) on page 281

:SENSe[:POWer]:SWEep:FREQuency:SPACing[:MODE] <Mode>

Selects the spacing for the frequency power analysis.

Parameters:

<Mode> LINear | LOGarithmic
 *RST: LINear

Example: SENS:SWE:FREQ:SPAC:MODE LIN
 Sets linear spacing of the sweep

Manual operation: See ["Spacing"](#) on page 281

:SENSe[:POWer]:SWEep:FREQuency:STARt <Start>

Sets the start frequency for the frequency mode.

Parameters:

<Start> float
 Range: 0 to 1E12
 *RST: 1E6

Example: SENS:SWE:FREQ:STAR 2.0GHZ
 Sets a sweep start at 2 GHz.

Manual operation: See ["Min"](#) on page 279

:SENSe[:POWer]:SWEep:FREQuency:STEPs <Steps>

Sets the number of measurement steps for the frequency mode.

Parameters:

<Steps> integer
 Range: 10 to 1000
 *RST: 200

Example: SENS:SWE:FREQ:STEP 500
 Sets 500 steps

Manual operation: See ["Steps"](#) on page 280

:SENSe[:POWer]:SWEep:FREQuency:STOP <Stop>

Sets the stop frequency for the frequency mode.

Parameters:

<Stop> float
 Range: 0 to 1E12
 *RST: 22GHZ

Example: `SENS:SWE:FREQ:STOP 20.0GHZ`
Sets the sweep stop to 20 GHz

Manual operation: See "[Max](#)" on page 279

:SENSe[:POWer]:SWEep:FREQuency:TIMing[:MODE] <Mode>

Selects the mode in terms of speed and precision of the response of a measurement.

Parameters:

<Mode> FAST | NORMal

FAST

Selection FAST leads to a fast measurement with a short integration time for each measurement step.

NORMal

NORMal leads to a longer but more precise measurement due to a higher integration time for each step.

*RST: FAST

Example: `SENS:SWE:FREQ:TIM:MODE FAST`
The fast measurement mode is selected.

Manual operation: See "[Timing](#)" on page 280

:SENSe[:POWer]:SWEep:FREQuency:YScale:AUTO <Auto>

Activates autoscaling of the Y axis of the diagram.

Parameters:

<Auto> OFF | CEXpanding | FEXpanding | CFLoating | FFLoating

OFF

Auto scaling is deactivated. If switching from activated to deactivated Auto scaling, the scaling is maintained.

CEXPanding | FEXpanding

Auto scale is activated. The scaling of the Y-axis is selected in such a way, that the trace is always visible. To this end, the range is expanded if the minimum or maximum values of the trace move outside the current scale. The step width is 5 dB for selection course and variable in the range of 0.2 dB to 5 dB for selection fine.

CFLoating | FFLoating

Auto scale is activated. The scaling of the Y-axis is selected in such a way, that the trace is always visible. To this end, the range is either expanded if the minimum or maximum values of the trace move outside the current scale or scaled down if the trace fits into a reduced scale. The step width is 5 dB for selection course and variable in the range of 0.2 dB to 5 dB for selection fine.

*RST: CEXPanding

Example: `SENS:SWE:FREQ:YSC:AUTO OFF`
Deactivates auto scale

Manual operation: See ["Auto Scale"](#) on page 283

:SENSe[:POWer]:SWEep:FREQuency:YSCale:AUTO:RESet

Resets the Y scale to suitable values after the use of auto scaling in the expanding mode. For this mode, the scale might get expanded because of temporarily high-power values. The reset function resets the diagram in such a way that it matches smaller power values again.

Example: `SENS:SWE:FREQ:YSC:AUTO:RES`
Resets auto scale

Usage: Event

Manual operation: See ["Reset Auto Scale"](#) on page 283

:SENSe[:POWer]:SWEep:FREQuency:YSCale:MAXimum <Maximum>

Sets the maximum value for the y axis of the measurement diagram.

Parameters:

<Maximum> float
Range: -200 to 100
Increment: 0.01
*RST: 40

Example: `SENS:SWE:FREQ:YSC:MAX 10DBM`
Sets 10 dBm as the upper limit of the measurement diagram.

Manual operation: See ["Min - Max Level"](#) on page 282

:SENSe[:POWer]:SWEep:FREQuency:YSCale:MINimum <Minimum>

Sets the minimum value for the y axis of the measurement diagram.

Parameters:

<Minimum> float
Range: -200 to 100
Increment: 0.01
*RST: -40

Example: `SENS:SWE:FREQ:YSC:MIN -10DB`
Sets -10 dBm as the lower limit of the measurement diagram.

Manual operation: See ["Min - Max Level"](#) on page 282

:SENSe[:POWer]:SWEep:HCOPY:DATA?

Queries the measurement data directly. The data is transferred to the remote client as data stream.

Readable ASCII data is available for hardcopy language CSV. The representation of the values depends on the selected orientation for the CSV format.

Return values:

<Data> block data

Example:

SENS:SWE:HCOP:DEV:LANG CSV

selects output format *.csv.

SENS:SWE:HCOP:DEV:LANG:CSV:ORI HOR

selects horizontal orientation

SENS:SWE:HCOP:DEV:LANG:CSV:SEP SEM

selects ";" as the separator between the values

SENS:SWE:HCOP:DEV:LANG:CSV:DPO DOT

selects "." as decimal point

SENS:SWE:HCOP:DATA?

queries the measurement data of the current traces

Response:

#2651009500000;1019000000;1028500000;1038000000

-9.5;-9.7;-6.3;-2.5

The hash symbol # introduces the data block. The next number indicates how many of the following digits describe the length of the data block. In the example, the 2 following digit indicates the length to be 65 characters.

Because horizontal representation is selected, a row with all the x-values of the active trace (frequency) follows. The second row contains all the y-values of the active trace (power). The rows end with a new line (each counts as one character).

Note: if more than one trace is active, the third row contains the x values of the second active trace, and so on.

Example:

SENS:SWE:HCOP:DEV:LANG:CSV:ORI VERT

selects horizontal orientation

SENS:SWE:HCOP:DATA?

queries the measurement data of the current traces

Response:

#2681009500000;-9.5; 1019000000;-9.7; 1028500000;-6.3;

1038000000;-2.5;

for vertical representation the length of the data block is 68 the first power value, the second row contains the second frequency value of the active trace followed by the second power value, and so on. The rows end with a new line (each counts as one character).

Note: if more than one trace is active, the first row also contains the value pairs of the second active trace, and so on.

Usage:

Query only

:SENSe[:POWer]:SWEep:HCOPy:DEVIce <Device>

Defines the output device. The setting is fixed to FILE, i.e. the hardcopy is stored in a file.

Parameters:

<Device> FILE | PRINter
 *RST: FILE

Example:

SENS:SWE:HCOP:DEV FIL
 Selects output device file.

:SENSe[:POWer]:SWEep:HCOPy:DEVIce:LANGUage <Language>

Selects the bitmap graphic format for the screenshot of the power analysis trace.

In addition, ASCII file format *.csv is offered. If file format *.csv is selected, the trace data is saved as an ASCII file with comma separated values. It is also possible to directly retrieve the data using command :SENSe[:POWer]:SWEep:HCOPy:DATA? on page 565

Parameters:

<Language> BMP | JPG | XPM | PNG | CSV
 *RST: BMP

Example:

SENS:SWE:HCOP:DEV:LANG BMP
 Selects output format *.bmp.

Manual operation: See "Format - Power Analysis" on page 303

:SENSe[:POWer]:SWEep:HCOPy:DEVIce:LANGUage:CSV:DPOint <DPoint>

Defines which character is used as the decimal point of the values, either dot or comma.

Parameters:

<DPoint> DOT | COMMa
 *RST: DOT

Example:

SENS:SWE:HCOP:DEV:LANG CSV
 Selects output format *.csv.
 SENS:SWE:HCOP:DEV:LANG:CSV:DPO DOT
 Selects character dot for being used as decimal point.

Manual operation: See "Decimal Point" on page 308

:SENSe[:POWer]:SWEep:HCOPy:DEVIce:LANGUage:CSV:HEADer <Header>

Defines whether each row (or column depending on the orientation) should be preceded by a header containing information about the trace (see also :SENSe[:POWer]:SWEep:HCOPy:DATA? on page 565).

Parameters:

<Header> OFF | STANdard
 *RST: OFF

Example: `SENS:SWE:HCOP:DEV:LANG CSV`
 Selects output format *.csv.
 `SENS:SWE:HCOP:DEV:LANG:CSV:HEAD STAN`
 Selects the standard header for the *.csv file.

Manual operation: See ["Row Header"](#) on page 308

:SENSe[:POWer]:SWEep:HCOPy:DEViCe:LANGUage:CSV:ORientation
 <Orientation>

Defines the orientation of the X/Y value pairs.

Parameters:

<Orientation> HORizontal | VERTical
 *RST: VERTical

Example: `SENS:SWE:HCOP:DEV:LANG CSV`
 Selects output format *.csv.
 `SENS:SWE:HCOP:DEV:LANG:CSV:ORI VERT`
 Selects vertical orientation, the value pairs are written in a column like structure (separated by the selected separator, e.g. tab)

Manual operation: See ["Orientation"](#) on page 307

:SENSe[:POWer]:SWEep:HCOPy:DEViCe:LANGUage:CSV[:COLumn]:SEParator
 <Separator>

Defines which character is to separate the values, either tabulator, semicolon, comma or blank.

Parameters:

<Separator> TABulator | SEMicolon | COMMa | BLANK
 *RST: COMMa

Example: `SENS:SWE:HCOP:DEV:LANG CSV`
 Selects output format *.csv.
 `SENS:SWE:HCOP:DEV:LANG:CSV:SEP TAB`
 A tab separates the values.

Manual operation: See ["Separator"](#) on page 308

:SENSe[:POWer]:SWEep:HCOPy:DEViCe:SIZE <Size>

Sets the size of the hardcopy in number of pixels. The first value of the size setting defines the width, the second value the height of the image.

Parameters:

<Size> 320,240 | 640,480 | 800,600 | 1024,768
 *RST: 320,240

Example: `SENS:SWE:HCOP:DEV:LANG BMP`
 Selects output format *.bmp.
 `SENS:SWE:HCOP:DEV:SIZE 320,240`
 The size of the bitmap is 320 pixels by 240 pixels.

:SENSe[:POWer]:SWEep:HCOPy:FILE[:NAME] <Name>

Creates or selects a file for storing the hardcopy after the `:SENSe[:POWer]:SWEep:HCOPy[:EXECute]` on page 573 command is sent. The directory is either defined with the command `MMEMory:CDIR` or the path is specified together with the file name. Access to the file via remote control is possible using the commands of the MMEM-Subsystem. In contrast, command `:SENSe[:POWer]:SWEep:HCOPy:DATA?` on page 565 transfers the hardcopy contents directly to the remote client where they can be further processed.

Parameters:

<Name> string

Example: `SENS:SWE:HCOP:DEV:LANG BMP`
 Selects output format *, bmp.
 `SENS:SWE:HCOP:FILE:AUTO:STAT OFF`
 Switches off automatic naming.
 `SENS:SWE:HCOP:FILE 'var/trace/nrp_tracel'`
 creates the file `nrp_tracel.bmp` in the trace directory.
 `SENS:SWE:HCOP:EXEC`
 Triggers the generation of a hardcopy of the current trace. The hardcopy is stored in the file `nrp_tracel.bmp`.

Manual operation: See "[File name - Power Analysis](#)" on page 303

:SENSe[:POWer]:SWEep:HCOPy:FILE[:NAME]:AUTO:DIRectory <Directory>

Defines the directory into which the hardcopy files are stored if auto naming is activated (`SENS:SWE:HCOP:FILE:AUTO:STAT ON`).

Parameters:

<Directory> string

Example: `SENS:SWE:HCOP:FILE:AUTO:DIR 'var/nrp'`
 Hardcopy file are stored in directory `var/nrp` if automatic naming is activated.

Manual operation: See "[Path](#)" on page 305

:SENSe[:POWer]:SWEep:HCOPy:FILE[:NAME]:AUTO:DIRectory:CLEar

Deletes all files with extensions `bmp` , `img`, `png`, `xpm` and `csv` in the directory set for automatic naming.

Example: `SENS:SWE:HCOP:FILE:AUTO:DIR 'var/nrp'`
 Hardcopy file are stored in directory `var/nrp` if automatic naming is activated.
`SENS:SWE:HCOP:FILEAUTO:DIR:CLE`
 Deletes all hardcopy file that are stored in the directory `var/nrp`.

Usage: Event

Manual operation: See ["Clear Parth"](#) on page 305

:SENSe[POWer]:SWEep:HCOPy:FILE[NAME]:AUTO:FILE?

Queries the file name generated with the automatic naming settings.

Note: As default the automatically generated file name is composed of: `>PAth>/<Prefix><YYYY><MM><DD><Number>.<Format>`. Each component can be deactivated/ activated separately to individually design the file name.

Return values:

`<File>` string

Example: `SENS:SWE:HCOP:DEV:LANG BMP`
 Selects output format `*.bmp`.
`SENS:SWE:HCOP:FILE:AUTO:DIR 'var/nrp'`
 Hardcopy files are stored in directory `var/nrp` if automatic naming is activated.
`SENS:SWE:HCOP:FILE:AUTO:PREF 'sens1'`
 The file name starts with the prefix `sens1`. The usage of automatic naming with prefix and date in the file name is preset (`...:STAT ON`).
`SENS:SWE:HCOP`
 Triggers the generation of a hardcopy of the current trace.
`SENS:SWE:HCOP:FILE:AUTO:FILE?`
 Queries the file name

Usage: Query only

Manual operation: See ["File name - Power Analysis"](#) on page 303

:SENSe[POWer]:SWEep:HCOPy:FILE[NAME]:AUTO:STATe <State>

Activates/deactivates automatic naming of the hardcopy files.

Parameters:

`<State>` 1 | ON | 0 | OFF
`*RST:` 1

Example: `SENS:SWE:HCOP:FILE:AUTO:STAT OFF`
 Deactivates automatic naming of the hardcopy files. The file name and directory is now defined with command.
`SENS:SWE:HCOP:FILE:NAME <psth>`

Manual operation: See ["File name - Power Analysis"](#) on page 303

:SENSe[:POWer]:SWEep:HCOPy:FILE[:NAME]:AUTO[:FILE]:DAY?

Queries the day of the date part in the automatic file name.

Return values:

<Day> integer
 Range: 1 to 31
 *RST: 1

Example: SENS:SWE:HCOP:FILE:AUTO:DAY?
 Queries the day of the date part in the automatic file name.

Usage: Query only

Manual operation: See ["Prefix, Year, Month, Day, Instrument Name"](#) on page 305

:SENSe[:POWer]:SWEep:HCOPy:FILE[:NAME]:AUTO[:FILE]:DAY:STATe <State>

Activates the usage of the day in the automatic file name.

Parameters:

<State> 1 | ON | 0 | OFF
 *RST: 1

Example: SENS:SWE:HCOP:FILE:AUTO:DAY:STAT OFF
 Deactivates the usage of the day in the automatic file name.

Manual operation: See ["Prefix, Year, Month, Day, Instrument Name"](#) on page 305

:SENSe[:POWer]:SWEep:HCOPy:FILE[:NAME]:AUTO[:FILE]:MONTH?

Queries the day of the date part in the automatic file name.

Return values:

<Month> integer
 Range: 1 to 12
 *RST: 1

Example: SENS:SWE:HCOP:FILE:AUTO:MONT?
 Queries the month of the date part in the automatic file name.

Usage: Query only

Manual operation: See ["Prefix, Year, Month, Day, Instrument Name"](#) on page 305

**:SENSe[:POWer]:SWEep:HCOPy:FILE[:NAME]:AUTO[:FILE]:MONTH:STATe
 <State>**

Activates the usage of the month in the automatic file name.

Parameters:

<State> 1 | ON | 0 | OFF
 *RST: 1

Example:

SENS:SWE:HCOP:FILE:AUTO:MONT:STAT OFF
 Deactivates the usage of the month in the automatic file name.

Manual operation: See ["Prefix, Year, Month, Day, Instrument Name"](#) on page 305

:SENSe[POWer]:SWEep:HCOPy:FILE[:NAME]:AUTO[:FILE]:NUMBer?

Queries the generated number in the automatic file name.

Return values:

<Number> integer
 Range: 0 to 999999
 *RST: 0

Example:

SENS:SWE:HCOP:FILE:AUTO:NUMB?
 Queries the number in the automatic file name.

Usage: Query only

Manual operation: See ["Current Auto Number"](#) on page 306

:SENSe[POWer]:SWEep:HCOPy:FILE[:NAME]:AUTO[:FILE]:PREFix <Prefix>

Sets the prefix part in the automatic file name.

Parameters:

<Prefix> string

Example:

SENS:SWE:HCOP:FILE:AUTO:PREF 'sensor'
 The prefix sensor is used in the automatically generated file name of the hardcopy file.

Manual operation: See ["Prefix, Year, Month, Day, Instrument Name"](#) on page 305

**:SENSe[POWer]:SWEep:HCOPy:FILE[:NAME]:AUTO[:FILE]:PREFix:STATe
<State>**

Activates the usage of the prefix in the automatic file name.

Parameters:

<State> 1 | ON | 0 | OFF
 *RST: 1

Example:

SENS:SWE:HCOP:FILE:AUTO:PREF:STAT OFF
 Deactivates the usage of the prefix in the automatic file name.

Manual operation: See ["Prefix, Year, Month, Day, Instrument Name"](#) on page 305

:SENSe[:POWer]:SWEep:HCOPy:FILE[:NAME]:AUTO[:FILE]:YEAR?

Queries the year of the date part in the automatic file name.

Return values:

<Year>	integer
Range:	1784 to 8000
*RST:	0

Example:

SENS:SWE:HCOP:FILE:AUTO:YEAR?

Queries the year of the date part in the automatic file name.

Usage:

Query only

Manual operation: See ["Prefix, Year, Month, Day, Instrument Name"](#) on page 305

:SENSe[:POWer]:SWEep:HCOPy:FILE[:NAME]:AUTO[:FILE]:YEAR:STATe <State>

Activates the usage of the year in the automatic file name.

Parameters:

<State>	1 ON 0 OFF
*RST:	1

Example:

SENS:SWE:HCOP:FILE:AUTO:YEAR:STAT OFF

Deactivates the usage of the year in the automatic file name.

Manual operation: See ["Prefix, Year, Month, Day, Instrument Name"](#) on page 305

:SENSe[:POWer]:SWEep:HCOPy[:EXECute]

Triggers the generation of a hardcopy of the current measurement diagram. The data is written into the file selected/created with the [:SENSe\[:POWer\]:SWEep:HCOPy:FILE\[:NAME\]](#) on page 569 command.

Example:

SENS:SWE:HCOP:DEV:LANG BMP

Selects output format *.bmp.

SENS:SWE:HCOP:FILE:AUTO:STAT OFF

Switches off automatic file naming.

SENS:SWE:HCOP:FILE 'var/nrp_tracel'

Creates the file nrp_tracel.bmp in the set path.

SENS:SWE:HCOP

Triggers the generation of a hardcopy of the current measurement diagram. The hardcopy is stored in the file nrp_tracel.bmp.

Usage:

Event

Manual operation: See ["File name - Power Analysis"](#) on page 303

:SENSe[:POWer]:SWEep:INITiate

Starts the power analysis with NRP power sensor.

Example: `SENS:SWE:INIT`
Start the power measurement.

Usage: Setting only

:SENSe[POWer]:SWEep:MODE <Mode>

Selects power versus frequency measurement (frequency response), power vs power measurement (power sweep, AM/AM) or power vs. time measurement.

Parameters:

<Mode> FREQuency | POWer | TIME
*RST: FREQuency

Example: `SENS:SWE:MODE FREQ`
Selects frequency mode.

Manual operation: See "[Mode](#)" on page 279

:SENSe[POWer]:SWEep:POWer:REFeRence:DATA:COpy

Generates a reference curve for "Power" measurement.

Example: `SENS:POW:SWE:POW:REF:DATA:COpy`
Generates a reference curve in power mode.

Usage: Event

Manual operation: See "[Save To Ref](#)" on page 276

:SENSe[POWer]:SWEep:POWer:REFeRence:DATA:POINts?

Queries the number of points from the reference curve in "Power" measurement.

Return values:

<Points> integer
Range: 10 to 1000

Example: `SENS:POW:SWE:POW:REF:DATA:POIN?`
Queries the number of points from the reference curve in power mode.

Usage: Query only

:SENSe[POWer]:SWEep:POWer:REFeRence:DATA:XVALues <XValues>

Sets or queries the x values of the two reference points, i.e. "Power X (Point A)" and "Power X (Point B)" in "Power" measurement.

Parameters:

<XValues> string

Example: `SENSe:POW:SWE:POW:REF:DATA:XVAL -15DBM,20DBM`
Sets the x value of reference "Point A" to -15 dBm, and the value of "Point B" to 20 dBm.

Manual operation: See "[Pow \(X\)](#)" on page 275

:SENSe[:POWer]:SWEep:POWer:REFeRence:DATA:YVALues <YValues>

Sets or queries the y values of the two reference points, i.e. "Power Y (Point A)" and "Power Y (Point B)" in "Power" measurement.

Parameters:

<YValues> string

Example: `SENSe:POW:SWE:TIME:REF:DATA:YVAL -30,10`
Sets the y value of reference "Point A" to -30 dBm, and the value of "Point B" to 10 dBm.

Manual operation: See "[Pow \(Y\)](#)" on page 276

:SENSe[:POWer]:SWEep:POWer:RMODe <RMode>

Selects single or continuous mode for measurement mode power in power analysis.

Parameters:

<RMode> SINGLE | CONTInuous

*RST: CONTInuous

Example: `SENS:SWE:POW:RMOD SING`
Selects single measurement.

Manual operation: See "[Execution](#)" on page 281

:SENSe[:POWer]:SWEep:POWer:SPACing[:MODE] <Mode>

Selects the spacing for the frequency power analysis.

Parameters:

<Mode> LINear

*RST: LINear

Example: `SENS:SWE:FREQ:SPAC:MODE LIN`
Sets linear spacing of the sweep.

Manual operation: See "[Spacing](#)" on page 281

:SENSe[:POWer]:SWEep:POWer:STARt <Start>

Sets the start level for the power versus power measurement.

Parameters:

<Start> float
 Range: -145 to 20
 Increment: 0.01
 *RST: 1MHZ

Example:

SENS:SWE:POW:STAR -20DBM
 Sets the start level to -20 dBm

Manual operation: See "[Min](#)" on page 279

:SENSe[:POWer]:SWEep:POWer:STEPs <Steps>

Sets the number of measurement steps for the power versus power measurement.

Parameters:

<Steps> integer
 Range: 10 to 1000
 *RST: 500

Example:

SENS:SWE:POW:STEP 500
 Sets the 500 measurement steps.

Manual operation: See "[Steps](#)" on page 280

:SENSe[:POWer]:SWEep:POWer:STOP <Stop>

Sets the stop level for the power versus power measurement.

Parameters:

<Stop> float
 Range: -145 to 20
 Increment: 0.01
 *RST: 40

Example:

SENS:SWE:POW:STOP 20.0DBM
 Sets the stop level to 20 dBm.

:SENSe[:POWer]:SWEep:POWer:TIMing[:MODE] <Mode>

Selects the timing mode of the measurement.

Parameters:

<Mode> FAST | NORMal

FAST

Selection FAST leads to a fast measurement with a short integration times for each measurement step.

NORMal

NORMal leads to a longer but more precise measurement due to a higher integration time for each step.

*RST: NORMal

Example: `SENS:SWE:POW:TIM:MODE FAST`
Selects fast mode.

Manual operation: See ["Timing"](#) on page 280

:SENSe[:POWER]:SWEep:POWer:YSCale:AUTO <Auto>

Activates autoscaling of the Y axis of the diagram.

Parameters:

<Auto> OFF | CEXPanding | FEXPanding | CFLoating | FFLoating

OFF

Auto scaling is deactivated. When switching from activated to deactivated Auto scaling, the scaling is maintained. When switching from deactivated to activated Auto scaling, the scaling is reset to min = max = 0.

CEXPanding | FEXPanding

Auto scale is activated. The scaling of the Y-axis is selected in such a way, that the trace is always visible. To this end, the range is expanded if the minimum or maximum values of the trace move outside the current scale. The step width is 5 dB for selection course and variable in the range of 0.2 dB to 5 dB for selection fine.

CFLoating | FFLoating

Auto scale is activated. The scaling of the Y-axis is selected in such a way, that the trace is always visible. To this end, the range is either expanded if the minimum or maximum values of the trace move outside the current scale or scaled down if the trace fits into a reduced scale. The step width is 5 dB for selection course and variable in the range of 0.2 dB to 5 dB for selection fine.

*RST: CEXPanding

Example: `SENS:SWE:POW:YSC:AUTO OFF`
Deactivates auto scale.

Manual operation: See ["Auto Scale"](#) on page 283

:SENSe[:POWER]:SWEep:POWer:YSCale:AUTO:RESet

Resets the Y scale to suitable values after the use of auto scaling in the expanding mode. For this mode, the scale might get expanded because of temporarily high power values. The reset function allows resetting the diagram to match smaller power values again.

Example: `SENS:SWE:POW:YSC:AUTO:RES`
Resets auto scale.

Usage: Event

Manual operation: See ["Reset Auto Scale"](#) on page 283

:SENSe[:POWer]:SWEep:POWer:YSCale:MAXimum <Maximum>

Sets the maximum value for the y axis of the measurement diagram.

Parameters:

<Maximum> float
 Range: -200 to 100
 Increment: 0.01
 *RST: 30

Example: SENS:SWE:POW:YSC:MAX 10DBM
 Sets 10 dBm as the upper limit of the measurement diagram.

Manual operation: See ["Min - Max Level"](#) on page 282

:SENSe[:POWer]:SWEep:POWer:YSCale:MINimum <Minimum>

Sets the minimum value for the y axis of the measurement diagram.

Parameters:

<Minimum> float
 Range: -200 to 100
 Increment: 0.01
 *RST: -40

Example: SENS:SWE:POW:YSC:MIN -10DBM
 Sets -10 dBm as the lower limit of the measurement diagram.

Manual operation: See ["Min - Max Level"](#) on page 282

:SENSe[:POWer]:SWEep:RMODe <RMode>

Selects single or continuous mode for power analysis (all measurement modes).

Parameters:

<RMode> SINGLE | CONTInuous
 *RST: SINGLE

Example: SENS:SWE:RMOD SING
 Selects single measurement.

Manual operation: See ["Execution"](#) on page 281

:SENSe[:POWer]:SWEep:TIME:AVERAge[:COUNT] <Count>

Selects the averaging factor in time mode. The count number determines how many measurement cycles are used to form a measurement result. Higher averaging counts reduce noise but increase the measurement time. Averaging requires a stable trigger event so that the measurement cycles have the same timing.

Parameters:

<Count> 1 | 2 | 4 | 8 | 16 | 32 | 64 | 128 | 256 | 512 | 1024
 *RST: 1

Example: `SENS:SWE:MODE TIME`
 Selects time mode.
 `SENS:SWE:TIME:AVER 128`
 Selects averaging factor 128.

Manual operation: See ["Average"](#) on page 280

:SENSe[:POWer]:SWEep:TIME:REFerence:DATA:COpy

Generates a reference curve for "Time" measurement.

Example: `SENS:POW:SWE:TIME:REF:DATA:COpy`
 Generates a reference curve in time mode.

Usage: Event

Manual operation: See ["Save To Ref"](#) on page 276

:SENSe[:POWer]:SWEep:TIME:REFerence:DATA:POINts?

Queries the number of points from the reference curve in "Time" measurement.

Return values:

<Points> integer
 Range: 10 to 1000
 *RST: 0

Example: `SENS:POW:SWE:TIME:REF:DATA:POIN?`
 Queries the number of points from the reference curve in time mode.

Usage: Query only

:SENSe[:POWer]:SWEep:TIME:REFerence:DATA:XVALues <XValues>

Sets or queries the x values of the two reference points, i.e. "Time X (Point A)" and "Time X (Point B)" in "Time" measurement.

Parameters:

<XValues> string

Example: `SENSe:POW:SWE:TIME:REF:DATA:XVAL 5,45`
 Sets the x value of reference "Point A" to 5 μ s, and the value of "Point B" to 45 μ s.

Manual operation: See ["Time \(X\)"](#) on page 276

:SENSe[:POWer]:SWEep:TIME:REFerence:DATA:YVALues <YValues>

Sets or queries the y values of the two reference points, i.e. "Power Y (Point A)" and "Power Y (Point B)" in "Time" measurement.

Parameters:

<YValues> string

Example:

SENSe:POW:SWE:TIME:REF:DATA:YVAL -30,10
 sets the y value of reference "Point A" to -30 dBm, and the value of "Point B" to 10 dBm.

Manual operation: See ["Pow \(Y\)"](#) on page 276

:SENSe[:POWer]:SWEep:TIME:RMODe <RMode>

Selects single or continuous mode for measurement mode time in power analysis.

Parameters:

<RMode> SINGLE | CONTInuous
 *RST: CONTInuous

Example:

SENS:SWE:TIME:RMOD SING
 Selects single measurement.

Manual operation: See ["Execution"](#) on page 281

:SENSe[:POWer]:SWEep:TIME:SPACing[:MODE] <Mode>

Queries the sweep spacing for the power versus time measurement. The spacing is fixed to linear.

Parameters:

<Mode> LINear
 *RST: LINear

Example:

SENS:SWE:TIME:SPAC?
 Queries the sweep spacing.

Manual operation: See ["Spacing"](#) on page 281

:SENSe[:POWer]:SWEep:TIME:STARt <Start>

Sets the start time for the power versus time measurement. Value 0 defines the trigger point. By choosing a negative time value, the trace can be shifted in the diagram. It is possible, that the measurement cannot be performed over the complete time range because of limitations due to sensor settings. In this case, an error message is output.

Parameters:

<Start> float
 Range: -1 to 1
 Increment: 1E-12
 *RST: -5E-6

Example:

SENS:SWE:TIME:STAR 0s
 Sets the start time to 0 s.

Manual operation: See ["Min"](#) on page 279

:SENSe[:POWer]:SWEep:TIME:STEPS <Steps>

Sets the number of measurement steps for the power versus time measurement. Value 0 defines the trigger point.

Parameters:

<Steps> integer
 Range: 10 to 1000
 *RST: 500

Example: SENS:SWE:TIME:STEP 500
 Sets the 500 measurement steps.

Manual operation: See ["Steps"](#) on page 280

:SENSe[:POWer]:SWEep:TIME:STOP <Stop>

Sets the stop time for the power versus time measurement.

Parameters:

<Stop> float
 Range: 0 to 2
 Increment: 1E-12
 *RST: 1E-3

Example: SENS:SWE:TIME:STOP 1ms
 Sets the stop time to 1 ms.

Manual operation: See ["Max"](#) on page 279

:SENSe[:POWer]:SWEep:TIME:TEVents <TriggerTEvents>

Determines, whether the measurement data processing starts with a trigger event in one of the sensors (Logical OR), or whether all channels have to be triggered (logical AND). Each sensor evaluates a trigger event according to its setting independently. This function supports the internal or external trigger modes with multi-channel time measurements.

Parameters:

<TriggerTEvents> AND | OR
 *RST: AND

Example: SENS:POW:SWE:TIME:TEV AND
 The measurement data processing starts when all channels are triggered.

Options: Option R&S SMAB-K28

Manual operation: See ["All Trigger Events"](#) on page 281

:SENSe[:POWer]:SWEep:TIME:YSCale:AUTO <Auto>

Activates autoscaling of the Y axis in the diagram.

Parameters:

<Auto>

OFF | CEXpanding | FEXpanding | CFLoating | FFLoating

OFF

Auto scaling is deactivated. When switching from activated to deactivated Auto scaling, the scaling is maintained. When switching from deactivated to activated Auto scaling, the scaling is reset to min = max = 0.

CEXpanding | FEXpanding

Auto scale is activated. The scaling of the Y-axis is selected in such a way, that the trace is always visible. To this end, the range is expanded if the minimum or maximum values of the trace move outside the current scale. The step width is 5 dB for selection course and variable in the range of 0.2 dB to 5 dB for selection fine.

CFLoating | FFLoating

Auto scale is activated. The scaling of the Y-axis is selected in such a way, that the trace is always visible. To this end, the range is either expanded if the minimum or maximum values of the trace move outside the current scale or scaled down if the trace fits into a reduced scale. The step width is 5 dB for selection course and variable in the range of 0.2 dB to 5 dB for selection fine.

*RST: CEXpanding

Example:

SENS:SWE:TIME:YSC:AUTO OFF

Deactivates auto scale

Manual operation: See ["Auto Scale"](#) on page 283

:SENSe[:POWer]:SWEep:TIME:YSCale:AUTO:RESet

Resets the Y scale to suitable values after the use of auto scaling in the expanding mode. For this mode, the scale might get expanded because of temporarily high power values. The reset function allows resetting the diagram to match smaller power values again.

Example:

SENS:SWE:TIME:YSC:AUTO:RES

Resets auto scale.

Usage:

Event

Manual operation: See ["Reset Auto Scale"](#) on page 283

:SENSe[:POWer]:SWEep:TIME:YSCale:MAXimum <Maximum>

Sets the maximum value for the y axis of the measurement diagram.

Parameters:

<Maximum> float
 Range: -200 to 100
 Increment: 0.01
 *RST: 30.0
 Default unit: dBm

Example:

SENS:SWE:TIME:YSC:MAX 10DBM
 Sets 10 dBm as the upper limit of the measurement diagram.

Manual operation: See "Min - Max Level" on page 282

:SENSe[:POWer]:SWEep:TIME:YSCale:MINimum <Minimum>

Sets the minimum value for the y axis of the measurement diagram.

Parameters:

<Minimum> float
 Range: -200 to 100
 Increment: 0.01
 *RST: dBm

Example:

SENS:SWE:TIME:YSC:MIN -10DBM
 Sets -10 dBm as the lower limit of the measurement diagram.

Manual operation: See "Min - Max Level" on page 282

15.15.6 TRACe subsystem

:TRACe<ch>:FREQ:SWEep:SRC.....	585
:TRACe<ch>:POW:SWEep:SRC.....	585
:TRACe<ch>:TIME:SWEep:SRC.....	586
:TRACe<ch>[:POWer]:SWEep:COLor.....	586
:TRACe<ch>[:POWer]:SWEep:COPY.....	587
:TRACe<ch>[:POWer]:SWEep:DATA:POINts?.....	587
:TRACe<ch>[:POWer]:SWEep:DATA:XVALues?.....	587
:TRACe<ch>[:POWer]:SWEep:DATA:YSValue?.....	588
:TRACe<ch>[:POWer]:SWEep:DATA:YVALues?.....	588
:TRACe<ch>[:POWer]:SWEep:FEED.....	588
:TRACe<ch>[:POWer]:SWEep:MEASurement:POWer:AVERage?.....	589
:TRACe<ch>[:POWer]:SWEep:MEASurement:POWer:HREFerence?.....	589
:TRACe<ch>[:POWer]:SWEep:MEASurement:POWer:LREFerence?.....	589
:TRACe<ch>[:POWer]:SWEep:MEASurement:POWer:MAXimum?.....	589
:TRACe<ch>[:POWer]:SWEep:MEASurement:POWer:MINimum?.....	589
:TRACe<ch>[:POWer]:SWEep:MEASurement:POWer:PULSe:BASE?.....	589
:TRACe<ch>[:POWer]:SWEep:MEASurement:POWer:PULSe:TOP?.....	589
:TRACe<ch>[:POWer]:SWEep:MEASurement:POWer:REFerence?.....	589
:TRACe<ch>[:POWer]:SWEep:MEASurement:PULSe:DCYCLe?.....	589
:TRACe<ch>[:POWer]:SWEep:MEASurement:PULSe:DURation?.....	589
:TRACe<ch>[:POWer]:SWEep:MEASurement:PULSe:PERiod?.....	589

Power sensor measurement subsystems

:TRACe<ch>[:POWer]:SWEep:MEASurement:PULSe:SEParation?	589
:TRACe<ch>[:POWer]:SWEep:MEASurement:PULSe:STATe?	589
:TRACe<ch>[:POWer]:SWEep:MEASurement:TRANSition:NEGative:DURation?	589
:TRACe<ch>[:POWer]:SWEep:MEASurement:TRANSition:NEGative:OCCurrence?	589
:TRACe<ch>[:POWer]:SWEep:MEASurement:TRANSition:NEGative:OVERshoot?	589
:TRACe<ch>[:POWer]:SWEep:MEASurement:TRANSition:POSitive:DURation?	589
:TRACe<ch>[:POWer]:SWEep:MEASurement:TRANSition:POSitive:OCCurrence?	589
:TRACe<ch>[:POWer]:SWEep:MEASurement:TRANSition:POSitive:OVERshoot?	589
:TRACe<ch>[:POWer]:SWEep:MEASurement:PULSe:DCYCLe:DISPlay:ANNotation[: STATe]	590
:TRACe<ch>[:POWer]:SWEep:MEASurement:PULSe:DURation:DISPlay:ANNotation[: STATe]	590
:TRACe<ch>[:POWer]:SWEep:MEASurement:PULSe:PERiod:DISPlay:ANNotation[: STATe]	590
:TRACe<ch>[:POWer]:SWEep:MEASurement:POWer:AVErAge:DISPlay:ANNotation[: STATe]	590
:TRACe<ch>[:POWer]:SWEep:MEASurement:POWer:PULSe:BASE:DISPlay: ANNotation[:STATe]	590
:TRACe<ch>[:POWer]:SWEep:MEASurement:POWer:HREFerence:DISPlay: ANNotation[:STATe]	590
:TRACe<ch>[:POWer]:SWEep:MEASurement:POWer:LREFerence:DISPlay: ANNotation[:STATe]	590
:TRACe<ch>[:POWer]:SWEep:MEASurement:POWer:MAXimum:DISPlay:ANNotation[: STATe]	590
:TRACe<ch>[:POWer]:SWEep:MEASurement:POWer:MINimum:DISPlay:ANNotation[: STATe]	590
:TRACe<ch>[:POWer]:SWEep:MEASurement:POWer:REFerence:DISPlay:ANNotation[: STATe]	590
:TRACe<ch>[:POWer]:SWEep:MEASurement:POWer:PULSe:TOP:DISPlay: ANNotation[:STATe]	590
:TRACe<ch>[:POWer]:SWEep:MEASurement:PULSe:SEParation:DISPlay:ANNotation[: STATe]	590
:TRACe<ch>[:POWer]:SWEep:MEASurement:TRANSition:NEGative:DURation:DISPlay: ANNotation[:STATe]	590
:TRACe<ch>[:POWer]:SWEep:MEASurement:TRANSition:NEGative:OCCurrence: DISPlay:ANNotation[:STATe]	590
:TRACe<ch>[:POWer]:SWEep:MEASurement:TRANSition:NEGative:OVERshoot: DISPlay:ANNotation[:STATe]	590
:TRACe<ch>[:POWer]:SWEep:MEASurement:TRANSition:POSitive:DURation:DISPlay: ANNotation[:STATe]	590
:TRACe<ch>[:POWer]:SWEep:MEASurement:TRANSition:POSitive:OCCurrence: DISPlay:ANNotation[:STATe]	590
:TRACe<ch>[:POWer]:SWEep:MEASurement:TRANSition:POSitive:OVERshoot: DISPlay:ANNotation[:STATe]	590
:TRACe<ch>[:POWer]:SWEep:MEASurement:PULSe:ALL:DISPlay:ANNotation[:STATe]	591
:TRACe<ch>[:POWer]:SWEep:PULSe:THReshold:BASE?	591
:TRACe<ch>[:POWer]:SWEep:PULSe:THReshold:POWer:HREFerence	591
:TRACe<ch>[:POWer]:SWEep:PULSe:THReshold:POWer:LREFerence	592
:TRACe<ch>[:POWer]:SWEep:PULSe:THReshold:POWer:REFerence	592
:TRACe<ch>[:POWer]:SWEep:STATe	592

:TRACe[:POWer]:SWEep:MEASurement:FULLscreen:DISPlay:ANNotation[:STATe].....	593
:TRACe[:POWer]:SWEep:MEASurement:GATE:DISPlay:ANNotation[:STATe].....	593
:TRACe[:POWer]:SWEep:MEASurement:MARKer:DISPlay:ANNotation[:STATe].....	594
:TRACe[:POWer]:SWEep:MEASurement:PULSe:DISPlay:ANNotation[:STATe].....	594
:TRACe[:POWer]:SWEep:MEASurement:STANdard:DISPlay:ANNotation[:STATe].....	594

:TRACe<ch>:FREQ:SWEep:SRC <FreqSource>

Determines the source of a trace for display in frequency measurement mode.

Parameters:

<FreqSource>	OFF SEN1 SEN2 SEN3 SEN4 HOLD REF ON
	ON OFF
	Activates or deactivates the display of a trace.
	SEN1 SEN2 SEN3 SEN4
	Activates the measurement results display of the sensor that is assigned to the trace.
	REF
	Selects a reference trace.
	HOLD
	Freezes the measurement results display of the sensor that is assigned to the trace.
	*RST: OFF

Example:

```
:TRACe2:FREQ:SWEep:SRC SEN2
Selects sensor2 for display in trace 2.
:TRACe1:FREQ:SWEep:SRC REF
Assigns the reference trace to trace 1.
:TRACe1:FREQ:SWEep:SRC ON
Activates trace 1 i.e. the reference trace.
```

Manual operation: See ["Indication - Trace Power Analysis"](#) on page 273

:TRACe<ch>:POW:SWEep:SRC <PowSource>

Determines the trace source of a trace for display in power measurement mode.

Parameters:

<PowSource>	OFF SEN1 SEN2 SEN3 SEN4 HOLD REF ON
	ON OFF
	Activates or deactivates the display of a trace.
	SEN1 SEN2 SEN3 SEN4
	Activates the measurement results display of the sensor that is assigned to the trace.
	REF
	Selects a reference trace.
	HOLD
	Freezes the measurement results display of the sensor that is assigned to the trace.

*RST: OFF

Example:

:TRACe1:POW:SWEep:SRC SEN1

Selects the connector assigned to the first port for display in trace 1.

:TRACe2:POW:SWEep:SRC HOLD

Freezes the power sweep measurement results in trace 1.

Manual operation: See ["Indication - Trace Power Analysis"](#) on page 273

:TRACe<ch>:TIME:SWEep:SRC <TimeSource>

Determines the trace source of a trace for display in time measurement mode.

Parameters:

<TimeSource> OFF | SEN1 | SEN2 | SEN3 | SEN4 | HOLD | REF | ON

ON|OFF

Activates or deactivates the display of a trace.

SEN1|SEN2|SEN3|SEN4

Activates the measurement results display of the sensor that is assigned to the trace.

REF

Selects a reference trace.

HOLD

Freezes the measurement results display of the sensor that is assigned to the trace.

*RST: OFF

Example:

:TRACe2:TIME:SWEep:SRC SEN2

Selects sensor2 for display in trace 2.

:TRACe1:TIME:SWEep:SRC REF

Assigns the reference trace to trace 1.

:TRACe1:TIME:SWEep:SRC ON

Activates trace 1 i.e. the reference trace.

Manual operation: See ["Indication - Trace Power Analysis"](#) on page 273

:TRACe<ch>[:POWer]:SWEep:COLor <Color>

Defines the color of a trace.

Parameters:

<Color> INVers | GRAY | YELLow | BLUE | GREen | RED | MAGenta

*RST: trace 1 = YELLow, trace 2 = GREen, trace 3 = RED.

Example:

TRAC2:SWE:COL GRAY

Trace2 is indicated in gray color.

Manual operation: See ["Color - Trace Power Analysis"](#) on page 273

:TRACe<ch>[:POWer]:SWEep:COpy <Copy>

Stores the selected trace data as reference trace.

Setting parameters:

<Copy> REFeRence

Example: TRAC2:SWE:COpy REF
Stores the current trace2 as reference trace'
TRAC1:SWE:FEED REF
Assigns the reference trace to trace 1.

Usage: Setting only

Manual operation: See ["Save to Ref - Trace Power Analysis"](#) on page 273

:TRACe<ch>[:POWer]:SWEep:DATA:POINts?

Queries the number of measurement points of the selected trace of the current power analysis.

Return values:

<Points> integer
Range: 10 to 1000
*RST: 0

Example: TRAC1:SWE:DATA:POIN?
Response: 624
Measurement trace 1 contains 624 measurement points

Usage: Query only

:TRACe<ch>[:POWer]:SWEep:DATA:XVALues?

Queries the x-axis values - frequency, power or time values - of the selected trace of the current power analysis.

Return values:

<XValues> string

Example: SENS:SWE:MODE FREQ
Sets measurement mode frequency versus power.
SENS:SWE:RMOD SING
Selects single measurement.
SENS:SWE:INIT
Starts the measurement.
*OPC?
Waits until measurement is performed.
TRAC1:SWE:DATA:XVAL?
Queries the x-axis values of trace 1.
TRAC1:SWE:DATA:YVAL?
Queries the y-axis values of trace 1

Usage: Query only

:TRACe<ch>[:POWer]:SWEep:DATA:YSValue? <XValue>

For a given x-axis value, queries the measurement (y-axis) value of the selected trace of the current power analysis.

Query parameters:

<XValue> float

Return values:

<YSValue> float
Increment: 1E-9

Example: TRACe1:SWE:DATA:YSValue? 2.3

Example: Queries the y-axis values of trace 1 at x-axis value of 2.3.
See :TRACe<ch>[:POWer]:SWEep:DATA:XVALues?
on page 587.

Usage: Query only

:TRACe<ch>[:POWer]:SWEep:DATA:YVALues?

Queries the measurement (y-axis) values of the selected trace of the current power analysis.

Return values:

<YValues> string

Example: SENS:SWE:TRAC2:DATA:YVAL?
Queries the power values of trace 2.
See :TRACe<ch>[:POWer]:SWEep:DATA:XVALues?
on page 587.

Usage: Query only

:TRACe<ch>[:POWer]:SWEep:FEED <Feed>

Selects the source for the trace data.

Parameters:

<Feed> SENS1 | SENS2 | SENS3 | REFerence | NONE | SENSor1 |
SENSor2 | SENSor3 | SENS4 | SENSor4

*RST: The preset value for each trace is evaluated during runtime as follows: If a sensor is plugged into the generator whose number corresponds to the trace number, this sensor is used to feed the trace and the state of the trace is ON; If no sensor is found with number corresponding to the trace number, the preset value of the trace is "Off".

Example:

```

TRAC2:SWE:COPY REF
Stores trace2 as reference trace.
TRAC1:SWE:FEED REF
Assigns the reference trace to trace 1.
TRAC1:SWE:STAT ON
Assigns the reference trace to trace 1.
SENS:SWE:RMOD SING
Selects single measurement
SENS:SWE:INIT
Starts the measurement

```

Manual operation: See ["Indication - Trace Power Analysis"](#) on page 273

```

:TRACe<ch>[:POWer]:SWEep:MEASurement:POWer:AVERage?
:TRACe<ch>[:POWer]:SWEep:MEASurement:POWer:HREFerence?
:TRACe<ch>[:POWer]:SWEep:MEASurement:POWer:LREFerence?
:TRACe<ch>[:POWer]:SWEep:MEASurement:POWer:MAXimum?
:TRACe<ch>[:POWer]:SWEep:MEASurement:POWer:MINimum?
:TRACe<ch>[:POWer]:SWEep:MEASurement:POWer:PULSe:BASE?
:TRACe<ch>[:POWer]:SWEep:MEASurement:POWer:PULSe:TOP?
:TRACe<ch>[:POWer]:SWEep:MEASurement:POWer:REFerence?
:TRACe<ch>[:POWer]:SWEep:MEASurement:PULSe:DCYCLE?
:TRACe<ch>[:POWer]:SWEep:MEASurement:PULSe:DURation?
:TRACe<ch>[:POWer]:SWEep:MEASurement:PULSe:PERiod?
:TRACe<ch>[:POWer]:SWEep:MEASurement:PULSe:SEParation?
:TRACe<ch>[:POWer]:SWEep:MEASurement:PULSe:STATe?
:TRACe<ch>[:POWer]:SWEep:MEASurement:TRANSition:NEGative:DURation?
:TRACe<ch>[:POWer]:SWEep:MEASurement:TRANSition:NEGative:
  OCCurrence?
:TRACe<ch>[:POWer]:SWEep:MEASurement:TRANSition:NEGative:OVERshoot?
:TRACe<ch>[:POWer]:SWEep:MEASurement:TRANSition:POSitive:DURation?
:TRACe<ch>[:POWer]:SWEep:MEASurement:TRANSition:POSitive:OCCurrence?
:TRACe<ch>[:POWer]:SWEep:MEASurement:TRANSition:POSitive:OVERshoot?

```

The above listed commands query the measured pulse parameter values.

Note: These commands are only available in time measurement mode and with R&S NRP-Z81 power sensors.

Return values:

```

<Overshoot>      float
                  Range:    0 to 100
                  Increment: 0.01
                  *RST:     0

```

Example:

```

TRAC1:SWE:MEAS:POW:HREF?
Queries the measured mesial threshold level of trace 1.
TRAC3:SWE:MEAS:POW:MAX?
Queries the measured peak power of trace 3.

```

Usage:

Query only

Manual operation: See "[Overshoot \(Rising Edge / Falling Edge\)](#)" on page 296

```
:TRACe<ch>[:POWer]:SWEep:MEASurement:PULSe:DCYClE:DISPlay:
  ANNotation[:STATe] <State>
:TRACe<ch>[:POWer]:SWEep:MEASurement:PULSe:DURation:DISPlay:
  ANNotation[:STATe] <State>
:TRACe<ch>[:POWer]:SWEep:MEASurement:PULSe:PERiod:DISPlay:
  ANNotation[:STATe] <State>
:TRACe<ch>[:POWer]:SWEep:MEASurement:POWer:AVERage:DISPlay:
  ANNotation[:STATe] <State>
:TRACe<ch>[:POWer]:SWEep:MEASurement:POWer:PULSe:BASE:DISPlay:
  ANNotation[:STATe] <State>
:TRACe<ch>[:POWer]:SWEep:MEASurement:POWer:HREFerence:DISPlay:
  ANNotation[:STATe] <State>
:TRACe<ch>[:POWer]:SWEep:MEASurement:POWer:LREFerence:DISPlay:
  ANNotation[:STATe] <State>
:TRACe<ch>[:POWer]:SWEep:MEASurement:POWer:MAXimum:DISPlay:
  ANNotation[:STATe] <State>
:TRACe<ch>[:POWer]:SWEep:MEASurement:POWer:MINimum:DISPlay:
  ANNotation[:STATe] <State>
:TRACe<ch>[:POWer]:SWEep:MEASurement:POWer:REFerence:DISPlay:
  ANNotation[:STATe] <State>
:TRACe<ch>[:POWer]:SWEep:MEASurement:POWer:PULSe:TOP:DISPlay:
  ANNotation[:STATe] <State>
:TRACe<ch>[:POWer]:SWEep:MEASurement:PULSe:SEParation:DISPlay:
  ANNotation[:STATe] <State>
:TRACe<ch>[:POWer]:SWEep:MEASurement:TRANSition:NEGative:DURation:
  DISPlay:ANNotation[:STATe] <State>
:TRACe<ch>[:POWer]:SWEep:MEASurement:TRANSition:NEGative:OCCurrence:
  DISPlay:ANNotation[:STATe] <State>
:TRACe<ch>[:POWer]:SWEep:MEASurement:TRANSition:NEGative:OVERshoot:
  DISPlay:ANNotation[:STATe] <State>
:TRACe<ch>[:POWer]:SWEep:MEASurement:TRANSition:POSitive:DURation:
  DISPlay:ANNotation[:STATe] <State>
:TRACe<ch>[:POWer]:SWEep:MEASurement:TRANSition:POSitive:OCCurrence:
  DISPlay:ANNotation[:STATe] <State>
:TRACe<ch>[:POWer]:SWEep:MEASurement:TRANSition:POSitive:OVERshoot:
  DISPlay:ANNotation[:STATe] <State>
```

The above listed commands select the pulse parameters which are indicated in the display and hardcopy file. Only six parameters can be indicated at a time.

Note: These commands are only available in time measurement mode and with R&S NRP-Z81 power sensors.

Parameters:

<State> 1 | ON | 0 | OFF
 *RST: 0

- Example:** `TRAC:SWE:MEAS:TRAC2:PULS:PER:DISP:ANN ON`
 Selects the pulse period to be indicated in the display.
`TRAC:SWE:MEAS:PULS:DISP:ANN ON`
 Activates indication of the selected pulse data in the display.
- Options:** Option R&S SMAB-K28
- Manual operation:** See ["Overshoot \(Rising Edge / Falling Edge\)"](#) on page 296

:TRACe<ch>[:POWer]:SWEep:MEASurement:PULSe:ALL:DISPlay:ANNotation[:STATE] <State>

Deactivates the indication of all pulse data of the selected trace. The parameters to be indicated can be selected with the `TRAC:SWE:MEAS:... .` commands. Only six parameters are indicated at a time.

Note: This command is only available in time measurement mode and with R&S NRP-Z81 power sensors.

Parameters:
 <State> 1 | ON | 0 | OFF
 *RST: 0

Example: `TRAC:SWE:MEAS:PULS:ALL:DISP:ANN OFF`
 Switches the indication of all pulse data off.

Options: Option R&S SMAB-K28

:TRACe<ch>[:POWer]:SWEep:PULSe:THReshold:BASE?

Queries how the threshold parameters are calculated.

Note: This parameter is only available in time measurement mode and R&S NRP-Z81 power sensors.

Return values:
 <Base> VOLTage | POWer
 *RST: VOLTage

Example: `TRAC1:SWE:PULS:THR:BAS?`
 Queries the threshold base of pulse data calculation.

Usage: Query only

Manual operation: See ["Base"](#) on page 289

:TRACe<ch>[:POWer]:SWEep:PULSe:THReshold:POWer:HREference<HReference>

Queries the upper threshold level of the overall pulse level. The distal power defines the end of the rising edge and the start of the falling edge of the pulse.

Note: This parameter is only available in time measurement mode and R&S NRP-Z81 power sensors.

Parameters:

<HReference> float
 Range: 0.0 to 100.0
 Increment: 0.01
 *RST: 90.0

Example:

TRAC2:SWE:PULS:THR:POW:HREF?
 Queries the upper reference level of trace 2.

Manual operation: See ["Distal"](#) on page 289

:TRACe<ch>[:POWer]:SWEep:PULSe:THReshold:POWer:LREference
 <LReference>

Queries the lower medial threshold level of the overall pulse level. The proximal power defines the start of the rising edge and the end of the falling edge of the pulse.

Note: This parameter is only available in time measurement mode and R&S NRP-Z81 power sensors.

Parameters:

<LReference> float
 Range: 0.0 to 100.0
 Increment: 0.01
 *RST: 10.0

Example:

TRAC:SWE:PULS:THR:POW:LREF?
 Queries the medial threshold level of trace 1.

Manual operation: See ["Proximal"](#) on page 290

:TRACe<ch>[:POWer]:SWEep:PULSe:THReshold:POWer:REference <Reference>

Queries the medial threshold level of the overall pulse level. This level is used to define the pulse width and pulse period.

Note: This parameter is only available in time measurement mode and R&S NRP-Z81 power sensors.

Parameters:

<Reference> float
 Range: 0.0 to 100.0
 Increment: 0.01
 *RST: 50.0

Example:

TRAC3:SWE:PULS:THR:POW:REF?
 Queries the medial threshold level of trace 3.

Manual operation: See ["Mesial"](#) on page 290

:TRACe<ch>[:POWer]:SWEep:STATe <State>

Activates the selected trace.

Parameters:

<State> OFF | ON | HOLD

*RST: The preset value for each trace is evaluated during runtime as follows: If a sensor is plugged into the generator whose number corresponds to the trace number, this sensor is used to feed the trace and the state of the trace is ON; If no sensor is found with a number corresponding to the trace number, the preset value of the trace is "Off".

Example:

TRAC2:SWE:COPY REF
Stores trace2 as reference trace.
TRAC1:SWE:FEED REF
Assigns the reference trace to trace 1.
TRAC1:SWE:STAT ON
Assigns the reference trace to trace 1.
SENS:SWE:RMOD SING
Selects single measurement.
SENS:SWE:INIT
Starts the measurement.

Manual operation: See ["Indication - Trace Power Analysis"](#) on page 273

:TRACe[:POWer]:SWEep:MEASurement:FULLscreen:DISPlay:ANNotation[:STATE] <State>

Selects fullscreen display of the measurement diagram on the display and in the hard-copy file.

Parameters:

<State> 1 | ON | 0 | OFF

*RST: 1

Example:

TRAC:SWE:MEAS:FULL:DISP:ANN ON
The display only shows the diagram.

Options:

Option R&S SMAB-K28

Manual operation: See ["Full Screen"](#) on page 287

:TRACe[:POWer]:SWEep:MEASurement:GATE:DISPlay:ANNotation[:STATE] <State>

Activates the indication of the time gate borders and values in the measurement diagram and in the hardcopy file. The gate settings are performed with the CALC:POW:SWE:TIME:GATE:... commands.

Parameters:

<State> 1 | ON | 0 | OFF

*RST: 1

Example: TRAC:SWE:MEAS:GATE:DISP:ANN ON
The diagram also shows the gate information.

Options: Option R&S SMAB-K28

Manual operation: See "[Gate View](#)" on page 286

:TRACe[:POWer]:SWEep:MEASurement:MARKer:DISPlay:ANNotation[:STATe]
<State>

Activates the indication of the markers and the marker list in the measurement diagram and in the hardcopy file.

Parameters:
<State> 1 | ON | 0 | OFF
*RST: 1

Example: TRAC:SWE:MEAS:MARK:DISP:ANN ON
The diagram also shows the marker information.

Options: Option R&S SMAB-K28

Manual operation: See "[Marker View](#)" on page 285

:TRACe[:POWer]:SWEep:MEASurement:PULSe:DISPlay:ANNotation[:STATe]
<State>

Activates the indication of the pulse data below the measurement diagram and storing the data in the hardcopy file. The parameters to be indicated can be selected with the following TRAC:SWE:MEAS:... commands. Only six parameters are indicated at one time.

Note: This command is only available in time measurement mode and with R&S NRPZ81 power sensors.

Parameters:
<State> 1 | ON | 0 | OFF
*RST: 1

Example: TRAC:SWE:MEAS:PULS:DISP:ANN ON
Activates indication of the selected pulse data.

Options: Option R&S SMAB-K28

Manual operation: See "[Pulse Data View](#)" on page 286

:TRACe[:POWer]:SWEep:MEASurement:STANdard:DISPlay:ANNotation[:STATe]
<State>

Selects the standard view, i.e. diagram and buttons but no lists are displayed and also stored in the hardcopy file.

Parameters:

<State> 1 | ON | 0 | OFF
 *RST: 1

Example:

TRAC:SWE:MEAS:STAN:DISP:ANN ON
 Activates indication of the selected pulse data.

Options:

Option R&S SMAB-K28

Manual operation: See "Standard View" on page 285

15.16 SENSe, READ, INITiate and SLISt subsystems

These subsystems contain the commands for configuring the power measurements with R&S NRP power sensor connected to the R&S SMA100B.



The local state is set with the `INIT` command. Switching off the local state enhances the measurement performance. Measurements results can be retrieved in local state on or off.

Sensor parameters are set with the `SENSe` commands.

To start the measurement and retrieve the result, use the `:READ<ch>[:POWER]?` command.

Suffix	Value range	Description
SENSe<ch>	[1] to 4	Indicates the sensor Sensor mapping: • <code>SENSe[1]</code> - default mapping for sensors connected to the [Sensor] connector • <code>SENSe2</code> - sensor connected to a [USB] connector • <code>SENSe3 4</code> - further connected sensors to [USB] connectors, in the connection order Use the <code>:SLISt</code> commands to change the sensor mapping
READ<ch>	[1] to 4	Sensor assignment
INITiate<hw>	[1] to 4	Sensor assignment
ELEMeNt<ch>	[1] to 25	Sensor-mapping list

Programming examples

Example: Detecting and assigning a power sensor

```
SLISt:LIST?
// Response: "NRP33SN-V-900007-USB Legacy","NRP-Z211-900001-USB Legacy"
// Lists all automatically detected sensors.

SLISt:SCAN:STATe 1
// Searches for sensors connected in the LAN or via the USBTMC protocol.

SLISt:SCAN:LENSor 'NRQ6',101624 // sensor name, serial number
SLISt:SCAN:LENSor 11.123.1.123, 101624 // IP address, serial number
// Adds sensors to the list, that are connected to LAN.

SLISt:SCAN:USENSor 'NRQ6',101624 //sensor name, serial number
SLISt:SCAN:USENSor #H15b,101624 //device ID (hexadecimal), serial number
SLISt:SCAN:USENSor 347,101624 //device ID (decimal), serial number
// Adds a sensor to the list, that is connected to the USB interface.

SLISt:LIST?
// Response: "NRP33SN-V-900007-USB Legacy","NRP-Z211-900001-USB Legacy",
// "NRP33SN-V-900005-USBTMC","NRP33SN-V-900011-LAN"
// Lists all automatically detected sensors.

SLISt:ELEMent3:MAPPing SENS1
// Maps the third sensor from the list to the first sensor channel.

SLISt:SENSor:MAP "NRPS18S-100654-USB Legacy", SENS3
// Maps the sensor to channel 3.

SLISt:CLEar[ALL]
// Remove all sensors that use VISA communication protocol
// from the sensor mapping list.
SLISt:CLEar:LAN
// Remove all sensors from the list, that use VISA and are connected over LAN.
SLISt:CLEar:USB
// Remove all sensors from the list, that use VISA and are connected over USB.
```

Example: Performing a simple power measurement

Prerequisite: The sensor is connected to the instrument and mapped to the first sensor channel.

```
INITiate1:CONTinuous ON
// Switches the continuous power measurement on.

READ1?
// Triggers the measurement and displays the results.
```


Example: Performing a power measurement with a fixed filter

Prerequisite: The sensor is connected to the instrument and mapped to the first sensor channel.

```

SENSe1:SOURce RF
// Sensor measures the power of the RF signal.

SENSe1:FILTer:TYPE NSRatio
// Selects fixed noise filter mode.

SENSe1:FILTer:NSRatio 0.02 DB
// Sets the maximum noise component in the result to 0.02 DB.

SENSe1:FILTer:NSRatio:MTIME 10
//Limits the settling time to 10 seconds.

SENSe1:APERture:DEFAult:STATe 0
// Deactivates the default aperture time of the sensor.

SENSe1:APERture:TIME 10e-6
// Sets the aperture time to 10 us.

SENSe1:UNIT DBM
// Selects unit dBm for the measured value.

INITiate:CONTinuous ON
// Switches the continous power measurement on.

READ?
// Triggers the measurement and displays the results.

```

:SLISt[:LIST]?.....	598
:SLISt:SCAN[:STATe].....	598
:SLISt:SCAN:LENSor.....	598
:SLISt:SCAN:USENSor.....	599
:SLISt:CLEar:LAN.....	599
:SLISt:CLEar:USB.....	599
:SLISt:CLEar[:ALL].....	600
:SLISt:ELEMent<ch>:MAPPing.....	600
:SLISt:SENSor:MAP.....	600
:SENSe<ch>:UNIT[:POWer].....	601
:SENSe<ch>[:POWer]:APERture:DEFAult:STATe.....	601
:SENSe<ch>[:POWer]:APERture:TIME.....	601
:SENSe<ch>[:POWer]:CORRection:SPDevice:SElect.....	602
:SENSe<ch>[:POWer]:CORRection:SPDevice:STATe.....	602
:SENSe<ch>[:POWer]:CORRection:SPDevice:LIST?.....	602
:SENSe<ch>[:POWer]:DISPlay:PERManent:PRiority.....	602
:SENSe<ch>[:POWer]:DISPlay:PERManent:STATe.....	603
:SENSe<ch>[:POWer]:FILTer:LENGth:AUTO?.....	603
:SENSe<ch>[:POWer]:FILTer:LENGth[:USER].....	603
:SENSe<ch>[:POWer]:FILTer:NSRatio.....	604

:SENSe<ch>[:POWer]:FILTer:NSRatio:MTIME.....	604
:SENSe<ch>[:POWer]:FILTer:SONCe.....	604
:SENSe<ch>[:POWer]:FILTer:TYPE.....	605
:SENSe<ch>[:POWer]:FREQuency.....	605
:SENSe<ch>[:POWer]:LOGGing:STATe.....	606
:SENSe<ch>[:POWer]:OFFSet.....	606
:SENSe<ch>[:POWer]:OFFSet:STATe.....	606
:SENSe<ch>[:POWer]:SNUMber?.....	607
:SENSe<ch>[:POWer]:SOURce.....	607
:SENSe<ch>[:POWer]:STATus[:DEVice]?.....	607
:SENSe<ch>[:POWer]:SVERsion?.....	608
:SENSe<ch>[:POWer]:TYPE?.....	608
:SENSe<ch>[:POWer]:ZERO.....	608

:SLISt[:LIST]?

Returns a list of all detected sensors in a comma-separated string.

Return values:

<SensorList> String of comma-separated entries

Each entry contains information on the sensor type, serial number and interface.

The order of the entries does not correspond to the order the sensors are displayed in the "NRP Sensor Mapping" dialog.

Example: See [Example "Detecting and assigning a power sensor"](#) on page 596.

Usage: Query only

Manual operation: See ["Sensor Mapping List"](#) on page 264

:SLISt:SCAN[:STATe] <State>

Starts the search for R&S NRP power sensors, connected in the LAN or via the USBTMC protocol.

Parameters:

<State> 1 | ON | 0 | OFF

*RST: 0

Example: See [Example "Detecting and assigning a power sensor"](#) on page 596.

Manual operation: See ["Scan"](#) on page 265

:SLISt:SCAN:LSENSor <IP>

Scans for R&S NRP power sensors connected in the LAN.

Setting parameters:

<IP> string
 *RST: 0

Example: See [Example "Detecting and assigning a power sensor"](#) on page 596.

Usage: Setting only

Manual operation: See ["Add LAN Sensor"](#) on page 265

:SLISt:SCAN:USENSor <DeviceID>, <Serial>

Scans for R&S NRP power sensors connected over a USB interface.

Parameters:

<Serial> integer
 Range: 0 to 999999

Setting parameters:

<DeviceID> String or Integer
 Range: 0 to 999999
 *RST: 0

Example: See [Example "Detecting and assigning a power sensor"](#) on page 596.

Usage: Setting only

Manual operation: See ["Add USBTMC Sensor"](#) on page 266

:SLISt:CLEAr:LAN

Removes all entries of R&S NRP power sensors connected in the LAN from the sensor mapping list.

Example: See [Example "Detecting and assigning a power sensor"](#) on page 596.

Usage: Event

Manual operation: See ["Clear"](#) on page 265

:SLISt:CLEAr:USB

Removes all entries of R&S NRP power sensors connected over USB and using the VISA communication protocol from the sensor mapping list.

Does not affect entries for sensors communicating over the USB legacy protocol.

Example: See [Example "Detecting and assigning a power sensor"](#) on page 596.

Usage: Event

Manual operation: See ["Clear"](#) on page 265

:SLISt:CLEAr[:ALL]

Removes all entries of R&S NRP power sensors using the VISA communication protocol (USB or LAN) from the sensor mapping list.

Does not affect sensors communicating over USB legacy protocol.

Example: See [Example "Detecting and assigning a power sensor"](#) on page 596.

Usage: Event

Manual operation: See ["Clear"](#) on page 265

:SLISt:ELEMent<ch>:MAPPING <Mapping>

Assigns an entry from the `:SLISt[:LIST]?` to one of the four sensor channels.

Parameters:

<Mapping> SENS1 | SENSor1 | SENS2 | SENSor2 | SENS3 | SENSor3 |
SENS4 | SENSor4 | UNMapped

Sensor channel.

*RST: UNMapped

Example: See [Example "Detecting and assigning a power sensor"](#) on page 596.

Manual operation: See ["Sensor Mapping List"](#) on page 264

:SLISt:SENSor:MAP <SensorId>, <Mapping>

Assigns a sensor directly to one of the sensor channels, using the sensor name and serial number.

To find out the the sensor name and ID, you can get it from the label of the R&S NRP, or using the command `:SLISt:SCAN[:STATe]`. This command detects all R&S NRP power sensors connected in the LAN or via 'USBTMC protocol.

Setting parameters:

<SensorId> string

<Mapping> enum

Example: See [Example "Detecting and assigning a power sensor"](#) on page 596.

Usage: Setting only

Manual operation: See ["Sensor Mapping List"](#) on page 264

:SENSe<ch>:UNIT[:POWER] <Power>

Selects the unit (Watt, dBm or dBμV) of measurement result display, queried with :
[READ<ch>\[:POWER\]?](#).

Parameters:

<Power> DBM | DBUV | WATT
 *RST: DBM

Example:

:SENS2:UNIT DBM

Selects dBm as unit for the measured value returned by command READ.

:READ2?

Response: 7.34

7.34 dBm are measured by sensor 2.

Manual operation: See ["Measured Level"](#) on page 256

:SENSe<ch>[:POWER]:APERTure:DEFAult:STATe <UseDefAp>

Deactivates the default aperture time of the respective sensor.

To specify a user-defined value, use the command :SENSe<ch>[:POWER]:
[APERTure:TIME](#) on page 601.

Parameters:

<UseDefAp> 1 | ON | 0 | OFF
 *RST: 1

Example:

See [Example "Performing a power measurement with a fixed filter"](#) on page 597.

Manual operation: See ["Default Aperture Time"](#) on page 262

:SENSe<ch>[:POWER]:APERTure:TIME <ApTime>

Defines the aperture time (size of the acquisition interval) for the corresponding sensor.

Parameters:

<ApTime> float
 Range: depends on connected power sensor
 Increment: 1E-9
 *RST: depends on connected power sensor

Example:

See [Example "Performing a power measurement with a fixed filter"](#) on page 597.

Manual operation: See ["Aperture Time"](#) on page 262

:SENSe<ch>[:POWer]:CORRection:SPDevice:SElect <Select>

Several S-parameter tables can be stored in a sensor. The command selects a loaded data set for S-parameter correction for the corresponding sensor.

Parameters:

<Select> float
*RST: 0

Manual operation: See "[S-Parameter](#)" on page 263

:SENSe<ch>[:POWer]:CORRection:SPDevice:STATe <State>

Activates the use of the S-parameter correction data.

Note: If you use power sensors with attenuator, the instrument automatically activates the use of S-parameter data.

Parameters:

<State> 1 | ON | 0 | OFF
*RST: 0

Example: :SENSe1:POWer:CORRection:SPDevice:STATe 1
Activates the use of the S-parameters correction data.

Manual operation: See "[S-Parameter](#)" on page 263

:SENSe<ch>[:POWer]:CORRection:SPDevice:LIST?

Queries the list of the S-parameter data sets that have been loaded to the power sensor.

Return values:

<List> string list
*RST: 0

Usage: Query only

Manual operation: See "[S-Parameter](#)" on page 263

:SENSe<ch>[:POWer]:DISPlay:PERManent:PRiority <Priority>

Selects average or peak power for permanent display.

Parameters:

<Priority> AVERAge | PEAK
*RST: AVERAge

Example: :SENSe1:DISPlay:PERManent:PRiority ON
Turns on the permanent view.
:SENSe1:DISPlay:PERManent:PRiority AVER
Sets the average power for display.

Manual operation: See "[Display](#)" on page 260

:SENSe<ch>[:POWer]:DISPlay:PERManent:STATe <State>

Activates the permanent display of the measured power level results. The instrument also indicates the sensor type, the connection, the measurement source and the offset if set.

Parameters:

<State> 1 | ON | 0 | OFF
*RST: 0

Example: :SENS1:POW:DISP:PERM:STAT ON
Turns on the permanent view.

Manual operation: See ["Display Permanent"](#) on page 260

:SENSe<ch>[:POWer]:FILTer:LENGth:AUTO?

Queries the current filter length in filter mode AUTO ([:SENSe<ch>\[:POWer\]:FILTer:TYPE](#))

Return values:

<Auto> float
Range: 1 to depends on R&S NRP power sensor type

Example: :SENS1:FILT:TYPE AUTO
Selects auto filter.
:SENS1:FILT:LENG:AUTO?
Queries the automatically set filter length.
Response: 1024

Usage: Query only

Manual operation: See ["Filter Length"](#) on page 262

:SENSe<ch>[:POWer]:FILTer:LENGth[:USER] <User>

Selects the filter length for [SENS:POW:FILT:TYPE USER](#). As the filter length works as a multiplier for the time window, a constant filter length results in a constant measurement time (see also ["About the measuring principle, averaging filter, filter length, and achieving stable results"](#) on page 250).

The R&S NRP power sensors provide different resolutions for setting the filter length, depending on the used sensor type.

For more information, refer to the specifications document.

Parameters:

<User> float
Range: 1 to depends on R&S NRP power sensor type
*RST: 1

Example: :SENS1:FILT:TYPE USER
 Selects user filter mode.
 :SENS1:FILT:LENG 16
 Sets a filter length of 16. E.g. using a sensor with 20 ms time window, the resulting measurement time is 640 ms (2x16x20 ms)

Manual operation: See ["Filter Length"](#) on page 262

:SENSe<ch>[:POWer]:FILTer:NSRatio <NSRatio>

Sets an upper limit for the relative noise content in fixed noise filter mode (:SENSe<ch>[:POWer]:FILTer:TYPE). This value determines the proportion of intrinsic noise in the measurement results.

Parameters:

<NSRatio> float
 Range: 0.001 to 1
 Increment: 0.001
 *RST: 0.01

Example: See [Example "Performing a power measurement with a fixed filter"](#) on page 597.

Manual operation: See ["Noise/Signal Ratio"](#) on page 262

:SENSe<ch>[:POWer]:FILTer:NSRatio:MTime <MTime>

Sets an upper limit for the settling time of the auto-averaging filter and thus limits the length of the filter.

Parameters:

<MTime> float
 Range: 1 to 999.99
 Increment: 0.01
 *RST: 8

Example: See [Example "Performing a power measurement with a fixed filter"](#) on page 597.

Manual operation: See ["Timeout"](#) on page 262

:SENSe<ch>[:POWer]:FILTer:SONCe

Starts searching the optimum filter length for the current measurement conditions. You can check the result with command :SENS1:POW:FILT:LENG:USER? in filter mode USER (:SENSe<ch>[:POWer]:FILTer:TYPE).

Example:

```
SENS1:FILT:TYPE USER
Selects user filter mode.
:SENS1:FILT:SONC
Activates the search for the optimum filter length.
:SENS1:FILT:LENG?
Returns the found optimum filter length.
Response: 128
```

Usage: Event

Manual operation: See "Auto Once" on page 262

:SENSe<ch>[:POWer]:FILTer:TYPE <Type>

Selects the filter mode. The filter length is the multiplier for the time window and thus directly affects the measurement time.

Parameters:

<Type>

AUTO | USER | NSRatio

AUTO

Automatically selects the filter length, depending on the measured value. The higher the power, the shorter the filter length, and vice versa.

Note: To avoid long settling times when the power is low, you can limit the averaging factor limited with the "timeout" parameter (:SENSe<ch>[:POWer]:FILTer:NSRatio:MTIME).

USER

Allows you to set the filter length manually. As the filter-length takes effect as a multiplier of the measurement time, you can achieve constant measurement times.

NSRatio

Selects the filter length (averaging factor) according to the criterion that the intrinsic noise of the sensor (2 standard deviations) does not exceed the specified noise content. You can define the noise content with command :SENSe<ch>[:POWer]:FILTer:NSRatio.

*RST: AUTO

Example: See Example "Performing a power measurement with a fixed filter" on page 597.

Manual operation: See "Filter" on page 261

:SENSe<ch>[:POWer]:FREQuency <Frequency>

Sets the RF frequency of the signal, if signal source :SENSe<ch>[:POWer]:SOURce USER is selected.

Parameters:

<Frequency> float
 *RST: 1 GHz

Example:

:SENS1:SOUR USER
 Selects user-defined source.
 :SENS1:FREQ 2.44GHz
 Sets the RF frequency of the source which is 2.44 GHz.

Manual operation: See ["Frequency"](#) on page 261

:SENSe<ch>[:POWer]:LOGGing:STATe <State>

Activates the recording of the power values, measured by a connected R&S NRP power sensor.

Parameters:

<State> 1 | ON | 0 | OFF
 *RST: 0

Example:

:SENS:LOGG:STAT ON
 Activates recording of the power measurement of the first sensor.

Manual operation: See ["Enable Logging"](#) on page 263

:SENSe<ch>[:POWer]:OFFSet <Offset>

Sets a level offset which is added to the measured level value after activation with command [:SENSe<ch>\[:POWer\]:OFFSet:STATe](#). The level offset allows, e.g. to consider an attenuator in the signal path.

Parameters:

<Offset> float
 Range: -100.0 to 100.0
 *RST: 0
 Default unit: dB

Example:

:SENS1:POW:OFFS 10.0
 Sets a level offset of 10 dB

Manual operation: See ["Level Offset State, Level Offset"](#) on page 261

:SENSe<ch>[:POWer]:OFFSet:STATe <State>

Activates the addition of the level offset to the measured value. The level offset value is set with command [:SENSe<ch>\[:POWer\]:OFFSet](#).

Parameters:

<State> 1 | ON | 0 | OFF
 *RST: 0

Example: `:SENS1:POW:OFFS 0.4dB`
 Sets a level offset of 0.4 dB
`:SENS1:POW:OFFS:STAT ON`
 A level offset of 0.4 dB is added to the measured value.

Manual operation: See ["Level Offset State, Level Offset"](#) on page 261

:SENSe<ch>[:POWer]:SNUMber?

Queries the serial number of the sensor.

Return values:

<SNumber> string

Example: `:SENS1:SNUM?`
 Queries the serial number.

Usage: Query only

Manual operation: See ["Sensor type and serial number"](#) on page 260

:SENSe<ch>[:POWer]:SOURce <Source>

Determines the signal to be measured.

Note: When measuring the RF signal, the sensor considers the corresponding correction factor at that frequency, and uses the level setting of the instrument as reference level.

Parameters:

<Source> A | USER | RF
 *RST: A

Example: See [Example "Performing a power measurement with a fixed filter"](#) on page 597.

Manual operation: See ["Use Frequency Of"](#) on page 261

:SENSe<ch>[:POWer]:STATus[:DEVice]?

Queries if a sensor is connected to the instrument.

Return values:

<Status> 1 | ON | 0 | OFF
 *RST: 0

Example: `:SENS1:STAT?`
 Response: 1
 A sensor is connected.

Usage: Query only

Manual operation: See ["State"](#) on page 260

:SENSe<ch>[:POWer]:SVERsion?

Queries the software version of the connected R&S NRP power sensor.

Return values:

<SVersion> string

Example: :SENS1:POW:SVER?

Queries the software version of the power sensor.

Usage: Query only

:SENSe<ch>[:POWer]:TYPE?

Queries the sensor type. The type is automatically detected.

Return values:

<Type> string

Example: :SENS1:TYPE?

Queries the type of sensor.

Response: NRP-Z21

The R&S NRP-Z21 sensor is used.

Usage: Query only

Manual operation: See ["Sensor type and serial number"](#) on page 260

:SENSe<ch>[:POWer]:ZERO

Performs zeroing of the sensor.

Zeroing is required after warm-up, i.e. after connecting the sensor.

Note: Switch off or disconnect the RF power source from the sensor before zeroing.

We recommend that you zero in regular intervals (at least once a day), if:

- The temperature has varied more than about 5 °C.
- The sensor has been replaced.
- You want to measure very low power.

Example: :SENS1:ZERO

Executes zeroing.

Usage: Event

Manual operation: See ["Zero"](#) on page 260

15.17 SCONfiguration subsystem

The SCONfiguration subsystem contains the commands for defining the system configuration setting, like stream mapping and used baseband configuration.

Required options

R&S SMAB-K554 Multiplier Control

Common suffixes

The following common suffixes are used in the control commands:

- RF<ch>

This suffix defines the RF connector. Since the R&S SMA100B has only one RF connector, the value range is [1] and using the suffix is optional.

Example: Connecting and configuring external instruments

The following example lists commands to connect and configure external instruments.

```
// *****
// Getting information about connected external instruments.
// *****
// General information about the connected external device
SCONfiguration:EXternal:RF1:REMOte:INFO?
//Response: "SZM75-100001","Frontend Connection","127.0.0.1","SZM75-100001","connected"

// Connector direction
SCONfiguration:EXternal:RF1:DIRection?
// Response: OUT

// Status of the remote connection
SCONfiguration:EXternal:RF1:RCONnection:STATe?
// Response: 1

// Name of the connected external instrument
SCONfiguration:EXternal:RF1:INAME?
// Response: "SZM75-100003"

// *****
// Connecting a frequency multiplier.
// *****
//Query available external instruments
SCONfiguration:EXternal:REMOte:LIST?
//Response: SZM75-100003,SZM75-100001,SZM75-100002

// Connecting a frequency multiplier
SCONfiguration:EXternal:RF:REMOte:ICONnect "SZM75-100001"

// Query the IF of the connected frequency multiplier
SOURCE1:EFRontend:FREQuency:IFRequency:VALue?
// Response: 18750000000
```

15.17.1 External instruments

The following commands configure external instruments, e.g. frequency multiplier R&S SZM.

Commands:

:SCONfiguration:EXternal:ACONnect.....	610
:SCONfiguration:EXternal:REMOte:CONnect[:ALL].....	610
:SCONfiguration:EXternal:REMOte:DISConnect[:ALL].....	610
:SCONfiguration:EXternal:PBEHaviour.....	610
:SCONfiguration:EXternal:RF<ch>:DIRection?.....	611
:SCONfiguration:EXternal:RF<ch>:RCONnection:STATe?.....	611
:SCONfiguration:EXternal:RF<ch>:INAMe?.....	611
:SCONfiguration:EXternal:REMOte:LIST?.....	611
:SCONfiguration:EXternal:REMOte:REName.....	612
:SCONfiguration:EXternal:RF<ch>:REMOte:ISElect.....	612
:SCONfiguration:EXternal:RF<ch>:REMOte:ICONnect.....	612
:SCONfiguration:EXternal:RF<ch>:REMOte:INFO?.....	612
:SCONfiguration:EXternal:REMOte:CLEan.....	613
:SCONfiguration:EXternal:RF<ch>:REMOte:CONnect.....	613
:SCONfiguration:EXternal:RF<ch>:REMOte:DISConnect.....	613

:SCONfiguration:EXternal:ACONnect <State>

Enables automatic detection and connection setup of connected external instruments.

Parameters:

<State> 1 | ON | 0 | OFF
 *RST: 0

Manual operation: See "[Auto Connect](#)" on page 177

:SCONfiguration:EXternal:REMOte:CONnect[:ALL]

:SCONfiguration:EXternal:REMOte:DISConnect[:ALL]

Triggers the instrument to establish the connections to all configured external instruments or to disconnect all existing connections.

Usage: Event

Manual operation: See "[Connect/Disconnect](#)" on page 176

:SCONfiguration:EXternal:PBEHaviour <State>

If enabled, the connection to the external instruments is retained after preset (*RST) of the instrument.

Parameters:

<State> 1 | ON | 0 | OFF
 *RST: n.a. (factory preset: 0)

Manual operation: See ["Preset behavior: Keep connections to external instruments"](#) on page 177

:SCONfiguration:EXternal:RF<ch>:DIRection?

Queries the connector direction.

Return values:

<Direction> NONE | IN | OUT
*RST: IN

Example: See [Example "Connecting and configuring external instruments"](#) on page 609.

Usage: Query only

Manual operation: See ["Direction"](#) on page 177

:SCONfiguration:EXternal:RF<ch>:RCONnection:STATe?

Queries the status of the remote connection.

Return values:

<State> 1 | ON | 0 | OFF

Example: See [Example "Connecting and configuring external instruments"](#) on page 609.

Usage: Query only

Manual operation: See ["Remote Connection Status"](#) on page 178

:SCONfiguration:EXternal:RF<ch>:INAMe?

Queries the name of the connected external instrument.

Return values:

<InstrName> string

Example: See [Example "Connecting and configuring external instruments"](#) on page 609.

Usage: Query only

Manual operation: See ["Instrument Name"](#) on page 178

:SCONfiguration:EXternal:REMOte:LIST?

Lists all available instruments.

Return values:

<InstrNames> String
String with symbolic names and/or alias names

Example: See [Example "Connecting and configuring external instruments"](#) on page 609

Usage: Query only

Manual operation: See ["External Instrument"](#) on page 179

:SCONfiguration:EXtErnal:REMOte:REName

Changes the symbolic name of the instrument.

Usage: Setting only

:SCONfiguration:EXtErnal:RF<ch>:REMOte:ISElect <InstrName>[, <RfPath>]

Selects an external instrument for the selected connector.

Parameters:

<InstrName> String
Instrument alias name, as retrieved with the command :
[SCONfiguration:EXtErnal:REMOte:LIST?](#).

<RfPath> String
Determines the used RF output of the external instrument.
For a one-path instrument, the output path is fixed.

Manual operation: See ["Apply"](#) on page 180

:SCONfiguration:EXtErnal:RF<ch>:REMOte:ICONnect <InstrName>, <RfPath>

Selects an external instrument for the selected connector and triggers connection.

Parameters:

<InstrName> string
Instrument alias name, as retrieved with the command :
[SCONfiguration:EXtErnal:REMOte:LIST?](#).

<RfPath> string
Determines the used RF output of the external instrument.
For a one-path instrument, the output path is fixed to RF1.

Example: See [Example "Connecting and configuring external instruments"](#) on page 609.

Usage: Setting only

Manual operation: See ["Apply and Connect"](#) on page 180

:SCONfiguration:EXtErnal:RF<ch>:REMOte:INFO?

Queries information on the external instrument.

Example: See [Example "Connecting and configuring external instruments"](#) on page 609.

Usage: Query only

Manual operation: See ["Set Symbolic Name"](#) on page 179

:SCONfiguration:EXTernal:REMOte:CLEan

Removes all instruments not connected via USB cable to the R&S SMA100B from the "External Instrument" list.

Usage: Event

Manual operation: See ["Clean All"](#) on page 179

:SCONfiguration:EXTernal:RF<ch>:REMOte:CONNeCT

Triggers the connection to the external instrument at the selected connector.

Usage: Event

:SCONfiguration:EXTernal:RF<ch>:REMOte:DISConnect

Triggers the disconnection of the external instrument at the selected connector.

Usage: Event

15.18 SOURce subsystem

The SOURce subsystem contains the commands for configuring signals.

Common suffixes

The following common suffixes are used in remote commands:

Suffix	Value range	Description
SOURce<hw>	[1]	- SOURce[1] = RF output (optional keyword) - LF output = SOURce:LFOutput (SOURce is optional keyword)

- [Analog modulation subsystems](#)..... 614
- [Avionic standards subsystems](#)..... 646
- [SOURce:CORRection subsystem](#)..... 689
- [SOURce:EFFrontend subsystem](#)..... 697
- [SOURce:FREQuency subsystem](#)..... 700
- [SOURce:INPut subsystem](#)..... 709
- [SOURce:LFOutput subsystem](#)..... 710
- [SOURce:LIST subsystem](#)..... 723

• SOURce:NOISe subsystem.....	735
• SOURce:PGEN subsystem.....	737
• SOURce:PHASe subsystem.....	739
• SOURce:POWer subsystem.....	740
• SOURce:ROSCillator subsystem.....	754
• SOURce:SWEep subsystem.....	760

15.18.1 Analog modulation subsystems

Option: see [Section 5.1, "Required options"](#), on page 77.

The subsystems in this section describe all commands for analog modulation of the RF signal. Divided in separate sections, you can configure amplitude modulation (AM), frequency modulation (FM), phase modulation (PhiM) and pulse modulation (PULM).

You can perform each of the modulations either with an internally generated modulation signal or with an externally applied signal.

To configure the internal signal, use the commands listed in [Section 15.18.7, "SOURce:LFOutput subsystem"](#), on page 710.

For more information:

See [Section 5, "Analog modulations"](#), on page 77.

15.18.1.1 SOURce:MODulation subsystem

The command in this subsystem allows you to disable all active modulations at once, and, vice versa, to restore the last active ones.

[:SOURce<hw>]:MODulation[:ALL][:STATE] <State>

Activates all modulations that were active before the last switching off.

Parameters:

<State> 1 | ON | 0 | OFF
 *RST: 0

Example:

```

SOURce1:AM1:DEPTH 30
SOURce1:AM1:SOURce LF1
SOURce1:AM1:STATe 1
SOURce1:FM1:DEVIation 1000
SOURce1:FM1:STATe 1
// disable both modulation
SOURce1:MODulation:ALL:STATe 0
SOURce1:AM1:STATe?
// 0
SOURce1:FM1:STATe?
// 0
// enable both modulation
SOURce1:MODulation:ALL:STATe 1
SOURce1:AM1:STATe?
// 1
SOURce1:FM1:STATe?
// 1

```

Manual operation: See "[Mod on/off]" on page 80

15.18.1.2 SOURce:AM subsystem

Option: R&S SMAB-K720

The AM subsystem contains the commands for setting the amplitude modulation and also the broadband amplitude modulation.

The following examples show some variants for generating AM signals.

The following examples show some variants for generating AM signals.

Example: Creating an amplitude modulated RF signal

Using the internal LF generator, the following command sequence configures an amplitude-modulated signal.

```

// Reset the instrument to start from a defined state.
*RST

// Set RF frequency and amplitude
:SOURce1:FREQuency:CW 6000000000
:SOURce1:POWer:LEVel:IMMediate:AMPLitude -25

// Configure the modulation signal
:SOURce1:LFOutput1:SHAPE SINE
:SOURce1:LFOutput1:FREQuency 20000

// Configure the amplitude modulation settings and switch AM on
:SOURce1:AM1:SOURce LF1
:SOURce1:AM1:DEPTH 30
:SOURce1:AM:RATio 40
:SOURce1:AM1:DEVIation:MODE UNC
:SOURce1:AM1:STATe 1

```

Example: Using combined LF signals

Using the internal LF generators of both paths, the following command sequences configure an amplitude-modulated signal with determined deviations depths.

```
// Configure the AM modulation settings with combined LF signal sources
:SOURce1:AM1:SOURce LF1
:SOURce1:AM1:DEPTh:LINear 32
// Select the modulation signal source for the second path
:SOURce1:AM2:SOURce LF2
// Combine the signals of both paths with fixed total deviation depth
:SOURce1:AM1:DEVIation:MODE TOT
:SOURce1:AM1:DEPTh:SUM 60

// Query the deviation depth of modulation signal in the second path
:SOURce1:AM2:DEPTh:LINear?
// Response: 28

// Combine the signals of both paths with fixed ratio
:SOURce1:AM1:DEVIation:MODE RAT
:SOURce1:AM1:RATio 100
:SOURce1:AM2:DEPTh:LINear 25

// Query the deviation depth of modulation signal in the first path
:SOURce1:AM1:DEPTh:LINear?
// Response: 25

:SOURce1:AM1:STATe 1
:SOURce1:AM2:STATe 1
```

Example: Using an external signal source

Using an external signal source, you can also determine whether you want to use only the AC component of the external modulation signal.

```
// Reset the instrument to start from a defined state
*RST

// Set frequency and amplitude
:SOURce1:FREQuency:CW 6000000000
:SOURce1:POWer:LEVel:IMMediate:AMPLitude -25

// Configure the amplitude modulation settings and turn on AM
:SOURce1:AM1:SOURce EXT1
:SOURce1:AM1:DEPTh 40

// Query the input sensitivity at the external modulation input
:SOURce1:AM1:SENSitivity?
// Response: 40
// Since the voltage value for full modulation is 1V,
// the resulting sensitivity is precisely 50%/V.
// This value is assigned to the voltage value for full
// modulation of the input.

// Select the coupling mode AC for external amplitude modulation
:SOURce1:INPut:MODext:COUPling1 AC

// For external AM signal input, adjust the sensitivity.
:SOURce1:AM1:TYPE EXP
:SOURce1:AM1:SOURce EXT1
:SOURce1:AM1:SENSitivity 25
:SOURce1:AM1:SENSitivity?
// Response: "25"

// Alternatively, use the scan mode for the level behavior of rotating antennas.
// SCAN automatically sets the modulation type to exponential.
:SOURce1:AM1:MODE SCAN
:SOURce1:AM1:SOURce EXT2
:SOURce1:AM1:DEPTh:EXponential 12
:SOURce1:AM1:DEPTh:EXponential?
// Response: "12"
// Enabling the external exponential AM changes the coupling in this example
// for EXT2
INPut:MODext:COUPling2 DC

// Switch on AM and RF signal output
:SOURce1:AM1:STATe 1
:OUTPut1:STATe 1
```

The following commands are available:

[SOURce<hw>]:AM<ch>:STATe.....	618
[SOURce<hw>]:AM<ch>:SOURce.....	618
[SOURce<hw>]:AM<ch>[:DEPT]h.....	619
[SOURce<hw>]:AM<ch>:DEPT]h:LINear.....	619
[SOURce<hw>]:AM<ch>:DEPT]h:EXPOntial.....	619
[SOURce<hw>]:AM:MODE.....	619
[SOURce<hw>]:AM:DEPT]h:SUM.....	620
[SOURce<hw>]:AM:DEVIation:MODE.....	620
[SOURce<hw>]:AM:RATio.....	620
[SOURce<hw>]:AM<ch>:SENSitivity:EXPOntial.....	621
[SOURce<hw>]:AM<ch>:SENSitivity[:LINear].....	621
[SOURce<hw>]:AM:TYPE.....	621

[SOURce<hw>]:AM<ch>:STATe <State>

Activates amplitude modulation.

Parameters:

<State> 1 | ON | 0 | OFF
 *RST: 0

Example: See [Example "Creating an amplitude modulated RF signal"](#) on page 615.

Manual operation: See ["State"](#) on page 84

[SOURce<hw>]:AM<ch>:SOURce <Source>

Selects the modulation source for amplitude modulation.

Parameters:

<Source> LF1 | LF2 | NOISe | EXT1 | EXT2 | EXTErnal | INTeRnal
LF1|LF2
 Uses an internally generated LF signal.
EXT1|EXT2
 Uses an externally supplied LF signal.
NOISe
 Uses the internally generated noise signal.
INTeRnal
 Uses the internally generated signal of LF1.
EXTErnal
 Uses an external LF signal (EXT1).
 *RST: LF1 <AM1>; LF2 <AM2>

Example: See [Example "Creating an amplitude modulated RF signal"](#) on page 615.

Manual operation: See ["Source"](#) on page 84

[:SOURce<hw>]:AM<ch>[:DEPT h] <Depth>

Sets the depth of the amplitude modulation in percent.

Suffix:

<ch> 1..2
Modulation signal channel

Parameters:

<Depth> float
Range: 0 to 100

Example: See [Example "Creating an amplitude modulated RF signal"](#) on page 615.

[:SOURce<hw>]:AM<ch>:DEPT h:LINear <DepthLin>

Sets the depth of the linear amplitude modulation in percent / volt.

Parameters:

<DepthLin> float
Range: 0 to 100
Increment: 0.1
*RST: 30

Example: See [Example "Creating an amplitude modulated RF signal"](#) on page 615. Similar to DEPT h.

Manual operation: See ["Depth"](#) on page 89

[:SOURce<hw>]:AM<ch>:DEPT h:EXPonential <DepthExp>

Sets the depth of the exponential amplitude modulation in dB/volt.

Parameters:

<DepthExp> float
Range: 0 to 100
Increment: 0.01
*RST: 10

Example: See [Example "Creating an amplitude modulated RF signal"](#) on page 615. Similar to DEPT h.

Manual operation: See ["Depth"](#) on page 89

[:SOURce<hw>]:AM:MODE <AmMode>

Selects the mode of the amplitude modulation.

[\[:SOURce<hw>\]:AM:MODE > SCAN](#) sets [\[:SOURce<hw>\]:AM:TYPE > EXPonential](#).

For active external exponential AM, automatically sets `[ :SOURce<hw> ] :INPut : MODext : COUPling<ch> > DC`.

Parameters:

<AmMode> SCAN | NORMal
*RST: NORMal

Example: See [Example "Using an external signal source"](#) on page 617.

Options: R&S SMAB-K721

Manual operation: See ["Mode"](#) on page 88

[:SOURce<hw>] :AM:DEPT h:SUM <AmDepthSum>

Sets the total depth of the LF signal when using combined signal sources in amplitude modulation.

Parameters:

<AmDepthSum> float
Range: 0 to 100
Increment: 0.1
*RST: 30

Example: See [Example "Using combined LF signals"](#) on page 616.

Manual operation: See ["Total Depth"](#) on page 89

[:SOURce<hw>] :AM:DEVIation:MODE <AmDevMode>

Selects the coupling mode. The coupling mode parameter also determines the mode for fixing the total depth.

Parameters:

<AmDevMode> UNCoupled | TOTal | RATio
UNCoupled
Does not couple the LF signals.
The deviation depth values of both paths are independent.
TOTal
Couples the deviation depth of both paths.
RATio
Couples the deviation depth ratio of both paths
*RST: UNCoupled

Example: See [Example "Using combined LF signals"](#) on page 616.

Manual operation: See ["Deviation Mode"](#) on page 89

[:SOURce<hw>] :AM:RATio <Ratio>

Sets the deviation ratio (path#2 to path#1) in percent.

Parameters:

<Ratio> float
 Range: 0 to 100
 Increment: 0.1
 *RST: 100

Example: See [Example "Creating an amplitude modulated RF signal"](#) on page 615.

Manual operation: See ["Ratio Path2/Path1"](#) on page 90

[:SOURce<hw>]:AM<ch>:SENSitivity:EXPonential <Sensitivity>

For [:SOURce<hw>]:AM:TYPEEXP, sets the sensitivity of the external signal source for amplitude modulation.

Parameters:

<Sensitivity> float
 Range: 0 to 100
 Increment: 0.01
 *RST: 10

Example: See [Example "Using an external signal source"](#) on page 617.

Manual operation: See ["Sensitivity"](#) on page 89

[:SOURce<hw>]:AM<ch>:SENSitivity[:LINear] <Sensitivity>

For [:SOURce<hw>]:AM:TYPELIN, sets the sensitivity of the external signal source for amplitude modulation.

Parameters:

<Sensitivity> float
 Range: 0 to 100
 Increment: 0.1
 *RST: 30

Example: See [Example "Using an external signal source"](#) on page 617.

Manual operation: See ["Sensitivity"](#) on page 89

[:SOURce<hw>]:AM:TYPE <AmType>

Selects the type of amplitude modulation.

For [:SOURce<hw>]:AM:MODESCAN, only EXPonential is available.

For active external exponential AM, automatically sets [:SOURce<hw>]:INPut:MODext:COUPling<ch>DC.

Parameters:

<AmType> LINear | EXPonential
 *RST: LINear

Example: See [Example "Using an external signal source"](#) on page 617.

Options: R&S SMAB-K721

Manual operation: See ["Type"](#) on page 88

15.18.1.3 SOURce:CHIRp subsystem

Option: see [Section 5.1, "Required options"](#), on page 77.

With the commands described in this section, you can configure the settings for chirp modulation, select the trigger mode and determine the parameters for an external pulse / trigger signal.

The following examples show some variants for generating the modulation chirp.

Example: Perform chirp modulation

Using the internal pulse generator, the following command sequence configures a chirp modulated RF signal.

```
// Reset the instrument to start from an initial state
*RST; *CLS

// Set the RF signal frequency and level
SOURce:FREQuency:CW 4000000000
SOURce:POWer:POWer: -25

// Configure the chirp modulation settings
// set the pulse parameters and the trigger mode
// query the compression ratio
// activate RF signal output

// Trigger a continuous chirp modulated signal
SOURce:CHIRp:TRIGger:MODE AUTO
SOURce:CHIRp:DIRectioN UP
SOURce:CHIRp:PULSe:PERioD 0.00001
SOURce:CHIRp:PULSe:WIDTh 0.000008
SOURce:CHIRp:BANDwidth 2000
SOURce:CHIRp:COMPressioN:RATio?
// Response: 0.01
SOURce:CHIRp:STATe 1
OUTPut1:STATe 1

// Trigger a single chirp modulation signal
SOURce:CHIRp:TRIGger:MODE SING
SOURce:CHIRp:DIRectioN DOWN
SOURce:CHIRp:PULSe:PERioD 0.00002
SOURce:CHIRp:PULSe:WIDTh 0.000002
SOURce:CHIRp:BANDwidth 5000
SOURce:CHIRp:STATe 1
SOURce:CHIRp:TRIGger:IMMediate
SOURce:CHIRp:PULSe:NUMBer?

// Alternatively configure the chirp modulation settings
// using an external pulse signal.
// Select the trigger mode, set the polarity of the external signal,
// select the impedance of the external pulse signal input
SOURce:CHIRp:TRIGger:MODE EXT
SOURce:CHIRp:TRIGger:EXternal:POLarity NORMal
SOURce:CHIRp:TRIGger:EXternal:IMPEDance G10K
SOURce:CHIRp:STATe 1
```

The following commands are available:

[:SOURce<hw>]:CHIRp:BANDwidth	624
[:SOURce<hw>]:CHIRp:COMPressioN:RATio?	624
[:SOURce<hw>]:CHIRp:DIRectioN	624
[:SOURce<hw>]:CHIRp:PULSe:NUMBer	624

[:SOURce<hw>]:CHIRp:PULSe:PERiod.....	625
[:SOURce<hw>]:CHIRp:PULSe:WIDTh.....	625
[:SOURce<hw>]:CHIRp:STATe.....	625
[:SOURce<hw>]:CHIRp:TRIGger:IMMediate.....	625
[:SOURce<hw>]:CHIRp:TRIGger:MODE.....	626

`[:SOURce<hw>]:CHIRp:BANDwidth <Bandwidth>`

Sets the modulation bandwidth of the chirp modulated signal.

Parameters:

<code><Bandwidth></code>	float
Range:	0 to Depends on hardware variant
Increment:	0.01
*RST:	1E3

Example: See [Example "Perform chirp modulation"](#) on page 623.

Manual operation: See ["Bandwidth"](#) on page 94

`[:SOURce<hw>]:CHIRp:COMPression:RATio?`

Queries the pulse compression ratio (= product of pulse width (s) and bandwidth (Hz)).

Return values:

<code><Ratio></code>	float
Range:	0 to 80E6
Increment:	0.01

Example: See [Example "Perform chirp modulation"](#) on page 623.

Usage: Query only

Manual operation: See ["Compression Ratio"](#) on page 94

`[:SOURce<hw>]:CHIRp:DIRection <Direction>`

Selects the direction of the chirp modulation.

Parameters:

<code><Direction></code>	DOWN UP
*RST:	UP

Example: See [Example "Perform chirp modulation"](#) on page 623.

Manual operation: See ["Direction"](#) on page 92

`[:SOURce<hw>]:CHIRp:PULSe:NUMBer <NumberOfPulses>`

Sets the number of pulses per trigger event in the trigger modes [SINGLE](#) and [ESINGLE](#).

Parameters:

<NumberOfPulses> integer
 Range: 1 to 32768
 *RST: 1

Example: See [Example "Perform chirp modulation"](#) on page 623.

[SOURce<hw>]:CHIRp:PULSe:PERiod <Period>

Sets the period of the generated modulation chirp. The period determines the repetition frequency of the internal signal.

Parameters:

<Period> float
 Range: 5E-6 (2E-7 with K23) to 100
 Increment: 1E-6
 *RST: 10E-6

Example: See [Example "Perform chirp modulation"](#) on page 623.

Manual operation: See ["Pulse Period"](#) on page 93

[SOURce<hw>]:CHIRp:PULSe:WIDTh <Width>

Sets the width of the generated pulse. The pulse width must be at least 1us less than the set pulse period.

Parameters:

<Width> float
 Range: 2E-6 (1E-7 with K23) to 100
 Increment: 1E-6
 *RST: 2E-6

Example: See [Example "Perform chirp modulation"](#) on page 623.

Manual operation: See ["Pulse Width"](#) on page 94

[SOURce<hw>]:CHIRp:STATe <State>

Activates the generation of a chirp modulation signal.

Parameters:

<State> 1 | ON | 0 | OFF
 *RST: 0

Example: See [Example "Perform chirp modulation"](#) on page 623.

Manual operation: See ["State"](#) on page 92

[SOURce<hw>]:CHIRp:TRIGger:IMMediate

Immediately starts the chirp signal generation.

Example: See [Example "Perform chirp modulation"](#) on page 623.

Usage: Event

Manual operation: See ["Execute Single Trigger"](#) on page 94

[SOURce<hw>]:CHIRp:TRIGger:MODE <Mode>

Selects the trigger mode for the chirp modulation signal.

Parameters:

<Mode> AUTO | EXTeRnal | EGATe | SINGle | ESINgle

*RST: AUTO

Example: See [Example "Perform chirp modulation"](#) on page 623.

Manual operation: See ["Trigger Mode"](#) on page 93

15.18.1.4 SOURce:FM subsystem

Option: R&S SMAB-K720

The FM subsystem contains the commands for setting the frequency modulation.

Example: Creating a frequency modulated RF signal

Using the internal LF generator, the following command sequence configures a frequency-modulated signal.

```
// Reset the instrument to start from a defined state
*RST

// Set RF frequency and amplitude
SOURce1:FREQuency:CW 6000000000
SOURce1:POWer:LEVel:IMMediate:AMPLitude -25

// Configure the modulation signal
SOURce1:LFOutput1:SHAPE SINE
SOURce1:LFOutput1:FREQuency 20000

// Configure the frequency modulation settings and switch FM on
SOURce1:FM1:SOURce LF1
SOURce1:FM1:DEVIation 1000
SOURce1:FM:RATio 40
SOURce1:FM:MODE LNOise
SOURce1:FM1:STATe 1

// Switch on LF and RF signal output
SOURce1:LFOutput1:STATe 1
OUTPut1:STATe 1
```

Example: Using combined LF signals

Using the internal LF generators of both paths, the following command sequences configure a frequency-modulated signal with determined deviations.

```
// Configure the FM modulation settings with combined LF signal sources
SOURce1:FM1:SOURce LF1
SOURce1:FM1:DEVIation 1000
// Select the modulation signal source for the second path
SOURce1:FM2:SOURce LF2
// Combine the signals of both paths with fixed total deviation depth
SOURce1:FM1:DEVIation:MODE TOT
SOURce1:FM1:DEVIation:SUM 5000

// Query the deviation depth of modulation signal in the second path
SOURce1:FM2:DEVIation?
// Response: 4000

// Combine the signals of both paths with fixed ratio
SOURce1:FM1:DEVIation:MODE RAT
SOURce1:FM1:RATio 100
SOURce1:FM2:DEVIation 10000

// Query the deviation depth of modulation signal in the first path
SOURce1:FM1:DEVIation?
// Response: 1000

SOURce1:FM1:STATe 1
SOURce1:FM2:STATe 1
```

Example: Using an external signal source

Alternatively configure the frequency modulation settings with an external modulation signal.

```
// Reset the instrument to start from a defined state
*RST

// Set RF frequency and amplitude
SOURce1:FREQuency:CW 6000000000
SOURce1:POWer:LEVel:IMMediate:AMPLitude -25

// Configure the frequency modulation settings and switch FM on
SOURce1:FM1:SOURce EXT1
SOURce1:FM1:DEVIation 5000

// Query the input sensitivity at the external modulation input
:SOURce1:FM1:SENSitivity?
// Response: 1000
// since the voltage value for full modulation is 1V,
// the resulting sensitivity is precisely 5000 Hz/V.
```

```
// Switch on FM and RF signal output
SOURce1:FM1:STATe 1
OUTPut1:STATe 1
```

The following commands are available:

[:SOURce<hw>]:FM<ch>:STATe	628
[:SOURce<hw>]:FM<ch>[:DEViation]	628
[:SOURce<hw>]:FM<ch>:SOURce	629
[:SOURce<hw>]:FM:DEViation:MODE	629
[:SOURce<hw>]:FM:DEViation:SUM	630
[:SOURce<hw>]:FM:RATio	630
[:SOURce<hw>]:FM:MODE	630
[:SOURce<hw>]:FM:SENSitivity?	630

[\[:SOURce<hw>\]:FM<ch>:STATe <State>](#)

Activates frequency modulation.

Suffix:

FM<ch> 1..2
 determines the modulation signal channel.

Parameters:

<State> 1 | ON | 0 | OFF
 *RST: 0

Example: See [Example "Creating a frequency modulated RF signal"](#) on page 626.

Manual operation: See ["State"](#) on page 84

[\[:SOURce<hw>\]:FM<ch>\[:DEViation\] <Deviation>](#)

Sets the modulation deviation of the frequency modulation in Hz.

Suffix:

FM<ch> 1|2
 Modulation signal channel

Parameters:

<Deviation> float
 The maximum deviation depends on the RF frequency and the selected modulation mode (see the specification document).

Range: 0 to max

Increment: 0.01

*RST: 1E3

Example: See [Example "Creating a frequency modulated RF signal"](#) on page 626.

Manual operation: See ["Deviation"](#) on page 84

[[:SOURce<hw>]:FM<ch>:SOURce <Source>

Selects the modulation source for frequency modulation.

Suffix:

FM<ch> 1|2
Modulation signal channel.

Parameters:

<Source> LF1 | LF2 | NOISe | EXT1 | INTernal | EXTernal | EXT2

LF1|LF2

Uses an internally generated LF signal.

INTernal = LF1

Works like LF1

EXTernal

Works like EXT1

EXT1|EXT2

Uses an externally supplied LF signal.

NOISe

Uses the internally generated noise signal.

*RST: LF1 <FM1>; LF2 <FM2>

Example: See [Example "Creating a frequency modulated RF signal"](#) on page 626.

Manual operation: See ["Source"](#) on page 84

[[:SOURce<hw>]:FM:DEVIation:MODE <FmDevMode>

Selects the coupling mode. The coupling mode parameter also determines the mode for fixing the total deviation.

Parameters:

<FmDevMode> UNCOupled | TOTal | RATio

UNCOupled

Does not couple the LF signals.

The deviation values of both paths are independent.

TOTal

Couples the deviation of both paths.

RATio

Couples the deviation ratio of both paths

*RST: UNCOupled

Example: See [Example "Using combined LF signals"](#) on page 627.

Manual operation: See ["Deviation Mode"](#) on page 85

[SOURce<hw>]:FM:DEVIation:SUM <FmDevSum>

Sets the total deviation of the LF signal when using combined signal sources in frequency modulation.

Parameters:

<FmDevSum> float
Range: 0 to 40E6
Increment: 0.01
*RST: 1E3

Example: See [Example "Using combined LF signals"](#) on page 627.

Manual operation: See ["Total Deviation"](#) on page 85

[SOURce<hw>]:FM:RATio <Ratio>

Sets the deviation ratio (path2 to path1) in percent.

Parameters:

<Ratio> float
Range: 0 to 100
Increment: 0.1
*RST: 100

Example: See [Example "Creating a frequency modulated RF signal"](#) on page 626.

Manual operation: See ["Ratio Path2/Path1"](#) on page 85

[SOURce<hw>]:FM:MODE <Mode>

Selects the mode for the frequency modulation.

Parameters:

<Mode> HBANDwidth | LNOise
HBANDwidth
Selects maximum range for modulation bandwidth.
LNOise
Selects optimized phase noise and spurious characteristics with reduced modulation bandwidth and FM deviation.
*RST: HBANDwidth

Example: See [Example "Creating a frequency modulated RF signal"](#) on page 626.

Manual operation: See ["Mode"](#) on page 85

[SOURce<hw>]:FM:SENSitivity?

Queries the sensitivity of the externally supplied signal for frequency modulation. The sensitivity depends on the set modulation deviation.

Return values:

<Sensitivity> float
 Sensitivity in Hz/V.
 It is assigned to the voltage value for full modulation of the input.
 Range: 0 to max
 Increment: 0.01

Example: See [Example "Using an external signal source"](#) on page 627.

Usage: Query only

15.18.1.5 SOURce:PM subsystem

Option: R&S SMAB-K720

The PM subsystem contains the commands for setting the phase modulation. You can configure the internal modulation source (LF generator) with the commands listed in [Section 15.18.7, "SOURce:LFOutput subsystem"](#), on page 710.

Example: Performing phase modulation

The following example shows a command sequence to perform phase modulation.

```
// Reset the instrument to start from an initial state
*RST; *CLS

// Set the RF signal frequency and level
:SOURce:FREQuency:CW 4000000000
:SOURce:POWer:LEVel:IMMediate:AMPLitude -25

// Configure the phase modulation settings
:SOURcel:LFOutput1:SHAPE SINE
:SOURcel:LFOutput1:FREQuency 1000

// Select the LF signal generated by the internal modulation generator
// or the internally generated noise signal
:SOURcel:PM1:DEVIation 1
:SOURcel:PM1:SOURce LF1
// :SOURcel:PM1:SOURce INTernal
// :SOURcel:PM1:SOURce NOISe
:SOURcel:PM1:RATio 40
:SOURcel:PM1:MODE HBAN

// Alternatively configure the phase modulation settings for an
// external modulation source and query the input sensitivity.
:SOURcel:PM1:SOURce EXT1
// :SOURcel:PM1:SOURce EXTernal
:SOURcel:PM1:DEVIation 1
:SOURcel:PM1:SENSitivity?
// Response: 1
// since the voltage value for full modulation is 1V,
```

```
// the resulting sensitivity is precisely 1RAD/V.
```

```
// Activate the signal output
```

```
:SOURce1:PM1:STATe 1
```

```
:OUTPut1:STATe 1
```

Example: Using combined LF signals

Using the internal LF generators of both paths, the following command sequences configure a phase-modulated signal with determined deviations.

```
// Configure the Phase modulation settings with combined LF signal sources
```

```
:SOURce1:PM1:SOURce LF1
```

```
:SOURce1:PM1:DEVIation 1.5
```

```
// Select the modulation signal source for the second path
```

```
:SOURce1:PM2:SOURce LF2
```

```
// Combine the signals of both paths with fixed total deviation depth
```

```
:SOURce1:PM1:DEVIation:MODE TOT
```

```
:SOURce1:PM1:DEVIation:SUM 2
```

```
// Query the deviation depth of the modulation signal in the second path
```

```
:SOURce1:PM2:DEVIation?
```

```
// Response: 0.5
```

```
// Combine the signals of both paths with fixed ratio
```

```
:SOURce1:PM1:DEVIation:MODE RAT
```

```
:SOURce1:PM1:RATio 80
```

```
:SOURce1:PM2:DEVIation?
```

```
// Response: 1.2
```

```
// Query the deviation depth of modulation signal in the first path
```

```
:SOURce1:PM1:DEVIation?
```

```
// Response: 1.5
```

```
:SOURce1:FM1:STATe 1
```

```
:SOURce1:FM2:STATe 1
```

The following commands are available:

<code>[SOURce<hw>]:PM<ch>:STATe</code>	632
<code>[SOURce<hw>]:PM<ch>:SOURce</code>	633
<code>[SOURce<hw>]:PM:MODE</code>	633
<code>[SOURce<hw>]:PM:DEVIation:MODE</code>	634
<code>[SOURce<hw>]:PM:DEVIation:SUM</code>	634
<code>[SOURce<hw>]:PM:RATio</code>	634
<code>[SOURce<hw>]:PM:SENSitivity?</code>	635
<code>[SOURce]:PM<ch>[:DEVIation]</code>	635

`[SOURce<hw>]:PM<ch>:STATe <State>`

Activates phase modulation.

Activation of phase modulation deactivates frequency modulation.

Suffix:

PM<ch> 1|2
Sets the modulation signal channel.

Parameters:

<State> 1 | ON | 0 | OFF
*RST: 0

Example: See [Example "Performing phase modulation"](#) on page 631.

Manual operation: See ["State"](#) on page 84

[[:SOURce<hw>]:PM<ch>:SOURce <Source>

Selects the modulation source for phase modulation signal.

Suffix:

PM<ch> 1|2
Sets the modulation signal channel.

Parameters:

<Source> LF1 | LF2 | NOISe | EXT1 | EXT2 | INTernal | EXTernal

LF1|LF2

Uses an internally generated LF signal.

EXT1|EXT2

Uses an externally supplied LF signal.

NOISe

Uses the internally generated noise signal.

INTernal

Uses the internally generated signal of LF1.

EXTernal

Uses an external LF signal (EXT1).

*RST: LF1 <PM1>; LF2 <PM2>

Example: See [Example "Performing phase modulation"](#) on page 631.

Manual operation: See ["Source"](#) on page 84

[[:SOURce<hw>]:PM:MODE <Mode>

Selects the mode for the phase modulation.

Parameters:

<Mode> HBANDwidth | HDEViation | LNOise

HBANDwidth

Sets the maximum available bandwidth.

HDEViation

Sets the maximum range for Φ M deviation.

LNOise

Selects a phase modulation mode with phase noise and spurious characteristics close to CW mode.

*RST: HBANdwidth

Example: See [Example "Performing phase modulation"](#) on page 631.

Manual operation: See ["Mode"](#) on page 87

[SOURce<hw>]:PM:DEVIation:MODE <PmDevMode>

Selects the coupling mode. The coupling mode parameter also determines the mode for fixing the total deviation.

Parameters:

<PmDevMode> UNCOupled | TOTal | RATio

UNCOupled

Does not couple the LF signals.

The deviation values of both paths are independent.

TOTal

Couples the deviation of both paths.

RATio

Couples the deviation ratio of both paths

*RST: UNCOupled

Example: See [Example "Using combined LF signals"](#) on page 632

Manual operation: See ["Deviation Mode"](#) on page 86

[SOURce<hw>]:PM:DEVIation:SUM <PmDevSum>

Sets the total deviation of the LF signal when using combined signal sources in phase modulation.

Parameters:

<PmDevSum> float
Range: 0 to max
Increment: 1E-6
*RST: 1

Example: See [Example "Using combined LF signals"](#) on page 632

Manual operation: See ["Total Deviation"](#) on page 86

[SOURce<hw>]:PM:RATio <Ratio>

Sets the deviation ratio (path2 to path1) in percent.

Parameters:

<Ratio> float
 Range: 0 to 100
 Increment: 0.01
 *RST: 100

Example: See [Example "Performing phase modulation"](#) on page 631.

Manual operation: See ["Ratio Path2/Path1"](#) on page 87

[[:SOURce<hw>]:PM:SENSitivity?

Queries the sensitivity of the externally applied signal for phase modulation.

The returned value reports the sensitivity in RAD/V. It is assigned to the voltage value for full modulation of the input.

Return values:

<Sensitivity> float

Example: See [Example "Performing phase modulation"](#) on page 631.

Usage: Query only

[[:SOURce]:PM<ch>[:DEVIation] <Deviation>

Sets the modulation deviation of the phase modulation in RAD.

Parameters:

<Deviation> float
 The maximal deviation depends on the RF frequency and the selected modulation mode (see the specifications document).
 Range: 0 to max
 Increment: 1
 *RST: 1
 Default unit: RAD

Example: See [Example "Performing phase modulation"](#) on page 631.

Manual operation: See ["Deviation"](#) on page 86

15.18.1.6 SOURce:PULM subsystem

Option: see [Section 5.1, "Required options"](#), on page 77.

The PULM subsystem contains the commands for setting the pulse modulation.

- [Pulse modulation settings](#)..... 636
- [Pulse train settings](#)..... 641
- [Pulse train data exchange](#)..... 644

Pulse modulation settings

With the commands described in this section, you can configure the settings for pulse modulation, select the trigger mode and determine delay times for the pulse modulation signal.

Example: Perform pulse modulation

The example shows a command sequence to perform pulse modulation.

```
// Reset the instrument to start from an initial state
*RST; *CLS

// Set the RF signal frequency and level
:SOURce:FREQuency:CW 4000000000
:SOURce:POWer:LEVel:IMMediate:AMPLitude -25

// Configure the pulse modulation settings
// Select the internal modulation generator,
// set trigger mode, select pulse mode, transition type

// Trigger a single pulse

:SOURce:PULM:SOURce INT
:SOURce:PULM:TRIGger:MODE SING
:SOURce:PULM:MODE DOUB
:SOURce:PULM:TTYpe SMO

:SOURce:PULM:TRIGger:IMMediate

// Alternatively configure the pulse modulation settings for
// external modulation source
// Select the source, set the polarity of the external signal,
// select the impedance for the external pulse modulation input/
// for the external pulse modulation trigger input
:SOURce:PULM:SOURce EXT
:SOURce:PULM:POLarity NORMal
:SOURce:PULM:IMPedance G1K

// Configure the pulse generator settings
// Set pulse period, width, and delay
:SOURce:PULM:PERiod 10 us
:SOURce:PULM:WIDth 8 us
:SOURce:PULM:DOUBle:WIDTh 0.0000012
:SOURce:PULM:DOUBle:DELay 0.0000045

// Activate the signal output
:SOURce:PGENerator:OUTPut:STATe 1
:SOURce:PULM:STATe 1
:OUTPut1:STATe 1
```

The following commands are available:

<code>[SOURce<hw>]:PULM:MODE</code>	637
<code>[SOURce<hw>]:PULM:TRIGger:MODE</code>	637
<code>[SOURce]:PULM[:INTernal][:TRain]:TRIGger:IMMediate</code>	638
<code>[SOURce<hw>]:PULM:PERiod</code>	638
<code>[SOURce<hw>]:PULM:WIDTh</code>	638
<code>[SOURce<hw>]:PULM:DELay</code>	638
<code>[SOURce<hw>]:PULM:DOUBle:DELay</code>	639
<code>[SOURce<hw>]:PULM:DOUBle:WIDTh</code>	639
<code>[SOURce<hw>]:PULM:DOUBle:STATe</code>	639
<code>[SOURce<hw>]:PULM:STATe</code>	639
<code>[SOURce<hw>]:PULM:SOURce</code>	639
<code>[SOURce<hw>]:PULM:TTYPe</code>	640
<code>[SOURce<hw>]:PULM:POLarity</code>	640
<code>[SOURce<hw>]:PULM:IMPedance</code>	640
<code>[SOURce<hw>]:PULM:THReshold</code>	641

`[SOURce<hw>]:PULM:MODE <Mode>`

Selects the mode for the pulse modulation.

Parameters:

<code><Mode></code>	SINGle DOUBle PTRain
SINGle	Generates a single pulse.
DOUBle	Generates two pulses within one pulse period.
PTRain	Generates a user-defined pulse train. Specify the pulse sequence with the commands: <code>[SOURce<hw>]:PULM:TRain:ONTime</code> <code>[SOURce<hw>]:PULM:TRain:OFFTime</code> <code>[SOURce<hw>]:PULM:TRain:REPetition</code>
*RST:	SINGle

Example: See [Example "Perform pulse modulation"](#) on page 636.

Options: PTRain requires R&S SMAB-K27

Manual operation: See ["Pulse Mode"](#) on page 97

`[SOURce<hw>]:PULM:TRIGger:MODE <Mode>`

Selects a trigger mode - auto, single, external, external single or external gated - for generating the modulation signal.

Parameters:

<code><Mode></code>	AUTO EXTeRnal EGATe SINGle ESINGle
*RST:	AUTO

Example: See [Example "Perform pulse modulation"](#) on page 636.

Manual operation: See ["Trigger Mode"](#) on page 98

[[:SOURce]:PULM[:INTERNAL]][:TRAIN]:TRIGGER:IMMEDIATE

If `[[:SOURce<hw>]:PULM:TRIGGER:MODESINGLE]`, triggers the pulse generator.

Example: See [Example "Perform pulse modulation"](#) on page 636.

Manual operation: See ["Execute Single Trigger"](#) on page 101

[[:SOURce<hw>]:PULM:PERIOD <Period>

Sets the period of the generated pulse, that means the repetition frequency of the internally generated modulation signal.

Parameters:

<Period> float
The minimum value depends on the installed options
R&S SMAB-K22 or R&S SMAB-K23
Range: 20E-9 to 100
Increment: 5E-9
*RST: 10E-6

Example: See [Example "Perform pulse modulation"](#) on page 636.

Manual operation: See ["Pulse Period"](#) on page 100

[[:SOURce<hw>]:PULM:WIDTH <Width>

Sets the width of the generated pulse, that means the pulse length. It must be at least 20ns less than the set pulse period.

Parameters:

<Width> float
Range: 20E-9 to 100
Increment: 10E-9
*RST: 2E-6

Example: See [Example "Perform pulse modulation"](#) on page 636.

Manual operation: See ["Pulse Width"](#) on page 101

[[:SOURce<hw>]:PULM:DELAY <Delay>

Sets the pulse delay.

Parameters:

<Delay> float
*RST: 1ms

Example: See [Example "Perform pulse modulation"](#) on page 636.

Manual operation: See ["Pulse Delay"](#) on page 101

[:SOURce<hw>]:PULM:DOUBle:DELay <Delay>

Sets the delay from the start of the first pulse to the start of the second pulse.

Parameters:

<Delay> float
*RST: 1E-6

Example: See [Example "Perform pulse modulation"](#) on page 636.

Manual operation: See ["Double Pulse Delay"](#) on page 101

[:SOURce<hw>]:PULM:DOUBle:WIDTh <Width>

Sets the width of the second pulse.

Parameters:

<Width> float
Increment: 5E-9

Example: See [Example "Perform pulse modulation"](#) on page 636.

Manual operation: See ["Double Pulse Width"](#) on page 101

[:SOURce<hw>]:PULM:DOUBle:STATe <State>

Provided for backward compatibility with former Rohde & Schwarz signal generators.

Works like the command [\[:SOURce<hw>\]:PULM:MODEDOUBle](#).

Parameters:

<State> 1 | ON | 0 | OFF
*RST: 0

[:SOURce<hw>]:PULM:STATe <State>

Activates pulse modulation.

Parameters:

<State> 1 | ON | 0 | OFF
*RST: 0

Example: See [Example "Perform pulse modulation"](#) on page 636.

Manual operation: See ["State"](#) on page 81

[:SOURce<hw>]:PULM:SOURce <Source>

Selects between the internal (pulse generator) or an external pulse signal for the modulation.

Parameters:

<Source> INTernal | EXTernal
 *RST: INTernal

Example: See [Example "Perform pulse modulation"](#) on page 636.

Manual operation: See ["Source"](#) on page 81

[[:SOURce<hw>]:PULM:TTYPe <Source>

Sets the transition mode for the pulse signal.

Parameters:

<Source> SMOothed | FAST
 SMOothed
 flattens the slew rate, resulting in longer rise/fall times.
 FAST
 enables fast transitions with shortest rise and fall times.
 *RST: FAST

Example: See [Example "Perform pulse modulation"](#) on page 636.

Manual operation: See ["Transition Type"](#) on page 82

[[:SOURce<hw>]:PULM:POLarity <Polarity>

Sets the polarity of the externally applied modulation signal.

Parameters:

<Polarity> NORMal | INVerted
 NORMal
 Suppresses the RF signal during the pulse pause.
 INVerted
 Suppresses the RF signal during the pulse.
 *RST: NORMal

Example: See [Example "Perform pulse modulation"](#) on page 636.

Manual operation: See ["Polarity"](#) on page 109

[[:SOURce<hw>]:PULM:IMPedance <Impedance>

Sets the impedance for the external pulse trigger and pulse modulation input.

Parameters:

<Impedance> G50 | G10K
 *RST: G10K

Example: See [Example "Perform pulse modulation"](#) on page 636.

Manual operation: See ["Impedance"](#) on page 109

[[:SOURce<hw>]:PULM:THReshold <Threshold>

Sets the threshold for the input signal at the [Pulse Ext] connector.

Parameters:

<Threshold> float
 Range: 0 to 2
 Increment: 0.1
 *RST: 1
 Default unit: V

Example: SOURce:PULM:THReshold 1

Manual operation: See ["Threshold"](#) on page 110

Pulse train settings

Option: R&S SMAB-K27

This section describes the commands for the pulse train modulation and the associated file handling.

See [Section 5.4.4.2, "Pulse generator > pulse train settings"](#), on page 102.

Example: Generating a pulse train signal

The following settings are required to perform pulse train modulation.



Always create and select pulse train data list first before you activate the pulse train mode. Otherwise, an error is displayed.

```
*RST; *CLS

// Set the RF signal frequency and level
:SOURce:FREQuency:CW 4000000000
:SOURce:POWer:LEVel:IMMediate:AMPLitude -25

// Create a pulse train data list
// Select the directory
:MMEM:CDIR '/var/user/'
:SOURcel:PULM:TRAI:n:CATalog?
// Reaponse: "my_pt"
// Create and/or select the pulse train data file
:SOURcel:PULM:TRAI:n:SElect "/var/user/pt"
// Enter the pulse train data
:SOURce:PULM:TRAI:n:ONTime 0.0001,0.00025,0.0001
:SOURce:PULM:TRAI:n:OFFTime 500us,500us,300us
:SOURce:PULM:TRAI:n:REPetition 2,0,3
// the second pulse is ignored

// Select pulse train mode
// Select the internal modulation generator and the pulse mode
```

```

:SOURce1:PULM:SOURce INT
:SOURce1:PULM:MODE PTR
:SOURce1:PULM:TRIGger:MODE EXT
:SOURce1:PGENerator:OUTPut:STATe 1
:SOURce1:PGENerator:OUTPut:POLarity NORM
:SOURce:PGENerator:OUTPut:STATe 1
:SOURce:PULM:STATe 1
:OUTPut1:STATe 1

:SOURce1:PULM:TRAI:n:CATalog?
// Response: "my_pt, pt"
:SOURce1:PULM:TRAI:n:DEL "/var/user/my_pt"

```

The following commands are available:

[:SOURce<hw>]:PULM:TRAI:n:CATalog?	642
[:SOURce<hw>]:PULM:TRAI:n:DELe	642
[:SOURce<hw>]:PULM:TRAI:n:ONTime	643
[:SOURce<hw>]:PULM:TRAI:n:OFFTime	643
[:SOURce<hw>]:PULM:TRAI:n:REPetition:POINts?	643
[:SOURce<hw>]:PULM:TRAI:n:ONTime:POINts?	643
[:SOURce<hw>]:PULM:TRAI:n:OFFTime:POINts?	643
[:SOURce<hw>]:PULM:TRAI:n:REPetition	643
[:SOURce<hw>]:PULM:TRAI:n:SELe	644

[\[:SOURce<hw>\]:PULM:TRAI:n:CATalog?](#)

Queries the available pulse train files in the specified directory.

Return values:

<Catalog> string
 List of list filenames, separated by commas

Example: See [Example "Generating a pulse train signal"](#) on page 641.

Usage: Query only

Manual operation: See ["Pulse Train Data"](#) on page 103

[\[:SOURce<hw>\]:PULM:TRAI:n:DELe](#) <Filename>

Deletes the specified pulse train file.

Setting parameters:

<Filename> string
 Filename or complete file path; file extension is optional.

Example: See [Example "Generating a pulse train signal"](#) on page 641.

Usage: Setting only

Manual operation: See ["Pulse Train Data"](#) on page 103

[:SOURce<hw>]:PULM:TRAI:n:ONTime <OnTime>

[:SOURce<hw>]:PULM:TRAI:n:OFFTime <OffTime>

Enters the pulse on/off times values in the selected list.

Parameters:

<OffTime> Offtime#1{, Offtime#2, ...} | binary block data
 List of comma-separated numeric values or binary block data, where:
 The list of numbers can be of any length.
 In binary block format, 8 (4) bytes are always interpreted as a floating-point number with double accuracy.
 See :FORMat [:DATA] on page 529 for details.
 The maximum length is 2047 values.
 Range: 0 ns to 10 ms

Example: See [Example "Generating a pulse train signal"](#) on page 641.

Manual operation: See ["Edit Pulse Train Data"](#) on page 104

[:SOURce<hw>]:PULM:TRAI:n:REPetition:POINts?

[:SOURce<hw>]:PULM:TRAI:n:ONTime:POINts?

[:SOURce<hw>]:PULM:TRAI:n:OFFTime:POINts?

Queries the number of on and off time entries and repetitions in the selected list.

Return values:

<Points> integer
 Range: 0 to INT_MAX
 *RST: 0

Example: See [Example "Generating a pulse train signal"](#) on page 641.

Usage: Query only

[:SOURce<hw>]:PULM:TRAI:n:REPetition <Repetition>

Sets the number of repetitions for each pulse on/off time value pair.

Parameters:

<Repetition> Repetition#1{, Repetition#2, ...}
 0 = ignore value pair
 Set "Repetition = 0" to skip a particular pulse without deleting the pulse on/off time value pair
 Range: 0 to 65535

Example: See [Example "Generating a pulse train signal"](#) on page 641.

Manual operation: See ["Edit Pulse Train Data"](#) on page 104

[:SOURce<hw>]:PULM:TRAI:n:SElect <Filename>

Selects or creates a data list in pulse train mode.

If the list with the selected name does not exist, a new list is created.

Parameters:

<Filename> string
 Filename or complete file path; file extension can be omitted.

Example: See [Example "Generating a pulse train signal"](#) on page 641.

Manual operation: See ["Pulse Train Data"](#) on page 103

Pulse train data exchange

Option: R&S SMAB-K27

With the following commands, you can configure pulse trains in ASCII format and export or import them accordingly.

```
:SOURce1:PULM:SOURce INT
:SOURce1:PULM:MODE PTR
:SOURce1:PULM:TRAI:n:SElect "/var/user/pt"
:SOURce1:PULM:STATe 1

:SOURce1:PULM:TRAI:n:DEXChange:MODE EXP
:SOURce1:PULM:TRAI:n:DEXChange:AFIle:EXTension TXT
:SOURce1:PULM:TRAI:n:DEXChange:AFIle:SEParator:DECimal DOT
:SOURce1:PULM:TRAI:n:DEXChange:AFIle:SEParator:COLumn SEM
:SOURce1:PULM:TRAI:n:DEXChange:AFIle:SEParator:COLumn COMM
:SOURce1:PULM:TRAI:n:DEXChange:SElect "/var/user/pt.pulstrn"
:SOURce1:PULM:TRAI:n:DEXChange:AFIle:SElect "/var/user/pt_script.txt"
:SOURce1:PULM:TRAI:n:DEXChange:EXECute
```

The following commands are available:

[:SOURce<hw>]:PULM:TRAI:n:DEXChange:MODE	644
[:SOURce<hw>]:PULM:TRAI:n:DEXChange:AFIle:EXTension	645
[:SOURce<hw>]:PULM:TRAI:n:DEXChange:AFIle:SEParator:DECimal	645
[:SOURce<hw>]:PULM:TRAI:n:DEXChange:AFIle:SEParator:COLumn	645
[:SOURce<hw>]:PULM:TRAI:n:DEXChange:AFIle:CATalog?	645
[:SOURce<hw>]:PULM:TRAI:n:DEXChange:AFIle:SElect	646
[:SOURce<hw>]:PULM:TRAI:n:DEXChange:SElect	646
[:SOURce<hw>]:PULM:TRAI:n:DEXChange:EXECute	646

[:SOURce<hw>]:PULM:TRAI:n:DEXChange:MODE <Mode>

Determines the import or export of a list.

Specify the source or destination file with the command [\[:SOURce<hw>\]:PULM:TRAI:n:DEXChange:SElect](#).

Parameters:

<Mode> IMPort | EXPort
 *RST: IMPort

Example: See ["Pulse train data exchange"](#) on page 644.

Manual operation: See ["Mode"](#) on page 106

[[:SOURce<hw>]:PULM:TRAI:DEXChange:AFILe:EXTension <Extension>

Determines the extension of the ASCII file for import or export, or to query existing files.

Parameters:

<Extension> TXT | CSV
 *RST: TXT

Example: See ["Pulse train data exchange"](#) on page 644.

Manual operation: See ["ASCII File Settings"](#) on page 106

[[:SOURce<hw>]:PULM:TRAI:DEXChange:AFILe:SEParator:DECimal <Decimal>

Sets "." (decimal point) or "," (comma) as the decimal separator used in the ASCII data with floating-point numerals.

Parameters:

<Decimal> DOT | COMMa
 *RST: DOT

Example: See ["Pulse train data exchange"](#) on page 644.

Manual operation: See ["ASCII File Settings"](#) on page 106

[[:SOURce<hw>]:PULM:TRAI:DEXChange:AFILe:SEParator:COLumn <Column>

Selects the separator between the frequency and level column of the ASCII table.

Parameters:

<Column> TABulator | SEMicolon | COMMa | SPACe
 *RST: COMMa

Example: See ["Pulse train data exchange"](#) on page 644.

Manual operation: See ["ASCII File Settings"](#) on page 106

[[:SOURce<hw>]:PULM:TRAI:DEXChange:AFILe:CATalog?

Queries the available ASCII files in the current or specified directory.

Return values:

<Catalog> string
 List of ASCII files *.txt or *.csv, separated by commas.

Example: See ["Pulse train data exchange"](#) on page 644.

Usage: Query only

Manual operation: See ["Select \(ASCII\) Source/Select \(ASCII\) Destination"](#) on page 107

[:SOURce<hw>]:PULM:TRAI:n:DEXChange:AFILe:SElect <Filename>

Selects the ASCII file to be imported or exported.

Parameters:

<Filename> string
Filename or complete file path; file extension can be omitted.

Example: See ["Pulse train data exchange"](#) on page 644.

Manual operation: See ["Select \(ASCII\) Source/Select \(ASCII\) Destination"](#) on page 107

[:SOURce<hw>]:PULM:TRAI:n:DEXChange:SElect <Filename>

Selects the ASCII file for import or export, containing a pulse train list.

Parameters:

<Filename> string
Filename or complete file path; file extension can be omitted.

Example: See ["Pulse train data exchange"](#) on page 644.

Manual operation: See ["Select Source/Select ASCII Destination"](#) on page 107

[:SOURce<hw>]:PULM:TRAI:n:DEXChange:EXECute

Usage: Event

Manual operation: See ["Import / Export"](#) on page 107

Executes the import or export of the selected list file, according to the transfer direction set with command [\[:SOURce<hw>\]:PULM:TRAI:n:DEXChange:MODE](#).

15.18.2 Avionic standards subsystems

Option: see [Section 6.1, "Required options"](#), on page 124.

The following subsections describe all commands for avionic standard modulation of the RF signal. Divided into separate avionic subsystem command sections, you can configure ADF, ILS and VOR modulation.

Programming examples are given for general configuration and avionic standard-specific configuration tasks.

Placeholder <Subsystem>

To simplify the description of the remote control commands, the placeholder <Subsystem> is introduced. Depending on the avionic standard used as an entry standard, replace this placeholder <Subsystem> with for example SOURce:ADF for ADF.



The replacement of the place holder <Subsystem> is mandatory, i.e. remote control commands containing this placeholder are not recognized and accepted by the instrument.

Example:

SCPI command <subsystem>:STATe:

- Entry Standard = ADF
SOURce:ADF:STATe
- Entry Standard = ILS
SOURce:ILS:STATe
- Entry Standard = VOR
SOURce:VOR:STATe
- Invalid command
<Subsystem>:STAT

Contents

• Programming examples	647
• General commands	651
• SOURce:ADF subsystem	654
• SOURce:ILS subsystem	657
• SOURce:VOR subsystem	680

15.18.2.1 Programming examples**Example: Saving and recalling a configuration**

This example shows how to query and load settings files, saved with the save/recall function for the ADF standard.

For other avionic standards, replace ADF by ILS or VOR.

```
SOURce1:ADF:PRESet
// Go to the "settings" directory.
MMEM:CDIR "/var/user/settings"
// List all files in the directory with extension *.adf.
SOURce1:ADF:SETTing:CATalog?
// adf_general, adf_comid

// Save the ADF configuration in the file "adf_general_latest.adf".
SOURce1:ADF:SETTing:STORe "/var/user/settings/adf_general_latest"
// Delete the file "adf_general.adf".
```

```

SOURCE1:ADF:SETTING:DELEte "/var/user/settings/adf_general"
SOURCE1:ADF:SETTING:CATalog?
// adf_general_latest, adf_comid

// Load the file "adf_general_latest.adf".
SOURCE1:ADF:SETTING:LOAD "/var/user/settings/adf_general_latest"

// Activate ADF signal generation.
SOURCE1:ADF:STATe 1

```

Example: Configuring and generating a ADF signal

```

SOURCE1:ADF:PRESet

// Configure ADF COM/ID settings.
SOURCE1:ADF:COMid:PERiod 9
SOURCE1:ADF:COMid:FREQuency 1020
SOURCE1:ADF:COMid:DEPTh 11
SOURCE1:ADF:COMid:TSCHEMA USER
SOURCE1:ADF:COMid:DOT 0.11
SOURCE1:ADF:COMid:DASH 0.29
SOURCE1:ADF:COMid:SYMBOL 0.11
SOURCE1:ADF:COMid:LETter 0.29
SOURCE1:ADF:COMid:STATe 1

// Activate ADF signal generation.
SOURCE1:ADF:STATe 1

```

Example: Configure and generate an ILS glide slope signal

```

SOURCE1:BB:ILS:PRESet

// Configure ILS localizer general settings.
SOURCE1:ILS:TYPE GS
SOURCE1:ILS:GS:FREQuency:MODE USER
SOURCE1:ILS:GS:FREQuency 334700000
SOURCE1:ILS:GS:FREQuency:MODE ICAO
SOURCE1:ILS:GS:ICAO:CHANnel?
// Response: CH18X
SOURCE1:ILS:GS:FREQuency:SYNChronize 1
SOURCE1:ILS:LOCALizer:ICAO:CHANnel?
// Response: CH18X
SOURCE1:ILS:LOCALizer:FREQuency?
// Response: 108100000
SOURCE1:ILS:GSLope:SOURce?
// Response: INT

// Configure ILS glide slope signal settings.
SOURCE1:ILS:GS:MODE NORM
SOURCE1:ILS:GS:DDM:POLarity P90_150
SOURCE1:ILS:GS:ULObE:FREQuency 90

```

```

SOURCE1:ILS:GS:LLOBe:FREQuency 150
SOURCE1:ILS:GS:PHASe 0

// Configure ILS glide slope amplitude settings.
SOURCE1:ILS:GS:DDM:DIRection UP
SOURCE1:ILS:GS:SDM 80
SOURCE1:ILS:GS:DDM:COUPling FIX
SOURCE1:ILS:GS:DDM:STEP DEC
SOURCE1:ILS:GS:DDM:CURREnt 0
SOURCE1:ILS:GS:DDM:DEPTh 0
SOURCE1:ILS:GS:DDM:LOGarithmic 0
SOURCE1:ILS:GS:DDM:PCT 0

// Activate ILS signal generation.
SOURCE1:ILS:STATe 1

```

Example: Configure and generate an ILS localizer signal

```

SOURCE1:ILS:PRESet

// Configure ILS localizer general settings.
SOURCE1:ILS:TYPE LOC
SOURCE1:ILS:LOCalizer:FREQuency:MODE USER
SOURCE1:ILS:LOCalizer:FREQuency 108100000
SOURCE1:ILS:LOCalizer:FREQuency:SYNChronize 1
SOURCE1:ILS:GS:FREQuency?
// Response: 108100000
SOURCE1:ILS:LOCalizer:FREQuency:MODE ICAO
SOURCE1:ILS:LOCalizer:ICAO:CHANnel CH26Y
SOURCE1:ILS:GS:ICAO:CHANnel?
// Response: CH26Y
SOURCE1:ILS:GS:FREQuency?
// Response: 108950000
SOURCE1:ILS:LOCalizer:SOURce?
// Response: INT

// Configure ILS localizer signal settings.
SOURCE1:ILS:LOCalizer:MODE NORM
SOURCE1:ILS:LOCalizer:DDM:POLarity P90_150
SOURCE1:ILS:LOCalizer:LLOBe:FREQuency 90
SOURCE1:ILS:LOCalizer:RLOBe:FREQuency 150
SOURCE1:ILS:LOCalizer:PHASe 0

// Configure ILS localizer amplitude settings.
SOURCE1:ILS:LOCalizer:DDM:DIRection LEFT
SOURCE1:ILS:LOCalizer:SDM 40
SOURCE1:ILS:LOCalizer:DDM:COUPling FIX
SOURCE1:ILS:LOCalizer:DDM:STEP DEC
SOURCE1:ILS:LOCalizer:DDM:CURREnt 0
SOURCE1:ILS:LOCalizer:DDM:DEPTh 0
SOURCE1:ILS:LOCalizer:DDM:LOGarithmic 0
SOURCE1:ILS:LOCalizer:DDM:PCT 0

```

```
// Configure ILS localizer COM/ID settings.
SOURCE1:ILS:LOCALizer:COMid:CODE "MUC"
SOURCE1:ILS:LOCALizer:COMid:PERiod 9
SOURCE1:ILS:LOCALizer:COMid:FREQuency 1020
SOURCE1:ILS:LOCALizer:COMid:DEPTh 10
SOURCE1:ILS:LOCALizer:COMid:TSCHEMA USER
SOURCE1:ILS:LOCALizer:COMid:DOT 0.11
SOURCE1:ILS:LOCALizer:COMid:DASH 0.29
SOURCE1:ILS:LOCALizer:COMid:SYMBOL 0.11
SOURCE1:ILS:LOCALizer:COMid:LETter 0.29
SOURCE1:ILS:LOCALizer:COMid:STATE 1

// Activate ILS signal generation.
SOURCE1:ILS:STATE 1
```

Example: Configure and generate an ILS marker beacons signal

```
SOURCE1:ILS:PRESet

// Configure ILS marker beacons general settings.
SOURCE1:ILS:TYPE MBE
SOURCE1:ILS:MBEacon:FREQuency:MODE USER
SOURCE1:ILS:MBEacon:FREQuency 75000000
SOURCE1:ILS:MBEacon:MARKer:FREQuency 400
SOURCE1:ILS:MBEacon:MARKer:DEPTh 95
SOURCE1:ILS:MBEacon:MARKer:PULSed?
// Response: "0"

// Configure ILS marker beacons COM/ID settings.
SOURCE1:ILS:MBEacon:COMid:CODE "MUC"
SOURCE1:ILS:MBEacon:COMid:PERiod 9
SOURCE1:ILS:MBEacon:COMid:FREQuency 1020
SOURCE1:ILS:MBEacon:COMid:DEPTh 5
SOURCE1:ILS:MBEacon:COMid:TSCHEMA USER
SOURCE1:ILS:MBEacon:COMid:DOT 0.11
SOURCE1:ILS:MBEacon:COMid:DASH 0.29
SOURCE1:ILS:MBEacon:COMid:SYMBOL 0.11
SOURCE1:ILS:MBEacon:COMid:LETter 0.29
SOURCE1:ILS:MBEacon:COMid:STATE 1

// Activate ILS signal generation.
SOURCE1:BB:ILS:STATE 1
```

Example: Configure and generate a VOR signal

```

SOURCE1:VOR:PRESet

// Configure VOR general settings.
SOURCE1:VOR:FREQuency:MODE USER
SOURCE1:VOR:FREQuency 108000000
SOURCE1:VOR:FREQuency:MODE ICAO
SOURCE1:VOR:ICAO:CHANnel?
// Response: RCH17X
SOURCE1:VOR:SOURce?
// Response: INT

// Configure VOR signal settings.
SOURCE1:VOR:MODE NORM
SOURCE1:VOR:VAR:FREQuency 30
SOURCE1:VOR:VAR:DEPTh 30
SOURCE1:VOR:SUBCarrier:FREQuency 9960
SOURCE1:VOR:SUBCarrier:DEPTh 30
SOURCE1:VOR:REFerence:DEViation 480

// Configure VOR position settings.
SOURCE1:VOR:BANGLe 1
SOURCE1:VOR:BANGLe:DIRection FROM

// Configure VOR COM/ID settings.
SOURCE1:VOR:COMid:PERiod 9
SOURCE1:VOR:COMid:FREQuency 1020
SOURCE1:VOR:COMid:DEPTh 11
SOURCE1:VOR:COMid:TSCHEMA USER
SOURCE1:VOR:COMid:DOT 0.11
SOURCE1:VOR:COMid:DASH 0.29
SOURCE1:VOR:COMid:SYMBOL 0.11
SOURCE1:VOR:COMid:LETTer 0.29
SOURCE1:VOR:COMid:STATe 1

// Activate VOR signal generation.
SOURCE1:VOR:STATe 1

```

15.18.2.2 General commands

<subsystem>:PRESet.....	652
[[:SOURCE<hw>]:ADF:PRESet.....	652
[[:SOURCE<hw>]:ILS:PRESet.....	652
[[:SOURCE<hw>]:VOR:PRESet.....	652
<subsystem>:SETTing:CATalog.....	652
[[:SOURCE<hw>]:ADF:SETTing:CATalog.....	652
[[:SOURCE<hw>]:ILS:SETTing:CATalog?.....	652
[[:SOURCE<hw>]:VOR:SETTing:CATalog?.....	652
<subsystem>:SETTing:DELeTe.....	652
[[:SOURCE<hw>]:ADF:SETTing:DELeTe.....	652

[:SOURCE<hw>]:ILS:SETTING:DELeTe.....	653
[:SOURCE<hw>]:VOR:SETTING:DELeTe.....	653
<subsystem>:SETTING:LOAD.....	653
[:SOURCE<hw>]:ADF:SETTING:LOAD.....	653
[:SOURCE<hw>]:ILS:SETTING:LOAD.....	653
[:SOURCE<hw>]:VOR:SETTING:LOAD.....	653
<subsystem>:SETTING:STORe.....	653
[:SOURCE<hw>]:ADF:SETTING:STORe.....	653
[:SOURCE<hw>]:ILS:SETTING:STORe.....	653
[:SOURCE<hw>]:VOR:SETTING:STORe.....	653
<subsystem>:STATe.....	653
[:SOURCE<hw>]:ADF:STATe.....	653
[:SOURCE<hw>]:ILS:STATe.....	654
[:SOURCE<hw>]:VOR:STATe.....	654
<subsystem>:FREQuency:SYNChronize:STATe.....	654
[:SOURCE<hw>]:ILS[:GS GSLope]:FREQuency:SYNChronize[:STATe].....	654
[:SOURCE<hw>]:ILS:LOCAlizer:FREQuency:SYNChronize[:STATe].....	654

<subsystem>:PRESet

[:SOURCE<hw>]:ADF:PRESet

[:SOURCE<hw>]:ILS:PRESet

[:SOURCE<hw>]:VOR:PRESet

Sets the parameters of the digital standard to their default values (*RST values specified for the commands).

Not affected is the state set with the command SOURCE<hw>:VOR:STATe.

Example: See [Example "Saving and recalling a configuration"](#) on page 647.

<subsystem>:SETTING:CATalog

[:SOURCE<hw>]:ADF:SETTING:CATalog

[:SOURCE<hw>]:ILS:SETTING:CATalog?

[:SOURCE<hw>]:VOR:SETTING:CATalog?

Queries the files with settings in the default directory. Listed are files with the file extension *.adf/*.ils/*.vor.

Return values:

<FileNames> <filename1>,<filename2>,...

Returns a string of filenames separated by commas.

Example: See [Example "Saving and recalling a configuration"](#) on page 647.

Usage: Query only

<subsystem>:SETTING:DELeTe

[:SOURCE<hw>]:ADF:SETTING:DELeTe <Filename>

**[[:SOURce<hw>]:ILS:SETting:DELeTe <Filename>
[[:SOURce<hw>]:VOR:SETting:DELeTe <Filename>**

Deletes the selected file from the default or the specified directory. Deleted are files with extension *.adf/*.ils/*.vor.

Setting parameters:

<Filename> "<filename>"
Filename or complete file path; file extension can be omitted

Example: See [Example "Saving and recalling a configuration"](#) on page 647.

Usage: Setting only

**<subsystem>:SETting:LOAD
[[:SOURce<hw>]:ADF:SETting:LOAD <Filename>
[[:SOURce<hw>]:ILS:SETting:LOAD <Filename>
[[:SOURce<hw>]:VOR:SETting:LOAD <Filename>**

Loads the selected file from the default or the specified directory. Loaded are files with extension *.adf/*.ils/*.vor.

Parameters:

<Filename> "<filename>"
Filename or complete file path; file extension can be omitted

Example: See [Example "Saving and recalling a configuration"](#) on page 647.

Usage: Setting only

**<subsystem>:SETting:STORe
[[:SOURce<hw>]:ADF:SETting:STORe <Filename>
[[:SOURce<hw>]:ILS:SETting:STORe <Filename>
[[:SOURce<hw>]:VOR:SETting:STORe <Filename>**

Saves the current settings into the selected file; the file extension (*.adf/*.ils/*.vor) is assigned automatically.

Parameters:

<Filename> "<filename>"
Filename or complete file path

Example: See [Example "Saving and recalling a configuration"](#) on page 647.

Usage: Setting only

**<subsystem>:STATe
[[:SOURce<hw>]:ADF:STATe <State>**

[:SOURce<hw>]:ILS:STATe <State>
[:SOURce<hw>]:VOR:STATe <State>

Activates/deactivates the VOR modulation.

Parameters:

<State> 1 | ON | 0 | OFF
 *RST: 0

Example: See [Example "Saving and recalling a configuration"](#) on page 647.

<subsystem>:FREQuency:SYNChronize:STATe

[:SOURce<hw>]:ILS[:GS|GSLope]:FREQuency:SYNChronize[:STATe] <Mode>
[:SOURce<hw>]:ILS:LOCalizer:FREQuency:SYNChronize[:STATe] <Mode>

Activates synchronization of the ILS localizer ICAO channel with the ILS glide slope ICAO channel.

The ILS glide slope/localizer frequency of the ICAO channel ([Table 6-2](#)) is set automatically.

Parameters:

<Mode> 0 | 1 | OFF | ON
 *RST: 0

Example: See [Example "Configure and generate an ILS localizer signal"](#) on page 649.

15.18.2.3 SOURce:ADF subsystem

Option: R&S SMAB-K25

The SOURce:ADF subsystem contains all commands for configuring the ADF signal.

Characteristics which are valid for all modulations and the LF output are configured in the SOURce:LFOutput subsystem. The signal is output at the LF connector.

Commands

[:SOURce<hw>]:ADF:COMid:CODE.....	655
[:SOURce<hw>]:ADF:COMid:DASH.....	655
[:SOURce<hw>]:ADF:COMid:DEPT.....	655
[:SOURce<hw>]:ADF:COMid:DOT.....	655
[:SOURce<hw>]:ADF:COMid:FREQuency.....	656
[:SOURce<hw>]:ADF:COMid:LETTer.....	656
[:SOURce<hw>]:ADF:COMid:PERiod.....	656
[:SOURce<hw>]:ADF:COMid:SYMBol.....	657
[:SOURce<hw>]:ADF:COMid:TSCHema.....	657
[:SOURce<hw>]:ADF:COMid[:STATe].....	657

[[:SOURce<hw>]:ADF:COMid:CODE <Code>

Sets the coding of the COM/ID signal by the international short name of the airport (e.g. MUC for the Munich airport).

The COM/ID tone is sent according to the selected code, see [Section D, "Morse code settings"](#), on page 860.

If no coding is set, the COM/ID tone is sent uncoded (key down).

Parameters:

<Code> string

Example: See [Example "Configuring and generating a ADF signal"](#) on page 648.

Manual operation: See ["Code"](#) on page 166

[[:SOURce<hw>]:ADF:COMid:DASH <Dash>

Sets the length of a Morse code dash.

Parameters:

<Dash> float
 Range: 50E-3 to 1
 Increment: 1E-4
 *RST: 300E-3

Example: See [Example "Configuring and generating a ADF signal"](#) on page 648.

Manual operation: See ["Dash Length"](#) on page 167

[[:SOURce<hw>]:ADF:COMid:DEPTH <Depth>

Sets the AM modulation depth of the COM/ID signal.

Parameters:

<Depth> float
 Range: 0 to 100
 Increment: 0.1
 *RST: 95

Example: See [Example "Configuring and generating a ADF signal"](#) on page 648.

Manual operation: See ["Depth"](#) on page 166

[[:SOURce<hw>]:ADF:COMid:DOT <Dot>

Sets the length of a Morse code dot.

Parameters:

<Dot> float
 Range: 50E-3 to 1
 Increment: 1E-4
 *RST: 100E-3

Example: See [Example "Configuring and generating a ADF signal"](#) on page 648.

Manual operation: See ["Dot Length"](#) on page 166

[SOURce<hw>]:ADF:COMid:FREQuency <Frequency>

Sets the frequency of the COM/ID signal.

Parameters:

<Frequency> float
 Range: 0.1 to 20E3
 Increment: 0.01
 *RST: 1020

Example: See [Example "Configuring and generating a ADF signal"](#) on page 648.

Manual operation: See ["Frequency"](#) on page 166

[SOURce<hw>]:ADF:COMid:LETter <Letter>

Sets the length of a Morse code letter space.

Parameters:

<Letter> float
 Range: 50E-3 to 1
 Increment: 1E-4
 *RST: 300E-3

Example: See [Example "Configuring and generating a ADF signal"](#) on page 648.

Manual operation: See ["Letter Space"](#) on page 167

[SOURce<hw>]:ADF:COMid:PERiod <Period>

Sets the period of the COM/ID signal.

Parameters:

<Period> float
 Range: 0 to 120
 Increment: 1E-3
 *RST: 9

Example: See [Example "Configuring and generating a ADF signal"](#) on page 648.

Manual operation: See ["Period"](#) on page 166

[[:SOURce<hw>]:ADF:COMid:SYMBol <Symbol>

Sets the length of the Morse code symbol space.

Parameters:

<Symbol> float
 Range: 50E-3 to 1
 Increment: 1E-4
 *RST: 100E-3

Example: See [Example "Configuring and generating a ADF signal"](#) on page 648.

Manual operation: See ["Symbol Space"](#) on page 167

[[:SOURce<hw>]:ADF:COMid:TSCHEMA <TSCHEMA>

Sets the time schema of the Morse code for the COM/ID signal.

Parameters:

<TSCHEMA> STD | USER
 *RST: STD

Example: See [Example "Configuring and generating a ADF signal"](#) on page 648.

Manual operation: See ["Time Schema"](#) on page 166

[[:SOURce<hw>]:ADF:COMid[:STATe] <State>

Enables/disables the COM/ID signal.

Parameters:

<State> 1 | ON | 0 | OFF
 *RST: 0

Example: See [Example "Configuring and generating a ADF signal"](#) on page 648.

Manual operation: See ["COM/ID State"](#) on page 166

15.18.2.4 SOURce:ILS subsystem

Option: R&S SMAB-K25

The SOURce:BB:ILS subsystem contains all commands for configuring the ILS signal.

Characteristics which are valid for all modulations and the LF output are configured in the **SOURce:LFOutput** subsystem. The signal is output at the LF connector.

Commands

[SOURce<hw>]:ILS:TYPE.....	659
[SOURce<hw>]:ILS[:GS GSLope]:DDM:COUPling.....	659
[SOURce<hw>]:ILS[:GS GSLope]:DDM:CURRent.....	660
[SOURce<hw>]:ILS[:GS GSLope]:DDM:DIRection.....	660
[SOURce<hw>]:ILS[:GS GSLope]:DDM:LOGarithmic.....	660
[SOURce<hw>]:ILS[:GS GSLope]:DDM:PCT.....	661
[SOURce<hw>]:ILS[:GS GSLope]:DDM:POLarity.....	661
[SOURce<hw>]:ILS[:GS GSLope]:DDM:STEP.....	661
[SOURce<hw>]:ILS[:GS GSLope]:DDM[:DEPT]h.....	662
[SOURce<hw>]:ILS[:GS GSLope]:FREQuency.....	662
[SOURce<hw>]:ILS[:GS GSLope]:FREQuency:MODE.....	662
[SOURce<hw>]:ILS[:GS GSLope]:FREQuency:SYNChronize[:STATe].....	663
[SOURce<hw>]:ILS[:GS GSLope]:ICAO:CHANnel.....	663
[SOURce<hw>]:ILS[:GS GSLope]:LLOBe[:FREQuency].....	664
[SOURce<hw>]:ILS[:GS GSLope]:MODE.....	664
[SOURce<hw>]:ILS[:GS GSLope]:PHASe.....	664
[SOURce<hw>]:ILS:GS GSLope:PRESet.....	665
[SOURce<hw>]:ILS[:GS GSLope]:SDM.....	665
[SOURce<hw>]:ILS[:GS GSLope]:SOURce.....	665
[SOURce<hw>]:ILS[:GS GSLope]:ULOBe[:FREQuency].....	666
[SOURce<hw>]:ILS:LOCalizer:COMid:CODE.....	666
[SOURce<hw>]:ILS:LOCalizer:COMid:DASH.....	666
[SOURce<hw>]:ILS:LOCalizer:COMid:DEPT]h.....	667
[SOURce<hw>]:ILS:LOCalizer:COMid:DOT.....	667
[SOURce<hw>]:ILS:LOCalizer:COMid:FREQuency.....	667
[SOURce<hw>]:ILS:LOCalizer:COMid:LETTer.....	667
[SOURce<hw>]:ILS:LOCalizer:COMid:PERiod.....	668
[SOURce<hw>]:ILS:LOCalizer:COMid:SYMBol.....	668
[SOURce<hw>]:ILS:LOCalizer:COMid:TSCHEMA.....	668
[SOURce<hw>]:ILS:LOCalizer:COMid[:STATe].....	669
[SOURce<hw>]:ILS:LOCalizer:DDM:COUPling.....	669
[SOURce<hw>]:ILS:LOCalizer:DDM:CURRent.....	669
[SOURce<hw>]:ILS:LOCalizer:DDM:DIRection.....	670
[SOURce<hw>]:ILS:LOCalizer:DDM:LOGarithmic.....	670
[SOURce<hw>]:ILS:LOCalizer:DDM:PCT.....	670
[SOURce<hw>]:ILS:LOCalizer:DDM:POLarity.....	671
[SOURce<hw>]:ILS:LOCalizer:DDM:STEP.....	671
[SOURce<hw>]:ILS:LOCalizer:DDM[:DEPT]h.....	671
[SOURce<hw>]:ILS:LOCalizer:FREQuency.....	672
[SOURce<hw>]:ILS:LOCalizer:FREQuency:MODE.....	672
[SOURce<hw>]:ILS:LOCalizer:FREQuency:SYNChronize[:STATe].....	672
[SOURce<hw>]:ILS:LOCalizer:ICAO:CHANnel.....	673
[SOURce<hw>]:ILS:LOCalizer:LLOBe[:FREQuency].....	673
[SOURce<hw>]:ILS:LOCalizer:MODE.....	674
[SOURce<hw>]:ILS:LOCalizer:PHASe.....	674

<code>[SOURce<hw>]:ILS:LOCalizer:PRESet</code>	674
<code>[SOURce<hw>]:ILS:LOCalizer:RLOBe[:FREQuency]</code>	675
<code>[SOURce<hw>]:ILS:LOCalizer:SDM</code>	675
<code>[SOURce<hw>]:ILS:LOCalizer:SOURce</code>	675
<code>[SOURce<hw>]:ILS:MBEacon:COMid:CODE</code>	676
<code>[SOURce<hw>]:ILS:MBEacon:COMid:DASH</code>	676
<code>[SOURce<hw>]:ILS:MBEacon:COMid:DEPT</code>	676
<code>[SOURce<hw>]:ILS:MBEacon:COMid:DOT</code>	677
<code>[SOURce<hw>]:ILS:MBEacon:COMid:FREQuency</code>	677
<code>[SOURce<hw>]:ILS:MBEacon:COMid:LETTer</code>	677
<code>[SOURce<hw>]:ILS:MBEacon:COMid:PERiod</code>	677
<code>[SOURce<hw>]:ILS:MBEacon:COMid:SYMBol</code>	678
<code>[SOURce<hw>]:ILS:MBEacon:COMid:TSCHema</code>	678
<code>[SOURce<hw>]:ILS:MBEacon:COMid[:STATe]</code>	678
<code>[SOURce<hw>]:ILS:MBEacon:FREQuency</code>	679
<code>[SOURce<hw>]:ILS:MBEacon:FREQuency:MODE</code>	679
<code>[SOURce<hw>]:ILS:MBEacon:MARKer:FREQuency</code>	679
<code>[SOURce<hw>]:ILS:MBEacon[:MARKer]:DEPT</code>	680
<code>[SOURce<hw>]:ILS:MBEacon:PRESet</code>	680
<code>[SOURce<hw>]:ILS:MBEacon[:MARKer]:PULSed</code>	680

`[SOURce<hw>]:ILS:TYPE <Type>`

Selects the ILS modulation type.

Parameters:

<Type> GS | LOCalize | GSLope | MBEacon
 *RST: GS

Example: See [Example "Configure and generate an ILS glide slope signal"](#) on page 648.

Manual operation: See ["ILS Component"](#) on page 141

`[SOURce<hw>]:ILS[:GS|GSLope]:DDM:COUPling <Coupling>`

Selects if the DDM value is fixed or is changed with a change of sum of modulation depths (SDM, see [\[:SOURce<hw>\]:ILS\[:GS|GSLope\]:SDM](#) on page 665).

Parameters:

<Coupling> FIXed | SDM
 *RST: FIXed

Example: See [Example "Configure and generate an ILS glide slope signal"](#) on page 648.

Manual operation: See ["DDM - SDM Coupling"](#) on page 148

[:SOURce<hw>]:ILS[:GS|GSLope]:DDM:CURRent <Current>

Sets the DDM value alternatively as a current by means of the ILS indicating instrument. The instrument current is calculated according to:

$$\text{DDM Current } \mu\text{A} = \text{DDM Depth } [\%] \times 857,125 \mu\text{A}$$

A variation of the instrument current automatically leads to a variation of the DDM value and the DDM value in dB.

Parameters:

<Current> float
 Range: -8.57125E-4 to 8.57125E-4
 Increment: 1E-7
 *RST: 0

Example: See [Example "Configure and generate an ILS glide slope signal"](#) on page 648.

Manual operation: See ["DDM Current"](#) on page 147

[:SOURce<hw>]:ILS[:GS|GSLope]:DDM:DIRection <Direction>

Sets the simulation mode for the ILS glide slope modulation signal. A change of the setting automatically changes the sign of the DDM value.

Parameters:

<Direction> UP | DOWN
UP
 The 150-Hz modulation signal is predominant, the DDM value is negative (the airplane is too low, it must climb).
DOWN
 The 90-Hz modulation signal is predominant, the DDM value is positive (the airplane is too high, it must descend).
 *RST: UP

Example: See [Example "Configure and generate an ILS glide slope signal"](#) on page 648.

Manual operation: See ["Fly Mode"](#) on page 146

[:SOURce<hw>]:ILS[:GS|GSLope]:DDM:LOGarithmic <Logarithmic>

Sets the depth of modulation value for ILS glide slope modulation in dB.

See also [\[:SOURce<hw>\]:ILS\[:GS|GSLope\]:DDM\[:DEPTh\]](#) on page 662.

Parameters:

<Logarithmic> float
 Range: -999.9 to 999.9
 Increment: 1E-4
 *RST: 0

Example: See [Example "Configure and generate an ILS glide slope signal"](#) on page 648.

Manual operation: See ["DDM Logarithmic"](#) on page 147

[:SOURce<hw>]:ILS[:GS|GSLope]:DDM:PCT <Pct>

Sets the difference in depth of modulation between the signal of the upper lobe (90 Hz) and the lower lobe (150 Hz). The maximum value equals the sum of the modulation depths of the 90 Hz and the 150 Hz tone.

See also [\[:SOURce<hw> \] : ILS \[:GS | GSLope \] : DDM \[:DEPTh \]](#) on page 662.

Parameters:

<Pct> float
 Range: -80.0 to 80.0
 Increment: 0.01
 *RST: 0

Example: See [Example "Configure and generate an ILS glide slope signal"](#) on page 648.

Manual operation: See ["DDM Percent"](#) on page 147

[:SOURce<hw>]:ILS[:GS|GSLope]:DDM:POLarity <Polarity>

Sets the polarity for DDM calculation (see [\[:SOURce<hw> \] : ILS \[:GS | GSLope \] : DDM \[:DEPTh \]](#) on page 662).

The DDM depth calculation depends on the selected polarity:

- Polarity 90 Hz - 150 Hz (default setting):

$$\text{DDM} = [\text{AM}(90 \text{ Hz}) - \text{AM}(150 \text{ Hz})] / 100\%$$
- Polarity 150 Hz - 90 Hz:

$$\text{DDM} = [\text{AM}(150 \text{ Hz}) - \text{AM}(90 \text{ Hz})] / 100\%$$

Parameters:

<Polarity> P90_150 | P150_90
 *RST: P90_150

Example: See [Example "Configure and generate an ILS glide slope signal"](#) on page 648.

Manual operation: See ["DDM Polarity"](#) on page 145

[:SOURce<hw>]:ILS[:GS|GSLope]:DDM:STEP <DdmStep>

Sets the variation of the difference in depth of modulation via the rotary knob.

Parameters:

<DdmStep> DECimal | PREDefined
 *RST: DECimal

Example: See [Example "Configure and generate an ILS glide slope signal"](#) on page 648.

Manual operation: See ["DDM Step"](#) on page 147

[:SOURce<hw>] : ILS : GS [GSLOpe] : DDM : DEPTH <Depth>

Sets the difference in depth of modulation between the signal of the upper/left lobe (90 Hz) and the lower/right lobe (150 Hz). The maximum value equals the sum of the modulation depths of the 90 Hz and the 150 Hz tone. The following is true:

$$\text{ILS : GS [GSLOpe] : DDM : DEPTH} = (\text{AM}(90\text{Hz}) - \text{AM}(150\text{Hz})) / 100\%$$

A variation of the DDM value automatically leads to a variation of the DDM value in dB and the value of the instrument current.

Parameters:

<Depth> float
 Range: -0.8 to 0.8
 Increment: 1E-4
 *RST: 0

Example: See [Example "Configure and generate an ILS glide slope signal"](#) on page 648.

Manual operation: See ["DDM Depth"](#) on page 147

[:SOURce<hw>] : ILS : GS [GSLOpe] : FREQUENCY <CarrierFreq>

Sets the carrier frequency of the signal.

Parameters:

<CarrierFreq> float
 Range: 100E3 to 6E9
 Increment: 0.01
 *RST: 334.7E6

Example: See [Example "Configure and generate an ILS glide slope signal"](#) on page 648.

Manual operation: See ["Carrier Frequency"](#) on page 143

[:SOURce<hw>] : ILS : GS [GSLOpe] : FREQUENCY : MODE <Mode>

Sets the mode for the carrier frequency of the signal.

Parameters:

<Mode> USER | ICAO
DECimal
 Activates user-defined variation of the carrier frequency.

ICAO

Activates variation in predefined steps according to standard ILS transmitting frequencies (see [Table 6-2](#)).

*RST: DECimal

Example: See [Example "Configure and generate an ILS glide slope signal"](#) on page 648.

Manual operation: See ["Carrier Frequency Mode"](#) on page 142

[:SOURce<hw>]:ILS[:GS[GSLope]:FREQuency:SYNChronize[:STATe] <Mode>

Activates synchronization of the ILS glide slope ICAO channel with the ILS localizer ICAO channel.

The ILS glide slope/localizer frequency of the ICAO channel ([Table 6-2](#)) is set automatically.

Parameters:

<Mode> 0 | 1 | OFF | ON
*RST: 0

Example: See [Example "Configure and generate an ILS glide slope signal"](#) on page 648.

[:SOURce<hw>]:ILS[:GS[GSLope]:ICAO:CHANnel <Channel>

Sets the ICAO channel and the corresponding transmitting frequency.

If avionic standard modulation is activated and you change the "RF Frequency", the frequency value of the closest ICAO channel is applied automatically. The "ICAO Channel" is also updated.

The ICAO channel settings for ILS glide slope/localizer components are coupled. For an overview of the ILS ICAO channel frequencies, see [Table 6-2](#).

Parameters:

<Channel> CH18X | CH18Y | CH20X | CH20Y | CH22X | CH22Y | CH24X | CH24Y | CH26X | CH26Y | CH28X | CH28Y | CH30X | CH30Y | CH32X | CH32Y | CH34X | CH34Y | CH36X | CH36Y | CH38X | CH38Y | CH40X | CH40Y | CH42X | CH42Y | CH44X | CH44Y | CH46X | CH46Y | CH48X | CH48Y | CH50X | CH50Y | CH52X | CH52Y | CH54X | CH54Y | CH56X | CH56Y
*RST: CH18X

Example: See [Example "Configure and generate an ILS glide slope signal"](#) on page 648.

Manual operation: See ["ICAO Channel"](#) on page 143

[[:SOURce<hw>]:ILS[:GS|GSLope]:LLOBe[:FREQuency] <Frequency>

Sets the modulation frequency of the antenna lobe arranged at the bottom viewed from the air plane for the ILS glide slope modulation signal.

Parameters:

<Frequency> float
 Range: 100 to 200
 Increment: 0.05
 *RST: 150

Example: See [Example "Configure and generate an ILS glide slope signal"](#) on page 648.

Manual operation: See ["Down Frequency"](#) on page 145

[[:SOURce<hw>]:ILS[:GS|GSLope]:MODE <Mode>

Sets the operating mode for the ILS glide slope modulation signal.

Parameters:

<Mode> NORM | ULObE | LLOBe

NORM

ILS glide slope modulation is active.

ULObE

Amplitude modulation of the output signal with the upper lobe (90Hz) signal component of the ILS glide slope signal is active.

LLOBe

Amplitude modulation of the output signal with the lower lobe (150Hz) signal component of the ILS glide slope signal is active.

*RST: NORM

Example: See [Example "Configure and generate an ILS glide slope signal"](#) on page 648.

Manual operation: See ["Operating Mode"](#) on page 144

[[:SOURce<hw>]:ILS[:GS|GSLope]:PHASe <Phase>

Sets the phase between the modulation signals of the upper and lower antenna lobe of the ILS glide slope signal.

Zero crossing of the lower lobe (150Hz) signal serves as a reference. The angle refers to the period of the signal of the right antenna lobe.

Parameters:

<Phase> float
 Range: -60 to 120
 Increment: 0.01
 *RST: 0.0

Example: See [Example "Configure and generate an ILS glide slope signal"](#) on page 648.

Manual operation: See ["Up/Down Phase"](#) on page 145

[:SOURce<hw>] : ILS : GS [GSLOpe] : PRESet

Sets the parameters of the ILS glide slope component to their default values (*RST values specified for the commands).

For other ILS preset commands, see [\[:SOURce<hw> \] : ILS : PRESet](#) on page 652.

Example: SOURce1 : ILS : GS : PRESet

Usage: Event

[:SOURce<hw>] : ILS [: GS [GSLOpe] : SDM <Sdm>

Sets the arithmetic sum of the modulation depths of the upper lobe (90 Hz) and lower lobe (150 Hz) for the ILS glide slope signal contents.

The RMS modulation depth of the sum signal depends on the phase setting of both modulation tones.

Parameters:

<Sdm> float
 Range: 0 to 100
 Increment: 0.1
 *RST: 80

Example: See [Example "Configure and generate an ILS glide slope signal"](#) on page 648.

Manual operation: See ["Sum of Depth"](#) on page 146

[:SOURce<hw>] : ILS [: GS [GSLOpe] : SOURCE <IlsGsSource>

Sets the modulation source for the avionic standard modulation.

If external modulation source is set, the external signal is added to the internal signal. Switching off the internal modulation source is not possible.

Parameters:

<IlsGsSource> INT | EXT | INT,EXT
INT
 Internal modulation source is used.
EXT|INT,EXT
 An external modulation source is used, additional to the internal modulation source.
 The external signal is input at the Ext connector.
 *RST: INT

Example: See [Example "Configure and generate an ILS glide slope signal"](#) on page 648.

Manual operation: See ["EXT AM"](#) on page 143

[:SOURce<hw>]:ILS[:GS|GSLope]:ULOB[:FREQuency] <Frequency>

Parameters:

<Frequency> float
 Range: 60 to 120
 Increment: 0.03
 *RST: 90

Example: See [Example "Configure and generate an ILS glide slope signal"](#) on page 648.

Manual operation: See ["Up Frequency"](#) on page 145

[:SOURce<hw>]:ILS:LOCalizer:COMid:CODE <Code>

Sets the coding of the COM/ID signal by the international short name of the airport (e.g. MUC for the Munich airport).

The COM/ID tone is sent according to the selected code, see [Section D, "Morse code settings"](#), on page 860.

If no coding is set, the COM/ID tone is sent uncoded (key down).

Parameters:

<Code> string

Example: See [Example "Configure and generate an ILS localizer signal"](#) on page 649.

Manual operation: See ["Code"](#) on page 156

[:SOURce<hw>]:ILS:LOCalizer:COMid:DASH <Dash>

Sets the length of a Morse code dash.

Parameters:

<Dash> float
 Range: 0.05 to 1
 Increment: 1E-4
 *RST: 0.3

Example: See [Example "Configure and generate an ILS localizer signal"](#) on page 649.

Manual operation: See ["Dash Length"](#) on page 157

[[:SOURce<hw>]:ILS:LOCalizer:COMid:DEPTh <Depth>

Sets the AM modulation depth of the COM/ID signal.

Parameters:

<Depth> float
 Range: 0 to 100
 Increment: 0.1
 *RST: 10

Example: See [Example "Configure and generate an ILS localizer signal"](#) on page 649.

Manual operation: See ["Depth"](#) on page 156

[[:SOURce<hw>]:ILS:LOCalizer:COMid:DOT <Dot>

Sets the length of a Morse code dot.

Parameters:

<Dot> float
 Range: 0.05 to 1
 Increment: 1E-4
 *RST: 0.1

Example: See [Example "Configure and generate an ILS localizer signal"](#) on page 649.

Manual operation: See ["Dot Length"](#) on page 157

[[:SOURce<hw>]:ILS:LOCalizer:COMid:FREQuency <Frequency>

Sets the frequency of the COM/ID signal.

Parameters:

<Frequency> float
 Range: 0.1 to 20E3
 Increment: 0.01
 *RST: 1020

Example: See [Example "Configure and generate an ILS localizer signal"](#) on page 649.

Manual operation: See ["Frequency"](#) on page 156

[[:SOURce<hw>]:ILS:LOCalizer:COMid:LETTer <Letter>

Sets the length of a Morse code letter space.

Parameters:

<Letter> float
 Range: 0.05 to 1
 Increment: 1E-4
 *RST: 0.3

Example: See [Example "Configure and generate an ILS localizer signal"](#) on page 649.

Manual operation: See ["Letter Space"](#) on page 157

[SOURce<hw>]:ILS:LOCalizer:COMid:PERiod <Period>

Sets the period of the COM/ID signal.

Parameters:

<Period> float
 Range: 0 to 120
 Increment: 1E-3
 *RST: 9

Example: See [Example "Configure and generate an ILS localizer signal"](#) on page 649.

Manual operation: See ["Period"](#) on page 156

[SOURce<hw>]:ILS:LOCalizer:COMid:SYMBol <Symbol>

Sets the length of the Morse code symbol space.

Parameters:

<Symbol> float
 Range: 0.05 to 1
 Increment: 1E-4
 *RST: 0.1

Example: See [Example "Configure and generate an ILS localizer signal"](#) on page 649.

Manual operation: See ["Symbol Space"](#) on page 157

[SOURce<hw>]:ILS:LOCalizer:COMid:TSCHEMA <TSchema>

Sets the time schema of the Morse code for the COM/ID signal.

Parameters:

<TSchema> STD | USER

STD

Activates the standard time schema of the Morse code.

The set [dot length](#) determines the [dash length](#), which is 3 times the dot length.

USER

Activates the user-defined time schema of the Morse code.
Dot and dash length, as well as [symbol](#) and [letter space](#) can be set separately.

*RST: STD

Example: See [Example "Configure and generate an ILS localizer signal"](#) on page 649.

Manual operation: See ["Time Schema"](#) on page 157

[:SOURce<hw>]:ILS:LOCalizer:COMid[:STATe] <State>

Enables/disables the COM/ID signal.

Parameters:

<State> 1 | ON | 0 | OFF

*RST: 0

Example: See [Example "Configure and generate an ILS localizer signal"](#) on page 649.

Manual operation: See ["COM/ID State"](#) on page 156

[:SOURce<hw>]:ILS:LOCalizer:DDM:COUPling <Coupling>

Selects if the DDM value is fixed or is changed with a change of sum of modulation depths (SDM, see [\[:SOURce<hw>\]:ILS:LOCalizer:SDM](#) on page 675).

Parameters:

<Coupling> FIXed | SDM

*RST: FIXed

Example: See [Example "Configure and generate an ILS localizer signal"](#) on page 649.

Manual operation: See ["DDM - SDM Coupling"](#) on page 154

[:SOURce<hw>]:ILS:LOCalizer:DDM:CURREnt <Current>

Sets the DDM value alternatively as a current by means of the ILS indicating instrument. The instrument current is calculated according to:

$$\text{DDM } \mu\text{A} = \text{DDM} \times 857,1 \mu\text{A}$$

A variation of the instrument current automatically leads to a variation of the DDM value and the DDM value in dB.

Parameters:

<Current> float

Range: -9.6775E-4 to 9.6775E-4

Increment: 1E-7

*RST: 0

Example: See [Example "Configure and generate an ILS localizer signal"](#) on page 649.

Manual operation: See ["DDM Current"](#) on page 154

[:SOURce<hw>]:ILS:LOCalizer:DDM:DIRection <Direction>

Sets the simulation mode for the ILS-LOC modulation signal. A change of the setting automatically changes the sign of the DDM value.

Parameters:

<Direction> LEFT | RIGHT

LEFT

The 150 Hz modulation signal is predominant, the DDM value is negative (the airplane is too far to the right, it must turn to the left).

RIGHT

The 90 Hz modulation signal is predominant, the DDM value is positive (the airplane is too far to the left, it must turn to the right).

*RST: LEFT

Example: See [Example "Configure and generate an ILS localizer signal"](#) on page 649.

Manual operation: See ["Fly Mode"](#) on page 153

[:SOURce<hw>]:ILS:LOCalizer:DDM:LOGarithmic <Logarithmic>

Sets the modulation depth in dB for ILS localizer modulation.

See also [\[:SOURce<hw>\]:ILS:LOCalizer:DDM\[:DEPTH\]](#) on page 671.

Parameters:

<Logarithmic> float
 Range: -999.9 to 999.9
 Increment: 1E-4
 *RST: 0

Example: See [Example "Configure and generate an ILS localizer signal"](#) on page 649.

Manual operation: See ["DDM Logarithmic"](#) on page 155

[:SOURce<hw>]:ILS:LOCalizer:DDM:PCT <Pct>

Sets the difference in depth of modulation between the signal of the left lobe (90 Hz) and the right lobe (150 Hz). The maximum value equals the sum of the modulation depths of the 90 Hz and the 150 Hz tone.

See also [\[:SOURce<hw>\]:ILS:LOCalizer:DDM\[:DEPTH\]](#) on page 671.

Parameters:

<Pct> float
 Range: -80.0 to 80.0
 Increment: 0.01
 *RST: 0

Example: See [Example "Configure and generate an ILS localizer signal"](#) on page 649.

Manual operation: See ["DDM Percent"](#) on page 155

[:SOURce<hw>]:ILS:LOCalizer:DDM:POLarity <Polarity>

Sets the polarity for DDM calculation (see [\[:SOURce<hw>\]:ILS:LOCalizer:DDM\[:DEPTh\]](#)).

The DDM depth calculation depends on the selected polarity:

- Polarity 90 Hz - 150 Hz (default setting):
 $\text{DDM} = [\text{AM} (90 \text{ Hz}) - \text{AM} (150 \text{ Hz})] / 100\%$
- Polarity 150 Hz - 90 Hz:
 $\text{DDM} = [\text{AM} (150 \text{ Hz}) - \text{AM} (90 \text{ Hz})] / 100\%$

Parameters:

<Polarity> P90_150 | P150_90
 *RST: P90_150

Example: See [Example "Configure and generate an ILS localizer signal"](#) on page 649.

Manual operation: See ["DDM polarity"](#) on page 152

[:SOURce<hw>]:ILS:LOCalizer:DDM:STEP <DdmStep>

Sets the variation step of the DDM values.

Parameters:

<DdmStep> DECimal | PREDefined
 *RST: DECimal

Example: See [Example "Configure and generate an ILS localizer signal"](#) on page 649.

Manual operation: See ["DDM Step"](#) on page 154

[:SOURce<hw>]:ILS:LOCalizer:DDM[:DEPTh] <Depth>

Sets the difference in depth of modulation between the signal of the upper/left lobe (90 Hz) and the lower/right lobe (150 Hz). The maximum value equals the sum of the modulation depths of the 90 Hz and the 150 Hz tone. The following is true:

$$\text{ILS:LOC:DDM:DEPTh} = (\text{AM}(90\text{Hz}) - \text{AM}(150\text{Hz})) / 100\%$$

A variation of the DDM value automatically leads to a variation of the DDM value in dB and the value of the instrument current.

Parameters:

<Depth> float
 Range: -0.4 to 0.4
 Increment: 1E-4
 *RST: 0

Example: See [Example "Configure and generate an ILS localizer signal"](#) on page 649.

Manual operation: See ["DDM Depth"](#) on page 154

[[:SOURce<hw>]:ILS:LOCalizer:FREQUency <CarrierFreq>

Sets the carrier frequency of the signal.

Parameters:

<CarrierFreq> float
 Range: 100E3 to 6E9
 Increment: 0.01
 *RST: 108.1E6

Example: See [Example "Configure and generate an ILS localizer signal"](#) on page 649.

Manual operation: See ["Carrier Frequency"](#) on page 149

[[:SOURce<hw>]:ILS:LOCalizer:FREQUency:MODE <ILsLocFreqMode>

Sets the mode for the carrier frequency of the signal.

Parameters:

<Mode> DECimal | ICAO

DECimal

Activates user-defined variation of the carrier frequency.

ICAO

Activates variation in predefined steps according to standard ILS transmitting frequencies (see [Table 6-2](#)).

*RST: DECimal

Example: See [Example "Configure and generate an ILS localizer signal"](#) on page 649.

Manual operation: See ["Carrier Frequency Mode"](#) on page 149

[[:SOURce<hw>]:ILS:LOCalizer:FREQUency:SYNChronize[:STATe] <Mode>

Activates synchronization of the ILS localizer ICAO channel with the ILS glide slope ICAO channel.

The ILS glide slope/localizer frequency of the ICAO channel ([Table 6-2](#)) is set automatically.

Parameters:

<Mode> 0 | 1 | OFF | ON
*RST: 0

Example: See [Example "Configure and generate an ILS localizer signal"](#) on page 649.

[[:SOURce<hw>]:ILS:LOCalizer:ICAO:CHANnel <SellcaoChan>

Sets the ICAO channel and the corresponding transmitting frequency.

If avionic standard modulation is activated and you change the "RF Frequency", the frequency value of the closest ICAO channel is applied automatically. The "ICAO Channel" is also updated.

The ICAO channel settings for ILS glide slope/localizer components are coupled. For an overview of the ILS ICAO channel frequencies, see [Table 6-2](#).

Parameters:

<SellcaoChan> CH18X | CH18Y | CH20X | CH20Y | CH22X | CH22Y | CH24X |
CH24Y | CH26X | CH26Y | CH28X | CH28Y | CH30X | CH30Y |
CH32X | CH32Y | CH34X | CH34Y | CH36X | CH36Y | CH38X |
CH38Y | CH40X | CH40Y | CH42X | CH42Y | CH44X | CH44Y |
CH46X | CH46Y | CH48X | CH48Y | CH50X | CH50Y | CH52X |
CH52Y | CH54X | CH54Y | CH56X | CH56Y
*RST: CH18X

Example: See [Example "Configure and generate an ILS localizer signal"](#) on page 649.

Manual operation: See ["ICAO Channel"](#) on page 150

[[:SOURce<hw>]:ILS:LOCalizer:LLOBe[:FREQuency] <Frequency>

Sets the modulation frequency of the antenna lobe arranged at the bottom viewed from the air plane for the ILS localizer modulation signal.

Parameters:

<Frequency> float
Range: 60 to 120
Increment: 0.03
*RST: 90

Example: See [Example "Configure and generate an ILS localizer signal"](#) on page 649.

Manual operation: See ["Left Frequency"](#) on page 152

[:SOURce<hw>]:ILS:LOCalizer:MODE <Mode>

Sets the operating mode for the ILS localizer modulation signal.

Parameters:

<Mode> NORM | LLOBe | RLOBe

NORM

ILS localizer modulation is active.

LLOBe

Amplitude modulation of the output signal with the left lobe (90Hz) signal component of the ILS localizer signal is active.

RLOBe

Amplitude modulation of the output signal with the right lobe (150Hz) signal component of the ILS localizer signal is active.

*RST: NORM

Example: See [Example "Configure and generate an ILS localizer signal"](#) on page 649.

Manual operation: See ["Operating Mode"](#) on page 151

[:SOURce<hw>]:ILS:LOCalizer:PHASe <Phase>

Sets the phase between the modulation signals of the left and right antenna lobe of the ILS localizer signal.

The zero crossing of the right lobe (150Hz) signal serves as a reference. The angle refers to the period of the signal of the right antenna lobe.

Parameters:

<Phase> float

Range: -60 to 120

Increment: 0.01

*RST: 0

Example: See [Example "Configure and generate an ILS localizer signal"](#) on page 649.

Manual operation: See ["Left/Right Phase"](#) on page 152

[:SOURce<hw>]:ILS:LOCalizer:PRESet

Sets the parameters of the ILS localizer component to their default values (*RST values specified for the commands).

For other ILS preset commands, see [\[:SOURce<hw>\]:ILS:PRESet](#) on page 652.

Example: SOURce1:ILS:LOCalizer:PRESet

Usage: Event

[[:SOURce<hw>]:ILS:LOCalizer:RLOBe[:FREQuency] <Frequency>

Sets the modulation frequency of the antenna lobe arranged at the right viewed from the air plane.

Parameters:

<Frequency> float
 Range: 100 to 200
 Increment: 0.05
 *RST: 150

Example: See [Example "Configure and generate an ILS localizer signal"](#) on page 649.

Manual operation: See ["Right Frequency"](#) on page 152

[[:SOURce<hw>]:ILS:LOCalizer:SDM <Sdm>

Sets the arithmetic sum of the modulation depths of the left lobe (90 Hz) and right lobe (150 Hz) for the ILS localizer signal contents.

The RMS modulation depth of the sum signal depends on the phase setting of both modulation tones.

Parameters:

<Sdm> float
 Range: 0 to 100
 Increment: 0.1
 *RST: 40

Example: See [Example "Configure and generate an ILS localizer signal"](#) on page 649.

Manual operation: See ["Sum of Depth"](#) on page 153

[[:SOURce<hw>]:ILS:LOCalizer:SOURce <IlsLocSource>

Sets the modulation source for the avionic standard modulation.

If external modulation source is set, the external signal is added to the internal signal. Switching off the internal modulation source is not possible.

Parameters:

<IlsLocSource> INT | EXT | INT,EXT

INT

Internal modulation source is used.

EXT|INT,EXT

An external modulation source is used, additional to the internal modulation source.

The external signal is input at the Ext connector.

*RST: INT

Example: See [Example "Configure and generate an ILS localizer signal"](#) on page 649.

Manual operation: See ["EXT AM"](#) on page 150

[[:SOURce<hw>][:ILS]:MBEacon:COMid:CODE <Code>

Sets the coding of the COM/ID signal by the international short name of the airport (e.g. MUC for the Munich airport).

The COM/ID tone is sent according to the selected code, see [Section D, "Morse code settings"](#), on page 860.

If no coding is set, the COM/ID tone is sent uncoded (key down).

Parameters:

<Code> string

Example: See [Example "Configure and generate an ILS marker beacons signal"](#) on page 650.

Manual operation: See ["Code"](#) on page 161

[[:SOURce<hw>][:ILS]:MBEacon:COMid:DASH <Dash>

Sets the length of a Morse code dash.

Parameters:

<Dash> float
 Range: 0.05 to 1
 Increment: 1E-4
 *RST: 0.3

Example: See [Example "Configure and generate an ILS marker beacons signal"](#) on page 650.

Manual operation: See ["Dash Length"](#) on page 162

[[:SOURce<hw>][:ILS]:MBEacon:COMid:DEPTTh <Depth>

Sets the AM modulation depth of the COM/ID signal.

Parameters:

<Depth> float
 Range: 0 to 100
 Increment: 0.1
 *RST: 5

Example: See [Example "Configure and generate an ILS marker beacons signal"](#) on page 650.

Manual operation: See ["Depth"](#) on page 161

[[:SOURce<hw>]][:ILS]:MBEacon:COMid:DOT <Dot>

Sets the length of a Morse code dot.

Parameters:

<Dot> float
 Range: 0.05 to 1
 Increment: 1E-4
 *RST: 0.1

Example: See [Example "Configure and generate an ILS marker beacons signal"](#) on page 650.

Manual operation: See ["Dot Length"](#) on page 162

[[:SOURce<hw>]][:ILS]:MBEacon:COMid:FREQuency <Frequency>

Sets the frequency of the COM/ID signal.

Parameters:

<Frequency> float
 Range: 0.1 to 20E3
 Increment: 0.01
 *RST: 1020

Example: See [Example "Configure and generate an ILS marker beacons signal"](#) on page 650.

Manual operation: See ["Frequency"](#) on page 161

[[:SOURce<hw>]][:ILS]:MBEacon:COMid:LETTer <Letter>

Sets the length of a Morse code letter space.

Parameters:

<Letter> float
 Range: 0.05 to 1
 Increment: 1E-4
 *RST: 0.3

Example: See [Example "Configure and generate an ILS marker beacons signal"](#) on page 650.

Manual operation: See ["Letter Space"](#) on page 162

[[:SOURce<hw>]][:ILS]:MBEacon:COMid:PERiod <Period>

Sets the period of the COM/ID signal.

Parameters:

<Period> float
 Range: 0 to 120
 Increment: 1E-3
 *RST: 9

Example: See [Example "Configure and generate an ILS marker beacons signal"](#) on page 650.

Manual operation: See ["Period"](#) on page 161

[[:SOURce<hw>][:ILS]:MBEacon:COMid:SYMBOL <Symbol>

Sets the length of the Morse code symbol space.

Parameters:

<Symbol> float
 Range: 0.05 to 1
 Increment: 1E-4
 *RST: 0.1

Example: See [Example "Configure and generate an ILS marker beacons signal"](#) on page 650.

Manual operation: See ["Symbol Space"](#) on page 162

[[:SOURce<hw>][:ILS]:MBEacon:COMid:TSCHEMA <Tschema>

Sets the time schema of the Morse code for the COM/ID signal.

Parameters:

<Tschema> STD | USER

STD

Activates the standard time schema of the Morse code.

The set [dot length](#) determines the [dash length](#), which is 3 times the dot length.

USER

Activates the user-defined time schema of the Morse code.

Dot and dash length, as well as [symbol](#) and [letter space](#) can be set separately.

*RST: STD

Example: See [Example "Configure and generate an ILS marker beacons signal"](#) on page 650.

Manual operation: See ["Time Schema"](#) on page 161

[[:SOURce<hw>][:ILS]:MBEacon:COMid[:STATe] <State>

Enables/disables the COM/ID signal.

Parameters:

<State> 1 | ON | 0 | OFF
 *RST: 0

Example: See [Example "Configure and generate an ILS marker beacons signal"](#) on page 650.

Manual operation: See ["COM/ID State"](#) on page 161

[[:SOURce<hw>][:ILS]:MBEacon:FREQuency <CarrierFreq>

Sets the carrier frequency for the ILS marker beacon signal.

Parameters:

<CarrierFreq> float
 Range: 100E3 to 6E9
 Increment: 0.01
 *RST: 75E6

Example: See [Example "Configure and generate an ILS marker beacons signal"](#) on page 650.

Manual operation: See ["Carrier Frequency"](#) on page 158

[[:SOURce<hw>][:ILS]:MBEacon:FREQuency:MODE <Mode>

Sets the carrier frequency mode of the ILS marker beacon signal.

Parameters:

<Mode> USER | PREDefined
 *RST: USER

Example: See [Example "Configure and generate an ILS marker beacons signal"](#) on page 650.

Manual operation: See ["Carrier Frequency Mode"](#) on page 158

[[:SOURce<hw>][:ILS]:MBEacon:MARKer:FREQuency <Frequency>

Sets the modulation frequency of the marker signal for the ILS marker beacon modulation signal.

Parameters:

<Frequency> 400 | 1300 | 3000
 *RST: 400
 Default unit: Hz

Example: See [Example "Configure and generate an ILS marker beacons signal"](#) on page 650.

Manual operation: See ["Marker Frequency"](#) on page 159

[[:SOURce<hw>]][:ILS]:MBEacon[:MARKer]:DEPTh <Depth>

Sets the modulation depth of the marker signal for the ILS marker beacon signal.

Parameters:

<Depth> float
 Range: 0 to 100
 Increment: 0.1
 *RST: 95

Example: See [Example "Configure and generate an ILS marker beacons signal"](#) on page 650.

Manual operation: See ["Marker Depth"](#) on page 159

[[:SOURce<hw>]][:ILS]:MBEacon:PRESet

Sets the parameters of the ILS marker beacons component to their default values (*RST values specified for the commands).

For other ILS preset commands, see [\[:SOURce<hw>\]:ILS:PRESet](#) on page 652.

Example: SOURce1:ILS:MBEacon:PRESet

Usage: Event

[[:SOURce<hw>]][:ILS]:MBEacon[:MARKer]:PULSed <Pulsed>

Activates the modulation of a pulsed marker signal (morse coding).

Parameters:

<Pulsed> 1 | ON | 0 | OFF
 *RST: 0

Example: See [Example "Configure and generate an ILS marker beacons signal"](#) on page 650.

Manual operation: See ["Pulsed Marker"](#) on page 159

15.18.2.5 SOURce:VOR subsystem

Option: R&S SMAB-K25

The SOURce:VOR subsystem contains all commands for configuring the VOR signal.

Characteristics which are valid for all modulations and the LF output are configured in the SOURce:LFOutput subsystem. The signal is output at the LF connector.

Commands

[:SOURce<hw>]:VOR:SOURce	681
[:SOURce<hw>]:VOR[:BANGLE]	681
[:SOURce<hw>]:VOR[:BANGLE]:DIRrection	682
[:SOURce<hw>]:VOR:COMid:CODE	682

<code>[:SOURce<hw>]:VOR:COMid:DASH</code>	682
<code>[:SOURce<hw>]:VOR:COMid:DEPT</code>	683
<code>[:SOURce<hw>]:VOR:COMid:DOT</code>	683
<code>[:SOURce<hw>]:VOR:COMid:FREQuency</code>	683
<code>[:SOURce<hw>]:VOR:COMid:LETTer</code>	684
<code>[:SOURce<hw>]:VOR:COMid:PERiod</code>	684
<code>[:SOURce<hw>]:VOR:COMid:SYMBol</code>	684
<code>[:SOURce<hw>]:VOR:COMid:TSCHEMA</code>	685
<code>[:SOURce<hw>]:VOR:COMid[:STATe]</code>	685
<code>[:SOURce<hw>]:VOR:FREQuency</code>	685
<code>[:SOURce<hw>]:VOR:FREQuency:MODE</code>	686
<code>[:SOURce<hw>]:VOR:ICAO:CHANnel</code>	686
<code>[:SOURce<hw>]:VOR:MODE</code>	687
<code>[:SOURce<hw>]:VOR:REFerence[:DEViation]</code>	688
<code>[:SOURce<hw>]:VOR:SUBCarrier:DEPT</code>	688
<code>[:SOURce<hw>]:VOR:SUBCarrier[:FREQuency]</code>	688
<code>[:SOURce<hw>]:VOR:VAR:FREQuency</code>	689
<code>[:SOURce<hw>]:VOR:VAR[:DEPT]</code>	689

`[ :SOURce<hw>]:VOR:SOURce` <VorSourceSel>

Sets the modulation source for the avionic standard modulation.

If external modulation source is set, the external signal is added to the internal signal. Switching off the internal modulation source is not possible.

Parameters:

<VorSourceSel> INT | EXT | INT,EXT

INT

Internal modulation source is used.

EXT|INT,EXT

An external modulation source is used, additional to the internal modulation source.

The external signal is input at the Ext connector.

*RST: INT

Example: See [Example "Configure and generate a VOR signal"](#) on page 651.

Manual operation: See ["EXT AM"](#) on page 129

`[ :SOURce<hw>]:VOR[:BANGLE]` <BAngle>

Sets the bearing angle between the VAR signal and the reference signal.

The orientation of the angle can be set with `[ :SOURce<hw>]:VOR[:BANGLE]:DIRection`.

Parameters:

<BAngle> float
 Range: 0 to 360
 Increment: 0.01
 *RST: 0

Example: See [Example "Configure and generate a VOR signal"](#) on page 651.

Manual operation: See ["Bearing Angle"](#) on page 132

[[:SOURce<hw>]:VOR[:BANGLE]:DIRECTION <Direction>

Sets the reference position of the phase information.

Parameters:

<Direction> FROM | TO
FROM
 The bearing angle is measured between the geographic north and the connection line from beacon to airplane.
TO
 The bearing angle is measured between the geographic north and the connection line from airplane to beacon.
 *RST: FROM

Example: See [Example "Configure and generate a VOR signal"](#) on page 651.

Manual operation: See ["Direction"](#) on page 132

[[:SOURce<hw>]:VOR:COMid:CODE <Code>

Sets the coding of the COM/ID signal by the international short name of the airport (e.g. MUC for the Munich airport).

The COM/ID tone is sent according to the selected code, see [Section D, "Morse code settings"](#), on page 860.

If no coding is set, the COM/ID tone is sent uncoded (key down).

Parameters:

<Code> string

Example: See [Example "Configure and generate a VOR signal"](#) on page 651.

Manual operation: See ["Code"](#) on page 133

[[:SOURce<hw>]:VOR:COMid:DASH <Dash>

Sets the length of a Morse code dash.

Parameters:

<Dash> float
 Range: 0.05 to 1
 Increment: 1E-4
 *RST: 0.3

Example: See [Example "Configure and generate a VOR signal"](#) on page 651.

Manual operation: See ["Dash Length"](#) on page 134

[SOURce<hw>]:VOR:COMid:DEPTH <Depth>

Sets the AM modulation depth of the COM/ID signal.

Parameters:

<Depth> float
 Range: 0 to 100
 Increment: 0.1
 *RST: 10

Example: See [Example "Configure and generate a VOR signal"](#) on page 651.

Manual operation: See ["Depth"](#) on page 134

[SOURce<hw>]:VOR:COMid:DOT <Dot>

Sets the length of a Morse code dot.

If the [time schema](#) is set to standard, the dash length (= 3 times dot length), symbol space (= dot length) and letter space (= 3 times dot length) is also determined by this entry.

Parameters:

<Dot> float
 Range: 0.05 to 1
 Increment: 1E-4
 *RST: 0.1

Example: See [Example "Configure and generate a VOR signal"](#) on page 651.

Manual operation: See ["Dot Length"](#) on page 134

[SOURce<hw>]:VOR:COMid:FREQuency <Frequency>

Sets the frequency of the COM/ID signal.

Parameters:

<Frequency> float
 Range: 0.1 to 20E3
 Increment: 0.01
 *RST: 1020

Example: See [Example "Configure and generate a VOR signal"](#) on page 651.

Manual operation: See ["Frequency"](#) on page 134

[[:SOURce<hw>]:VOR:COMid:LETter <Letter>

Sets the length of a Morse code letter space.

Parameters:

<Letter> float
 Range: 0.05 to 1
 Increment: 1E-4
 *RST: 0.3
 Default unit: s

Example: See [Example "Configure and generate a VOR signal"](#) on page 651.

Manual operation: See ["Letter Space"](#) on page 135

[[:SOURce<hw>]:VOR:COMid:PERiod <Period>

Sets the period of the COM/ID signal.

Parameters:

<Period> float
 Range: 0 to 120
 Increment: 1E-3
 *RST: 9

Example: See [Example "Configure and generate a VOR signal"](#) on page 651.

Manual operation: See ["Period"](#) on page 134

[[:SOURce<hw>]:VOR:COMid:SYMBol <Symbol>

Sets the length of the Morse code symbol space.

Parameters:

<Symbol> float
 Range: 0.05 to 1
 Increment: 1E-4
 *RST: 0.1

Example: See [Example "Configure and generate a VOR signal"](#) on page 651.

Manual operation: See ["Symbol Space"](#) on page 135

[[:SOURce<hw>]:VOR:COMid:TSCHEMA <Tschema>

Sets the time schema of the Morse code for the COM/ID signal.

Parameters:

<Tschema> STD | USER

STD

Activates the standard time schema of the Morse code.

The set [dot length](#) determines the [dash length](#), which is 3 times the dot length.

USER

Activates the user-defined time schema of the Morse code.

Dot and dash length, as well as [symbol](#) and [letter space](#) can be set separately.

*RST: STD

Example: See [Example "Configure and generate a VOR signal"](#) on page 651.

Manual operation: See ["Time Schema"](#) on page 134

[[:SOURce<hw>]:VOR:COMid:STATE] <State>

Enables/disables the COM/ID signal.

Parameters:

<State> 1 | ON | 0 | OFF

*RST: 0

Example: See [Example "Configure and generate a VOR signal"](#) on page 651.

Manual operation: See ["COM/ID State"](#) on page 133

[[:SOURce<hw>]:VOR:FREQUENCY <CarrierFreq>

Sets the carrier frequency of the signal.

Parameters:

<CarrierFreq> float

Range: 100E3 to 6E9

Increment: 0.01

*RST: 108E6

Example: See [Example "Configure and generate a VOR signal"](#) on page 651.

Manual operation: See ["Carrier Frequency"](#) on page 129

[[:SOURce<hw>]:VOR:FREQuency:MODE <Mode>

Sets the mode for the carrier frequency of the signal.

Parameters:

<Mode> DECimal | ICAO

DECimal

Activates user-defined variation of the carrier frequency.

ICAO

Activates variation in predefined steps according to standard VOR transmitting frequencies (see [Table 6-1](#)).

*RST: DECimal

Example: See [Example "Configure and generate a VOR signal"](#) on page 651.

Manual operation: See ["Carrier Frequency Mode"](#) on page 129

[[:SOURce<hw>]:VOR:ICAO:CHANnel <Channel>

Sets the ICAO channel and the corresponding transmitting frequency.

If avionic standard modulation is activated and you change the "RF Frequency", the frequency value of the closest ICAO channel is applied automatically. The "ICAO Channel" is also updated.

The carrier frequency is set automatically to the value of the ICAO channel. For an overview of the VOR ICAO channel frequencies, see [Table 6-1](#).

Parameters:

<Channel>

CH17X | CH17Y | CH19X | CH19Y | CH21X | CH21Y | CH23X |
 CH23Y | CH25X | CH25Y | CH27X | CH27Y | CH29X | CH29Y |
 CH31X | CH31Y | CH33X | CH33Y | CH35X | CH35Y | CH37X |
 CH37Y | CH39X | CH39Y | CH41X | CH41Y | CH43X | CH43Y |
 CH45X | CH45Y | CH47X | CH47Y | CH49X | CH49Y | CH51X |
 CH51Y | CH53X | CH53Y | CH55X | CH55Y | CH57X | CH57Y |
 CH58X | CH58Y | CH59X | CH59Y | CH70X | CH70Y | CH71X |
 CH71Y | CH72X | CH72Y | CH73X | CH73Y | CH74X | CH74Y |
 CH75X | CH75Y | CH76X | CH76Y | CH77X | CH77Y | CH78X |
 CH78Y | CH79X | CH79Y | CH80X | CH80Y | CH81X | CH81Y |
 CH82X | CH82Y | CH83X | CH83Y | CH84X | CH84Y | CH85X |
 CH85Y | CH86X | CH86Y | CH87X | CH87Y | CH88X | CH88Y |
 CH89X | CH89Y | CH90X | CH90Y | CH91X | CH91Y | CH92X |
 CH92Y | CH93X | CH93Y | CH94X | CH94Y | CH95X | CH95Y |
 CH96X | CH96Y | CH97X | CH97Y | CH98X | CH98Y | CH99X |
 CH99Y | CH100X | CH100Y | CH101X | CH101Y | CH102X |
 CH102Y | CH103X | CH103Y | CH104X | CH104Y | CH105X |
 CH105Y | CH106X | CH106Y | CH107X | CH107Y | CH108X |
 CH108Y | CH109X | CH109Y | CH110X | CH110Y | CH111X |
 CH111Y | CH112X | CH112Y | CH113X | CH113Y | CH114X |
 CH114Y | CH115X | CH115Y | CH116X | CH116Y | CH117X |
 CH117Y | CH118X | CH118Y | CH119X | CH119Y | CH120X |
 CH120Y | CH121X | CH121Y | CH122X | CH122Y | CH123X |
 CH123Y | CH124X | CH124Y | CH125X | CH125Y | CH126X |
 CH126Y

*RST: CH17X

Example:

See [Example "Configure and generate a VOR signal"](#)
 on page 651.

Manual operation: See ["ICAO Channel"](#) on page 129

[:SOURce<hw>]:VOR:MODE <Mode>

Sets the operating mode for the VOR modulation signal.

Parameters:

<Mode>

NORM | VAR | SUBCarrier | FMSubcarrier

NORM

VOR modulation is active.

VAR

Amplitude modulation of the output signal with the variable signal component (30Hz signal content) of the VOR signal.

The modulation depth of the 30 Hz signal can be set with [:
[SOURce<hw>\]:VOR:VAR\[:DEPTH\]](#).

SUBCarrier

Amplitude modulation of the output signal with the unmodulated FM carrier (9960Hz) of the VOR signal.

The modulation depth of the 30 Hz signal can be set with [:SOURce<hw>]:VOR:SUBCarrier:DEPTh.

FMSubcarrier

Amplitude modulation of the output signal with the frequency modulated FM carrier (9960Hz) of the VOR signal.

The modulation depth of the 30 Hz signal can be set with [:SOURce<hw>]:VOR:SUBCarrier:DEPTh.

The frequency deviation can be set with [:SOURce<hw>]:VOR:REFerence[:DEViation].

*RST: NORM

Example: See [Example "Configure and generate a VOR signal"](#) on page 651.

Manual operation: See ["Mode"](#) on page 130

[[:SOURce<hw>]:VOR:REFerence[:DEViation] <Deviation>

Sets the frequency deviation of the reference signal on the FM carrier.

Parameters:

<Deviation> integer
Range: 0 to 960
*RST: 480

Example: See [Example "Configure and generate a VOR signal"](#) on page 651.

Manual operation: See ["REF Deviation"](#) on page 131

[[:SOURce<hw>]:VOR:SUBCarrier:DEPTh <Depth>

Sets the AM modulation depth of the FM carrier.

Parameters:

<Depth> float
Range: 0 to 100
Increment: 0.1
*RST: 30

Example: See [Example "Configure and generate a VOR signal"](#) on page 651.

Manual operation: See ["Subcarrier Depth"](#) on page 131

[[:SOURce<hw>]:VOR:SUBCarrier[:FREQuency] <Frequency>

Sets the frequency of the FM carrier.

Parameters:

<Frequency> float
 Range: 5E3 to 15E3
 Increment: 0.01
 *RST: 9.96E3

Example: See [Example "Configure and generate a VOR signal"](#) on page 651.

Manual operation: See ["Subcarrier Frequency"](#) on page 131

[:SOURce<hw>]:VOR:VAR:FREQuency <Frequency>

Sets the frequency of the variable and the reference signal. As the two signals must have the same frequency, the setting is valid for both signals.

Parameters:

<Frequency> float
 Range: 10 to 60
 Increment: 0.01
 *RST: 30

Example: See [Example "Configure and generate a VOR signal"](#) on page 651.

Manual operation: See ["VAR/REF Frequency"](#) on page 131

[:SOURce<hw>]:VOR:VAR[:DEPT]h <Depth>

Sets the AM modulation depth of the 30Hz variable signal.

Parameters:

<Depth> float
 Range: 0 to 100
 Increment: 0.1
 *RST: 30

Example: See [Example "Configure and generate a VOR signal"](#) on page 651.

Manual operation: See ["VAR Depth"](#) on page 131

15.18.3 SOURce:CORRection subsystem

The SOURce:CORRection subsystem contains the commands for defining correction values for external test assemblies.

You can acquire the correction values anytime, regardless of the modulation settings of the generator. During correction, the R&S SMA100B adds the correction values to the output level of the respective RF frequency.

Determine the correction values in one of the following ways:

- Measure the RF output level at several frequency points and enter the value pairs manually in a table
- Connect an R&S NRP to the generator output signal and send the command `[ :SOURce<hw> ] :CORRection:CSET:DATA [ :SENSor<ch> ] [ :POWer ] :SONCe` to fill the table automatically.

Save correction values to files with file extension `*.uco`.

Refer to [Section 15.5.2, "Handling files in the default or in a specified directory"](#), on page 495 for general information on file handling in the default and in a specific directory.

Programming examples

The examples in this section assume that:

- The files are stored in the default directory.
- `*RST` does not affect data lists.

Example: To create RF level correction values

The following example shows a command sequence to create and activate a list for assigning level correction values to arbitrary RF frequencies. Further hardware settings are not considered.

```
// Reset the instrument to start from an initial state
// Query the available user correction list files in the default
// directory. Select a file or create a file.
// *****
*RST; *CLS
:SOURce1:CORRection:CSET:CATalog?
// Response: "ucor1"
// Select the file ucor1.uco.
:SOURce1:CORRection:CSET:SElect "/var/user/ucor1"

// Enter the frequency/level value pairs in the table; existing data
// is overwritten. Query the number of frequency/power entries.
:SOURce1:CORRection:CSET:DATA:FREQuency 100MHz,110MHz,120MHz,130MHz,140MHz,150MHz
:SOURce1:CORRection:CSET:DATA:POWer -10,-7.5,-5.0,-2.5,0,2.5
:SOURce1:CORRection:CSET:DATA:FREQuency:POINTs?
// 6
:SOURce1:CORRection:CSET:DATA:POWer:POINTs?
// 6

// Enable user correction mode and RF output
:SOURce1:CORRection:STATe 1
:OUTPut1:STATe ON

// Query the currently used correction value
:SOURce1:CORRection:VALue?
// -2.5
```

```
// Delete a user correction file
:SOURcel:CORRection:CSET:DELEte "/var/user/ucor1.uco"
```

Example: To fill user correction data with a sensor

The following example shows a command sequence to fill a user correction list automatically supported by a connected R&S NRP.

```
// Fill a user correction list with the level values
// measured by an R&S NRP,
// store the data in a file and enable user correction.

*RST; *CLS

:SOURcel:CORRection:CSET:SElect "/var/user/Ucor1_AutoFill.uco"
:SOURcel:CORRection:CSET:DATA:FREQuency 100MHz,110MHz,120MHz,130MHz,140MHz,150MHz
:SOURcel:CORRection:ZERoing:STATe 1
:SOURcel:CORRection:CSET:DATA:SENSor1:POWer:SONCe
// Query the number of automatically filled correction level values
:SOURcel:CORRection:CSET:DATA:POWer:POINTs?
// 6
:SOURcel:CORRection:STATe 1

// Query the correction value at a certain frequency
:FREQ 120000000
:SOURcel:CORRection:VALue?
// -52.13
```

Example: To export user correction lists

The following example shows a command sequence to export a user correction list (here the list created with the example before) into an ASCII file. Further hardware settings are not considered.

```
// Select a user correction file for exporting to file in ASCII format
// Set ASCII data parameters
// Set the ASCII file extension, the decimal separator
// and the column separator for the ASCII data
:SOURcel:CORRection:DEXChange:AFIle:CATalog?
// my_ucor
:SOURcel:CORRection:CSET:CATalog?
// ucor1,Ucor1_AutoFill
:SOURcel:CORRection:CSET:SElect "/var/user/Ucor1_AutoFill.uco"
:SOURcel:CORRection:DEXChange:AFIle:EXTension CSV
:SOURcel:CORRection:DEXChange:AFIle:SEParator:DECimal DOT
:SOURcel:CORRection:DEXChange:AFIle:SEParator:COLumn COMMa

// Select source and destination
:SOURcel:CORRection:DEXChange:AFIle:SElect "/var/user/ucor2ASCII"
```

```
// Export the user correction data into the ASCII file
:SOURcel:CORRection:DEXChange:MODE EXPort
:SOURcel:CORRection:DEXChange:EXECute

// Query the available ASCII files with extension .csv
:SOURcel:CORRection:DEXChange:AFILe:CATalog?
// ucor2ASCII,my_ucor

// Import a user correction ASCII file
:SOURcel:CORRection:DEXChange:MODE IMPort
:SOURcel:CORRection:DEXChange:AFILe:SElect "/var/user/my_ucor"
:SOURcel:CORRection:DEXChange:EXECute
```

Commands:

- [Correction settings](#)..... 692
- [Correction data exchange](#)..... 695

15.18.3.1 Correction settings

[:SOURce<hw>]:CORRection:CSET:DATA:FREQuency <Frequency>

Enters the frequency value in the table selected with [\[:SOURce<hw>\]:CORRection:CSET\[:SElect \]](#).

Parameters:

<Frequency> Frequency#1[, Frequency#2, ...]
 String of values with default unit Hz.

Example: See [Example "To create RF level correction values"](#)
 on page 690 .

Manual operation: See ["Frequency \(Hz\)"](#) on page 243

[:SOURce<hw>]:CORRection:CSET:DATA:POWer <Power>

Enters the level values to the table selected with [\[:SOURce<hw>\]:CORRection:CSET\[:SElect \]](#).

Parameters:

<Power> Power#1[, Power#2, ...]
 String of values with default unit dB.
 *RST: 0

Example: See [Example "To create RF level correction values"](#)
 on page 690 .

Manual operation: See ["Correction Value \(dB\)"](#) on page 243

[[:SOURce<hw>]:CORRection:CSET:DATA:FREQuency:POINts?

[[:SOURce<hw>]:CORRection:CSET:DATA:POWer:POINts?

Queries the number of frequency/level values in the selected table.

Return values:

<Points> integer
 Range: 0 to 10000
 *RST: 0

Example: See [Example "To create RF level correction values"](#) on page 690 .

Usage: Query only

[[:SOURce<hw>]:CORRection:CSET:DATA[:SENSor<ch>]][:POWer]:SONCe

Fills the selected user correction table with the level values measured by the power sensor for the given frequencies.

To select the used power sensor set the suffix in key word `SENSe`.

Example: See [Example "To fill user correction data with a sensor"](#) on page 691.

Usage: Event

Manual operation: See ["Fill User Correction Data with Sensor"](#) on page 245

[[:SOURce<hw>]:CORRection:CSET[:SELEct] <Filename>

Selects or creates a file for the user correction data.

If the file with the selected name does not exist, a new file is created.

Parameters:

<Filename> string
 Filename or complete file path; file extension can be omitted.

Example: See [Example "To create RF level correction values"](#) on page 690 .

Manual operation: See ["UCOR Data"](#) on page 240

[[:SOURce<hw>]:CORRection:VALue?

Queries the current value for user correction.

Return values:

<Value> float
 Range: -100 to 100
 Increment: 0.01
 *RST: 0

Example: See [Example "To create RF level correction values"](#) on page 690 .

Usage: Query only

Manual operation: See ["User Correction"](#) on page 240

[:SOURce<hw>]:CORRection:ZEROing:STATe <State>

Activates the zeroing procedure before filling the user correction data acquired by a sensor.

Parameters:

<State> 1 | ON | 0 | OFF
*RST: 1

Example: See [Example "To fill user correction data with a sensor"](#) on page 691.

Manual operation: See ["Fill User Correction Data with Sensor"](#) on page 245

[:SOURce<hw>]:CORRection:CSET:DATA[:SENSor<ch>][:POWer]:SONCe

Fills the selected user correction list with the level values measured by the power sensor for the given frequencies.

Suffix:

SENSor<ch> Defines the used power sensor, i.e. the sensor whose values are used.

Example: See [Example "To fill user correction data with a sensor"](#) on page 691.

Usage: Event

[:SOURce<hw>]:CORRection[:STATe] <State>

Activates user correction with the currently selected table.

Parameters:

<State> 1 | ON | 0 | OFF
*RST: 0

Example: See [Example "To create RF level correction values"](#) on page 690 .

Manual operation: See ["State"](#) on page 240

[:SOURce]:CORRection:CSET:CATalog?

Queries a list of available user correction tables.

Return values:

<Catalog> string
List of list filenames, separated by commas

Example: See [Example "To create RF level correction values"](#) on page 690 .

Usage: Query only

Manual operation: See ["UCOR Data"](#) on page 240

[[:SOURce]:CORRection:CSET:DELeTe <Filename>

Deletes the specified user correction list file.

Setting parameters:

<Filename> string
Filename or complete file path; file extension is optional.

Example: See [Example "To create RF level correction values"](#) on page 690 .

Usage: Setting only

Manual operation: See ["UCOR Data"](#) on page 240

15.18.3.2 Correction data exchange

With the following commands, you can configure user correction lists and export or import them accordingly.

[[:SOURce<hw>]:CORRection:DEXChange:AFILe:CATalog?

Queries the available ASCII files for export or import of user correction data in the current or specified directory.

Return values:

<Catalog> string
List of ASCII files *.txt or *.csv, separated by commas.

Example: See [Example "To create RF level correction values"](#) on page 690 .

Usage: Query only

Manual operation: See ["Select \(ASCII\) Source/Select \(ASCII\) Destination"](#) on page 107

[[:SOURce<hw>]:CORRection:DEXChange:AFILe:EXTension <Extension>

Determines the extension of the ASCII files for file import or export, or to query existing files.

Parameters:

<Extension> TXT | CSV
 *RST: TXT

Example: See [Example "To export user correction lists"](#) on page 691 .

Manual operation: See ["ASCII File Settings"](#) on page 106

[:SOURce<hw>]:CORRection:DEXChange:AFILe:SElect <Filename>

Selects the ASCII file to be imported or exported.

Parameters:

<Filename> string
 Filename or complete file path; file extension can be omitted.

Example: See [Example "To export user correction lists"](#) on page 691 .

Manual operation: See ["Select \(ASCII\) Source/Select \(ASCII\) Destination"](#) on page 107

[:SOURce<hw>]:CORRection:DEXChange:AFILe:SEParator:COLumn <Column>

Selects the separator between the frequency and level column of the ASCII table.

Parameters:

<Column> TABulator | SEMicolon | COMMa | SPACe
 *RST: COMMa

Example: See [Example "To export user correction lists"](#) on page 691 .

Manual operation: See ["ASCII File Settings"](#) on page 106

[:SOURce<hw>]:CORRection:DEXChange:AFILe:SEParator:DECimal <Decimal>

Sets the decimal separator used in the ASCII data between '.' (decimal point) and ',' (comma) with floating-point numerals.

Parameters:

<Decimal> DOT | COMMa
 *RST: DOT

Example: See [Example "To export user correction lists"](#) on page 691 .

Manual operation: See ["ASCII File Settings"](#) on page 106

[:SOURce<hw>]:CORRection:DEXChange:EXECute

Executes the import or export of the selected correction list, according to the previously set transfer direction with command [\[:SOURce<hw>\]:CORRection:DEXChange:MODE](#).

Example: See [Example "To export user correction lists"](#) on page 691 .

Usage: Event

Manual operation: See ["Import / Export"](#) on page 107

[:SOURce<hw>]:CORRection:DEXChange:MODE <Mode>

Determines import or export of a user correction list.

Specify the source or destination file with the command [\[:SOURce<hw>\] :CORRection:DEXChange:SElect](#).

Parameters:

<Mode> IMPort | EXPort
 *RST: IMPort

Example: See [Example "To export user correction lists"](#) on page 691 .

Manual operation: See ["Mode"](#) on page 106

[:SOURce<hw>]:CORRection:DEXChange:SElect <Filename>

Selects the ASCII file for import or export, containing a user correction list.

Parameters:

<Filename> string
 Filename or complete file path; file extension can be omitted.

Example: See [Example "To export user correction lists"](#) on page 691 .

Manual operation: See ["Select Source/Select ASCII Destination"](#) on page 107

15.18.4 SOURce:EFRontend subsystem

The SOURce:EFRontend subsystem contains the commands for configuring settings of an external frontend.

Example: Configuring external frontend frequency bands

```
SOURce1:EFRontend:FREquency:IFrequency:VALue?
// Response in Hz: "18750000000" (= 18.75 GHz)
```

Example: Configuring external frontend connection settings

```
SOURce1:EFRontend:IDN?
// Response: "Rohde&Schwarz,SZM75,1443.5004K02/100001,1.34.6,1.2.1"

//Query the installed hardware options
SOURce1:EFRontend:OPT?
// Response: "SZM-E,SZM-I"
```

Example: Configuring external frontend cable correction

```
// Query available cable correction files.
SOURCE1:EFRontend:ALIGNment:FILE:CATalog?
// Select a cable correction file stored on the instrument.
SOURCE1:EFRontend:ALIGNment:FILE:SElect "/var/user/ExtFrontend/CableCorrectionFiles/
if_default_cable_1347_7552_00.s2p"
// Query upper and lower frequency range of the IF correction data.
SOURCE1:EFRontend:ALIGNment:FILE:FREquency:RANGE:LOWer?
// Response in Hz: "12000000000" (12 GHz)
SOURCE1:EFRontend:ALIGNment:FILE:FREquency:RANGE:UPPer?
// Response in Hz: "19250000000" (19.25 GHz)
SOURCE1:EFRontend:ALIGNment:STATE 1
```

Commands:

[SOURCE<hw>]:EFRontend[:FREquency]:IFRequency[:VALue]?	698
[SOURCE<hw>]:EFRontend:IDN?	698
[SOURCE<hw>]:EFRontend:OPT?	699
[SOURCE<hw>]:EFRontend:ALIGNment:FILE:FREquency:RANGE:LOWer?	699
[SOURCE<hw>]:EFRontend:ALIGNment:FILE:FREquency:RANGE:UPPer?	699
[SOURCE<hw>]:EFRontend:ALIGNment:FILE:CATalog?	699
[SOURCE<hw>]:EFRontend:ALIGNment:FILE[:SElect]	699
[SOURCE<hw>]:EFRontend:ALIGNment[:STATE]	700
[SOURCE<hw>]:EFRontend:SCREW:POSition?	700

[[SOURCE<hw>](#)]:EFRontend[:FREquency]:IFRequency[:VALue]?

Queries the frequency of the IF signal, that is the frequency at the RF 50 Ω connector.

Return values:

<IntFrequency> float

Example: See [Example "Configuring external frontend frequency bands"](#) on page 697.

Usage: Query only

Manual operation: See ["Intermediate Frequency"](#) on page 182

[[SOURCE<hw>](#)]:EFRontend:IDN?

Identification

Returns the IDN string, i.e. the identification of the external frontend.

Return values:

<IdnString> string

Example: See [Example "Configuring external frontend connection settings"](#) on page 697.

Usage: Query only

Manual operation: See ["Hardware Config"](#) on page 183

[SOURce<hw>]:EFRontend:OPT?

Option identification query

Queries the options included in the external frontend.

For more information, refer to the specifications document.

Return values:

<OptString> string

The query returns a list of options. The options are returned at fixed positions in a comma-separated string. A zero is returned for options that are not installed.

Example: See [Example "Configuring external frontend connection settings"](#) on page 697.

Usage: Query only

Manual operation: See ["Options"](#) on page 184

[SOURce<hw>]:EFRontend:ALIGNment:FILE:FREQUENCY:RANGE:LOWer?**[SOURce<hw>]:EFRontend:ALIGNment:FILE:FREQUENCY:RANGE:UPPer?**

Queries the upper/lower frequency range of IF values required at the connected external frontend.

We recommend that you cover this range in the cable correction file.

Return values:

<CableCorrFreqUp> float

Example: See [Example "Configuring external frontend cable correction"](#) on page 698.

Usage: Query only

Manual operation: See ["Recommended Frequency Range"](#) on page 186

[SOURce<hw>]:EFRontend:ALIGNment:FILE:CATalog?

Queries the cable correction files with settings in the default directory.

Listed are cable correction files with extension *.s2p or *.uco.

Example: See [Example "Configuring external frontend cable correction"](#) on page 698.

Usage: Query only

Manual operation: See ["Load Cable Correction File"](#) on page 185

[SOURce<hw>]:EFRontend:ALIGNment:FILE[:SElect] <CableCorrFileName>

Selects an existing correction file to compensate for cable losses. Selectable files have file extension *.s2p or *.uco.

Parameters:

<Filename> string

Example:See [Example "Configuring external frontend cable correction"](#) on page 698.**Manual operation:**See ["Load Cable Correction File"](#) on page 185**[:SOURce<hw>]:EFRontend:ALIGNment[:STATe] <CableCorrState>**

Activates correction of the IF signal for different IF signal frequencies.

Parameters:

<CableCorrState> 1 | ON | 0 | OFF

*RST: 0

Example:See [Example "Configuring external frontend cable correction"](#) on page 698.**Manual operation:**See ["State"](#) on page 185**[:SOURce<hw>]:EFRontend:SCREW:POSition?**

Requires a connected external frequency multiplier with installed mechanically attenuator option.

Queries the value of the screw position required on the connected external frequency multiplier.

Return values:

<ScrewPosition> integer

Range: 0 to 150

*RST: 0

Usage:

Query only

15.18.5 SOURce:FREQuency subsystem

The SOURce:FREQuency subsystem contains the commands used to define the frequency settings for the RF sources and sweeps.

Example: To configure RF frequency settings

```

:SOURce1:FREQuency:MODE CW
:SOURce1:FREQuency:CW 6000000000
:SOURce1:FREQuency:OFFSet 2000000000
:SOURce1:FREQuency:MULTiplier 1.5
:SOURce1:FREQuency:CW?
// Response in Hz: 11000000000

// Optionally, configure a user-defined frequency step mode.
:SOURce1:FREQuency:STEP:MODE USER

```



```
:SOURce1:FREQuency:STEP:INCRement 1000000
:SOURce1:FREQuency:CW UP

:SOURce1:PHASe 2
:SOURce1:PHASe:REFerence
```

Example: Setting a phase continuous frequency range

```
SOURce1:FREQuency:CW 502000000
SOURce1:FREQuency:PHASe:MODE NARR
SOURce1:FREQuency:PHASe:CONTInuous:STATe 1
*****
// Query the frequency range
SOURce1:FREQuency:PHASe:CONTInuous:LOW?
// Response: 49370890
SOURce1:FREQuency:PHASe:CONTInuous:HIGH?
// Response: 50421376
*****
// Vary the frequency. Within the specified range the signal is phase continuous.
SOURce1:FREQuency:CW 499000000
SOURce1:FREQuency:CW 500000000
SOURce1:FREQuency:CW 501000000
SOURce1:FREQuency:CW 503000000
```

[SOURce<hw>]:FREQuency:MODE.....	701
[SOURce<hw>]:FREQuency[:CW FIXed].....	702
[SOURce<hw>]:FREQuency[:CW FIXed]:RCL.....	703
[SOURce<hw>]:FREQuency:MANual.....	704
[SOURce<hw>]:FREQuency:MULTIplier.....	704
[SOURce<hw>]:FREQuency:OFFSet.....	704
[SOURce<hw>]:FREQuency:CENTer.....	705
[SOURce<hw>]:FREQuency:SPAN.....	705
[SOURce<hw>]:FREQuency:STARt.....	705
[SOURce<hw>]:FREQuency:STOP.....	706
[SOURce<hw>]:FREQuency:STEP:MODE.....	706
[SOURce<hw>]:FREQuency:STEP[:INCRement].....	707
[SOURce<hw>]:FREQuency:PLL:MODE.....	707
[SOURce<hw>]:FREQuency:PHASe:CONTInuous:HIGH?.....	707
[SOURce<hw>]:FREQuency:PHASe:CONTInuous:LOW?.....	708
[SOURce<hw>]:FREQuency:PHASe:CONTInuous:MODE.....	708
[SOURce<hw>]:FREQuency:PHASe:CONTInuous:STATe.....	709

[SOURce<hw>]:FREQuency:MODE <Mode>

Sets the frequency mode for generating the RF output signal. The selected mode determines the parameters to be used for further frequency settings.

Parameters:

<Mode> CW | FIXed | SWEEp | LIST | COMBined

CW|FIXed

Sets the fixed frequency mode. CW and FIXed are synonyms. The instrument operates at a defined frequency, set with command `[ :SOURce<hw> ] :FREQuency [ :CW | FIXed ]`.

SWEep

Sets sweep mode.

The instrument processes frequency (and level) settings in defined sweep steps.

Set the range and current frequency with the commands:

`[ :SOURce<hw> ] :FREQuency:START` on page 705 and `[ :SOURce<hw> ] :FREQuency:STOP` on page 706,
`[ :SOURce<hw> ] :FREQuency:CENTer` on page 705,
`[ :SOURce<hw> ] :FREQuency:SPAN` on page 705,
`[ :SOURce<hw> ] :FREQuency:MANual` on page 704

LIST

Sets list mode.

The instrument processes frequency and level settings by means of values loaded from a list.

To configure list mode settings, use the commands of the [Section 15.18.8, "SOURce:LIST subsystem"](#), on page 723.

COMBined

Sets the combined RF frequency / level sweep mode.

The instrument processes frequency and level settings in defined sweep steps.

Set the range and current frequency with the commands:

`[ :SOURce<hw> ] :COMBined:FREQuency:START` on page 771 and `[ :SOURce<hw> ] :COMBined:FREQuency:STOP` on page 771,
`[ :SOURce<hw> ] :COMBined:POWer:START` on page 771 and `[ :SOURce<hw> ] :COMBined:POWer:STOP` on page 772

*RST: CW

Example: See [Example "To configure RF frequency settings"](#) on page 700,

Example: See [Example "Setting up an RF frequency or power sweep"](#) on page 762

Manual operation: See ["State \(RF frequency sweep\)"](#) on page 204

`[ :SOURce<hw> ] :FREQuency [ :CW | FIXed ] <Fixed>`

Sets the frequency of the RF output signal in the selected path.

The effect depends on the selected mode:

- In CW mode (`FREQ:MODE CW | FIXed`), the instrument operates at a fixed frequency.
- In sweep mode (`FREQ:MODE SWE`), the value applies to the sweep frequency. The instrument processes the frequency settings in defined sweep steps.

- In user mode (`FREQ:STEP:MODE USER`), you can vary the current frequency step by step.

For more information, refer to the specifications document.

Parameters:

<Fixed>

float

The following settings influence the value range:

An offset set with the command `[ :SOURce<hw> ] :FREQuency:OFFSet`

Numerical value

Sets the frequency in CW and sweep mode

UP|DOWN

Varies the frequency step by step in user mode.

The frequency is increased or decreased by the value set with the command `[ :SOURce<hw> ] :FREQuency:STEP [ :INCRement ]`.

Range: (RFmin + OFFSet) to (RFmax + OFFSet)

Increment: depends on options

*RST: depends on options

Example: See [Example "To configure RF frequency settings"](#) on page 700

Example: See [Example "Setting up an RF frequency or power sweep"](#) on page 762

Manual operation: See ["Frequency"](#) on page 68

`[ :SOURce<hw> ] :FREQuency [ :CW|FIXed ] :RCL <Rcl>`

Set whether the RF frequency value is retained or taken from a loaded instrument configuration, when you recall instrument settings with command `*RCL`.

Parameters:

<Rcl>

INCLude | EXCLude

INCLude

Takes the frequency value of the loaded settings.

EXCLude

Retains the current frequency when an instrument configuration is loaded.

*RST: INCLude

Example: `SOURce1:FREQuency:CW:RCL INCLude`

Manual operation: See ["Exclude Frequency"](#) on page 344

[:SOURce<hw>]:FREQuency:MANual <Manual>

Sets the frequency and triggers a sweep step manually if [SWEep:MODE MAN](#).

Parameters:

<Manual>

float

You can select any frequency within the setting range, where:

START is set with [\[:SOURce<hw>\]:FREQuency:START](#)

STOP is set with [\[:SOURce<hw>\]:FREQuency:STOP](#)

OFFSet is set with [\[:SOURce<hw>\]:FREQuency:OFFSet](#)

Range: (START + OFFSet) to (STOP + OFFSet)

Increment: 0.01Hz

*RST: 100 MHz

Default unit: Hz

Example:

See [Example "Setting up an RF frequency or power sweep"](#) on page 762

Manual operation: See ["Current Frequency"](#) on page 205

[:SOURce<hw>]:FREQuency:MULTiplier <Multiplier>

Sets the multiplication factor $N_{\text{FREQ:MULT}}$ of a subsequent downstream instrument.

The parameters offset $f_{\text{FREQ:OFFSer}}$ and multiplier $N_{\text{FREQ:MULT}}$ affect the frequency value set with the command [FREQ](#).

The query [FREQ?](#) returns the value corresponding to the formula:

$$f_{\text{FREQ}} = f_{\text{RFout}} * N_{\text{FREQ:MULT}} + f_{\text{FREQ:OFFSer}}$$

See ["RF frequency and level display with a downstream instrument"](#) on page 62.

Parameters:

<Multiplier>

float

Range: -10000 to 10000

Increment: 0.001

*RST: 1

Example:

See [Example "To configure RF frequency settings"](#) on page 700

Manual operation: See ["Multiplier"](#) on page 69

[:SOURce<hw>]:FREQuency:OFFSet <Offset>

Sets the frequency offset $f_{\text{FREQ:OFFSet}}$ of a downstream instrument.

The parameters offset $f_{\text{FREQ:OFFSer}}$ and multiplier $N_{\text{FREQ:MULT}}$ affect the frequency value set with the command [FREQ](#).

The query [FREQ?](#) returns the value corresponding to the formula:

$$f_{\text{FREQ}} = f_{\text{RFout}} * N_{\text{FREQ:MULT}} + f_{\text{FREQ:OFFSer}}$$

See ["RF frequency and level display with a downstream instrument"](#) on page 62.

Note: The offset also affects RF frequency sweep.

Parameters:

<Offset> float
Increment: 0.01
*RST: 0

Example: See [Example "To configure RF frequency settings"](#) on page 700

Manual operation: See ["Offset"](#) on page 69

[[:SOURce<hw>]:FREQUENCY:CENTer <Center>

Sets the center frequency of the sweep.

The maximum value depends on the installed hardware options.

For more information, refer to the specifications document.

Parameters:

<Center> float
Range: 300 kHz to depends on options
Increment: 0.01 Hz
*RST: 300E6
Default unit: Hz

Example: See [Example "Setting up an RF frequency or power sweep"](#) on page 762.

Manual operation: See ["Center Frequency"](#) on page 210

**[[:SOURce<hw>]:FREQUENCY:SPAN **

Sets the span of the frequency sweep range.

Parameters:

 float
Full frequency range
Increment: 0.01
*RST: 400E6

Example: See [Example "Setting up an RF frequency or power sweep"](#) on page 762.

Manual operation: See ["Span"](#) on page 211

[[:SOURce<hw>]:FREQUENCY:START <Start>

Sets the start frequency for the RF sweep.

The maximum value depends on the installed hardware options.

For more information, refer to the specifications document.

Parameters:

<Start> float
 Range: 300 kHz to depends on options
 Increment: 0.01 Hz
 *RST: 100 MHz

Example: See [Example "Setting up an RF frequency or power sweep"](#) on page 762.

Manual operation: See ["Start Frequency/Stop Frequency"](#) on page 210

[[:SOURce<hw>]:FREQuency:STOP <Stop>

Sets the stop frequency range for the RF sweep.

The maximum value depends on the installed hardware options.

For more information, refer to the specifications document.

Parameters:

<Stop> float
 Range: 300 kHz to depends on options
 Increment: 0.01 Hz
 *RST: 500 MHz
 Default unit: Hz

Example: See [Example "Setting up an RF frequency or power sweep"](#) on page 762.

Manual operation: See ["Start Frequency/Stop Frequency"](#) on page 210

[[:SOURce<hw>]:FREQuency:STEP:MODE <Mode>

Defines the type of step size to vary the RF frequency at discrete steps with the commands [FREQ UP](#) or [FREQ DOWN](#).

Parameters:

<Mode> DECimal | USER
DECimal
 Increases or decreases the level in steps of ten.
USER
 Increases or decreases the level in increments, set with the command [FREQ:STEP\[:INCR\]](#).
 *RST: DECimal

Example: See [Example "To configure RF frequency settings"](#) on page 700.

Manual operation: See ["Variation Active"](#) on page 69

[[:SOURce<hw>]:FREQuency:STEP[:INCRement] <Increment>

Sets the step width.

You can use this value to vary the RF frequency with command [FREQ UP](#) or [FREQ DOWN](#).

If you have activated [FREQ:STEP:MODE USER](#).

Note: This value also applies to the step width of the rotary knob on the instrument and, in user-defined step mode, increases or decreases the frequency.

Parameters:

<Increment> float
 Range: 0 Hz to RFmax - 100 kHz
 Increment: 0.01 Hz
 *RST: 1E6

Example: See [Example "To configure RF frequency settings"](#) on page 700

Manual operation: See ["Variation Step"](#) on page 70

[[:SOURce<hw>]:FREQuency:PLL:MODE <Mode>

Selects the PLL (Phase Locked Loop) bandwidth of the main synthesizer.

Parameters:

<Mode> NORMal | NARRow
 NORMal
 Maximum modulation bandwidth and FM/PhiM deviation.
 NARRow
 Narrow PLL bandwidth
 *RST: NORMal

Example: SOURce:FREQuency:PLL:MODE NORMal

Manual operation: See ["Main PLL Bandwidth"](#) on page 69

[[:SOURce<hw>]:FREQuency:PHASe:CONTInuous:HIGH?

Queries the maximum frequency of the frequency range for phase continuous settings.

The maximum frequency of the frequency range depends on the mode selected with the command [\[:SOURce<hw>\]:FREQuency:PHASe:CONTInuous:MODE](#).

Return values:

<High> float
 Range: 1E5 to 6E9
 Increment: 0.01
 *RST: 1E9
 Default unit: Hz

Example:	See Example "Setting a phase continuous frequency range" on page 701.
Usage:	Query only
Options:	R&S SMAB-B22
Manual operation:	See "Frequency Range From / To" on page 76

[:SOURce<hw>]:FREQuency:PHASe:CONTInuous:LOW?

Queries the minimum frequency of the frequency range for phase continuous settings.

The minimum frequency of the frequency range depends on the mode selected with the command [\[:SOURce<hw>\]:FREQuency:PHASe:CONTInuous:MODE](#).

Return values:

<Low>	float
	Range: 1E5 to 6E9
	Increment: 0.01
	*RST: 1E9
	Default unit: Hz

Example:	See Example "Setting a phase continuous frequency range" on page 701.
Usage:	Query only
Options:	R&S SMAB-B22
Manual operation:	See "Frequency Range From / To" on page 76

[:SOURce<hw>]:FREQuency:PHASe:CONTInuous:MODE <Mode>

Selects the mode that determines the frequency range for the phase continuity.

To query the frequency range, use the commands [\[:SOURce<hw>\]:FREQuency:PHASe:CONTInuous:HIGH?](#) and [\[:SOURce<hw>\]:FREQuency:PHASe:CONTInuous:LOW?](#)

Parameters:

<Mode>	NARRow WIDE
	NARRow
	Small frequency range, asymmetrically around the RF frequency.
	WIDE
	Large frequency range, symmetrically around the RF frequency.
	*RST: NARRow

Example:	See [:SOURce<hw>]:FREQuency:PHASe:CONTInuous:LOW? on page 708
Options:	R&S SMAB-B711 (required for frequency range WIDE) R&S SMAB-B22

Manual operation: See ["Frequency Range"](#) on page 76

[:SOURce<hw>]:FREQuency:PHASe:CONTInuous:STATe <State>

Activates phase continuity of the RF frequency.

The frequency range is limited and varies depending on the set RF frequency. You can query the range with the commands [\[:SOURce<hw>\]:FREQuency:PHASe:CONTInuous:HIGH?](#) on page 707 and [\[:SOURce<hw>\]:FREQuency:PHASe:CONTInuous:LOW?](#) on page 708.

Note: Restricted structure of command line.

In phase continuous mode, the R&S SMA100B only processes the first command of a command line and ignores further commands if they are on the same line.

Parameters:

<State> 1 | ON | 0 | OFF
*RST: 0

Example: See [Example "Setting a phase continuous frequency range"](#) on page 701.

Options: R&S SMAB-B22

Manual operation: See ["Phase Continuous Active"](#) on page 75

15.18.6 SOURce:INPut subsystem

The SOURce:INPut subsystem contains the commands for configuring the inputs for external modulation signals. The instrument trigger setting influences all sweeps and is effective in the List mode (Instrument Trigger).

[\[:SOURce<hw>\]:INPut:MODext:COUPling<ch>](#).....709
[\[:SOURce<hw>\]:INPut:MODext:IMPedance<ch>](#).....710
[\[:SOURce\]:INPut:TRIGger:SLOPe](#).....710

[:SOURce<hw>]:INPut:MODext:COUPling<ch> <Coupling>

Selects the coupling mode for an externally applied modulation signal.

Parameters:

<Coupling> AC | DC
AC
Passes the AC signal component of the modulation signal.
DC
Passes the modulation signal with both components, AC and DC.
For active external exponential AM, automatically sets [\[:SOURce<hw>\]:INPut:MODext:COUPling<ch>](#)DC.
*RST: AC

Example: `INP:MOD:COUP AC`
Selects the coupling mode AC for an externally applied modulation signal.

Manual operation: See ["Coupling \(AC/DC\)"](#) on page 115

[:SOURce<hw>]:INPut:MODext:IMPedance<ch> <Impedance>

Sets the impedance for the externally supplied modulation signal.

Parameters:

<Impedance> G50 | G600 | HIGH
G50 = 50 Ohm to ground
G600 = 600 Ohm to ground
HIGH = 100 kOhm to ground
*RST: HIGH

Example: See `[ :SOURce<hw>]:INPut:MODext:COUPling<ch>` on page 709.

Manual operation: See ["Impedance"](#) on page 116

[:SOURce]:INPut:TRIGger:SLOPe <Slope>

Sets the polarity of the active slope of an applied instrument trigger.

Parameters:

<Slope> NEGative | POSitive
*RST: POSitive

Example: `INP:TRIG:SLOP NEG`
Activates the falling slope of the external trigger signal at the trigger input.

Manual operation: See ["Trigger Slope"](#) on page 209

15.18.7 SOURce:LFOutput subsystem

The `SOURce:LFOutput` subsystem contains the commands for setting the LF signal source in CW and Sweep mode and for analog modulation.

Example: Setting up an LF sweep

The following example shows a command sequence to set up an LF sweep.

```
// Reset the instrument to start from an initial state
*RST; *CLS

// Set the trigger mode, the sweep mode and the sweep range
TRIGger1:LFFSweep:SOURce SINGLE
SOURce1:LFOutput1:SWEep:FREQuency:MODE AUTO
```

```

SOURcel:LFOutput1:FREQuency:START 1 kHz
SOURcel:LFOutput1:FREQuency:STOP 7 kHz

// Select linear spacing
// Select the waveform shape for the frequency sweep cycle
// Set the step width and the dwell time.
SOURcel:LFOutput1:SWEep:FREQuency:SPACing LINear
SOURcel:LFOutput1:SWEep:FREQuency:SHAPE SAWtooth
SOURcel:LFOutput1:SWEep:FREQuency:STEP:LINear 100 Hz
SOURcel:LFOutput1:SWEep:FREQuency:DWELL 150 ms
// Alternatively to the step width set the number of steps
SOURcel:LFOutput1:SWEep:FREQuency:POINTs 61

// Activate change to start frequency while waiting for next trigger
// Prerequisites: sweep mode single and sweep waveform sawtooth
SOURcel:LFOutput:SWEep:FREQuency:RETRace 1

// Activate the LF frequency sweep
SOURcel:LFOutput:FREQuency:MODE SWE

// Trigger the sweep(depending on the set mode) and query the status
// Perform a one-off LF sweep
SOURcel:LFOutput1:SWEep:FREQuency:EXECute
SOURcel:LFOutput1:SWEep:FREQuency:RUNning?
// 1
// the sweep is running

// *****
// For manual step LF sweep use the following commands
*RST; *CLS
SOURcel:LFOutput:SWEep:FREQuency:MODE MANual
// Activate the LF frequency sweep
SOURcel:LFOutput:FREQuency:MODE SWEep
// Activate LF Output1.
SOURcel:LFOutput1:STATe 1
// Input the frequency manually for each step
SOURcel:LFOutput1:FREQuency:MANual 2 kHz
SOURcel:LFOutput1:FREQuency:MANual 2.1 kHz
// Alternatively use UP or DOWN parameter with set step width.
SOURcel:LFOutput1:SWEep:FREQuency:STEP:LINear 60000 Hz
// SOURcel:LFOutput1:SWEep:FREQuency:STEP:LOGarithmic 10 PCT
SOURcel:LFOutput1:FREQuency:MANual UP

```

Example: Configuring the LF generator

The following is a simple example on how to configure the LF generator and output the generated signal.

```

// configure the signal of the LF1 generator
SOURcel:LFOutput1:SHAPE SQU
SOURcel:LFOutput1:SHAPE:PULSE:PERiod 0.001

```

```

SOURce1:LFOutput1:SHApe:PULSe:WIDTh 0.0005
SOURce1:LFOutput1:SHApe:PULSe:DCYCLe 0.5
// configure the signal of the LF1 generator
SOURce1:LFOutput2:SHApe SINE
SOURce1:LFOutput2:FREQuency 1000000
SOURce1:LFOutput2:PERiod?
// 0.000001

// changing the LF signal shape
// SOURce1:LFOutput2:SHApe TRAP
// SOURce1:LFOutput2:SHApe:PULSe:PERiod 0.2
// SOURce1:LFOutput2:SHApe:TRAPeZe:RISE 0.0001
// SOURce1:LFOutput2:SHApe:TRAPeZe:FALL 0.001
// SOURce1:LFOutput2:SHApe:TRAPeZe:FALL 0.0001
// SOURce1:LFOutput2:SHApe:TRAPeZe:HIGH 0.0005
// SOURce1:LFOutput2:SHApe TRI
// SOURce1:LFOutput2:SHApe:PULSe:PERiod 0.1
// SOURce1:LFOutput2:SHApe:TRIangle:RISE 0.0001

// activate the LF output and select the LF1 as signal source
// configure the LF output signal
SOURce1:LFOutput1:FREQuency:MODE CW
SOURce1:LFOutput1:STATe 1
SOURce1:LFOutput1:SOURce LF1
SOURce1:LFOutput1:VOLTagE 1
SOURce1:LFOutput1:OFFSet 0.001

```

- [LF generator settings](#)..... 712
- [LF sweep settings](#)..... 719

15.18.7.1 LF generator settings

With the commands described in this section, you can configure the LF signal source.

[:SOURce]:LFOutput<ch>:BANDwidth?	713
[:SOURce]:LFOutput<ch>:FREQuency	713
[:SOURce<hw>]:LFOutput<ch>:PERiod?	713
[:SOURce<hw>]:LFOutput:FREQuency:MANual	714
[:SOURce<hw>]:LFOutput:FREQuency:MODE	714
[:SOURce<hw>]:LFOutput:FREQuency:STOP	715
[:SOURce<hw>]:LFOutput:FREQuency:STARt	715
[:SOURce]:LFOutput<ch>[:STATe]	715
[:SOURce]:LFOutput<ch>:INTernal:VOLTagE	715
[:SOURce]:LFOutput:OFFSet	716
[:SOURce]:LFOutput<ch>:SOURce	716
[:SOURce]:LFOutput<ch>:SOURce:PATH	716
[:SOURce]:LFOutput:VOLTagE	716
[:SOURce<hw>]:LFOutput<ch>:SHApe	717
[:SOURce<hw>]:LFOutput<ch>:SHApe:PULSe:DCYCLe	717
[:SOURce<hw>]:LFOutput<ch>:SHApe:PULSe:PERiod	717

<code>[SOURce<hw>]:LFOutput<ch>:SHAPE:PULSE:WIDTH</code>	718
<code>[SOURce<hw>]:LFOutput<ch>:SHAPE:TRAPeZe:FALL</code>	718
<code>[SOURce<hw>]:LFOutput<ch>:SHAPE:TRAPeZe:HIGH</code>	718
<code>[SOURce<hw>]:LFOutput<ch>:SHAPE:TRAPeZe:PERiod</code>	718
<code>[SOURce<hw>]:LFOutput<ch>:SHAPE:TRAPeZe:RISE</code>	719
<code>[SOURce<hw>]:LFOutput<ch>:SHAPE:TRlangle:PERiod</code>	719
<code>[SOURce<hw>]:LFOutput<ch>:SHAPE:TRlangle:RISE</code>	719

`[SOURce]:LFOutput<ch>:BANDwidth?`

Queries the bandwidth of the external LF signal.

Return values:

<Bandwidth> BW0M2 | BW10m
 *RST: BW10m

Example:

```
LFO:BAND?
// BW10m
// the bandwidth of the externally supplied LF signal is 10 MHz
```

Usage: Query only

Manual operation: See ["Bandwidth"](#) on page 116

`[SOURce]:LFOutput<ch>:FREQuency <Frequency>`

Sets the frequency of the LF signal in `[SOURce<hw>]:LFOutput:FREQuency:MODE` CW | FIXed mode.

Note

- If signal source "Internal" is set, the instrument performs the analog modulations (AM/FM/PhiM/PM) with this frequency.
- In sweep mode (`[SOURce<hw>]:LFOutput:FREQuency:MODE` SWE), the frequency is coupled with the sweep frequency.

Parameters:

<Frequency> float
 Range: depends on the installed options
 Increment: 0.01
 *RST: 1000
 Default unit: Hz

Example:

```
SOURce1:LFOutput1:FREQuency 5 kHz
// sets the LF frequency
```

Manual operation: See ["Frequency"](#) on page 114

`[SOURce<hw>]:LFOutput<ch>:PERiod?`

Queries the repetition frequency of the sine signal.

Return values:

<LfSinePeriod> float
 Range: 1E-6 to 100
 Increment: 10E-9
 *RST: 0.001
 Default unit: s

Example: See [Example "Configuring the LF generator"](#) on page 711.

Usage: Query only

[:SOURce<hw>]:LFOutput:FREQuency:MANual <Manual>

Sets the frequency of the subsequent sweep step if [LFO:SWE:MODE MAN](#).

Use a separate command for each sweep step.

Parameters:

<Manual> float
 You can select any value within the setting range, where:
 START is set with [\[:SOURce<hw>\]:LFOutput:FREQuency:START](#)
 STOP is set with [\[:SOURce<hw>\]:LFOutput:FREQuency:STOP](#)
 Range: START to STOP
 Increment: 0.1
 *RST: 1000

Example: See [Example "Setting up an LF sweep"](#) on page 710.

Manual operation: See ["Current Frequency"](#) on page 205

[:SOURce<hw>]:LFOutput:FREQuency:MODE <Mode>

Sets the mode for the output of the LF generator frequency, and determines the commands to be used for frequency settings.

Parameters:

<Mode> CW | FIXed | SWEep
CW|FIXed
 Sets the fixed-frequency mode. CW and FIXed are synonyms.
 To set the output frequency, use command [\[:SOURce\]:LFOutput<ch>:FREQuency](#)
SWEep
 Sets sweep mode.
 To set the frequency, use the commands:
[\[:SOURce<hw>\]:LFOutput:FREQuency:START](#) and [\[:SOURce<hw>\]:LFOutput:FREQuency:STOP](#)
 Or [\[:SOURce<hw>\]:LFOutput:FREQuency:MANual](#)
 *RST: CW

Example: See [Example "Setting up an LF sweep"](#) on page 710.

Manual operation: See ["State \(LF frequency sweep\)"](#) on page 111

```
[ :SOURce<hw>]:LFOutput:FREQuency:STOP <Stop>
[ :SOURce<hw>]:LFOutput:FREQuency:START <Start>
```

Sets the start/stop frequency for `[ :SOURce<hw>]:LFOutput:FREQuency:MODE` SWEEP.

Parameters:

<Start> float
 Range: 0.1 Hz to 1 MHz
 Increment: 0.1
 *RST: 1 KHz

Example: See [Example "Setting up an LF sweep"](#) on page 710.

Manual operation: See ["Start Frequency/Stop Frequency"](#) on page 210

```
[ :SOURce]:LFOutput<ch>[:STATE] <State>
```

Activates LF signal output.

Parameters:

<State> 1 | ON | 0 | OFF
 *RST: 0

Example: See [Example "Configuring the LF generator"](#) on page 711.

Manual operation: See ["State"](#) on page 118

```
[ :SOURce]:LFOutput<ch>:INTernal:VOLTage <Voltage>
```

Sets the output voltage for the LF generators.

The sum of both values must not exceed the overall output voltage, set with command `[ :SOURce]:LFOutput:VOLTage`.

Suffix:

<ch> [1]|2
 LF1 and LF2

Parameters:

<Voltage> float
 Range: 0 to 4
 Increment: 0.001
 *RST: 1

Example: See [Example "Configuring the LF generator"](#) on page 711.

Manual operation: See ["Output Voltage"](#) on page 118

[[:SOURce]:LFOutput:OFFSet <Offset>

Sets a DC offset at the LF Output.

Parameters:

<Offset>	float
Range:	depends on lfo voltage
Increment:	0.001
*RST:	0

Example: See [Example "Configuring the LF generator"](#) on page 711.

Manual operation: See ["DC-Offset"](#) on page 118

[[:SOURce]:LFOutput<ch>:SOURce <Source>

Determines the LF signal to be synchronized, when monitoring is enabled.

Parameters:

<Source>	LF1 LF2 NOISe AM FMPM EXT1 EXT2
LF1 LF2	Selects an internally generated LF signal.
NOISe	Selects an internally generated noise signal.
EXT1 EXT2	Selects an externally supplied LF signal
AM	Selects the AM signal.
FMPM	Selects the signal also used by the frequency or phase modulations.
*RST:	LF1

Example: See [Example "Configuring the LF generator"](#) on page 711.

Manual operation: See ["Source"](#) on page 118

[[:SOURce]:LFOutput<ch>:SOURce:PATH <SourPath>

Determines the path of the LF output source.

Parameters:

<SourPath>	A B
*RST:	A

Example: `LFO:SOUR:PATH?`
Queries the currently set path for the LF output signal source.

[[:SOURce]:LFOutput:VOLTage <Voltage>

Sets the voltage of the LF output.

Parameters:

<Voltage> float
 Range: dynamic (see specifications document)
 Increment: 0.001
 *RST: 1

Example:

SOURce:LFOutput:VOLTage 1.5

[[:SOURce<hw>]:LFOutput<ch>:SHAPE <Shape>

Selects the waveform shape of the LF signal.

Parameters:

<Shape> SINE | SQUare | PULSe | TRIangle | TRAPeze
 *RST: SINE

Example:

See [Example "Configuring the LF generator"](#) on page 711.

Options:

R&S SMAB-K24

Manual operation:

See ["Shape"](#) on page 112

[[:SOURce<hw>]:LFOutput<ch>:SHAPE:PULSe:DCYCLE <DCycle>

Sets the duty cycle for the shape pulse.

Parameters:

<DCycle> float
 Range: 1E-6 to 100
 Increment: 1E-6
 *RST: 50
 Default unit: PCT

Example:

See [Example "Configuring the LF generator"](#) on page 711.

Manual operation:

See ["Pulse Duty Cycle"](#) on page 114

[[:SOURce<hw>]:LFOutput<ch>:SHAPE:PULSe:PERiod <Period>

Sets the period of the generated pulse. The period determines the repetition frequency of the internal signal.

Parameters:

<Period> float
 Range: 1E-6 to 100
 Increment: 1E-8
 *RST: 1E-3

Example:

See [Example "Configuring the LF generator"](#) on page 711.

Manual operation:

See ["Period"](#) on page 114

[[:SOURce<hw>]:LFOutput<ch>:SHAPE:PULSE:WIDTH <Width>

Sets the pulse width of the generated pulse.

Parameters:

<Width> float
 Range: 1E-6 to 100
 Increment: 1E-8
 *RST: 5E-4

Example: See [Example "Configuring the LF generator"](#) on page 711.

Manual operation: See ["Pulse Width"](#) on page 114

[[:SOURce<hw>]:LFOutput<ch>:SHAPE:TRAPeZe:FALL <Fall>

Selects the fall time for the trapezoid shape of the LF generator.

Parameters:

<Fall> float
 Range: 1E-6 to 100
 Increment: 10E-9
 *RST: 250E-6

Example: See [Example "Configuring the LF generator"](#) on page 711.

Manual operation: See ["Trapezoid Rise / Fall"](#) on page 114

[[:SOURce<hw>]:LFOutput<ch>:SHAPE:TRAPeZe:HIGh <High>

Sets the high time for the trapezoid signal of the LF generator.

Parameters:

<High> float
 Range: 1E-6 to 100
 Increment: 10E-9
 *RST: 250E-6

Example: See [Example "Configuring the LF generator"](#) on page 711.

Manual operation: See ["Trapezoid High"](#) on page 114

[[:SOURce<hw>]:LFOutput<ch>:SHAPE:TRAPeZe:PERiod <Period>

Sets the period of the generated trapezoid shape. The period determines the repetition frequency of the internal signal.

Parameters:

<Period> float
 Range: 1E-6 to 100
 Increment: 1E-8
 *RST: 1E-3

Example: See [Example "Configuring the LF generator"](#) on page 711.

Manual operation: See ["Period"](#) on page 114

[SOURce<hw>]:LFOutput<ch>:SHAPE:TRAPeZe:RISE <Rise>

Selects the rise time for the trapezoid shape of the LF generator.

Parameters:

<Rise>	float
Range:	1E-6 to 100
Increment:	10E-9
*RST:	250E-6

Example: See [Example "Configuring the LF generator"](#) on page 711.

Manual operation: See ["Trapezoid Rise / Fall"](#) on page 114

[SOURce<hw>]:LFOutput<ch>:SHAPE:TRIangle:PERiod <Period>

Sets the period of the generated pulse. The period determines the repetition frequency of the internal signal.

Parameters:

<Period>	float
Range:	1E-6 to 100
Increment:	10E-9
*RST:	0.001

Example: See [Example "Configuring the LF generator"](#) on page 711.

Manual operation: See ["Period"](#) on page 114

[SOURce<hw>]:LFOutput<ch>:SHAPE:TRIangle:RISE <Rise>

Selects the rise time for the triangle single of the LF generator.

Parameters:

<Rise>	float
Range:	1E-6 to 100
Increment:	10E-9
*RST:	0.5E-3

Example: See [Example "Configuring the LF generator"](#) on page 711.

Manual operation: See ["Triangle Rise"](#) on page 114

15.18.7.2 LF sweep settings

With the commands described in this section, you can configure the sweep of the LF signal.

[SOURce<hw>]:LFOutput:SWEep[:FREQUENCY]:DWELI.....	720
[SOURce<hw>]:LFOutput:SWEep[:FREQUENCY]:EXECute.....	720
[SOURce<hw>]:LFOutput:SWEep[:FREQUENCY]:MODE.....	720
[SOURce<hw>]:LFOutput:SWEep[:FREQUENCY]:POINts.....	721
[SOURce<hw>]:LFOutput:SWEep[:FREQUENCY]:RETRace.....	721
[SOURce<hw>]:LFOutput:SWEep[:FREQUENCY]:RUNNing?.....	721
[SOURce<hw>]:LFOutput:SWEep[:FREQUENCY]:SHAPE.....	722
[SOURce<hw>]:LFOutput:SWEep[:FREQUENCY]:SPACing.....	722
[SOURce<hw>]:LFOutput:SWEep[:FREQUENCY]:STEP:LOGarithmic.....	722
[SOURce<hw>]:LFOutput:SWEep[:FREQUENCY]:STEP[LINear].....	723

[SOURce<hw>]:LFOutput:SWEep[:FREQUENCY]:DWELI <Dwell>

Sets the dwell time for each frequency step of the sweep.

Parameters:

<Dwell>	float
Range:	0.001 to 100
Increment:	100E-6
*RST:	0.01
Default unit:	s

Example: See [Example "Setting up an LF sweep"](#) on page 710.

Manual operation: See ["Dwell Time"](#) on page 208

[SOURce<hw>]:LFOutput:SWEep[:FREQUENCY]:EXECute

Immediately starts an LF sweep.

[:SOURce<hw>] :LFOutput :SWEep [:FREQUENCY] :MODE determines which sweep is executed, e.g. SOURce:LFOutput:SWEep:FREQUENCY:MODE STEP.

Example: See [Example "Setting up an LF sweep"](#) on page 710.

Usage: Event

Manual operation: See ["Execute Single Sweep"](#) on page 209

[SOURce<hw>]:LFOutput:SWEep[:FREQUENCY]:MODE <Mode>

Sets the cycle mode of the LF sweep.

Parameters:

<Mode>	AUTO MANual STEP
AUTO	Performs a complete sweep cycle from the start to the end value when a trigger event occurs. The dwell time determines the time period until the signal switches to the next step.

MANual

Performs a single sweep step when a manual trigger event occurs.

The trigger system is not active. To trigger each frequency step of the sweep individually, use the command `[ :SOURce<hw> ] :LFOutput:FREQUENCY:MANual` on page 714.

STEP

Each trigger command triggers one sweep step only.

The frequency increases by the value set with the commands:

`[ :SOURce<hw> ] :LFOutput:SWEep[:FREQUENCY]:STEP[:LINear]` (linear spacing)

`[ :SOURce<hw> ] :LFOutput:SWEep[:FREQUENCY]:STEP:LOGarithmic` (logarithmic spacing)

*RST: AUTO

Example: See [Example "Setting up an LF sweep"](#) on page 710.

Manual operation: See ["Mode"](#) on page 205

[:SOURce<hw>] :LFOutput:SWEep[:FREQUENCY]:POINTs <Points>

Sets the number of steps in an LF sweep.

For information on how the value is calculated and the interdependency with other parameters, see [Section 8.2.1, "Correlating parameters in sweep mode"](#), on page 197

Parameters:

<Points> integer
Range: 2 to POINTs
*RST: 50

Example: See [Example "Setting up an LF sweep"](#) on page 710.

[:SOURce<hw>] :LFOutput:SWEep[:FREQUENCY]:RETRace <State>

Activates that the signal changes to the start frequency value while it is waiting for the next trigger event.

You can enable this feature, when you are working with sawtooth shapes in sweep mode "Single" or "External Single".

Parameters:

<State> 1 | ON | 0 | OFF
*RST: 0

Manual operation: See ["Retrace"](#) on page 206

[:SOURce<hw>] :LFOutput:SWEep[:FREQUENCY]:RUNNing?

Queries the current status of the LF frequency sweep mode.

Return values:

<State> 1 | ON | 0 | OFF

Example: See [Example "Setting up an LF sweep"](#) on page 710.

Usage: Query only

[:SOURce<hw>]:LFOutput:SWEep[:FREQuency]:SHAPE <Shape>

Sets the cycle mode for a sweep sequence (shape).

Parameters:

<Shape> SAWTooth | TRIangle
*RST: SAWTooth

Example: See [Example "Setting up an LF sweep"](#) on page 710.

Manual operation: See ["Shape"](#) on page 207

[:SOURce<hw>]:LFOutput:SWEep[:FREQuency]:SPACing <Spacing>

Selects linear or logarithmic sweep spacing.

Parameters:

<Spacing> LINear | LOGarithmic
*RST: LINear

Example: See [Example "Setting up an LF sweep"](#) on page 710.

Manual operation: See ["Spacing"](#) on page 208

**[:SOURce<hw>]:LFOutput:SWEep[:FREQuency]:STEP:LOGarithmic
<Logarithmic>**

Sets the step width factor for logarithmic sweeps to calculate the frequencies of the steps.

For information on how the value is calculated and the interdependency with other parameters, see [Section 8.2.1, "Correlating parameters in sweep mode"](#), on page 197

Parameters:

<Logarithmic> float
The unit is mandatory
Range: 0.01 to 100
Increment: 0.01
*RST: 1
Default unit: PCT

Example: See [Example "Setting up an LF sweep"](#) on page 710.

Manual operation: See ["Step Linear/Step Logarithmic"](#) on page 211

[[:SOURce<hw>]:LFOutput:SWEep[:FREQuency]:STEP[:LINear] <Linear>

Sets the step width for the linear sweep.

For information on how the value is calculated and the interdependency with other parameters, see [Section 8.2.1, "Correlating parameters in sweep mode"](#), on page 197

Parameters:

<Linear>	float
Range:	0.1 to STOP-START
Increment:	0.1
*RST:	1000

Example: See [Example "Setting up an LF sweep"](#) on page 710.

Manual operation: See ["Step Linear/Step Logarithmic"](#) on page 211

15.18.8 SOURce:LIST subsystem

The SOURce:LIST subsystem contains all commands for defining lists and for handling of list files.

List files have the predefined file extension *.lsw.

Refer to [Section 15.5.2, "Handling files in the default or in a specified directory"](#), on page 495 for general information on file handling in the default and in a specific directory.



- *RST does not affect data lists.
- SCPI refers to the individual lists as segments.

Example: Create an RF list and activate the list mode

The following example shows a command sequence to create an RF list and to activate the list mode. Further hardware settings are not considered.

```
// Reset the instrument to start from an initial state
// Query the available list files in the default
// directory /var/user
// Select the list file or create it (if not existing)
*RST; *CLS
:SOURcel:LIST:CAT?
// Response:- shows the name of available list files (if applicable)
:SOURcel:LIST:SEL "/var/user/list1.lsw"

// Write the frequency/level/dwell time values in the selected list file
// existing data is overwritten
// Query the number of frequency/power/dwell time entries in the selected list
// Query the amount of free memory (in bytes) for list mode lists
:SOURcel:LIST:FREQ 58 MHz, 61 MHz, 73 MHz, 86 MHz, 91 MHz, 92 MHz, 98 MHz
:SOURcel:LIST:POW 13 dBm, 12 dBm, 5 dBm, 3 dBm, 0 dBm, 4 dBm, 6 dBm
```

```

:SOURcel:LIST:DWEL:LIST 10000, 100000, 200000, 19000, 10000, 150000, 220000
:SOURcel:LIST:FREQ:POIN?
// 7
:SOURcel:LIST:POW:POINT?
// 7
:SOURcel:LIST:DWEL:LIST:POIN?
// 7
:SOURcel:LIST:FREE?
// 2147483647 (bytes of free memory)

// Use dwell times from list
// Configure the list mode parameters
// Enable RF output
:SOURcel:LIST:MODE AUTO
:SOURcel:LIST:TRIG:SOUR AUTO
:SOURcel:LIST:DWEL:MODE "LIST"

:OUTPut1:STAT ON

// Use global dwell time
// Set only a part of the list (value pairs 3 to 5) to be processed
// Configure the list mode parameters using global dwell time
// Enable RF output
:SOURcel:LIST:IND:START 2
:SOURcel:LIST:IND:STOP 4
:SOURcel:LIST:MODE AUTO
:SOURcel:LIST:TRIG:SOUR AUTO
:SOURcel:LIST:DWEL:LIST 500 ms
:OUTPut1:STAT ON

// Enable the list mode
// Trigger the list (depending on the mode, not needed with trigger
// mode AUTO); query the current index
// Reset the list to the starting point
:SOURcel:FREQ:MODE LIST
:SOURcel:LIST:TRIG:EXEC
:SOURcel:LIST:RUNN?
:SOURcel:LIST:IND?
// 3
// value changes when the value is queried again
:SOURcel:LIST:RES

// For list mode STEP use the following commands
*RST; *CLS
// Change list mode to STEP
:SOURcel:LIST:MODE STEP
// Activate RF Output1
:OUTPut1:STAT 1
// Activate the list mode
:SOURcel:FREQ:MODE LIST
// For each step: select frequency/powerlevel pair as index from the list

```



```

:SOURce1:LIST:IND 2
:SOURce1:LIST:IND 3
:SOURce1:LIST:IND 4

// Use the selected list for path B (with List Mode B default settings)
:SOURce2:LIST:SEL "/var/user/list1.lsw"
:OUTPut2:STAT ON
:SOURce2:FREQ:MODE LIST
:SOURce2:LIST:IND?
// 2
// value changes when the value is queried again

// Deactivate the list mode
:SOURce1:FREQ:MODE CW

```

Example: List mode data exchange

The following example shows a command sequence to export a list (here the RF list created with the example before) into an ASCII file. Further hardware settings are not considered.

```

*RST; *CLS
LIST:DEXC:MODE EXP

// Set ASCII data parameters
// Set the ASCII file extension, the decimal separator
// and the column separator for the ASCII data
:SOURce1:LIST:DEXC:AFIL:EXT CSV
:SOURce1:LIST:DEXC:AFIL:SEP:DEC DOT
:SOURce1:LIST:DEXC:AFIL:SEP:COL COMM

// Select source and destination path/directory
// Query available listfiles in default directory "/var/user"
:SOURce1:LIST:CAT?
// list1
:SOURce1:LIST:DEXC:AFIL:SEL "/var/user/list1ASCII"
:SOURce1:LIST:DEXC:SEL "/var/user/list1"

// Export the list file data into the ASCII file
:SOURce1:LIST:DEXC:EXEC

// Query the available ASCII files with extension .csv
:SOURce1:LIST:DEXC:AFIL:CAT?
// Response: "list1ASCII"

// Deactivate the list mode
:SOURce1:FREQ:MODE CW

```

- [List mode settings](#).....726
- [List mode file operation](#).....731
- [List mode data exchange](#).....733

15.18.8.1 List mode settings

With the following commands, you can create list mode data, select the trigger mode and determine the dwell time.

[:SOURce<hw>]:LIST:DWELI	726
[:SOURce<hw>]:LIST:DWELI:MODE	726
[:SOURce<hw>]:LIST:DWELI:LIST	727
[:SOURce<hw>]:LIST:DWELI:LIST:POINts?	727
[:SOURce<hw>]:LIST:FREQuency	727
[:SOURce<hw>]:LIST:FREQuency:POINts?	728
[:SOURce<hw>]:LIST:INDEx	728
[:SOURce<hw>]:LIST:INDEx:STARt	728
[:SOURce<hw>]:LIST:INDEx:STOP	728
[:SOURce<hw>]:LIST:MODE	729
[:SOURce<hw>]:LIST:POWEr	729
[:SOURce<hw>]:LIST:POWEr:POINts?	729
[:SOURce<hw>]:LIST:TRIGger:EXECute	730
[:SOURce<hw>]:LIST:TRIGger:SOURce	730
[:SOURce<hw>]:LIST:RUNNing?	731

[\[:SOURce<hw>\]:LIST:DWELI](#) <Dwell>

Sets the global dwell time. The instrument generates the signal with the frequency / power value pairs of each list entry for that particular period.

See also [Significant parameters and functions](#).

Parameters:

<Dwell>	float
	Range: 1E-3 to 100
	Increment: 1E-6
	*RST: 0.01

Example: See [Example "Create an RF list and activate the list mode"](#) on page 723.

Manual operation: See ["Global Dwell Time"](#) on page 219

[\[:SOURce<hw>\]:LIST:DWELI:MODE](#) <DwellMode>

Selects the dwell time mode.

Parameters:

<DwellMode>	LIST GLOBal
	LIST
	Uses the dwell time, specified in the data table for each value pair individually.
	GLOBal
	Uses a constant dwell time, set with command [:SOURce<hw>]:LIST:DWELI .

*RST: GLOBal

Example: See [Example "Create an RF list and activate the list mode"](#) on page 723.

Manual operation: See ["Dwell Time Mode"](#) on page 219

[:SOURce<hw>]:LIST:DWELI:LIST <Dwell>

Enters the dwell time values in the selected list in μ s.

Parameters:

<Dwell> <Dwell#1>{, <Dwell#2>, ...} | block data

You can either enter the data as a list of numbers, or as binary block data. The list of numbers can be of any length, with the list entries separated by commas.

In binary block format, 8 (4) bytes are always interpreted as a floating-point number with double accuracy. See also : [FORMat \[: DATA \]](#) on page 529 for more details.

Example: See [Example "Create an RF list and activate the list mode"](#) on page 723.

Manual operation: See ["Dwell Time \(s\)"](#) on page 225

[:SOURce<hw>]:LIST:DWELI:LIST:POINTS?

Queries the number (points) of dwell time entries in the selected list.

Return values:

<Points> integer

Range: 0 to INT_MAX

*RST: 0

Example: See [Example "Create an RF list and activate the list mode"](#) on page 723.

Usage: Query only

[:SOURce<hw>]:LIST:FREQuency <Frequency>

Enters the frequency values in the selected list.

Parameters:

<Frequency> <Frequency#1>{, <Frequency#2>, ...} | block data

You can either enter the data as a list of numbers, or as binary block data.

The list of numbers can be of any length, with the list entries separated by commas.

In binary block format, 8 (4) bytes are always interpreted as a floating-point number with double accuracy.

See also : [FORMat \[: DATA \]](#).

Range: 300 kHz to RFmax (depends on the installed options)

Example: See [Example "Create an RF list and activate the list mode"](#) on page 723.

Manual operation: See ["Frequency \(Hz\)"](#) on page 224

[SOURce<hw>]:LIST:FREQuency:POINts?

Queries the number (points) of frequency entries in the selected list.

Return values:

<Points> integer
 Range: 0 to INT_MAX
 *RST: 0

Example: See [Example "Create an RF list and activate the list mode"](#) on page 723.

Usage: Query only

[SOURce<hw>]:LIST:INDeX <Index>

Sets the list index in [LIST:MODE STEP](#).

After the trigger signal, the instrument processes the frequency and level settings of the selected index.

Parameters:

<Index> integer
 *RST: 0

Example: See [Example "Create an RF list and activate the list mode"](#) on page 723.

Manual operation: See ["Current Index"](#) on page 218

[SOURce<hw>]:LIST:INDeX:STARt <Start>

[SOURce<hw>]:LIST:INDeX:STOP <Stop>

Sets the start and stop index of the index range which defines a subgroup of frequency/level value pairs in the current list.

Parameters:

<Stop> integer
 Index range
 Only values inside this range are processed in list mode
 Range: 0 to list length
 *RST: 0

Example: See [Example "Create an RF list and activate the list mode"](#) on page 723.

Manual operation: See ["List Range from/to"](#) on page 221

[[:SOURce<hw>]:LIST:MODE <Mode>

Sets the list mode.

The instrument processes the list according to the selected mode and trigger source. See [LIST:TRIG:SOUR AUTO](#), [SING](#) or [EXT](#) for the description of the trigger source settings.

Parameters:

<Mode> AUTO | STEP

AUTO

Each trigger event triggers a complete list cycle.

STEP

Each trigger event triggers only one step in the list processing cycle. The list is processed in ascending order.

*RST: AUTO

Example: See [Example "Create an RF list and activate the list mode"](#) on page 723.

Manual operation: See ["Mode"](#) on page 219

[[:SOURce<hw>]:LIST:POWer <Power>

Enters the level values in the selected list. The number of level values must correspond to the number of frequency values. Existing data is overwritten.

Parameters:

<Power> <Power#1>{, <Power#2>, ...} | block data

You can either enter the data as a list of numbers, or as binary block data.

The list of numbers can be of any length, with the list entries separated by commas.

In binary block format, 8 (4) bytes are always interpreted as a floating-point number with double accuracy.

See also [:FORMat \[:DATA\]](#).

Range: depends on the installed options

Default unit: dBm

Example: See [Example "Create an RF list and activate the list mode"](#) on page 723.

Manual operation: See ["Power \(dBm\)"](#) on page 225

[[:SOURce<hw>]:LIST:POWer:POINts?

Queries the number (points) of level entries in the selected list.

Return values:

<Points> integer
 Range: 0 to INT_MAX
 *RST: 0

Example: See [Example "Create an RF list and activate the list mode"](#) on page 723.

Usage: Query only

[:SOURce<hw>]:LIST:TRIGger:EXECute

Starts the processing of a list in list mode.

Example: See [Example "Create an RF list and activate the list mode"](#) on page 723.

Usage: Event

Manual operation: See ["Execute Single"](#) on page 220

[:SOURce<hw>]:LIST:TRIGger:SOURce <Source>

Selects the trigger source for processing lists.

The designation of the parameters correspond to those in sweep mode. SCPI standard uses other designations for the parameters, which are also accepted by the instrument. The SCPI designation should be used if compatibility is an important consideration. For an overview, see the following table:

Rohde & Schwarz parameter	SCPI parameter	Applies to the list mode parameters:
AUTO	IMMediate	[:SOURce<hw>]:LIST:MODE AUTO
SINGle	BUS	[:SOURce<hw>]:LIST:MODE AUTO or [:SOURce<hw>]:LIST:MODE STEP
EXTErnal	EXTErnal	[:SOURce<hw>]:LIST:MODE AUTO or [:SOURce<hw>]:LIST:MODE STEP

Parameters:

<Source>

AUTO | IMMediate | SINGle | BUS | EXTErnal

AUTO|IMMediate

The trigger is free-running, i.e. the trigger condition is fulfilled continuously. The selected list is restarted as soon as it is finished.

SINGle|BUS

The list is triggered by the command [:SOURce<hw>]:LIST:TRIGger:EXECute. The list is executed once.

EXTErnal

The list is triggered externally and executed once.

*RST: AUTO

Example: See [Example "Create an RF list and activate the list mode"](#) on page 723.

Manual operation: See ["Mode"](#) on page 219

[[:SOURce<hw>]:LIST:RUNNING?

Queries the current state of the list mode.

Return values:

<State> 1 | ON | 0 | OFF
1
 Signal generation based on the list mode is active.

Example: See [Example "Create an RF list and activate the list mode"](#) on page 723.

Usage: Query only

15.18.8.2 List mode file operation

The following section covers basic commands to file handling in list mode.

[:SOURce<hw>]:LIST:CATalog?	731
[:SOURce<hw>]:LIST:DELeTe	731
[:SOURce<hw>]:LIST:DELeTe:ALL	732
[:SOURce<hw>]:LIST:FREE?	732
[:SOURce<hw>]:LIST:RESet	732
[:SOURce<hw>]:LIST:SELeCt	733

[[:SOURce<hw>]:LIST:CATalog?

Queries the available list files in the specified directory.

Return values:

<Catalog> string
 List of list filenames, separated by commas

Example: See [Example "Create an RF list and activate the list mode"](#) on page 723.

Usage: Query only

Manual operation: See ["List Mode Data"](#) on page 220

[[:SOURce<hw>]:LIST:DELeTe <Filename>

Deletes the specified list.

Setting parameters:

<Filename> string
 Filename or complete file path; file extension is optional.

Example: See `[ :SOURce<hw> ] :LIST:DELeTe:ALL` on page 732.

Usage: Setting only

Manual operation: See "List Mode Data" on page 220

`[ :SOURce<hw> ] :LIST:DELeTe:ALL`

Deletes all lists in the set directory.

This command can only be executed, if:

- No list file is selected.
- List mode is disabled.

Example:

```

SOUR1:LIST:CAT?
// list,my_list
SOUR1:LIST:DEL "/var/user/list1"
SOUR1:LIST:CAT?
// my_list
SOUR1:FREQ:MODE?
// LIST
SOUR1:LIST:SEL?
// /var/user/my_list.lsw
//deactivate list mode
SOUR1:FREQ:MODE CW
SOUR1:LIST:DELeTe:ALL
SOUR1:LIST:CAT?
// -
// all list files are deleted

```

Usage: Event

Manual operation: See "List Mode Data" on page 220

`[ :SOURce<hw> ] :LIST:FREE?`

Queries the amount of free memory (in bytes) for list mode lists.

Return values:

<code><Free></code>	integer
Range:	0 to INT_MAX
*RST:	0

Example: See [Example "Create an RF list and activate the list mode"](#) on page 723.

Usage: Query only

`[ :SOURce<hw> ] :LIST:RESet`

Jumps to the beginning of the list.

Example: See [Example "Create an RF list and activate the list mode"](#) on page 723.

Usage: Event

Manual operation: See ["Reset"](#) on page 220

[:SOURce<hw>]:LIST:SElect <Filename>

Selects or creates a data list in list mode.

If the list with the selected name does not exist, a new list is created.

Parameters:

<Filename> string
Filename or complete file path; file extension can be omitted.

Example: See [Example "Create an RF list and activate the list mode"](#) on page 723.

Manual operation: See ["List Mode Data"](#) on page 220

15.18.8.3 List mode data exchange

With the following commands, you can configure lists in ASCII format and export or import them accordingly.

[:SOURce<hw>]:LIST:DEXChange:AFILe:CATalog?	733
[:SOURce<hw>]:LIST:DEXChange:AFILe:EXTension	734
[:SOURce<hw>]:LIST:DEXChange:AFILe:SElect	734
[:SOURce<hw>]:LIST:DEXChange:AFILe:SEParator:COLumn	734
[:SOURce<hw>]:LIST:DEXChange:AFILe:SEParator:DECimal	734
[:SOURce<hw>]:LIST:DEXChange:EXECute	735
[:SOURce<hw>]:LIST:DEXChange:MODE	735
[:SOURce<hw>]:LIST:DEXChange:SElect	735

[:SOURce<hw>]:LIST:DEXChange:AFILe:CATalog?

Queries the available ASCII files for export or import of list mode data in the current or specified directory.

Return values:

<Catalog> string
List of ASCII files *.txt or *.csv, separated by commas.

Example: See [Example "List mode data exchange"](#) on page 725.

Usage: Query only

Manual operation: See ["Select \(ASCII\) Source/Select \(ASCII\) Destination"](#) on page 107

[:SOURce<hw>]:LIST:DEXChange:AFILe:EXTension <Extension>

Determines the extension of the ASCII file for import or export, or to query existing files.

Parameters:

<Extension> TXT | CSV
*RST: TXT

Example: See [Example "List mode data exchange"](#) on page 725.

Manual operation: See ["ASCII File Settings"](#) on page 106

[:SOURce<hw>]:LIST:DEXChange:AFILe:SElect <Filename>

Selects the ASCII file to be imported or exported.

Parameters:

<Filename> string
Filename or complete file path; file extension can be omitted.

Example: See [Example "List mode data exchange"](#) on page 725.

Manual operation: See ["Select \(ASCII\) Source/Select \(ASCII\) Destination"](#) on page 107

[:SOURce<hw>]:LIST:DEXChange:AFILe:SEParator:COLumn <Column>

Selects the separator between the frequency and level column of the ASCII table.

Parameters:

<Column> TABulator | SEMicolon | COMMa | SPACe
*RST: COMMa

Example: See [Example "List mode data exchange"](#) on page 725.

Manual operation: See ["ASCII File Settings"](#) on page 106

[:SOURce<hw>]:LIST:DEXChange:AFILe:SEParator:DECimal <Decimal>

Sets "." (decimal point) or "," (comma) as the decimal separator used in the ASCII data with floating-point numerals.

Parameters:

<Decimal> DOT | COMMa
*RST: DOT

Example: See [Example "List mode data exchange"](#) on page 725.

Manual operation: See ["ASCII File Settings"](#) on page 106

[:SOURce<hw>]:LIST:DEXChange:EXECute

Executes the import or export of the selected list file, according to the previously set transfer direction with command [\[:SOURce<hw>\]:LIST:DEXChange:MODE](#)

Example: See [Example "List mode data exchange"](#) on page 725.

Usage: Event

Manual operation: See ["Import / Export"](#) on page 107

[:SOURce<hw>]:LIST:DEXChange:MODE <Mode>

Determines the import or export of a list.

Specify the source or destination file with the command [\[:SOURce<hw>\]:LIST:DEXChange:SElect](#).

Parameters:

<Mode> IMPort | EXPort
*RST: IMPort

Example: See [Example "List mode data exchange"](#) on page 725.

Manual operation: See ["Mode"](#) on page 106

[:SOURce<hw>]:LIST:DEXChange:SElect <Filename>

Selects the ASCII file for import or export, containing a list.

Parameters:

<Filename> string
Filename or complete file path; file extension can be omitted.

Example: See [Example "List mode data exchange"](#) on page 725.

Manual operation: See ["Select Source/Select ASCII Destination"](#) on page 107

15.18.9 SOURce:NOISe subsystem

The SOURce:NOISe subsystem contains the commands for:

- Setting the noise modulation signal. The noise generator is optional.

Example: To configure the noise generator

```
:SOURce1:NOISe:DISTRibution GAUSS
:SOURce1:NOISe:BANDwidth 10000000

SOURce1:NOISe:BANDwidth:STATe 1

:SOURce1:LFOutput1:SOURce NOIS
:SOURce1:LFOutput1:STATe 1

:SOURce1:NOISe:LEVel:RELative?
// Response in dB: -83.86
:SOURce1:NOISe:LEVel:ABSolute?
// Response in dB: -13.86
```

- [Noise generator](#).....736

15.18.9.1 Noise generator

[:SOURce<hw>]:NOISe:BANDwidth BWIDth	736
[:SOURce<hw>]:NOISe:BWIDth:STATe	736
[:SOURce<hw>]:NOISe:DISTRibution	737
[:SOURce<hw>]:NOISe:LEVel:RELative?	737
[:SOURce<hw>]:NOISe:LEVel[:ABSolute]?	737

[:SOURce<hw>]:NOISe:BANDwidth|BWIDth <BWidth>

Sets the noise level in the system bandwidth when bandwidth limitation is enabled.

Parameters:

<BWidth>	float
Range:	100E3 to 10E6
Increment:	100E3
*RST:	100E3

Example: See [Example "To configure the noise generator"](#) on page 736.

Manual operation: See ["Bandwidth"](#) on page 117

[:SOURce<hw>]:NOISe:BWIDth:STATe <State>

Activates noise bandwidth limitation.

Parameters:

<State>	1 ON 0 OFF
*RST:	0

Example: See [Example "To configure the noise generator"](#) on page 736.

Manual operation: See ["Bandwidth"](#) on page 117

[SOURce<hw>]:NOISe:DISTRibution <Distribution>

Sets the distribution of the noise power density.

Parameters:

<Distribution> GAUSs | EQUal
*RST: GAUSs

Example: See [Example "To configure the noise generator"](#) on page 736.

Manual operation: See ["Distribution"](#) on page 116

[SOURce<hw>]:NOISe:LEVel:RELative?

Queries the level of the noise signal per Hz in the total bandwidth.

Return values:

<Relative> float
Range: -149.18 to -52.67
Increment: 0.1
*RST: -69.84

Example: See [Example "To configure the noise generator"](#) on page 736.

Usage: Query only

Manual operation: See ["Noise Density"](#) on page 119

[SOURce<hw>]:NOISe:LEVel[:ABSolute]?

Queries the level of the noise signal in the system bandwidth within the enabled bandwidth limitation.

Return values:

<Absolute> float
Noise level within the bandwidth limitation
*RST: 3.84 MHz

Example: See [Example "To configure the noise generator"](#) on page 736.

Usage: Query only

Manual operation: See ["Noise Level"](#) on page 119

15.18.10 SOURce:PGEN subsystem

The PGEN subsystem contains the commands for setting output of the pulse modulation signal.

Example: Using pulse generator as source for pulse modulation

```
// select pulse generator as source for pulse modulation
// enable pulse modulation
SOURCE1:PULM:SOURCE INT
SOURCE1:PULM:STATE 1
// pulse generator and signal output are also activated
SOURCE1:PGENERATOR:STATE?
// 1
SOURCE1:PGENERATOR:OUTPUT:STATE?
// 1
PGENERATOR:OUTPUT:POLARITY NORMAL
// to disable pulse generator
SOURCE1:PGENERATOR:STATE 0
// activate the pulse modulation of the RF carrier
SOURCE1:PULM:STATE 1
```

```
[ :SOURCE<hw>]:PGENERATOR:OUTPUT:POLARITY..... 738
[ :SOURCE<hw>]:PGENERATOR:OUTPUT[:STATE]..... 738
[ :SOURCE<hw>]:PGENERATOR:STATE..... 739
```

[:SOURCE<hw>]:PGENERATOR:OUTPUT:POLARITY <Polarity>

Sets the polarity of the pulse output signal.

Parameters:

<Polarity> NORMAL | INVERTED

NORMAL

Outputs the pulse signal during the pulse width, that means during the high state.

INVERTED

Inverts the pulse output signal polarity. The pulse output signal is suppressed during the pulse width, but provided during the low state.

*RST: NORMAL

Example: See [Example "Using pulse generator as source for pulse modulation"](#) on page 738.

Manual operation: See ["Pulse Output Polarity"](#) on page 101

[:SOURCE<hw>]:PGENERATOR:OUTPUT[:STATE] <State>

Activates the output of the pulse modulation signal.

Parameters:

<State> 1 | ON | 0 | OFF

*RST: 0

Example: See [Example "Using pulse generator as source for pulse modulation"](#) on page 738.

Manual operation: See ["Pulse Output State"](#) on page 101

[:SOURce<hw>]:PGENerator:STATe <State>

Enables the output of the video/sync signal.

If the pulse generator is the current modulation source, activating the pulse modulation automatically activates the signal output and the pulse generator.

Parameters:

<State> 1 | ON | 0 | OFF
 *RST: 0

Example: See [Example "Using pulse generator as source for pulse modulation"](#) on page 738.

15.18.11 SOURce:PHASe subsystem

This subsystem contains the commands for adjusting the phase of the RF output signal relative to a reference signal of the same frequency.

Example: Programming Example

```
// change the phase relative to the current phase
SOURce1:PHASe 2 DEG
// adopt the setting as the current phase
SOURce1:PHASe:REFerence
```

The following commands are available:

[:SOURce<hw>]:PHASe	739
[:SOURce<hw>]:PHASe:REFerence	739

[:SOURce<hw>]:PHASe <Phase>

Sets the phase variation relative to the current phase.

Parameters:

<Phase> float
 Range: -36000 to 36000
 Increment: 0.001
 *RST: 0
 Default unit: DEG

Example: See [Example "Programming Example"](#) on page 739.

Manual operation: See ["Delta Phase"](#) on page 76

[:SOURce<hw>]:PHASe:REFerence

Assigns the value set with command [\[:SOURce<hw>\]:PHASe](#) as the reference phase.

Example: See [Example "Programming Example"](#) on page 739.

Usage: Event

Manual operation: See ["Reset Delta Phase Display"](#) on page 76

15.18.12 SOURce:POWer subsystem

The SOURce:POWer subsystem contains the commands for setting the output level, level control and level correction of the RF signal.

The default units are dBm. To change the units, perform one of the following:

- Enter the unit after the numerical value
Example: :POW 0.5V
- Set the unit with the command :UNIT:POWer.

Example: Configuring the RF output power

```
:SOURce1:POWer:CW?
// Response -30
:SOURce1:POWer:CW -25
:SOURce1:POWer:OFFSet?
// Response 0
:SOURce1:POWer:OFFSet 2

:SOURce1:POWer:STEP:MODE?
// Response: DEC
:SOURce1:POWer:STEP:MODE USER
:SOURce1:POWer:STEP:INCRement 2
:SOURce1:POWer:LEVel:IMMediate:AMPLitude UP
```

Example: Configure the settings for external ALC

The example shows a command sequence to set the parameters of the external ALC mode. It is assumed that you have set up the measurement with the external coupler, detector diode and the R&S SMA100B as described in [Section 9.2.2, "How to set up an external ALC"](#), on page 235.

```
// Reset the instrument to start from an initial state
*RST; *CLS

// Select the external ALC mode
// configure the detector coupling factor
// and required RF generator level

SOURce:POWer:ALC[:STATe] EALC
SOURce:POWer:ALC:EDETector:FACTOR 16
SOURce:POWer:ALC:EDETector:LEVel 20

// Execute the instrument detector offset compensation.
```



```

SOURce:POWer:ALC:SONCe
// This function recalculates and compensates internally detected offset voltages

// Activate RF Output.
Output1:STATe 1

```

Example: Configure the settings for NRP power control

The example shows a command sequence to configure a closed loop power control setup.

It is assumed that you have set up the measurement with the amplifier, external coupler, the power sensor and the R&S SMA100B as described in [Section 9.4.4, "NRP power control"](#), on page 254.

```

// Reset the instrument to start from an initial state
*RST; *CLS

// Select the sensor used for nrp power control
// that is e.g., connected to a second USB interface

:SOURce1:POWer:SPC:SElect SENS2

// Configure the nrp power control settings
// use the measured peak power for power control
// set the unit dBm for the target level value
// set the target level, e.g. - 10 dBmM
// use the measured target level as reference level
// select single measurement mode to acquire one level value
// set the capture range for the control loop, e.g. +/- 15 dB
// set a time delay between the sensor readings, e.g. 2 ms

:SOURce1:POWer:SPC:PEAK ON
:SENSe1:UNIT:POWer DMB
:SOURce1:POWer:SPC:TARGet -10
:SOURce1:POWer:SPC:MEASure
:SOURce1:POWer:SPC:MODE SINGLE
:SOURce1:POWer:SPC:CRANge 15
:SOURce1:POWer:SPC:DELay 2 ms

// Enable NRP power control measurement
// switch on RF output
// start the single measurement manually

:Output1:STATe 1
:SOURce1:POWer:SPC:STATe ON
:SOURce1:POWer:SPC:SINGLE

// Query if the power control works properly
:SOURce1:POWer:SPC:WARning?
// Response: 1 -> power control doew not work as expected

```

Example: Configuring level attenuator

```

SOURcel:POWer:ATTenuation 20dB
// set the level attenuation manually

SOURcel:POWer:ATTenuation:RFOF:MODE FATTenuation
// set maximum attenuation when the RF output is turned off

SOURce:POWer:ATTenuation:VSWR?
// query the level value of the VSWR output

SOURcel:POWer:AATTenuation?
// query the currently active attenuation
// Response: 100

SOURcel:POWer:ATTenuation:DIGital 7.2

```

Example: Setting a digital attenuation

```

SOURcel:POWer:ATTenuation:DIGital 7.2
// set an attenuation for the baseband signal.

```

[SOURce<hw>]:POWer:ALC[:STATe].....	743
[SOURce<hw>]:POWer:ALC:DSEnSitivity.....	743
[SOURce<hw>]:POWer:ALC:EDEtector:FACTor.....	744
[SOURce<hw>]:POWer:ALC:EDEtector:LEVel.....	744
[SOURce<hw>]:POWer:ALC:SONCe.....	744
[SOURce<hw>]:POWer:ATTenuation:PATTenuator.....	745
[SOURce<hw>]:POWer:ATTenuation:RFOF:MODE.....	745
[SOURce<hw>]:POWer:EMF:STATe.....	745
[SOURce<hw>]:POWer:LBEHaviour.....	746
[SOURce<hw>]:POWer:LIMit[:AMPLitude].....	746
[SOURce<hw>]:POWer:MANual.....	746
[SOURce<hw>]:POWer:MODE.....	747
[SOURce<hw>]:POWer:POWer.....	747
[SOURce<hw>]:POWer:START.....	748
[SOURce<hw>]:POWer:STOP.....	748
[SOURce<hw>]:POWer:SPC:CRANge.....	748
[SOURce<hw>]:POWer:SPC:DELay.....	748
[SOURce<hw>]:POWer:SPC:MEASure.....	749
[SOURce<hw>]:POWer:SPC:MODE.....	749
[SOURce<hw>]:POWer:SPC:PEAK.....	749
[SOURce<hw>]:POWer:SPC:SElect.....	749
[SOURce<hw>]:POWer:SPC:SINGLE.....	750
[SOURce<hw>]:POWer:SPC:STATe.....	750
[SOURce<hw>]:POWer:SPC:TARGet.....	750
[SOURce<hw>]:POWer:SPC:WARning?.....	750

[SOURce<hw>]:POWER:STEP:MODE.....	751
[SOURce<hw>]:POWER:STEP[:INCRement].....	751
[SOURce<hw>]:POWER[:LEVel][:IMMediate]:OFFSet.....	752
[SOURce<hw>]:POWER[:LEVel][:IMMediate]:RCL.....	752
[SOURce<hw>]:POWER[:LEVel][:IMMediate][:AMPLitude].....	752
[SOURce<hw>]:POWER[:LEVel][:IMMediate]:REFLevel.....	753
[SOURce<hw>]:POWER:RANGe:LOWer?.....	753
[SOURce<hw>]:POWER:RANGe:UPPer?.....	753
[SOURce<hw>]:POWER:RANGe:MIN?.....	754
[SOURce<hw>]:POWER:RANGe:MAX?.....	754
[SOURce]:POWER:WIGNore.....	754

[SOURce<hw>]:POWER:ALC[:STATe] <State>

Parameters:

<State> 0 | OFF | AUTO | 1 | ON | ONTable | PRESet | OFFTable | EALC

AUTO

Adjusts the output level to the operating conditions automatically.

1|ON

Activates internal level control permanently.

OFFTable

Controls the level using attenuation values of the internal ALC table.

0|OFF

Provided only for backward compatibility with other Rohde & Schwarz signal generators.

The R&S SMA100B accepts these values and maps them automatically as follows:

0|OFF = OFFTable

ONTable

Starts with the attenuation setting from the table and continues with automatic level control.

EALC

Activates external ALC mode.

*RST: AUTO

Example: See [Example "Configure the settings for external ALC"](#) on page 740

Manual operation: See ["State"](#) on page 234

[SOURce<hw>]:POWER:ALC:DSENSitivity <Sensitivity>

Sets the sensitivity of the ALC detector.

Parameters:

<Sensitivity> AUTO | FIXEd

AUTO

Selects the optimum sensitivity automatically.

FIXed

Fixes the internal level detector.

*RST: AUTO

Example: POW:ALC:DSEN FIX

Manual operation: See ["Detector Sensitivity"](#) on page 234

[[:SOURce<hw>]:POWER:ALC:EDETector:FACTor <DetectorFact>

Sets the attenuation value of the RF coupler.

Parameters:

<DetectorFact> float
 Range: -200 to 200
 Increment: 0.01
 *RST: 16

Example: See [Example "Configure the settings for external ALC"](#) on page 740

Options: R&S SMAB-K726

Manual operation: See ["Detector Coupling Factor"](#) on page 235

[[:SOURce<hw>]:POWER:ALC:EDETector:LEVel <ReqGenLev>

Sets the maximum power level at the RF output required for compensating the external ALC coupler and cable losses.

Parameters:

<ReqGenLev> float
 Range: -145 to 40
 Increment: 0.01
 *RST: 20

Example: See [Example "Configure the settings for external ALC"](#) on page 740

Options: R&S SMAB-K726

Manual operation: See ["Required Generator Level"](#) on page 235

[[:SOURce<hw>]:POWER:ALC:SONCe

Activates level control for correction purposes temporarily.

Example: POW:ALC OFF
 Deactivates automatic level control at the RF output.
 POW:ALC:SONC
 Executes level control (once).

Usage: Event

Manual operation: See ["Readjust"](#) on page 74

[[:SOURce<hw>]:POWer:ATTenuation:PATTenuator <StepAttSel>

Selects the type of step attenuator used below 20 GHz.

Parameters:

<StepAttSel> MECHanical | ELECTronic

MECHanical

Uses the mechanical step attenuator at all frequencies.

ELECTronic

Uses the electronic step attenuator up to 20 GHz.

Options: R&S SMAB-B35/-B37/-B39, not available for R&S SMAB-B36S

Manual operation: See ["Step Attenuator below 20 GHz"](#) on page 230

[[:SOURce<hw>]:POWer:ATTenuation:RFOff:MODE <Mode>

Selects the state the attenuator is to assume if the RF signal is switched off.

Parameters:

<Mode> UNCHanged | FATTenuation

FATTenuation

The step attenuator switches to maximum attenuation

UNCHanged

Retains the current setting and keeps the output impedance constant during RF off.

*RST: n.a. (factory preset: FATTenuation)

Example:

SOURce1:POWer:ATTenuation:RFOff:MODE
FATTenuation

uses maximum attenuation when the RF output is turned off.

Manual operation: See ["RF OFF Mode"](#) on page 230

[[:SOURce<hw>]:POWer:EMF:STATe <State>

Displays the signal level as voltage of the EMF. The displayed value represents the voltage over a 50 Ohm load.

Parameters:

<State> 1 | ON | 0 | OFF

*RST: n.a. (factory preset: 0)

Example:

POW:EMF:STAT 1

Activates voltage level display.

Manual operation: See ["Display Level as Voltage of EMF"](#) on page 370

[:SOURce<hw>]:POWER:LBEHaviour <Behaviour>**Parameters:**

<Behaviour>

AUTO | UNINterrupted | MONotone | CVSWr | HDUN

UNINterrupted|MONotone

Uninterrupted level settings and strictly monotone modes.

CVSWr

Constant VSWR

HDUN

High dynamic uninterrupted level settings.

*RST: AUTO

Example:

SOURce1:POWER:LBEHaviour AUTO

Options:

R&S SMAB-K724

Manual operation:See ["Setting Characteristics"](#) on page 73

[:SOURce<hw>]:POWER:LIMit[:AMPLitude] <Amplitude>

Limits the maximum RF output level in CW and sweep mode.

It does not influence the "Level" display or the response to the query [:
SOURce<hw>]:POWER[:LEVel] [:IMMediate] [:AMPLitude].**Parameters:**

<Amplitude>

float

Range: depends on the installed options

Increment: 0.01

*RST: n.a. (factory preset: 30)

Example:

SOURce1:POWER:LIMit:AMPLitude 10

Manual operation:See ["Limit"](#) on page 72

[:SOURce<hw>]:POWER:MANual <Manual>Sets the level for the subsequent sweep step if [SWE:POW:MODE MAN](#).

Use a separate command for each sweep step.

Parameters:

<Manual>

float

You can select any level within the setting range, where:

START is set with [:SOURce<hw>]:POWER:START

STOP is set with [:SOURce<hw>]:POWER:STOP

OFFSet is set with [:SOURce<hw>]:POWER[:LEVel] [:
IMMediate]:OFFSet

Range: (START + OFFSet) to (STOP + OFFSet)

Increment: 0.01

Default unit: dBm

Example: See [Example "Setting up an RF frequency or power sweep"](#) on page 762

Manual operation: See ["Current Level"](#) on page 205

`[ :SOURce<hw>]:POWER:MODE <Mode>`

Selects the operating mode of the instrument to set the output level.

Parameters:

<Mode> CW | FIXed | SWEep

CW|FIXed

Operates at a constant level.

CW and FIXed are synonyms.

To set the output level value, use the command `[ :SOURce<hw>]:POWER[:LEVel][:IMMediate][:AMPLitude]`.

SWEep

Sets sweep mode.

Set the range and current level with the commands:

`[ :SOURce<hw>]:POWER:STARt` and `[ :SOURce<hw>]:POWER:STOP`,
`[ :SOURce<hw>]:POWER:MANual`.

*RST: CW

Example: See [Example "Setting up an RF frequency or power sweep"](#) on page 762

Manual operation: See ["State \(RF level sweep\)"](#) on page 205

`[ :SOURce<hw>]:POWER:POWER <Power>`

Sets the level **at the RF output** connector.

This value does not consider a specified offset.

The command `[ :SOURce<hw>]:POWER[:LEVel][:IMMediate][:AMPLitude]` sets the level of the "Level" display, that means the level containing offset.

See ["RF frequency and level display with a downstream instrument"](#) on page 62.

Parameters:

<Power> float

Level at the RF output, without level offset

Range: See specifications document.

Increment: 0.01

Default unit: dBm

Example: `SOURce1:POWER:POWER 15`
`// sets the level at the RF output.`

Manual operation: See ["Amplitude"](#) on page 71

[:SOURce<hw>]:POWER:START <Start>

[:SOURce<hw>]:POWER:STOP <Stop>

Sets the RF start/stop level in sweep mode.

Parameters:

<Stop> float

Sets the setting range calculated as follows:

(Level_min + OFFSet) to (Level_max + OFFSet)

Where the values are set with the commands:

[:SOURce<hw>]:POWER[:LEVel][:IMMediate]:OFFSet

[:SOURce<hw>]:POWER:START

[:SOURce<hw>]:POWER:STOP

Range: Minimum level to maximum level

*RST: -30 (Start)/ -10 (Stop)

Default unit: dBm

Example: See [Example "Setting up an RF frequency or power sweep"](#) on page 762

Manual operation: See ["Start Level / Stop Level"](#) on page 212

[:SOURce<hw>]:POWER:SPC:CRANge <PowCntrlCRange>

Defines the capture range of the power control system.

Within the range:

Target Level +/- Catch Range

the power control locks and tries to achieve the target level. Readings outside the range are not considered.

Parameters:

<PowCntrlCRange> float

Range: 0 to 50

Increment: 0.01

*RST: 30

Example: See [Example "Configure the settings for NRP power control"](#) on page 741

Manual operation: See ["Catch Range +/-"](#) on page 257

[:SOURce<hw>]:POWER:SPC:DELay <PowCntrlDelay>

Sets a waiting time for the generator to adjust the output level. After the delay time has elapsed, the power sensor measures the next value.

Parameters:

<PowCntrlDelay> integer

Range: 0 to 1000

*RST: 0

Example: See [Example "Configure the settings for NRP power control"](#) on page 741

Manual operation: See ["Delay Time"](#) on page 257

[:SOURce<hw>]:POWER:SPC:MEASure

Sets the measured power value as reference level.

Example: See [Example "Configure the settings for NRP power control"](#) on page 741

Usage: Event

Manual operation: See ["Take Measurement as Target Level"](#) on page 256

[:SOURce<hw>]:POWER:SPC:MODE <ControlMode>

Selects the measurement mode for the power sensor.

Parameters:

<ControlMode> AUTO | SINGLE

AUTO

Measures the level values continuously.

SINGLE

Executes one measurement, triggered by the command [\[:SOURce<hw>\]:POWER:SPC:SINGLE](#) on page 750.

*RST: AUTO

Example: See [Example "Configure the settings for NRP power control"](#) on page 741

Manual operation: See ["Mode"](#) on page 256

[:SOURce<hw>]:POWER:SPC:PEAK <PowCntrlPeak>

Activates power control by means of the peak power values, provided the power sensor supports this function.

Parameters:

<PowCntrlPeak> 1 | ON | 0 | OFF

*RST: 0

Example: See [Example "Configure the settings for NRP power control"](#) on page 741

[:SOURce<hw>]:POWER:SPC:SElect <PowCntrlSelect>

Selects the power sensor used for power control.

Parameters:

<PowCntrlSelect> SENS1 | SENS2 | SENS3 | SENS4 | SENSor1 | SENSor2 |
SENSor3 | SENSor4
*RST: SENS1

Example: See [Example "Configure the settings for NRP power control"](#) on page 741

Manual operation: See ["Sensor"](#) on page 256

[SOURce<hw>]:POWER:SPC:SINGLE

Triggers the power sensor to measure the power value once.

Usage: Event

Manual operation: See ["Execute Single"](#) on page 257

[SOURce<hw>]:POWER:SPC:STATE <PowCntrlState>

Starts power control using the selected sensor. The control loop periodically adjusts the output level of the signal generator. After switching off, the running loop is completed.

Parameters:

<PowCntrlState> 1 | ON | 0 | OFF
*RST: 0

Example: See [Example "Configure the settings for NRP power control"](#) on page 741

Manual operation: See ["State"](#) on page 255

[SOURce<hw>]:POWER:SPC:TARGET <PowCntrlTarget>

Sets the target level required at the DUT. To define the unit of the power value, use command [:UNIT:Power](#) on page 817.

Parameters:

<PowCntrlTarget> float
Range: -50 to 30
Increment: 0.01
*RST: -10

Example: See [Example "Configure the settings for NRP power control"](#) on page 741

Manual operation: See ["Target Level"](#) on page 256

[SOURce<hw>]:POWER:SPC:WARNing?

Queries if the activated power control works properly.

If the power control does not work, the query returns warning state 1. On the screen, the R&S SMA100B indicates a warning icon.

Return values:

<WarningState> 1 | ON | 0 | OFF
 *RST: 0

Example: See [Example "Configure the settings for NRP power control"](#) on page 741.

Usage: Query only

[:SOURce<hw>]:POWER:STEP:MODE <Mode>

Defines the type of step width to vary the RF output power step-by-step with the commands [POW UP](#) or [POW DOWN](#).

Parameters:

<Mode> DECimal | USER

DECimal

Increases or decreases the level in steps of ten.

USER

Increases or decreases the level in increments, determined with the command [\[:SOURce<hw>\]:POWER:STEP\[:INCRement\]](#).

*RST: DECimal

Example: See [Example "Configuring the RF output power"](#) on page 740.

Manual operation: See ["Variation Active"](#) on page 69

[:SOURce<hw>]:POWER:STEP[:INCRement] <Increment>

Specifies the step width in the appropriate path for [POW:STEP:MODE USER](#).

To adjust the level step-by-step with this increment value, use the command [POW UP](#), or [POW DOWN](#).

Note: The command also sets "Variation Step" in the manual control, that means the user-defined step width for setting the level with the rotary knob or the [Up/Down] arrow keys.

Parameters:

<Increment> float
 Range: 0 to 200
 Increment: 0.01
 *RST: 1
 Default unit: dB

Example: See [Example "Configuring the RF output power"](#) on page 740.

Manual operation: See ["Variation Step"](#) on page 70

[:SOURce<hw>]:POWer[:LEVel][:IMMediate]:OFFSet <Offset>

Sets the level offset of a downstream instrument.

The level at the RF output is not changed.

To query the resulting level, as it is at the output of the downstream instrument, use the command `[ :SOURce<hw>]:POWer[:LEVel][:IMMediate][:AMPLitude]`.

See ["RF frequency and level display with a downstream instrument"](#) on page 62.

Note: The level offset also affects the RF level sweep.

Parameters:

<Offset> float
 Range: -100 to 100
 Increment: 0.01
 *RST: 0
 Default unit: dB
 Level offset is always expreced in dB; linear units (V, W, etc.) are not supported

Example: POWer:OFFSet 10
 Sets the RF level offset to 10 dB

Manual operation: See ["Offset"](#) on page 72

[:SOURce<hw>]:POWer[:LEVel][:IMMediate]:RCL <Rcl>

Determines whether the current level is retained or if the stored level setting is adopted when an instrument configuration is loaded.

Parameters:

<Rcl> INCLude | EXCLude
 INCLude
 Takes the current level when an instrument configuration is loaded.
 EXCLude
 Retains the current level when an instrument configuration is loaded.
 *RST: INCLude

Example: POW:RCL INCL
 Takes the level value from an instrument configuration loaded with command [*RCL](#).

Manual operation: See ["Exclude Level"](#) on page 344

[:SOURce<hw>]:POWer[:LEVel][:IMMediate][:AMPLitude] <Amplitude>

Sets the RF level applied to the DUT.

To activate the RF output use command `:OUTPut<hw>[:STATe]` ("RF On"/"RF Off").

The following applies $\text{POWer} = \text{RF output level} + \text{OFFSet}$, where:

- POWer is the values set with `[ :SOURce<hw> ] :POWer [ :LEVel ] [ :IMMediate ] [ :AMPLitude ]`
- RF output level is set with `[ :SOURce<hw> ] :POWer :POWer` on page 747
- OFFSet is set with `[ :SOURce<hw> ] :POWer [ :LEVel ] [ :IMMediate ] :OFFSet`

Parameters:

<Amplitude>

float

The following settings influence the value range:

OFFSet set with the command `[ :SOURce<hw> ] :POWer [ :LEVel ] [ :IMMediate ] :OFFSet`

Numerical value

Sets the level

UP|DOWN

Varies the level step by step.

The level is increased or decreased by the value set with the command `[ :SOURce<hw> ] :POWer :STEP [ :INCRement ]`.

Range: (Level_min + OFFSet) to (Level_max + OFFSet)

*RST: -30

Default unit: dBm

Example:

`POWer -30`

Sets the RF level

Example:

See also `[ :SOURce<hw> ] :POWer :STEP :MODE` on page 751.

Manual operation:

See "Amplitude" on page 71

`[ :SOURce<hw> ] :POWer [ :LEVel ] [ :IMMediate ] :REFLevel <ReferenceLevel>`

Queries the reference level of the user correction.

The reference level is the sum of the amplitude and the level offset, set with the commands `[ :SOURce<hw> ] :POWer :POWer` `[ :SOURce<hw> ] :POWer [ :LEVel ] [ :IMMediate ] :OFFSet`.

Parameters:

<ReferenceLevel>

float

Range: -245 to 120

Increment: 0.01

*RST: -30

Manual operation:

See "Generator Settings used for Measurement" on page 246

`[ :SOURce<hw> ] :POWer :RANGe :LOWer?`

`[ :SOURce<hw> ] :POWer :RANGe :UPPer?`

Queries the current interruption-free range of the level.

Return values:

<Upper> float
 Increment: 0.01
 Default unit: dBm

Example:

```
SOURce1:POWer:RANge:UPPer?
// -15
SOURce1:POWer:RANge:LOW?
// -50
```

Usage: Query only

Manual operation: See ["Level Range"](#) on page 74

[[:SOURce<hw>]:POWer:RANge:MIN?

[[:SOURce<hw>]:POWer:RANge:MAX?

Queries the current power range of the level sweep.

Return values:

<PowRangeMax> float
 Range: depends on settings
 Increment: 0.01
 *RST: -10
 Default unit: dBm

Example:

```
SOURce1:POWer:RANge:MIN?
// -90
SOURce1:POWer:RANge:MAX?
// 8
```

Usage: Query only

Manual operation: See ["Sweep Level Range"](#) on page 214

[[:SOURce]:POWer:WIGNore <State>

Ignores level range warnings.

Parameters:

<State> 1 | ON | 0 | OFF
 *RST: n.a. (factory preset: 0)

Example:

```
SOURce:POWer:WIGNore 1
```

15.18.13 SOURce:ROSCillator subsystem

The SOURce:ROSCillator subsystem contains the commands for setting the external and internal reference frequency.

Example: Configuring the reference oscillator

```
// Using 100 MHz external reference source
SOURce:ROSCillator:PRESet
SOURce:ROSCillator:SOURce EXT
SOURce:ROSCillator:EXTErnal:RFOFF:STATe 1
SOURce:ROSCillator:EXTErnal:FREQuency 100MHZ
SOURce:ROSCillator:EXTErnal:SBANDwidth WIDE
// 100 MHz (loop through) and 1 GHz output
SOURce:ROSCillator:OUTPut:FREQuency:MODE LOOP
SOURce:ROSCillator:OUTPut:ALTErnate:FREQuency:MODE DER1G
SOURce:ROSCillator:INTernAl:ADJust:STATe 0

// Variable external reference frequency
// SOURce:ROSCillator:EXTErnal:FREQuency VAR
// SOURce:ROSCillator:EXTErnal:FREQuency:VARIable 100000000

// Using the internal reference frequency
SOURce:ROSCillator:SOURce INT
SOURce:ROSCillator:INTernAl:TUNing:STATe 1
SOURce:ROSCillator:INTernAl:TUNing:SLOPe LOW
// 10 MHz and 1 GHz output
SOURce:ROSCillator:OUTPut:FREQuency:MODE DER10M
SOURce:ROSCillator:OUTPut:ALTErnate:FREQuency:MODE DER1G

// Query calibration value
CALibration:ROSCillator?
// 32767
// Set an internal source
// Activate user-defined adjustment value of 1000
SOURce:ROSCillator:SOURce INT
SOURce:ROSCillator:INTernAl:ADJust:STATe 1
SOURce:ROSCillator:INTernAl:ADJust:VALue 1000

// query calibration value
CALibration:ROSCillator:DATA?
// 32767
// change the calibration value
CALibration:ROSCillator:DATA 20000
SOURce:ROSCillator:INTernAl:ADJust:VALue?
// 13767
// i.e. CalValue_Def - CalValue_User = 32767 - 20000 = 13767

SOURce:ROSCillator:INTernAl:ADJust:VALue 0
CALibration:ROSCillator:DATA?
// 20000
// user-defined adjustment value is 0
// i.e. user-defined adjustment is activated
// but the calibration value is used
// and the calibration value is the user-defined value
*RST
SOURce:ROSCillator:INTernAl:ADJust:VALue?
```

```
// -12767
// user-defined adjustment value is not affected by preset
// the adjustment value is calculated as
// - (CalValue_Def - CalValue_User - AdjValue_User)
CALibration:ROSCillator:DATA?
// 32767
// calibration value is preset

// to resume calibrated state
SOURce:ROSCillator:INTernal:ADJust:VALue 0
SOURce:ROSCillator:INTernal:ADJust:STATe 0
// or
// SYSTem:FPreSt
```

[SOURce]:ROSCillator:PRESet.....	756
[SOURce]:ROSCillator:SOURce.....	756
[SOURce]:ROSCillator:INTernal:TUNing[:STATe].....	757
[SOURce]:ROSCillator:INTernal:TUNing:SLOPe.....	757
[SOURce]:ROSCillator:EXTernal:RFOFF[:STATe].....	757
[SOURce]:ROSCillator:EXTernal:FREQuency.....	757
[SOURce]:ROSCillator:EXTernal:FREQuency:VARiable.....	758
[SOURce]:ROSCillator:EXTernal:SBANdwidth.....	758
[SOURce]:ROSCillator:EXTernal:MLRange?.....	758
[SOURce]:ROSCillator:EXTernal:NSBandwidth?.....	759
[SOURce]:ROSCillator:OUTPut:FREQuency:MODE.....	759
[SOURce]:ROSCillator:OUTPut:ALternate:FREQuency:MODE.....	759
[SOURce]:ROSCillator[:INTernal]:ADJust:VALue.....	760
[SOURce]:ROSCillator[:INTernal]:ADJust[:STATe].....	760

[SOURce]:ROSCillator:PRESet

Resets the reference oscillator settings.

Example: See [Example "Configuring the reference oscillator"](#) on page 755.

Usage: Event

Manual operation: See ["Set to Default"](#) on page 319

[SOURce]:ROSCillator:SOURce <Source>

Selects between internal or external reference frequency.

Parameters:

<Source> INTernal | EXTernal
 *RST: n.a. (factory preset: INTernal)

Example: See [Example "Configuring the reference oscillator"](#) on page 755.

Manual operation: See ["Source"](#) on page 319

[[:SOURce]:ROSCillator:INTernal:TUNing[:STATe] <State>

Activates the EFC (external frequency control).

Parameters:

<State> 1 | ON | 0 | OFF

*RST: n.a. (factory preset: 1)

Example: See [Example "Configuring the reference oscillator"](#) on page 755.

Manual operation: See ["External Tuning Active"](#) on page 321

[[:SOURce]:ROSCillator:INTernal:TUNing:SLOPe <State>

Sets the sensitivity of the external tuning volatge.

Parameters:

<State> LOW | HIGH

*RST: n.a. (factory preset: LOW)

Example: See [Example "Configuring the reference oscillator"](#) on page 755.

Manual operation: See ["External Tuning Slope"](#) on page 321

[[:SOURce]:ROSCillator:EXTernal:RFOFF[:STATe] <State>

Determines that the RF output is turned off when the external reference signal is selected, but missing.

Parameters:

<State> 1 | ON | 0 | OFF

*RST: n.a. (factory preset: 0)

Example: See [Example "Configuring the reference oscillator"](#) on page 755.

Manual operation: See ["Deactivate RF Output \(if external reference is missing\)"](#) on page 319

[[:SOURce]:ROSCillator:EXTernal:FREQuency <Frequency>

Sets the frequency of the external reference.

Parameters:

<Frequency> 100MHZ | 1GHZ | VARiable | 10MHZ

*RST: n.a. (factory preset: 10MHZ)

Example: See [Example "Configuring the reference oscillator"](#) on page 755.

Options: VARiable requires R&S SMAB-K704
100MHZ|1GHZ require R&S SMAB-K703

Manual operation: See ["External Reference Frequency"](#) on page 319

[[:SOURce]:ROSCillator:EXTernal:FREQuency:VARiable <Frequency>

Specifies the user-defined external reference frequency.

Parameters:

<Frequency>	float
Range:	1E6 to 100E6
Increment:	0.1
*RST:	n.a. (factory preset: 1E7)
Default unit:	Hz

Example: See [Example "Configuring the reference oscillator"](#) on page 755.

Options: R&S SMAB-K704

Manual operation: See ["Variable Reference Frequency"](#) on page 320

[[:SOURce]:ROSCillator:EXTernal:SBANDwidth <SBandwidth>

Selects the synchronization bandwidth for the external reference signal.

Depending on the RF hardware version and the installed options, the synchronization bandwidth varies.

For more information, refer to the specifications document.

Parameters:

<SBandwidth>	WIDE NARRow
NARRow	The synchronization bandwidth is a few Hz.
WIDE	Uses the widest possible synchronization bandwidth.
*RST:	n.a. (factory preset: WIDE)

Example: See [Example "Configuring the reference oscillator"](#) on page 755.

Manual operation: See ["Synchronization Bandwidth"](#) on page 320

[[:SOURce]:ROSCillator:EXTernal:MLRange?

Queries the minimum locking range for the selected external reference frequency.

Depending on the RF hardware version, and the installed options, the minimum locking range varies.

For more information, refer to the specifications document.

Return values:

<MinLockRange>	string
----------------	--------

Example: SOUR:ROSC:EXT:MLR?

Usage: Query only

Manual operation: See ["Minimum Locking Range"](#) on page 320

[[:SOURce]:ROSCillator:EXTernal:NSBandwidth?

Queries the nominal synchronization bandwidth for the selected external reference frequency and synchronization bandwidth.

Return values:

<NomBandwidth> string

Example: SOUR:ROSC:EXT:NSB?

Usage: Query only

Manual operation: See ["Nominal Synchronization Bandwidth"](#) on page 320

[[:SOURce]:ROSCillator:OUTPut:FREQuency:MODE <OutpFreqMode>

Sets the output reference frequency.

Parameters:

<OutpFreqMode> DER10M | DER100M | OFF | LOOPthrough

OFF

Disables the output.

DER10M|DER100M

Sets the output reference frequency to 10 MHz or 100 MHz.

The reference frequency is derived from the internal reference frequency.

LOOPthrough

This option is unavailable for

ROSCillator:EXTernal:FREQuency 1GHZ. Forwards the input reference frequency to the reference frequency output.

*RST: n.a. (factory preset: DER10M)

Example: See [Example "Configuring the reference oscillator"](#) on page 755.

Manual operation: See ["Reference Output/1 GHz Reference Output"](#) on page 321

[[:SOURce]:ROSCillator:OUTPut:ALTernate:FREQuency:MODE <OutpFreqMode>

Sets the output reference frequency.

Parameters:

<OutpFreqMode> LOOPthrough | DER1G | OFF

OFF

Disables the output.

DER1G

Sets the output reference frequency to 1 GHz.

The reference frequency is derived from the internal reference frequency.

LOOPthrough

If [:SOURce]:ROSCillator:EXternal:FREQuency 1GHZ, forwards the input reference frequency to the reference frequency output.

*RST: n.a. (factory preset: OFF)

Example: See [Example "Configuring the reference oscillator"](#) on page 755.

Manual operation: See ["Reference Output/1 GHz Reference Output"](#) on page 321

[:SOURce]:ROSCillator[:INTernal]:ADJust:VALue <Value>

Specifies the frequency correction value (adjustment value).

Parameters:

<Value> integer

*RST: 0

Example: See [:SOURce]:ROSCillator[:INTernal]:ADJust[:STATe] on page 760

Manual operation: See ["Adjustment Value"](#) on page 322

[:SOURce]:ROSCillator[:INTernal]:ADJust[:STATe] <State>

Determines whether the calibrated (off) or a user-defined (on) **adjustment value** is used for fine adjustment of the frequency.

Parameters:

<State> 1 | ON | 0 | OFF

0

Fine adjustment with the calibrated frequency value

1

User-defined adjustment value.

The instrument is no longer in the calibrated state.

The calibration value is, however, not changed. The instrument resumes the calibrated state if you send

SOURce:ROSCillator:INTernal:ADJust:STATe 0.

*RST: n.a. (factory preset: 0)

Example: See [Example "Configuring the reference oscillator"](#) on page 755.

Manual operation: See ["Adjustment Active"](#) on page 322

15.18.14 SOURce:SWEep subsystem

The SOURce:SWEep subsystem contains the commands for configuring RF sweep signals.



- The keyword [:FREQuency] can be omitted, then the commands are SCPI-compliant.
- To activate an RF sweep mode, use the following commands:
 - RF frequency sweep: `SOURce:FREQuency:MODE SWEEp`
(`SOURce:FREQuency:MODE CW (off)`)
 - RF level sweep: `SOURce:POWer:MODE SWEEp` (`SOURce:POWer:MODE CW (off)`)
 - RF combined sweep: `SOURce:FREQuency:MODE SWEEp`
(`SOURce:FREQuency:MODE CW (off)`)
- All sweeps, including the LF sweep, can be set independently of each other.
- All sweeps can be set independently of each other.

See [Section 8.1, "Signal generation and triggering in the sweep and list modes"](#), on page 189.

Example: Setting up an RF frequency or power sweep

The following example shows a command sequence to set up an RF frequency sweep, triggered by the execute command. For an RF power sweep, replace `FREQuency` in the `SWEep` commands with `POWeR`.

Exceptions are the power spacing (defined with `LINEar` only) and the power step width (defined with `LOGarithmic` only).

```
// Reset the instrument to start from an initial state
// Switch off display update to improve performance
// (especially with short dwell times)
// Set the sweep mode (first two commands) and the sweep range
// Select linear spacing
// Select the waveform shape for the frequency sweep
*RST; *CLS
SYSTem:DISPlay:UPDate OFF
// Select sweep mode
SOURce:FREquency:MODE SWEep

TRIGger1:FSWep:SOURce SINGLE
SOURcel:SWEep:FREQuency:MODE AUTO
SOURcel:FREQuency:SPAN 300 MHz
SOURcel:FREQuency:CENTer 200 MHz
// Alternatively use
// SOURcel:FREQuency:STARt 50 MHz
// SOURcel:FREQuency:STOP 350 MHz
SOURcel:SWEep:FREQuency:SPACing LINEar
SOURcel:SWEep:FREQuency:SHAPE SAWTooth

// Initiate an LF frequency sweep
TRIGger1:FSWep:SOURce SINGLE
SOURcel:SWEep:FREQuency:MODE AUTO
TRIGger:LFFSweep

// Activate change to start frequency while waiting for next trigger
// Prerequisites: sweep mode single and sweep waveform sawtooth
SOURcel:SWEep:FREQuency:RETRace 1
// Alternatively reset all sweeps to their initial value
SOURcel:SWEep:RESet:ALL

// Set the step width and dwell time
SOURcel:SWEep:FREQuency:STEP:LINEar 1 MHz
// Alternatively set the number of steps, then the sweep step width is
// set automatically
SOURcel:SWEep:FREQuency:POINts 301
SOURcel:SWEep:FREQuency:DWELl 500 ms
// With logarithmic spacing select the step width as follows
// (steps of 10 percent of the previous frequency in each instance)
SOURcel:SWEep:FREQuency:SPACing LOG
SOURcel:SWEep:FREQuency:STEP:LOGarithmic 10PCT
```

```

// Activate the sweep
// Trigger the sweep (depending on the set mode) and query the status
SOURcel:FREQuency:MODE SWEep
// Perform a one-off RF frequency sweep
SOURcel:SWEep:FREQuency:EXECute
SOURcel:SWEep:FREQuency:RUNning?
// 1
// the frequency sweep is running

// For manual step RF sweep use the following commands
*RST; *CLS
// Set the frequency range
SOURcel:FREQuency:STARt 50 MHz
SOURcel:FREQuency:STOP 350 MHz
SOURcel:FREQuency:MANual 30 MHz
// Activate manual step RF sweep
SOURcel:SWEep:FREQuency:MODE MANual
// Activate the RF frequency sweep.
SOURcel:FREQuency:MODE SWEep
// Activate RF Output1.
Output1:STATe 1
// Set the frequency manually for each step
SOURcel:FREQuency:MANual 200 MHz
SOURcel:FREQuency:MANual 201 MHz
// Alternatively use the UP or DOWN commands with the set step width.
SOURcel:SWEep:FREQuency:STEP:LINear 1 MHz
SOURcel:FREQuency:MANual UP

// Trigger an enabled sweep immediately
TRIGger1:FSWeep:SOURce SINGLE
SOURcel:SWEep:FREQuency:MODE AUTO
TRIGger<hw>[:SWEep][:IMMediate]

// Query the interruption-free level range
SOURcel:POWer:RANGe:LOWer?
// Response: -50
SOURcel:POWer:RANGe:UPPer?
// Response: -15

// Activate a combined RF frequency / level sweep
*RST; *CLS
*RST; *CLS
SYSTem:DISPlay:UPDate OFF
TRIGger1:FSWeep:SOURce SINGLE
SOURcel:SWEep:COMBined:MODE AUTO
SOURcel:SWEep:COMBined:COUNT 200
SOURcel:FREQuency:STARt 1000000000 Hz
SOURcel:FREQuency:STOP 5000000000 Hz

```

```

SOURcel:POWer:STARt -30 dBm
SOURcel:POWer:STOP -10 dBm
SOURcel:SWEep:COMBined:RETRace 1
SOURcel:SWEep:COMBined:SHApe SAWT
SOURcel:SWEep:COMBined:DWELL 0.01
// Activate combined RF frequency/level sweep
SOURcel:FREQuency:MODE COMB
// Activate RF Output1.
Output1:STATe 1
// Execute combined frequency / level sweep
SOURcel:SWEep:COMBined:EXECute

// Configure an RF frequency ramp sweep
// Select a continuous analog frequency sweep,
// synchronized with the sweep time, repeating automatically
// set start and stop frequency
SOURcel:SWEep:GENeration ANAL
// TRIGger1:FSweep:SOURce AUTO
SOURcel:SWEep:FREQuency:MODE AUTO
SOURcel:SWEep:FREQuency:MODE:ADVanced AUTO
INITiatel:FSweep:CONTinuous 1
SOURcel:FSweep:TRIGger:SOURce:ADVanced IMM
// TRIGger1:FSweep:SOURce:ADVanced IMM
SOURcel:SWEep:FREQuency:STARt 100000000
SOURcel:SWEep:FREQuency:STOP 500000000
SOURcel:SWEep:FREQuency:CENter 300000000
SOURcel:SWEep:FREQuency:SPAN 400000000
SOURcel:SWEep:FREQuency:TIME 0.015
SOURcel:SWEep:FREQuency:SHApe SAWT
SOURcel:FREQuency:MODE SWE
// Activate RF Output1.
Output1:STATe 1

// Query blanked frequency points
SOURcel:SWEep:FREQuency:ANALog:SWPoints?
// 8500,10000,12000,17000,100000,1000000,8000000,12500000,
// ...,75000000000,80000000000,150000000000,300000000000

```

:SWEep:TYPE.....	765
[SOURce<hw>]:SWEep:POWer:DWELL.....	765
[SOURce<hw>]:SWEep:GENeration.....	766
[SOURce<hw>]:SWEep:POWer:MODE.....	766
[SOURce<hw>]:SWEep:POWer:POINts.....	766
[SOURce<hw>]:SWEep:POWer:SPACing:MODE?.....	767
[SOURce<hw>]:SWEep:POWer:STEP[:LOGarithmic].....	767
[SOURce<hw>]:SWEep[:FREQuency]:ANALog:SWPoints?.....	767
[SOURce<hw>]:SWEep[:FREQuency]:DWELL.....	768
[SOURce<hw>]:SWEep[:FREQuency]:MODE.....	768
[SOURce<hw>]:SWEep[:FREQuency]:POINts.....	768
[SOURce<hw>]:SWEep[:FREQuency]:SPACing.....	769

[:SOURce<hw>]:SWEep:POWer:SHApe.....	769
[:SOURce<hw>]:SWEep[:FREQuency]:SHApe.....	769
[:SOURce<hw>]:SWEep:POWer:EXECute.....	769
[:SOURce<hw>]:SWEep[:FREQuency]:EXECute.....	769
[:SOURce<hw>]:SWEep:POWer:RETRace.....	770
[:SOURce<hw>]:SWEep[:FREQuency]:RETRace.....	770
[:SOURce<hw>]:SWEep:POWer:RUNNing?.....	770
[:SOURce<hw>]:SWEep[:FREQuency]:RUNNing?.....	770
[:SOURce<hw>]:SWEep[:FREQuency]:STEP:LOGarithmic.....	770
[:SOURce<hw>]:SWEep[:FREQuency]:STEP[:LINear].....	771
[:SOURce<hw>]:COMBined:FREQuency:START.....	771
[:SOURce<hw>]:COMBined:FREQuency:STOP.....	771
[:SOURce<hw>]:COMBined:POWer:START.....	771
[:SOURce<hw>]:COMBined:POWer:STOP.....	772
[:SOURce<hw>]:SWEep:COMBined:COUNt.....	772
[:SOURce<hw>]:SWEep:COMBined:DWELl.....	772
[:SOURce<hw>]:SWEep:COMBined:EXECute.....	773
[:SOURce<hw>]:SWEep:COMBined:MODE.....	773
[:SOURce<hw>]:SWEep:COMBined:RETRace.....	774
[:SOURce<hw>]:SWEep:COMBined:SHApe.....	774
[:SOURce<hw>]:SWEep:RESet[:ALL].....	774
[:SOURce<hw>]:SWEep[:FREQuency]:TIME.....	774
[:SOURce<hw>]:SWEep:MARKer:OUTPut:POLarity.....	775
[:SOURce<hw>]:SWEep[:FREQuency]:MARKer:ACTive.....	775
[:SOURce<hw>]:SWEep[:FREQuency]:MARKer<ch>:FREQuency.....	775
[:SOURce<hw>]:SWEep[:FREQuency]:MARKer<ch>:FState.....	776

:SWEep:TYPE <SweepType>

Provided for compatibility between SCPI and Rohde & Schwarz commands.

Parameters:

<SweepType>	ADVanced STANdard
*RST:	n.a. (factory preset: STANdard)

[:SOURce<hw>]:SWEep:POWer:DWELl <Dwell>

Sets the dwell time for a level sweep step.

Parameters:

<Dwell>	float
Range:	0.001 to 100
Increment:	100E-6
*RST:	0.01

Example: See [Example "Setting up an RF frequency or power sweep"](#) on page 762.

Manual operation: See ["Dwell Time"](#) on page 208

[:SOURce<hw>]:SWEep:GENeration <SweepType>

Selects frequency sweep type.

Parameters:

<SweepType> STEPped | ANALog

STEPped

Performs a frequency sweep.

ANALog

Performs a continuous analog frequency sweep (ramp), synchronized with the sweep time [:SOURce<hw>]:SWEep[:FREQuency]:TIME.

*RST: STEPped

Example: See [Example "Setting up an RF frequency or power sweep"](#) on page 762.

Manual operation: See ["Sweep Type"](#) on page 204

[:SOURce<hw>]:SWEep:POWer:MODE <Mode>

Sets the cycle mode for the level sweep.

Parameters:

<Mode> AUTO | MANual | STEP

AUTO

Each trigger triggers exactly one complete sweep.

MANual

The trigger system is not active. You can trigger every step individually with the command [:SOURce<hw>]:POWer:MANual. The level value increases at each step by the value that you define with [:SOURce<hw>]:POWer:STEP[:INCRement]. Values directly entered with the command [:SOURce<hw>]:POWer:MANual are not taken into account.

STEP

Each trigger triggers one sweep step only. The level increases by the value entered with [:SOURce<hw>]:POWer:STEP[:INCRement].

*RST: AUTO

Example: See [Example "Setting up an RF frequency or power sweep"](#) on page 762.

Manual operation: See ["Mode"](#) on page 205

[:SOURce<hw>]:SWEep:POWer:POINts <Points>

Sets the number of steps within the RF level sweep range.

Parameters:

<Points> integer
Range: 2 to Max

Example: See [Example "Setting up an RF frequency or power sweep"](#) on page 762.

[[:SOURce<hw>]:SWEep:POWer:SPACing:MODE?

Queries the level sweep spacing. The sweep spacing for level sweeps is always linear.

Return values:

<Mode> LINear
*RST: LINear

Example: SWE:POW:SPAC:MODE?
queries the sweep spacing for a level sweep at RF output.
Result: "LIN"
linear spacing

Usage: Query only

[[:SOURce<hw>]:SWEep:POWer:STEP[:LOGarithmic] <Logarithmic>

Sets a logarithmically determined step size for the RF level sweep. The level is increased by a logarithmically calculated fraction of the current level.

Parameters:

<Logarithmic> float
The unit dB is mandatory.
Range: 0.01 to 139
Increment: 0.01
*RST: 1
Default unit: dB

Example: See [Example "Setting up an RF frequency or power sweep"](#) on page 762.

Manual operation: See ["Step"](#) on page 213

[[:SOURce<hw>]:SWEep[:FREQuency]:ANALog:SWPoints?

Queries blank points during the RF frequency sweep in ramp sweep mode.

At certain switchover frequency points, the R&S SMA100B shortly blanks the RF signal to adjust the settings accordingly.

This query returns all blanked frequency points within the entire frequency range, regardless of the set frequency sweep range.

Example: See [Example "Setting up an RF frequency or power sweep"](#) on page 762.

Usage: Query only

[:SOURce<hw>]:SWEep[:FREQuency]:DWELI <Dwell>

Sets the dwell time for a frequency sweep step.

Parameters:

<Dwell> float
 Range: 0.001 to 100
 Increment: 100E-6
 *RST: 0.01

Example: See [Example "Setting up an RF frequency or power sweep"](#) on page 762.

Manual operation: See ["Dwell Time"](#) on page 208

[:SOURce<hw>]:SWEep[:FREQuency]:MODE <Mode>

Sets the cycle mode for the frequency sweep.

Parameters:

<Mode> AUTO | MANual | STEP

AUTO

Each trigger event triggers exactly one complete sweep.

MANual

The trigger system is not active. You can trigger every step individually by input of the frequencies with the command [:SOURce<hw>]:FREQuency:MANual.

STEP

Each trigger event triggers one sweep step. The frequency increases by the value entered with [:SOURce<hw>]:SWEep[:FREQuency]:STEP[:LINear] (linear spacing) or [:SOURce<hw>]:SWEep[:FREQuency]:STEP:LOGarithmic (logarithmic spacing).

*RST: AUTO

Example: See [Example "Setting up an RF frequency or power sweep"](#) on page 762.

Manual operation: See ["Mode"](#) on page 205

[:SOURce<hw>]:SWEep[:FREQuency]:POINTs <Points>

Sets the number of steps within the RF frequency sweep range.

Two separate POINTs values are used for linear or logarithmic sweep spacing. This command always affects the currently set sweep spacing that you can set via the following command:

:SOURce<hw>:SWEep:FREQuency:SPACing LINear|LOGarithmic

Parameters:

<Points> integer
Range: 2 to Max

Example: See [Example "Setting up an RF frequency or power sweep"](#) on page 762.

[:SOURce<hw>]:SWEep[:FREQuency]:SPACing <Spacing>

Selects the mode for the calculation of the frequency intervals, with which the current frequency at each step is increased or decreased.

The keyword [:FREQuency] can be omitted; then the command is SCPI-compliant.

Parameters:

<Spacing> LINear | LOGarithmic

LINear

Sets a fixed frequency value as step width and adds it to the current frequency.

The linear step width is entered in Hz, see [:SOURce<hw>]:SWEep[:FREQuency]:STEP[:LINear].

LOGarithmic

Sets a constant fraction of the current frequency as step width and adds it to the current frequency.

The logarithmic step width is entered in %, see [:SOURce<hw>]:SWEep[:FREQuency]:STEP:LOGarithmic.

*RST: LINear

Example: See [Example "Setting up an RF frequency or power sweep"](#) on page 762.

Manual operation: See ["Spacing"](#) on page 208

[:SOURce<hw>]:SWEep:POWER:SHAPE <Shape>

[:SOURce<hw>]:SWEep[:FREQuency]:SHAPE <Shape>

Determines the waveform shape for a frequency sweep sequence.

Parameters:

<Shape> SAWTooth | TRIangle
*RST: SAWTooth

Example: See [Example "Setting up an RF frequency or power sweep"](#) on page 762.

Manual operation: See ["Shape"](#) on page 207

[:SOURce<hw>]:SWEep:POWER:EXECute

[:SOURce<hw>]:SWEep[:FREQuency]:EXECute

Executes an RF frequency sweep.

The command performs a single sweep and is therefore only effective in manual sweep mode.

Example: See [Example "Setting up an RF frequency or power sweep"](#) on page 762.

Usage: Event

Manual operation: See ["Execute Single Sweep"](#) on page 209

[:SOURce<hw>]:SWEep:POWer:RETRace <State>

[:SOURce<hw>]:SWEep[:FREQuency]:RETRace <State>

Activates that the signal changes to the start frequency value while it is waiting for the next trigger event.

You can enable this feature, when you are working with sawtooth shapes in sweep mode "Single" or "External Single".

Parameters:

<State> 1 | ON | 0 | OFF
*RST: 0

Example: See [Example "Setting up an RF frequency or power sweep"](#) on page 762.

Manual operation: See ["Retrace"](#) on page 206

[:SOURce<hw>]:SWEep:POWer:RUNNing?

[:SOURce<hw>]:SWEep[:FREQuency]:RUNNing?

Queries the current sweep state.

Return values:

<State> 1 | ON | 0 | OFF

Example: See [Example "Setting up an RF frequency or power sweep"](#) on page 762.

Usage: Query only

[:SOURce<hw>]:SWEep[:FREQuency]:STEP:LOGarithmic <Logarithmic>

Sets a logarithmically determined step width for the RF frequency sweep. The value is added at each sweep step to the current frequency.

Parameters:

<Logarithmic> float
The unit is mandatory.
Range: 0.01 to 100
Increment: 1E-3
*RST: 1
Default unit: PCT

Example: See [Example "Setting up an RF frequency or power sweep"](#) on page 762.

Manual operation: See ["Step Linear/Step Logarithmic"](#) on page 211

[[:SOURce<hw>]:SWEep[:FREQUENCY]:STEP[:LINear] <Linear>

Sets the step width for linear sweeps.

Parameters:

<Linear> float
 Range: 0.001 Hz to (STOP - START)
 Increment: 0.01

Example: See [Example "Setting up an RF frequency or power sweep"](#) on page 762.

Manual operation: See ["Step Linear/Step Logarithmic"](#) on page 211

[[:SOURce<hw>]:COMBined:FREQUENCY:START <CombFreqStart>

Sets the start frequency of the combined RF sweep.

Parameters:

<CombFreqStart> float
 Range: -59999E5 to 12E9
 Increment: 0.01
 *RST: 100E6

Example: See [Example "Setting up an RF frequency or power sweep"](#) on page 762.

Manual operation: See ["Start Frequency/Stop Frequency"](#) on page 210

[[:SOURce<hw>]:COMBined:FREQUENCY:STOP <CombFreqStop>

Sets the end frequency of the combined RF frequency / level sweep.

Parameters:

<CombFreqStop> float
 Range: -59999E5 to 12E9
 Increment: 0.01
 *RST: 500E6

Example: See [Example "Setting up an RF frequency or power sweep"](#) on page 762.

Manual operation: See ["Start Frequency/Stop Frequency"](#) on page 210

[[:SOURce<hw>]:COMBined:POWER:START <CombPowStart>

Sets the start level value of the combined RF sweep.

Parameters:

<CombPowStart> float
 Range: -245 to 120
 Increment: 0.01
 *RST: -30

Example: See [Example "Setting up an RF frequency or power sweep"](#) on page 762.

Manual operation: See ["Start Level / Stop Level"](#) on page 212

[:SOURce<hw>]:COMBined:POWER:STOP <CombPowStop>

Sets the stop level value of the combined RF frequency / level sweep.

Parameters:

<CombPowStop> float
 Range: -245 to 120
 Increment: 0.01
 *RST: -10

Example: See [Example "Setting up an RF frequency or power sweep"](#) on page 762.

Manual operation: See ["Start Level / Stop Level"](#) on page 212

[:SOURce<hw>]:SWEep:COMBined:COUNT <StepCount>

Defines the number of sweeps you want to execute.

This parameter applies to `[ :SOURce<hw>]:SWEep:COMBined:MODE > SINGLE`. To start the sweep signal generation, use the command `[ :SOURce<hw>]:SWEep:COMBined:EXECute` on page 773.

Parameters:

<StepCount> integer
 Range: 1 to SeMAX_INT_STEP-1
 *RST: 501

Example: See [Example "Setting up an RF frequency or power sweep"](#) on page 762.

Manual operation: See ["Step Count"](#) on page 213

[:SOURce<hw>]:SWEep:COMBined:DWELL <Dwell>

Sets the dwell time for the combined frequency / level sweep.

Parameters:

<Dwell> float
 Range: 0.01 to 100
 Increment: 100E-6
 *RST: 0.01

Example: See [Example "Setting up an RF frequency or power sweep"](#) on page 762.

Manual operation: See ["Dwell Time"](#) on page 208

[:SOURce<hw>]:SWEep:COMBined:EXECute

Executes an RF frequency / level sweep cycle.

The command triggers one single sweep manually. Therefore, you can use it in manual sweep mode, selected with the command [\[:SOURce<hw>\]:SWEep:COMBined:MODE > MANual](#).

Example: See [Example "Setting up an RF frequency or power sweep"](#) on page 762.

Usage: Event

Manual operation: See ["Execute Single Sweep"](#) on page 209

[:SOURce<hw>]:SWEep:COMBined:MODE <SweepCombMode>

Sets the cycle mode for the combined frequency / level sweep.

Parameters:

<SweepCombMode> AUTO | MANual | STEP

AUTO

Each trigger event triggers exactly one complete sweep.

MANual

The trigger system is not active. You can trigger every step individually by input of the frequencies with the commands [\[:SOURce<hw>\]:FREQuency:MANual](#) and [\[:SOURce<hw>\]:POWer:MANual](#).

STEP

Each trigger event triggers one sweep step.

*RST: AUTO

Example: See [Example "Setting up an RF frequency or power sweep"](#) on page 762.

Manual operation: See ["Mode"](#) on page 205

[[:SOURce<hw>]:SWEep:COMBined:RETRace <RetraceState>

Activates that the signal changes to the start level value while it is waiting for the next trigger event.

You can enable this feature, when you are working with sawtooth shapes in sweep mode "Single" or "External Single".

Parameters:

<RetraceState> 1 | ON | 0 | OFF
*RST: 0

Example: See [Example "Setting up an RF frequency or power sweep"](#) on page 762.

Manual operation: See ["Retrace"](#) on page 206

[[:SOURce<hw>]:SWEep:COMBined:SHAPE <Shape>

Selects the waveform shape for the combined frequency / level sweep sequence.

Parameters:

<Shape> SAWTooth | TRIangle
*RST: SAWTooth

Example: See [Example "Setting up an RF frequency or power sweep"](#) on page 762.

Manual operation: See ["Shape"](#) on page 207

[[:SOURce<hw>]:SWEep:RESet[:ALL]

Resets all active sweeps to the starting point.

Usage: Event

Manual operation: See ["Reset Sweep"](#) on page 209

[[:SOURce<hw>]:SWEep[:FREQuency]:TIME <Time>

Sets the duration of a frequency ramp sweep step.

Parameters:

<Time> float
Range: 0.01 to 100
Increment: 1E-4
*RST: 0.015
Default unit: s

Example: SOURce1:SWEep:FREQuency:SPACing RAMP
SOURce1:SWEep:FREQuency:TIME 0.020

Options: R&S SMAB-B28

Manual operation: See ["Sweep Time"](#) on page 208

[:SOURce<hw>]:SWEep:MARKer:OUTPut:POLarity <Polarity>

Selects the polarity of the marker signal.

Parameters:

<Polarity> NORMal | INVerted

NORMal

Marker level is high when after reaching the mark.

INVerted

Marker level is low after reaching the mark.

*RST: NORMal

Example: See [\[:SOURce<hw>\]:SWEep\[:FREQuency\]:MARKer<ch>:FREQuency](#) on page 775.

Options: R&S SMAB-B28

Manual operation: See ["Marker Polarity"](#) on page 217

[:SOURce<hw>]:SWEep[:FREQuency]:MARKer:ACTive <Active>

Defines the marker signal to be output with a higher voltage than all other markers.

Parameters:

<Active> NONE | M01 | M02 | M03 | M04 | M05 | M06 | M07 | M08 | M09 | M10

*RST: NONE

Example: See [\[:SOURce<hw>\]:SWEep\[:FREQuency\]:MARKer<ch>:FREQuency](#) on page 775.

Options: R&S SMAB-B28

Manual operation: See ["Active Marker"](#) on page 217

[:SOURce<hw>]:SWEep[:FREQuency]:MARKer<ch>:FREQuency <Frequency>

Sets the frequency of the selected marker.

Suffix:

<ch> 1 to 10
Marker

Parameters:

<Frequency> float
Increment: 0.01
RST: 100 + n 100

Example:

```

SOURce1:SWEep:MARKer:OUTPut:POLarity NORMal
three markers at 1 GHz, 2 GHz and 3 GHz
SOURce1:SWEep:FREQuency:MARKer1:FREQuency
1000000000
SOURce1:SWEep:FREQuency:MARKer2:FREQuency
2000000000
SOURce1:SWEep:FREQuency:MARKer3:FREQuency
3000000000
SOURce1:SWEep:FREQuency:MARKer1:FSTate 1
SOURce1:SWEep:FREQuency:MARKer2:FSTate 1
SOURce1:SWEep:FREQuency:MARKer3:FSTate 1
SOURce1:SWEep:FREQuency:MARKer:ACTIVE M03

```

Options: R&S SMAB-B28

Manual operation: See ["Frequency x"](#) on page 216

[:SOURce<hw>]:SWEep[:FREQuency]:MARKer<ch>:FSTate <FState>

Activates the selected marker.

Suffix:

<ch> 1 to 10
Marker

Parameters:

<FState> 1 | ON | 0 | OFF
*RST: 0

Example: See [\[:SOURce<hw>\]:SWEep\[:FREQuency\]:MARKer<ch>:FREQuency](#) on page 775.

Options: R&S SMAB-B28

Manual operation: See ["State"](#) on page 216

15.19 SYSTem subsystem

The SYSTem subsystem contains a series of commands for general functions which do not directly affect signal generation.

Example: To check the instrument specifications

```

// Check information on specifications document versions.
// Query all versions saved on the instrument:
:SYSTem:SPECification:VERSion:CATalog?
"04.03,04.02,04.01,04.00,03.04,03.03,03.02,03.01,03.00,02.96,02.95,02.94,
02.02,02.01,02.00,01.03,01.02,01.01,01.00"

// Query the initial version of your delivery.
:SYSTem:SPECification:VERSion:FACTory?

```

```
// Response: "04.00"

// Select a specific version:
:SYSTem:SPECification:VERSion "04.01"

// Check information of a particular specifications document.
// Query the IDs of all parameters listed in the selected version:
:SYSTem:SPECification:VERSion "04.03"
:SYSTem:SPECification:IDENTification:CATalog?
"ID_RF_FREQ_SETTING_TIME_ALC_ON_MS,ID_RF_FREQ_SETTING_TIME_MS,..."

// Query specification information on a specific parameter by its ID.
:SYSTem:SPECification? "ID_RF_FREQ_SETTING_TIME_ALC_ON_MS"
// Returns the specified value of the parameter.
```

Example: To check network-related settings

```
:SYSTem:COMMunicate:NETWork:STATus?
// Response: "1"
:SYSTem:PROTectioN1:STATe 0,123456

:SYSTem:COMMunicate:NETWork:IPAddress:MODE STAT
:SYSTem:COMMunicate:NETWork:IPAddress "10.113.0.104"
:SYSTem:COMMunicate:NETWork:IPAddress:DNS "10.0.2.166"
:SYSTem:COMMunicate:NETWork:COMMON:HOSTname?
// Response: "SMA100B-102030"
:SYSTem:COMMunicate:NETWork:COMMON:WORKgroup "instrument"
:SYSTem:COMMunicate:NETWork:COMMON:DOMAIN "rsint.net"
:SYSTem:COMMunicate:NETWork:IPAddress:GATeway "10.113.0.1"
:SYSTem:COMMunicate:NETWork:IPAddress:SUBNet:MASK "255.255.252.0"
:SYSTem:COMMunicate:NETWork:MACaddress "08 00 27 a3 a1 70"
:SYSTem:PROTectioN1:STATe 1
```

Example: To restart the network

```
:SYSTem:COMMunicate:NETWork:REStart
// terminates the network connection and sets it up again
```

Example: To find out VISA resource strings

```
:SYSTem:COMMunicate:NETWork:RESource?
// Response: "TCPIP::10.113.0.104::inst0::INSTR"

:SYSTem:COMMunicate:HISLip:RESource?
// Response: "TCPIP::10.113.0.104::hislip0::INSTR"

:SYSTem:COMMunicate:SOCKet:RESource?
// Response: "TCPIP::10.113.0.104::5025::SOCKET"

:SYSTem:COMMunicate:USB:RESource?
// "USB::0x0AAD::0x01DD::100001::INSTR"
```

```

:SYSTem:COMMunicate:GPIB:RESource?
// Response: "GPIB::28::INSTR"
:SYSTem:COMMunicate:GPIB:SELF:ADDRESS?
// Response: 28
:SYSTem:COMMunicate:GPIB:LTERminator?
// Response: STAN

:SYSTem:COMMunicate:SERial:RESource?
// Response: "ASRL1::INSTR"
:SYSTem:COMMunicate:SERial:SBITS?
// Response: 1
:SYSTem:COMMunicate:SERial:BAUD?
// Response: 115200
:SYSTem:COMMunicate:SERial:PARity?
// Response: NONE

```

Disabling LAN services

- **NOTICE!** Risk of loosing access over LAN. Disabling the LAN interface or the common services "LAN", "SCPI over LAN", "VNC" and "HTTP" locks the remote access to the instrument.

Use the commands in [Example "To disable the LAN interface and LAN services"](#) on page 778 to disable or enable the LAN interface and LAN interface services individually.

- a) For the first parameter of the command, enter the security password of your instrument.
The default password is 123456.
- b) For the second parameter of the command, enter the state: 1 (ON), 0 (OFF)

Example: To disable the LAN interface and LAN services

```

// *****
// Disable the LAN interface.
// *****
SYSTem:SECurity:NETWork:STATe "<password>", 0

// *****
// Disable the LAN services individually.
// *****
SYSTem:SECurity:NETWork:RAW:STATe "<password>", 0
// Disables remote access over raw socket.
SYSTem:SECurity:NETWork:SOE:STATe "<password>", 0
// Disables SCPI over Ethernet/LAN communication.
SYSTem:SECurity:NETWork:VNC:STATe "<password>", 0
// Disables remote access over VNC.
SYSTem:SECurity:NETWork:HTTP:STATe "<password>", 0
// Disables remote access over HTTP.
SYSTem:SECurity:NETWork:RPC:STATe "<password>", 0
// Disables remote access over remote procedure call (RPC).
SYSTem:SECurity:NETWork:SSH:STATe "<password>", 0

```

```
// Disables SSH network protocol that is used for service purposes.
SYSTem:SECurity:NETWork:FTP:STATe "<password>", 0
// Disables FTP for file transfer.
SYSTem:SECurity:NETWork:SMB:STATe "<password>", 0
// Disables shared access over SMB.
SYSTem:SECurity:NETWork:AVAHi:STATe "<password>", 0
// Disables Avahi service for automatic instrument configuration in the network.
SYSTem:SECurity:NETWork:SWUPdate:STATe "<password>", 0
// Disables software updates over LAN.
```

Example: To query the error queue

```
:SYSTem:ERRor:STATic?
// Response: -221,"Settings conflict", 153,"Input voltage out of range", ...
// Returns all static errors that are collected in the error queue.

:SYSTem:ERRor:HISTory:ClEar
// Deletes the history entries.
```

Example: To configure date and time

```
// Query the date and time settings of the instrument.
:SYSTem:DATE?
// Response: 2023,1,16;1
:SYSTem:TIME?
// Response: 18,15,17;1
:SYSTem:TIME:ZONE?
// Response: "";1 //default UTC setting
:SYSTem:TIME:PROTOcol?
// Response: "OFF";1
// No protocol selected.
:SYSTem:NTP:STATe?
// Response: 0;1
// NTP is disabled.

// Setting the timezone and NTP time protocol
:SYSTem:TIME:ZONE:CATalog?
// Response: "UTC,leap-seconds.list,leapseconds,Africa/Abidjan,..."
:SYSTem:TIME:ZONE "Europe/Berlin"
// Set the NTP server address.
:SYSTem:NTP:HOST "timesource.net"
:SYSTem:NTP:STATe?
// Response: "1"
// The NTP time server is enabled.
```

Commands:

:SYSTem:ERRor:ALL?	781
:SYSTem:ERRor:CODE:ALL?	782
:SYSTem:ERRor:CODE[:NEXT]?	782
:SYSTem:ERRor:COUNt?	783
:SYSTem:ERRor[:NEXT]?	783

:SYSTem:ERRor:GNEXt?	784
:SYSTem:ERRor:HISTory:CLEar	784
:SYSTem:ERRor:STATic?	784
:SYSTem:DLOCK	784
:SYSTem:KLOCK	785
:SYSTem:NINFormation?	785
:SYSTem:ULOCK	785
:SYSTem:LOCK:OWNer?	786
:SYSTem:LOCK:RELease:ALL	786
:SYSTem:LOCK:REQuest[:EXCLusive]?	786
:SYSTem:SAV	787
:SYSTem:RCL	787
:SYSTem:PROTect<ch>[:STATe]	787
:SYSTem:COMMunicate:GPIB:LTERminator	788
:SYSTem:COMMunicate:GPIB:RESource?	788
:SYSTem:COMMunicate:GPIB[:SELF]:ADDReSS	788
:SYSTem:COMMunicate:HISLip:RESource?	789
:SYSTem:COMMunicate:NETWork:IPADdress	789
:SYSTem:COMMunicate:NETWork:IPADdress:MODE	789
:SYSTem:COMMunicate:NETWork:MACaddress	789
:SYSTem:COMMunicate:NETWork:RESource?	790
:SYSTem:COMMunicate:NETWork:REStart	790
:SYSTem:COMMunicate:NETWork:STATus?	790
:SYSTem:COMMunicate:NETWork[:COMMon]:DOMain	790
:SYSTem:COMMunicate:NETWork[:COMMon]:HOSTname	790
:SYSTem:COMMunicate:NETWork[:COMMon]:WORKgroup	791
:SYSTem:COMMunicate:NETWork[:IPADdress]:DNS	791
:SYSTem:COMMunicate:NETWork[:IPADdress]:GATeway	791
:SYSTem:COMMunicate:NETWork[:IPADdress]:SUBNet:MASK	791
:SYSTem:COMMunicate:SERial:BAUD	792
:SYSTem:COMMunicate:SERial:PARity	792
:SYSTem:COMMunicate:SERial:RESource?	792
:SYSTem:COMMunicate:SERial:SBITs	792
:SYSTem:COMMunicate:SOCKet:RESource?	792
:SYSTem:COMMunicate:USB:RESource?	793
:SYSTem:HELP:EXPort	793
:SYSTem:IDENtification	793
:SYSTem:IDENtification:PRESet	794
:SYSTem:IRESponse	794
:SYSTem:ORESponse	794
:SYSTem:LANGuage	795
:SYSTem:INFormation:SCPI	795
:SYSTem:SECurity:NETWork:AVAHi[:STATe]	795
:SYSTem:SECurity:NETWork:FTP[:STATe]	795
:SYSTem:SECurity:NETWork:HTTP[:STATe]	796
:SYSTem:SECurity:NETWork:RAW[:STATe]	796
:SYSTem:SECurity:NETWork:REMSupport[:STATe]	796
:SYSTem:SECurity:NETWork:RPC[:STATe]	796
:SYSTem:SECurity:NETWork:SMB[:STATe]	797
:SYSTem:SECurity:NETWork:SOE[:STATe]	797

:SYSTem:SECurity:NETWork:SSH[:STATe].....	797
:SYSTem:SECurity:NETWork:SWUPdate[:STATe].....	798
:SYSTem:SECurity:NETWork:VNC[:STATe].....	798
:SYSTem:SECurity:NETWork[:STATe].....	798
:SYSTem:SECurity:SANitize[:STATe].....	798
:SYSTem:SECurity:VOLMode[:STATe].....	799
:SYSTem:SPECification?.....	799
:SYSTem:SPECification:VERSion.....	800
:SYSTem:SPECification:IDENtification:CATalog?.....	800
:SYSTem:SPECification:PARAmeter?.....	800
:SYSTem:SPECification:VERSion:CATalog?.....	801
:SYSTem:SPECification:VERSion:FACTory?.....	801
:SYSTem:SRData?.....	801
:SYSTem:STARtup:COMPLete?.....	801
:SYSTem:DATE.....	802
:SYSTem:NTP:HOSTName.....	802
:SYSTem:NTP:STATe.....	802
:SYSTem:TIME.....	802
:SYSTem:TIME:ZONE.....	803
:SYSTem:TIME:ZONE:CATalog?.....	803
:SYSTem:TIME:PROTocol.....	803
:SYSTem:UPTime?.....	804
:SYSTem:BIOS:VERSion?.....	804
:SYSTem:VERSion?.....	804
:SYSTem:OSYStem?.....	804
:SYSTem:MMEMory:PATH:USER?.....	805
:SYSTem:DFPRint.....	805
:SYSTem:REBoot.....	805
:SYSTem:REStart.....	806
:SYSTem:SHUTdown.....	806
:SYSTem:WAIT.....	806
:SYSTem:FILEs:TEMPorary:DELeTe.....	806

:SYSTem:ERRor:ALL?

Queries the error/event queue for all unread items and removes them from the queue.

Return values:

<All> string
 Error/event_number,"Error/event_description>[:Device-depend-
 ent info]"
 A comma separated list of error number and a short description
 of the error in FIFO order.
 If the queue is empty, the response is 0, "No error"
 Positive error numbers are instrument-dependent. Negative
 error numbers are reserved by the SCPI standard.
 Volatile errors are reported once, at the time they appear. Identical
 errors are reported repeatedly only if the original error has
 already been retrieved from (and hence not any more present in)
 the error queue.

Example:

```
SYSTem:ERRor:ALL?
// queries all entries in the error queue.
Response: 0, 'no error'
// no errors have occurred since the error queue was last read out.
```

Usage: Query only

Manual operation: See ["Clear History"](#) on page 822

:SYSTem:ERRor:CODE:ALL?

Queries the error numbers of all entries in the error queue and then deletes them.

Return values:

<All> string
Returns the error numbers. To retrieve the entire error text, send the command [:SYSTem:ERRor:ALL?](#).

0
"No error", i.e. the error queue is empty

Positive value
Positive error numbers denote device-specific errors

Negative value
Negative error numbers denote error messages defined by SCPI.

Example:

```
SYSTem:ERRor:CODE:ALL?
// queries all entries in the error queue.
Response: 0
// no errors have occurred since the error queue was last read out.
```

Usage: Query only

:SYSTem:ERRor:CODE[:NEXT]?

Queries the error number of the oldest entry in the error queue and then deletes it.

Return values:

<Next> string
Returns the error number. To retrieve the entire error text, send the command [:SYSTem:ERRor:ALL?](#).

0
"No error", i.e. the error queue is empty

Positive value
Positive error numbers denote device-specific errors

Negative value
Negative error numbers denote error messages defined by SCPI.

Example:

```
SYSTem:ERRor:CODE:NEXT?
// queries the oldest entry in the error queue.
Response: 0
// no errors have occurred since the error queue was last read out.
```

Usage:

Query only

:SYSTem:ERRor:COUNT?

Queries the number of entries in the error queue.

Return values:

<Count> integer
0
 The error queue is empty.

Example:

```
SYSTem:ERRor:COUNT?
// queries the number of entries in the error queue.
Response: 1
// one error has occurred since the error queue was last read out.
```

Usage:

Query only

:SYSTem:ERRor[:NEXT]?

Queries the error/event queue for the oldest item and removes it from the queue.

Return values:

<Next> string
 Error/event_number,"Error/event_description";[Device-dependent info]"
 Error number and a short description of the error.
 If the queue is empty, the response is 0, "No error"
 Positive error numbers are instrument-dependent. Negative error numbers are reserved by the SCPI standard.
 Volatile errors are reported once, at the time they appear. Identical errors are reported repeatedly only if the original error has already been retrieved from (and hence not any more present in) the error queue.

Example:

```
SYSTem:ERRor:NEXT?
// queries the oldest entry in the error queue.
Response: 0, 'no error'
// no errors have occurred since the error queue was last read out.
```

Usage:

Query only

Manual operation: See ["Static Notifications/History"](#) on page 822

:SYSTem:ERRor:GNEXt?

Similar to `:SYSTem:ERRor[:NEXT]?`, but queries the next entry from the global persistent error/event queue.

Return values:

`<NextGlobalError>` string
 Error/event number, "Error/event description" [;Device dependent info]
 An error number and a short description of the error.
 Positive error numbers are instrument-dependent. Negative error numbers are reserved by the SCPI standard.

Example:

```
SYSTem:ERRor:GNEXt?  
// queries the next error message from the global error queue.
```

Usage: Query only

:SYSTem:ERRor:HISTory:CLEar

Clears the error history.

Example: See [Example "To query the error queue"](#) on page 779

Usage: Event

Manual operation: See ["Clear History"](#) on page 822

:SYSTem:ERRor:STATic?

Returns a list of all errors existing at the time when the query is started. This list corresponds to the display on the info page under manual control.

Return values:

`<StaticErrors>` string

Example: See [Example "To query the error queue"](#) on page 779

Usage: Query only

Manual operation: See ["Static Notifications/History"](#) on page 822

:SYSTem:DLOCK <DispLockStat>

Disables the manual operation over the display, including the front panel keyboard of the instrument.

Parameters:

`<DispLockStat>` 1 | ON | 0 | OFF
 *RST: n.a. (factory preset: 0)

Example:

```
SYST:DLOC ON  
Activates the display lock. The instrument cannot be operated  
via the display until it has been enabled with SYST:DLOC OFF.
```

Manual operation: See ["User Interface"](#) on page 393

:SYSTem:KLOCk <State>

Disables the front panel keyboard of the instrument.

Parameters:

<State> 1 | ON | 0 | OFF
 *RST: n.a. (factory preset: 0)

Example:

SYST:KLOC ON
 Locks the front panel and external controls.
 To enable the controls, send SYST:KLOC OFF.

Manual operation: See ["User Interface"](#) on page 393

:SYSTem:NINformation?

Queries the oldest information message ("Error History > Level > Info") in the error/event queue.

Return values:

<NextInfo> string

Example:

:SYSTem:NINformation?
 Queries the oldest entry in the info message queue.
 Response: 90,"Info;=== Instrument startup...
 ==="
 Information message containing error number 90, that states,
 that the instrument startup is complete.

Usage: Query only

:SYSTem:ULOCK <SecPassWord>, <Mode>

Locks or unlocks the user interface of the instrument.

Parameters:

<Mode> ENABLEd | DONLy | DISabled | TOFF | VNConly

ENABLEd

Unlocks the display, the touchscreen and all controls for the manual operation.

DONLy

Locks the touchscreen and controls for the manual operation of the instrument. The display shows the current settings.

VNConly

Locks the touchscreen and controls for the manual operation, and enables remote operation over VNC. The display shows the current settings.

TOFF

Locks the touchscreen for the manual operation of the instrument. The display shows the current settings.

DISabled

Locks the display, the touchscreen and all controls for the manual operation.

*RST: n.a. (factory preset: ENABLEd)

Setting parameters:

<SecPassWord> string

Example:

:SYST:ULOC "<password>", DIS

Activates the user interface lock, including display and controls.

Manual operation: See ["User Interface"](#) on page 393

:SYSTem:LOCK:OWNer?

Queries the sessions that have locked the instrument currently.

If an exclusive lock is set, the query returns the owner of this exclusive lock, otherwise it returns `NONE`.

Return values:

<Owner> string

Example:

SYST:LOCK:OWN?

Returns the owner of locking.

Response: `NONE`

The instrument is not locked.

Usage: Query only

:SYSTem:LOCK:RELease:ALL

Revokes the exclusive access to the instrument.

Usage: Setting only

:SYSTem:LOCK:REQuest[:EXCLusive]?

Queries whether a lock for exclusive access to the instrument via ethernet exists. If successful, the query returns a 1, otherwise 0.

Return values:

<Success> integer

Example:

SYST:LOCK:REQ?

Queries the state of exclusive locking.

Response: 1

The exclusive locking is active.

Usage: Query only

:SYSTem:SAV <Pathname>

Saves the current R&S SMA100B settings in a file. To determine the file name and storage location, enter the directory and file name with the command. According to the file type, the R&S SMA100B assigns the extension (*.savrc1txt) automatically.

Setting parameters:

<Pathname> string

Example:

```
SYSTem:SAV "/var/user/temp/Test"
// saves the file "Test.savrc1txt" in the directory /var/user/temp/.
```

Usage:

Setting only

:SYSTem:RCL <Pathname>

Selects and uploads a *.savrc1txt file with previously saved R&S SMA100B settings from the default or a specified directory.

Setting parameters:

<Pathname> string

Example:

```
SYSTem:RCL "/var/user/temp/Test"
// loads the "Test.savrc1txt" file from the directory /var/user/temp/.
```

Usage:

Setting only

:SYSTem:PROTect<ch>[:STATe] <State>[, <Key>]

Activates and deactivates the specified protection level.

Suffix:

<ch> Indicates the protection level.
See also ["Protection"](#) on page 389

Parameters:

<State> 1 | ON | 0 | OFF
*RST: n.a. (factory preset: 1)

Setting parameters:

<Key> integer
The respective functions are disabled when the protection level is activated. No password is required for activation of a level. A password must be entered to deactivate the protection level. The default password for the first level is 123456. This protection level is required to unlock internal adjustments for example.

Example: To activate protection level:
`SYSTem:PROTect1:STATe 1`
 Internal adjustments or hostname cannot be changed.
 To unlock protection level 1:
`SYSTem:PROTect1:STATe 0,123456`
 Internal adjustments are accessible.

Manual operation: See ["Protection Level/Password"](#) on page 395

:SYSTem:COMMunicate:GPIB:LTERminator <LTerminator>

Sets the terminator recognition for remote control via GPIB interface.

Parameters:

<LTerminator> STANdard | EOI

EOI

Recognizes an LF (Line Feed) as the terminator only when it is sent with the line message EOI (End of Line). This setting is recommended particularly for binary block transmissions, as binary blocks may coincidentally contain a character with value LF (Line Feed), although it is not determined as a terminator.

STANdard

Recognizes an LF (Line Feed) as the terminator regardless of whether it is sent with or without EOI.

*RST: n.a. (factory preset: STANdard)

Example: See [Example "To find out VISA resource strings"](#) on page 777.

:SYSTem:COMMunicate:GPIB:RESource?

Queries the visa resource string for remote control via the GPIB interface.

To change the GPIB address, use the command `:SYSTem:COMMunicate:GPIB[:SELF]:ADDRes`.

Return values:

<Resource> string

Example: See [Example "To find out VISA resource strings"](#) on page 777.

Usage: Query only

:SYSTem:COMMunicate:GPIB[:SELF]:ADDRes <Address>

Sets the GPIB address.

Parameters:

<Address> integer
 Range: 0 to 30
 *RST: n.a. (factory preset: 28)

Example: See [Example "To find out VISA resource strings"](#) on page 777.

Manual operation: See ["GPIB Channel Address"](#) on page 427

:SYSTem:COMMunicate:HISLip:RESource?

Queries the VISA resource string. This string is used for remote control of the instrument with HiSLIP protocol.

Return values:

<Resource> string

Example: See [Example "To find out VISA resource strings"](#) on page 777.

Usage: Query only

Manual operation: See ["HISLIP"](#) on page 425

:SYSTem:COMMunicate:NETWork:IPADdress <IpAddress>

Sets the IP address.

Parameters:

<IpAddress> string
 Range: 0.0.0.0. to ff.ff.ff.ff

Example: See [Example "To check network-related settings"](#) on page 777.

Manual operation: See ["IP Address"](#) on page 423

:SYSTem:COMMunicate:NETWork:IPADdress:MODE <Mode>

Selects manual or automatic setting of the IP address.

Parameters:

<Mode> AUTO | STATic
 *RST: n.a. (factory preset: AUTO)

Example: See [Example "To check network-related settings"](#) on page 777.

Manual operation: See ["Address Mode"](#) on page 423

:SYSTem:COMMunicate:NETWork:MACaddress <MacAddress>

Queries the MAC address of the network adapter.

This is a password-protected function. Unlock the protection level 1 to access it.

Parameters:

<MacAddress> string

Example: See [Example "To check network-related settings"](#) on page 777.

Manual operation: See ["MAC Address"](#) on page 424

:SYSTem:COMMunicate:NETWork:RESource?

Queries the visa resource string for Ethernet instruments.

Return values:

<Resource> string

Example: See [Example "To find out VISA resource strings"](#) on page 777.

Usage: Query only

Manual operation: See ["VXI11"](#) on page 425

:SYSTem:COMMunicate:NETWork:REStart

Restarts the network.

Example: See [Example "To restart the network"](#) on page 777.

Usage: Event

Manual operation: See ["Restart Network"](#) on page 422

:SYSTem:COMMunicate:NETWork:STATus?

Queries the network configuration state.

Return values:

<State> 1 | ON | 0 | OFF

Example: See [Example "To check network-related settings"](#) on page 777.

Usage: Query only

Manual operation: See ["Network Status"](#) on page 422

:SYSTem:COMMunicate:NETWork[:COMMON]:DOMain <Domain>

Determines the primary suffix of the network domain.

Parameters:

<Domain> string

Example: See [Example "To check network-related settings"](#) on page 777.

Manual operation: See ["DNS Suffix"](#) on page 424

:SYSTem:COMMunicate:NETWork[:COMMON]:HOSTname <Hostname>

Sets an individual hostname for the R&S SMA100B.

Note: We recommend that you do not change the hostname to avoid problems with the network connection. If you change the hostname, be sure to use a unique name.

This is a password-protected function. Unlock the protection level 1 to access it.

Parameters:

<Hostname> string

Example: See [Example "To check network-related settings"](#) on page 777.**Manual operation:** See ["Hostname"](#) on page 423**:SYSTem:COMMunicate:NETWork[:COMMON]:WORKgroup** <Workgroup>

Sets an individual workgroup name for the instrument.

Parameters:

<Workgroup> string

Example: See [Example "To check network-related settings"](#) on page 777.**Manual operation:** See ["Workgroup"](#) on page 423**:SYSTem:COMMunicate:NETWork[:IPAdDress]:DNS** <DNS>

Determines or queries the network DNS server to resolve the name.

Parameters:

<DNS> string

Example: See [Example "To check network-related settings"](#) on page 777.**Manual operation:** See ["DNS Server"](#) on page 424**:SYSTem:COMMunicate:NETWork[:IPAdDress]:GATeway** <Gateway>

Sets the IP address of the default gateway.

Parameters:

<Gateway> string

Range: 0.0.0.0 to ff.ff.ff.ff

Example: See [Example "To check network-related settings"](#) on page 777.**Manual operation:** See ["Default Gateway"](#) on page 424**:SYSTem:COMMunicate:NETWork[:IPAdDress]:SUBNet:MASK** <Mask>

Sets the subnet mask.

Parameters:

<Mask> string

Example: See [Example "To check network-related settings"](#) on page 777.**Manual operation:** See ["Subnet Mask"](#) on page 423

:SYSTem:COMMunicate:SERial:BAUD <Baud>

Defines the baudrate for the serial remote control interface.

Parameters:

<Baud> 2400 | 4800 | 9600 | 19200 | 38400 | 57600 | 115200
*RST: n.a. (factory preset: 115200)

Example: See [Example "To find out VISA resource strings"](#) on page 777.

Manual operation: See ["Baud Rate"](#) on page 427

:SYSTem:COMMunicate:SERial:PARity <Parity>

Enters the parity for the serial remote control interface.

Parameters:

<Parity> NONE | ODD | EVEN
*RST: n.a. (factory preset: NONE)

Example: See [Example "To find out VISA resource strings"](#) on page 777.

Manual operation: See ["Parity"](#) on page 427

:SYSTem:COMMunicate:SERial:RESource?

Queries the visa resource string for the serial remote control interface. This string is used for remote control of the instrument.

Return values:

<Resource> string

Example: See [Example "To find out VISA resource strings"](#) on page 777.

Usage: Query only

Manual operation: See ["SERIAL"](#) on page 426

:SYSTem:COMMunicate:SERial:SBITs <SBits>

Defines the number of stop bits for the serial remote control interface.

Parameters:

<SBits> 1 | 2
*RST: n.a. (factory preset: 1)

Example: See [Example "To find out VISA resource strings"](#) on page 777.

Manual operation: See ["Stop Bits"](#) on page 428

:SYSTem:COMMunicate:SOCKet:RESource?

Queries the visa resource string for remote control via LAN interface, using TCP/IP socket protocol.

Return values:

<Resource> string

Example: See [Example "To find out VISA resource strings"](#) on page 777.**Usage:** Query only**Manual operation:** See ["Socket"](#) on page 426**:SYSTem:COMMunicate:USB:RESource?**

Queries the visa resource string for remote control via the USB interface.

Return values:

<Resource> string

Example: See [Example "To find out VISA resource strings"](#) on page 777.**Usage:** Query only**Manual operation:** See ["USB"](#) on page 426**:SYSTem:HELP:EXPort**

Saves the online help as zip archive in the user directory.

Example:

```
:SYSTem:HELP:EXPort
MMEM:CDIR?
// "/var/user"
MMEM:CAT?
// .., "Log,DIR,4096", "help.tgz,BIN,69836600"
// confirms that help zip archive is saved.
```

Usage: Event**Manual operation::** "Setup > Help > Export Help to User Path"**:SYSTem:IDENtification <Identification>**Selects the mode to determine the "IDN String" and the "OPT String" for the instrument, selected with command [:SYSTem:LANGuage](#).**Note:** While working in an emulation mode, the R&S SMA100B specific command set is disabled, that is, the SCPI command `SYST:IDEN` is discarded.**Parameters:**

<Identification> AUTO | USER

AUTO

Automatically determines the strings.

USER

User-defined strings can be selected.

***RST:** n.a. (factory preset: AUTO)

Example: `SYST:IDEN AUTO`
Automatically assigns the OPT and IDN strings according to the selected instrument language.

Manual operation: See ["Mode"](#) on page 429

:SYSTem:IDENtification:PRESet

Sets the *IDN and *OPT strings in user defined mode to default values.

Example: `SYST:IDEN USER`
`SYST:IDEN:PRES`

Usage: Event

Manual operation: See ["Set to Default"](#) on page 429

:SYSTem:IRESpone <IdnResponse>

Defines the user defined identification string for *IDN.

Note: While working in an emulation mode, the instrument's specific command set is disabled, i.e. the SCPI command `SYST:IRES` is discarded.

Parameters:

<IdnResponse> string

Example: `SYST:IDEN USER`
`// Selects a user-defined identification`
`SYST:IRES "Test Device"`
`// Defines identification string 'test device'`
`*IDN?`
`// Response: 'test device'`

Manual operation: See ["IDN String"](#) on page 429

:SYSTem:ORESpone <OResponse>

Defines the user defined response string for *OPT.

Note: While working in an emulation mode, the instrument's specific command set is disabled, i.e. the SCPI command `SYST:ORES` is discarded.

Parameters:

<OResponse> string

Example: `SYST:IDEN USER`
`// Selects a user-defined identification`
`SYST:ORES "Test Option"`
`// Defines the OPT string 'test option'`
`*OPT?`
`// Response: 'test option'`

Manual operation: See ["OPT String"](#) on page 430

:SYSTem:LANGuage <Language>

Sets the remote control command set.

Parameters:

<Language> string

Example:

```
SYSTem:LANGuage "SCPI"
// selects SCPI command set
```

Manual operation: See ["Language"](#) on page 429

:SYSTem:INFormation:SCPI <InfoString>

Inserts system information in recorded SCPI command lists, for example information on a missing command.

Parameters:

<InfoString> string

Example:

```
SYST:INF:SCPI "missing command"
enters the information into a recorded SCPI command list.
```

:SYSTem:SECurity:NETWork:AVAHI[:STATE] <SecPassWord>, <AvahiState>

Disables the Avahi service for automatic configuration of the instrument in a network.

Parameters:

<AvahiState> 1 | ON | 0 | OFF

Setting parameters:

<SecPassWord> string
Current security password.

Example: See [Example "To disable the LAN interface and LAN services"](#) on page 778.

Manual operation: See ["LAN Services"](#) on page 397

:SYSTem:SECurity:NETWork:FTP[:STATE] <SecPassWord>, <FtpState>

Disables FTP protocol for file transfer between the instrument and host.

Parameters:

<FtpState> 1 | ON | 0 | OFF

Setting parameters:

<SecPassWord> string
Current security password.

Example: See [Example "To disable the LAN interface and LAN services"](#) on page 778.

Manual operation: See ["LAN Services"](#) on page 397

:SYSTem:SECurity:NETWork:HTTP[:STATe] <SecPassWord>, <HttpState>

Disables control of the instrument over HTTP, the protocol for hypermedia information systems.

Parameters:

<HttpState> 1 | ON | 0 | OFF

Setting parameters:

<SecPassWord> string
Current security password.

Example: See [Example "To disable the LAN interface and LAN services"](#) on page 778.

Manual operation: See ["LAN Services"](#) on page 397

:SYSTem:SECurity:NETWork:RAW[:STATe] <SecPassWord>, <RawState>

Disables the LAN interface for remote control of the instrument over raw socket port.

Parameters:

<RawState> 1 | ON | 0 | OFF

Setting parameters:

<SecPassWord> string
Current security password.

Example: See [Example "To disable the LAN interface and LAN services"](#) on page 778.

:SYSTem:SECurity:NETWork:REMSupport[:STATe] <NetRemSupport>

Disables communication over SSH (SCP) for service purposes.

Parameters:

<NetRemSupport> 1 | ON | 0 | OFF
*RST: n.a. (factory preset: 1)

Example: See [Example "To disable the LAN interface and LAN services"](#) on page 778.

Manual operation: See ["LAN Services"](#) on page 397

:SYSTem:SECurity:NETWork:RPC[:STATe] <SecPassWord>, <RpcState>

Enables the LAN interface for remote control of the instrument via remote procedure calls (RPC).

Parameters:

<RpcState> 1 | ON | 0 | OFF

Setting parameters:

<SecPassWord> string
Current security password.

Example: See [Example "To disable the LAN interface and LAN services"](#) on page 778.

:SYSTem:SECurity:NETWork:SMB[:STATe] <SecPassWord>, <SmbState>

Disables access to the file system, printers and serial ports in a network over SMB.

Parameters:

<SmbState> 1 | ON | 0 | OFF

Setting parameters:

<SecPassWord> string
Current security password.

Example: See [Example "To disable the LAN interface and LAN services"](#) on page 778.

Manual operation: See ["LAN Services"](#) on page 397

:SYSTem:SECurity:NETWork:SOE[:STATe] <SecPassWord>, <SoeState>

Disables control of the instrument over LAN using SCPI commands.

Parameters:

<SoeState> 1 | ON | 0 | OFF

Setting parameters:

<SecPassWord> string
Current security password.

Example: See [Example "To disable the LAN interface and LAN services"](#) on page 778.

Manual operation: See ["LAN Services"](#) on page 397

:SYSTem:SECurity:NETWork:SSH[:STATe] <SecPassWord>, <SshState>

Disables control of the instrument over LAN using the SSH network protocol.

Parameters:

<SshState> 1 | ON | 0 | OFF

Setting parameters:

<SecPassWord> string
Current security password.

Example: See [Example "To disable the LAN interface and LAN services"](#) on page 778.

Manual operation: See ["LAN Services"](#) on page 397

:SYSTem:SECurity:NETWork:SWUPdate[:STATe] <SecPassWord>, <SwUpdateState>

Disables software update over LAN.

Parameters:

<SwUpdateState> 1 | ON | 0 | OFF

Setting parameters:

<SecPassWord> string
Current security password.

Example: See [Example "To disable the LAN interface and LAN services"](#) on page 778.

Manual operation: See ["LAN Services"](#) on page 397

:SYSTem:SECurity:NETWork:VNC[:STATe] <SecPassWord>, <VncState>

Disables the VNC interface for remote control of the instrument.

Parameters:

<VncState> 1 | ON | 0 | OFF

Setting parameters:

<SecPassWord> string
Current security password.

Example: See [Example "To disable the LAN interface and LAN services"](#) on page 778.

Manual operation: See ["LAN Services"](#) on page 397

:SYSTem:SECurity:NETWork[:STATe] <SecPassWord>, <LanStorState>

Disables the LAN interface in general, including all services.

Parameters:

<LanStorState> 1 | ON | 0 | OFF

Setting parameters:

<SecPassWord> string
Current security password.
The default password is 123456.

Example: See [Example "To disable the LAN interface and LAN services"](#) on page 778

Manual operation: See ["LAN"](#) on page 397

:SYSTem:SECurity:SANitize[:STATe] <SecPassWord>, <MmemProtState>

Sanitizes the internal memory.

Parameters:

<MmemProtState> 0 | 1 | OFF | ON
 *RST: 0

Setting parameters:

<SecPassWord> string

Example:

SYSTem:SECurity:SANitize[:STATE] 1

Manual operation: See ["Sanitize"](#) on page 392

:SYSTem:SECurity:VOLMode[:STATE] <SecPassWord>, <MmemProtState>

Activates volatile mode, so that no user data can be written to the internal memory permanently.

To enable volatile mode, reboot the instrument. Otherwise the change has no effect.

Parameters:

<MmemProtState> 0 | 1 | OFF | ON
 *RST: 0

Setting parameters:

<SecPassWord> string
 Current security password
 The default password is 123456.

Example:

SYSTem:SECurity:VOLMode:STATE "123456", 1
 SYSTem:REBoot

Manual operation: See ["Volatile Mode"](#) on page 391

:SYSTem:SPECification? <Id>

Retrieves data sheet information for a specific parameter.

Setting parameters:

<Id> string
 Identifies the name of the entry in the data sheet, as queried with the command [:SYSTem:SPECification:IDENTification:CATalog?](#) on page 800

Return values:

<ValList> float
 Comma-separated list with the specified and, if available, the typical value of the parameter, as specified in the data sheet. See also [Section 14.7.4, "Datasheet"](#), on page 451.

Example:

See [Example "To check the instrument specifications"](#) on page 776.

Usage:

Query only

:SYSTem:SPECification:VERSion <Version>

Selects a data sheet version from the data sheets saved on the instrument.

Further queries regarding the data sheet parameters (<Id>) and their values refer to the selected data sheet.

To query the list of data sheet versions, use the command **:SYSTem:SPECification:VERSion:CATalog?** on page 801.

Parameters:

<Version> string

Example: See **:SYSTem:SPECification?** on page 799.

:SYSTem:SPECification:IDENtification:CATalog?

Queries the parameter identifiers (<Id>) available in the data sheet.

Return values:

<IdList> string
Comma-separated string of the parameter identifiers (<Id>)

Example: See **:SYSTem:SPECification?** on page 799.

Usage: Query only

:SYSTem:SPECification:PARAmeter? <Id>[, <Parameter>]

Retrieves data sheet information for a specific parameter.

Setting parameters:

<Id> string
Identifies the name of the entry in the data sheet.
Query the data sheet parameters with the command **:SYSTem:SPECification:IDENtification:CATalog?**.

<Parameter> float
An additional value the result (ValList) depends on.

Return values:

<ValList> float
Comma-separated list with the specified and, if available, the typical value of the parameter, as specified in the data sheet.

Example: **Note:** The following values are merely an example. Your instrument may not support the same parameters.
SYST:SPEC:PAR? "ID_RF_FREQ_SETTING_TIME_MS",0.1
SYST:SPEC:PAR? "ID_RF_LEVEL_MAX_GENERAL_DBM",
0.1

Usage: Query only

:SYSTem:SPECification:VERSion:CATalog?

Queries all data sheet versions stored in the instrument.

Return values:

<VersCatalog> string

Example: See [:SYSTem:SPECification?](#) on page 799.

Usage: Query only

:SYSTem:SPECification:VERSion:FACTory?

Queries the data sheet version of the factory setting.

Return values:

<Version> string

Example: See [:SYSTem:SPECification?](#) on page 799.

Usage: Query only

Manual operation: See ["Versions"](#) on page 829

:SYSTem:SRData?

Queries the SCPI recording data from the internal file.

This feature enables you to transfer an instrument configuration to other test environments, as e.g. laboratory virtual instruments.

Return values:

<FileData> block data

Example:

```
SYSTem:SRData?
// #3118:SOURce1:ROSCillator:SOURce EXT
// :SOURce1:FREQuency:CW 4000000000
// :SOURce1:FREQuency:OFFSet 1000000
// :SOURce1:AM1:STATe 1
// :OUTPut1:STATe 1
```

Usage: Query only

:SYSTem:STARtup:COMPlete?

Queries if the startup of the instrument is completed.

Return values:

<Complete> 1 | ON | 0 | OFF
*RST: 0

Example:

```
SYSTem:STARtup:COMPlate?
Response: 1
// the instrument has started and is ready for operation.
```

Usage: Query only

:SYSTem:DATE <Year>, <Month>, <Day>

Queries or sets the date for the instrument-internal calendar.

This is a password-protected function. Unlock the protection level 1 to access it.

Parameters:

<Year>	integer
<Month>	integer
	Range: 1 to 12
<Day>	integer
	Range: 1 to 31

Example: See [Example "To configure date and time"](#) on page 779.

Manual operation: See ["Date"](#) on page 840

:SYSTem:NTP:HOSTname <NTPName>

Sets the address of the NTP server. You can enter the IP address, or the hostname of the time server, or even set up an own vendor zone. See the Internet for more information on NTP.

Parameters:

<NTPName>	string
-----------	--------

Manual operation: See ["NTP Address"](#) on page 841

:SYSTem:NTP:STATe <UseNtpState>

Activates clock synchronization via NTP.

Parameters:

<UseNtpState>	1 ON 0 OFF
*RST:	n.a. (factory preset: 0)

Example: See [Example "To configure date and time"](#) on page 779.

Manual operation: See ["NTP Address"](#) on page 841

:SYSTem:TIME <Hour>, <Minute>, <Second>

Queries or sets the time for the instrument-internal clock.

This is a password-protected function. Unlock the protection level 1 to access it.

Parameters:

<Hour>	integer
	Range: 0 to 23

<Minute> integer
Range: 0 to 59

<Second> integer
Range: 0 to 59

Example: See [Example "To configure date and time"](#) on page 779.

Manual operation: See ["Time"](#) on page 840

:SYSTem:TIME:ZONE <TimeZone>

Sets the timezone. You can query the list of the available timezones with [:SYSTem:TIME:ZONE:CATalog?](#).

Parameters:

<TimeZone> string

Example: See [Example "To configure date and time"](#) on page 779.

Manual operation: See ["Timezone"](#) on page 841

:SYSTem:TIME:ZONE:CATalog?

Queries the list of available timezones.

Return values:

<Catalog>

Example: See [Example "To configure date and time"](#) on page 779.

Usage: Query only

Manual operation: See ["Timezone"](#) on page 841

:SYSTem:TIME:PROTocol <TimeProtocol>

Sets the date and time of the operating system.

Parameters:

<TimeProtocol> OFF | NONE | 0 | NTP | ON | 1

NONE

Sets the date and time according to the selected timezone, see [:SYSTem:TIME:ZONE:CATalog?](#) on page 803 and [:SYSTem:TIME:ZONE](#) on page 803.

NTP

Sets the date and time derived from the network time protocol. To select the NTP time server, use the commands [:SYSTem:NTP:HOSTname](#) on page 802 and [:SYSTem:NTP:STATe](#) on page 802.

*RST: n.a. (factory preset: NONE)

Example: See [Example "To configure date and time"](#) on page 779.

Manual operation: See ["Time Protocol"](#) on page 841

:SYSTem:UPTime?

Queries the up time of the operating system.

Return values:

<UpTime> "<ddd.hh:mm:ss>"

Example:

SYSTem:UPTime?

Response: "0.08:11:00"

Usage:

Query only

:SYSTem:BIOS:VERSion?

Queries the BIOS version of the instrument.

Return values:

<Version> string

Example:

SYST:BIOS:VERS?

queries the BIOS version.

Response: 123456

Usage:

Query only

:SYSTem:VERSion?

Queries the SCPI version the instrument's command set complies with.

Return values:

<Version> string

Example:

SYSTem:VERSion

// queries the SCPI version.

Response: "1996"

// the instrument complies with the SCPI version from 1996.

Usage:

Query only

:SYSTem:OSYSstem?

Queries the operating system of the instrument.

Return values:

<OperSystem> string

Example:

SYSTem:OSYSstem?

Response: "Linux"

Usage:

Query only

:SYSTem:MMEMory:PATH:USER?

Queries the user directory, that means the directory the R&S SMA100B stores user files on.

Return values:

<PathUser> string

Example:

```
SYSTem:MMEMory:PATH:USER?
Response: "'/var/user/'"
```

Usage: Query only

:SYSTem:DFPRint <Directory>

Creates a file with the device footprint of the product.

The content is formatted in machine-readable form, suitable for automatic further processing.

The generic file name is composed of

DeviceFootprint_<SerialNumber>_<Date>_<Time>.xml. R&S SMA100B saves the file in the definable directory. If the directory is not specified, it saves the footprint file in the internal default directory (/var/lib/Rohde-Schwarz/DeviceFootprint).

You can download the file by using the SCPI commands of the MMEMory subsystem.

Setting parameters:

<Directory> string
 Path to the directory for saving the device footprint file.
 Ensure that you have the permission to write into the directory.

Return values:

<DeviceFootprint> string
 Information on the product type, identification and the installed hardware, software and further service-related information on the product's configuration.

Example:

```
SYSTem:DFPRint "/var/user/devicefootprint"

SYSTem:DFPRint?
// MMEM:DATA?
// returns the device footprint information saved with SYST:DFPRint
```

:SYSTem:REBoot

Reboots the instrument including the operating system.

Usage: Event

:SYSTem:REStart

Restarts the instrument without restarting the operating system.

Usage: Event

:SYSTem:SHUTdown

Shuts down the instrument.

Usage: Event

Manual operation: See ["Shut down"](#) on page 848

:SYSTem:WAIT <TimeMs>

Delays the execution of the subsequent remote command by the specified time.

This function is useful, for example to execute an SCPI sequence automatically but with a defined time delay between some commands.

See [Section 13.2.2, "How to assign actions to the \[★ \(User\)\] key"](#), on page 376.

Setting parameters:

<TimeMs> integer
Wait time in ms
Range: 0 to 10000
*RST: 0

Example:
`SYSTem:WAIT 10000`
`// Waits 10s before resetting the instrument.`
`*RST`

Usage: Setting only

:SYSTem:FILEs:TEMPorary:DELeTe

Deletes the temporary files from the internal memory or, if installed, from the SD card slot.

Example:
`:SYSTem:FILEs:TEMPorary:DELeTe`
`// temporary files are removed`

Usage: Event

15.20 STATus subsystem

This system contains the commands for the status reporting system. See also [Section 14.4, "Status reporting system"](#), on page 418 for detailed information.

*RST on page 490 has no effect on the status registers.

Value ranges

- Queries return the current value of the respective register, which permits a check of the device status.
Return values: A decimal value in the range 0 to 32767 ($=2^{15}-1$)
- The configuration commands set the respective register thus determining which status changes of the R&S SMA100B cause the status registers to be changed.
Setting values: A decimal value in the range 0 to 32767 ($=2^{15}-1$)

:STATus:OPERation:CONDition?	807
:STATus:OPERation:ENABle	807
:STATus:OPERation[:EVENT]	808
:STATus:OPERation:NTRansition	808
:STATus:OPERation:PTRansition	808
:STATus:PRESet	808
:STATus:QUEStionable:CONDition	809
:STATus:QUEStionable:ENABle	809
:STATus:QUEStionable[:EVENT]	809
:STATus:QUEStionable:NTRansition	809
:STATus:QUEStionable:PTRansition	810
:STATus:QUEue[:NEXT]?	810

:STATus:OPERation:CONDition?

Queries the content of the CONDition part of the STATus:OPERation register.

This part contains information on the action currently being performed in the instrument. The content is not deleted after being read out because it indicates the current hardware status.

Return values:

<Condition> string

Example: :STATus:OPERation:CONDition?

Usage: Query only

:STATus:OPERation:ENABle <Enable>

Sets the bits of the ENABle part of the STATus:OPERation register. This setting determines which events of the Status-Event part are forwarded to the sum bit in the status byte. These events can be used for a service request.

Parameters:

<Enable> string

Example: :STAT:OPER:ENAB 32767
all events are forwarded to the sum bit of the status byte.

:STATus:OPERation[:EVENT] < >

Queries the content of the EVENT part of the STATus:OPERation register. This part contains information on the actions performed in the instrument since the last readout. The content of the EVENT part is deleted after being read out.

Parameters:

< > string

Example:

:STAT:OPER:EVENT?

queries the STATus:OPERation:EVENT register.

:STATus:OPERation:NTRansition <Ntransition>

Sets the bits of the NTRansition part of the STATus:OPERation register. If a bit is set, a transition from 1 to 0 in the condition part causes an entry to be made in the EVENT part of the register. The disappearance of an event in the hardware is thus registered, for example the end of an adjustment.

Parameters:

<Ntransition> string

Example:

:STAT:OPER:NTR 0

a transition from 1 to 0 in the condition part of the Status:Operation register does not cause an entry to be made in the EVENT part.

:STATus:OPERation:PTRansition <Ptransition>

Sets the bits of the PTRansition part of the STATus:OPERation register. If a bit is set, a transition from 0 to 1 in the condition part causes an entry to be made in the EVENT part of the register. A new event in the hardware is thus registered, for example the start of an adjustment.

Parameters:

<Ptransition> string

Example:

:STAT:OPER:PTR 32767

all transitions from 0 to 1 in the condition part of the Status:Operation register cause an entry to be made in the EVENT part.

:STATus:PRESet <Preset>

Resets the status registers. All PTRansition parts are set to FFFFh (32767), i.e. all transitions from 0 to 1 are detected. All NTRansition parts are set to 0, i.e. a transition from 1 to 0 in a CONDition bit is not detected. The ENABLE parts of STATus:OPERation and STATus:QUESTionable are set to 0, i.e. all events in these registers are not passed on.

Parameters:

<Preset> string

Example: `STAT:PRES`
resets the status registers.

:STATus:QUESTionable:CONDition <Condition>

Queries the content of the CONDition part of the STATus:QUESTionable register. This part contains information on the action currently being performed in the instrument. The content is not deleted after being read out since it indicates the current hardware status.

Parameters:
<Condition> string

Example: `:STATus:QUESTionable:CONDition?`
queries the Status:Questionable:Condition register.

:STATus:QUESTionable:ENABle <Enable>

Sets the bits of the ENABle part of the STATus:QUESTionable register. The enable part determines which events of the STATus:EVENT part are enabled for the summary bit in the status byte. These events can be used for a service request.

If a bit in the ENABle part is 1, and the corresponding EVENT bit is true, a positive transition occurs in the summary bit. This transition is reported to the next higher level.

Parameters:
<Enable> string

Example: `STAT:QUES:ENAB 1`
Problems when performing an adjustment cause an entry to be made in the sum bit.

:STATus:QUESTionable[:EVENT] < >

Queries the content of the EVENT part of the STATus:QUESTionable register. This part contains information on the actions performed in the instrument since the last readout. The content of the EVENT part is deleted after being read out.

Parameters:
< > string

Example: `STAT:QUES:EVEN?`
queries the Status:Questionable:Event register.

:STATus:QUESTionable:NTRansition <Ntransition>

Sets the bits of the NTRansition part of the STATus:QUESTionable register. If a bit is set, a transition from 1 to 0 in the condition part causes an entry to be made in the EVENT part of the register.

Parameters:
<Ntransition> string

Example: `STAT:QUES:NTR 0`
 a transition from 1 to 0 in the condition part of the STATUS:QUESTIONable register does not cause an entry to be made in the EVENT part

:STATUS:QUESTIONable:PTRansition <PTransition>

Sets the bits of the NTRansition part of the STATUS:QUESTIONable register. If a bit is set, a transition from 1 to 0 in the condition part causes an entry to be made in the EVENT part of the register.

Parameters:

<PTransition> string

Example: `STAT:QUES:PTR 32767`
 all transitions from 0 to 1 in the condition part of the STATUS:QUESTIONable register cause an entry to be made in the EVENT part

:STATUS:QUEue[:NEXT]?

Queries the oldest entry in the error queue and then deletes it. Positive error numbers denote device-specific errors, and negative error numbers denote error messages defined by SCPI. If the error queue is empty, 0 ("No error") is returned.

The command is identical to `:SYSTEM:ERROR[:NEXT]?` on page 783.

Return values:

<Next> string

Example: `:STATUS:QUEue?`
 queries the oldest entry in the error queue.
 Response: 0, 'no error'
 no errors have occurred since the error queue was last read out

Usage: Query only

15.21 TEST subsystem

The TEST subsystem contains the commands for performing test routines directly at the hardware assemblies.

The selftest responses with a 0 if the test is performed successfully, otherwise a value other than 0 is returned. None of the commands of this system has a *RST value.

Example: Testing the screen display

```
// show the check screen
:TEST:PIXel:WINDow 1
// select the color for the display, e.g. blue
TEST:PIXel:COLor BLUE
// select the sequence for changing the color automatically
TEST:PIXel:COLor AUTO //(~3s per color)
// select a specific RGB color, e.g. black
TEST:PIXel:RGBA 0,0,0,255
// turn on the gradient
TEST:PIXel:GRADient 1
// switch to text mode
:TEST:PIXel:TEXT 1
// set the point size of the text
:TEST:PIXel:POINTsize 600
// exit the check screen
:TEST:PIXel:WINDow 0
```

```
:TEST<hw>:ALL:START.....811
:TEST<hw>:ALL:RESult?.....811
:TEST:PIXel:COLor.....811
:TEST:PIXel:GRADient.....812
:TEST:PIXel:POINTsize.....812
:TEST:PIXel:RGBA.....812
:TEST:PIXel:TEXT.....812
:TEST:PIXel:WINDow.....813
```

:TEST<hw>:ALL:START

Starts the selftest. Use the command `:TEST<hw>:ALL:RESult?` to query the progress of the test.

Usage: Event

:TEST<hw>:ALL:RESult?

Queries the progress of the performed selftest. Start the selftest with `:TEST<hw>:ALL:START`.

Return values:

<Result> 0 | 1 | RUNning | STOPped
 *RST: STOPped

Usage: Query only

:TEST:PIXel:COLor <PixTestColor>

Selects the color of the screen.

"AUTO" switches from one color to the next in time intervals of approximately 3 s per color.

Setting parameters:

<PixTestColor> RED | BLUE | WHITE | GREEN | AUTO | GR25 | GR50 | GR75 | BLACK
 *RST: RED

Example: See [Example "Testing the screen display"](#) on page 811.

Usage: Setting only

Manual operation: See ["Check Display Screen"](#) on page 846

:TEST:PIXel:GRADient <PixTestGradStat>

Activates the gradient for display screen test.

Parameters:

<PixTestGradStat> 1 | ON | 0 | OFF
 *RST: 0

Example: See [Example "Testing the screen display"](#) on page 811.

Manual operation: See ["Check Display Screen"](#) on page 846

:TEST:PIXel:POINTsize <PixTestGradStat>

Sets the point size of the test text.

Parameters:

<PixTestGradStat> integer
 Range: 0 to 999
 *RST: n.a. (no preset. default: 0)

Example: See [Example "Testing the screen display"](#) on page 811.

Manual operation: See ["Check Display Screen"](#) on page 846

:TEST:PIXel:RGBA

Sets a specific RGBA color for the screen.

Example: See [Example "Testing the screen display"](#) on page 811.

Manual operation: See ["Check Display Screen"](#) on page 846

:TEST:PIXel:TEXT <PixTestGradStat>

Activates the test text mode.

Parameters:

<PixTestGradStat> 1 | ON | 0 | OFF
 *RST: 0

Example: See [Example "Testing the screen display"](#) on page 811.

Manual operation: See ["Check Display Screen"](#) on page 846

:TEST:PIXel:WINDow <PixTestWindow>

Activates the check display screen.

Setting parameters:

<PixTestWindow> 1 | ON | 0 | OFF
 *RST: 0

Example: See [Example "Testing the screen display"](#) on page 811.

Usage: Setting only

Manual operation: See ["Check Display Screen"](#) on page 846

15.22 TRIGger subsystem

The TRIGger system contains the commands for selecting the trigger source for the RF and LF sweep.

You can work with an internal or with an externally applied trigger signal. In this case, use the commands in the SOURce:INPut subsystem to configure the signal.

The trigger system of the R&S SMA100B is a simplified implementation of the SCPI trigger system. The TRIGger system differs from the SCPI system as follows:

- No INITiate command; the instrument behaves as if INITiate:CONTinuous ON were set.
- Under TRIGger several sweep subsystems exist.
- The trigger source names correspond directly to the various settings of manual control. SCPI uses different names which are also accepted by the instrument. The SCPI names should be used if compatibility is an important consideration.

In addition to these commands, see more trigger-related commands in the modulation and RF signal subsystems.

Table 15-1: Cross-reference between the manual and remote control

R&S proprietary value name	SCPI conform value name	Parameter in manual control
AUTO	IMMediate	"Auto" mode
SINGLE	BUS	"Single" mode.

R&S proprietary value name	SCPI conform value name	Parameter in manual control
EXternal	EXternal	"Ext Single" and "Ext Step" mode. Use command <code>LFO:SWEep:MODE</code> to select between the two sweep modes.
EAUTO	-	"Ext Start/Stop" mode.

:TRIGger<hw>:FSWeep:SOURce.....	814
:TRIGger<hw>:LFFSweep:SOURce.....	814
:TRIGger<hw>:PSWeep:SOURce.....	814
:TRIGger<hw>[:SWEep]:SOURce.....	814
:TRIGger<hw>:FPSWeep:SOURce.....	815
:TRIGger<hw>:FSWeep[:IMMediate].....	816
:TRIGger<hw>:LFFSweep:IMMediate.....	816
:TRIGger<hw>:PSWeep[:IMMediate].....	816
:TRIGger<hw>[:SWEep][:IMMediate].....	816
:TRIGger<hw>:LFFSweep.....	816

```

:TRIGger<hw>:FSWeep:SOURce <Source>
:TRIGger<hw>:LFFSweep:SOURce <Source>
:TRIGger<hw>:PSWeep:SOURce <Source>
:TRIGger<hw>[:SWEep]:SOURce <Source>

```

Selects the trigger source for the corresponding sweeps:

- FSWeep - RF frequency
- LFFSweep - LF frequency
- PSWeep - RF level
- SWEep - all sweeps

The source names of the parameters correspond to the values provided in manual control of the instrument. They differ from the SCPI-compliant names, but the instrument accepts both variants.

Use the SCPI name, if compatibility is an important issue. Find the corresponding SCPI-compliant commands in [Cross-reference between the manual and remote control](#).

Setting parameters:

<Source> AUTO | IMMediate | SINGLE | BUS | EXternal | EAUTO

AUTO [IMMediate]

Executes a sweep automatically.

In this free-running mode, the trigger condition is met continuously. I.e. when a sweep is completed, the next one starts immediately.

SINGLE [BUS]

Executes one complete sweep cycle.

The following commands initiate a trigger event:

*TRG on page 491

```
[ :SOURce<hw> ] :SWEep:POWer:EXECute
[ :SOURce<hw> ] :SWEep[:FREQuency]:EXECute
:TRIGger<hw>[:SWEep][:IMMediate], :TRIGger<hw>:
PSWep[:IMMediate] and :TRIGger<hw>:FSWep[:
IMMediate].
```

Set the sweep mode with the commands:

```
[ :SOURce<hw> ] :SWEep:POWer:MODEAUTO|STEP
[ :SOURce<hw> ] :SWEep[:FREQuency]:MODEAUTO|STEP
[ :SOURce<hw> ] :LFOutput:SWEep[:FREQuency]:MODE
AUTO|STEP
```

In step mode (STEP), the instrument executes only one step.

EXternal

An external signal triggers the sweep.

EAUTO

An external signal triggers the sweep. When one sweep is finished, the next sweep starts.

A second trigger event stops the sweep at the current frequency, a third trigger event starts the trigger at the start frequency, and so on.

*RST: AUTO

Example: See [Example "Setting up an RF frequency or power sweep"](#) on page 762

Usage: Setting only

:TRIGger<hw>:FPSWep:SOURce <FpTrigSource>

Selects the trigger source for the combined RF frequency / level sweep.

The parameter names correspond to the manual control. If needed, see [table Table 15-1](#) for selecting the trigger source with SCPI compliant parameter names.

Parameters:

<FpTrigSource> AUTO | IMMediate | SINGLE | BUS | EXternal | EAUTO

AUTO|IMMediate

Executes the combined RF sweep automatically. In this free-running mode, the trigger condition is met continuously. I.e. as soon as a sweep is completed, the next one starts immediately.

SINGLE|BUS

Executes one complete sweep cycle triggered by the GPIB commands [:SOURce<hw>] :SWEep:COMBined:EXECute or

*TRG. The mode has to be set to [:SOURce<hw>] :SWEep:COMBined:MODE > AUTO.

EXtErnal

An external signal triggers the sweep.

EAUTo

An external signal triggers the sweep. As soon as one sweep is finished, the next sweep starts. A second trigger event stops the sweep at the current frequency and level value pairs, a third trigger event starts the trigger at the start values, and so on.

*RST: No enum range assigned!

Manual operation: See ["Mode"](#) on page 205

```
:TRIGger<hw>:FSweep[:IMMediate]
:TRIGger<hw>:LFFSweep:IMMediate
:TRIGger<hw>:PSweep[:IMMediate]
:TRIGger<hw>[:SWEep][:IMMediate]
```

Performs a single sweep and immediately starts the activated, corresponding sweep:

- FSWep - RF frequency
- PSweep - RF level
- LFFSweep - LF frequency
- SWEep - all sweeps

Effective in the following configuration:

- TRIG:FSW|LFFS|PSW|[:SWE]:SOUR **SING**
- SOUR:SWE:FREQ|POW:MODE **AUTO** or SOUR:LFO:SWE:[FREQ:]MODE **AUTO**

Alternatively, you can use the **IMMediate** command instead of the respective **SWEep**:
[FREQ:]|POW:EXECute command.

Example: TRIG
Starts all active sweeps.

Usage: Event

Manual operation: See ["Execute Single Sweep"](#) on page 209

```
:TRIGger<hw>:LFFSweep
```

Executes an LF frequency sweep in the following configuration:

- TRIG:LFFS:SOUR **SING**
- LFO:SWE:MODE **AUTO**

Example: LFO:SWE:MODE AUTO
TRIG:LFFS:SOUR SING
TRIG:LFFSweep

Usage: Event

15.23 UNIT subsystem

The `UNIT` subsystem is used to set default units for parameters if no unit is indicated in a command. These settings are valid for the entire instrument.

Example: Setting default units for remote control

```
UNIT:POW V
UNIT:ANGL DEG
```

Sets V (volts) as unit of all power parameters, DEG (degrees) for the phase modulation angle and KMH for the speed.

:UNIT:ANGLE	817
:UNIT:POWer	817

:UNIT:ANGLE <Angle>

Sets the default unit for phase modulation angle. The command affects no other parameters, such as RF phase, or the manual control or display.

Parameters:

- <Angle>
- DEGree | DEGRee | RADian
- *RST: RADian

:UNIT:POWer <Power>

Sets the default unit for all power parameters. This setting affects the GUI, as well as all remote control commands that determine power values.

Parameters:

- <Power>
- V | DBUV | DBM
- *RST: DBM

16 Troubleshooting and notifications

Handling R&S SMA100B start-up issues

If the product does not start, a blown fuse in the power supply can be the cause. Contact the Rohde & Schwarz customer service to confirm the fault symptoms. If the power supply has a blown fuse, you must return the product to the Rohde & Schwarz customer service to have the power supply replaced. Follow the instructions from the Rohde & Schwarz customer service.

If you need to transport or ship the instrument, see [Section 17, "Transporting"](#), on page 833.

Understanding R&S SMA100B notifications

The R&S SMA100B distinguishes between various notifications caused by events or functions. It displays a notification in the "Info" line on the screen temporarily, and saves all notifications in a history list. In addition, an event initiates an entry in the event/error queue of the status reporting system.

See:

- [Section 14.4, "Status reporting system"](#), on page 418
- [Section 16.4, "Querying notifications"](#), on page 821

16.1 Notifications

Notifications inform about operation states of the instrument, and point out deviations, deficiencies or imperfection of functions that initiate an event in the instrument. The instrument distinguishes the notifications according to the significance of the events by different icons.



Some events require that you eliminate the deviation to make sure that the instrument operates correctly.

To access the notifications and history list dialog, see [Section 16.4, "Querying notifications"](#), on page 821. In remote control mode, you can query the notifications using the command `:SYSTem:ERRor:ALL?` on page 781.

16.1.1 Volatile notifications

Volatile notifications report automatic settings in the instrument (e.g. switching off incompatible types of modulation) or on entries that are not accepted by the instrument (e.g. range violations).

Volatile notifications do not normally demand user actions and disappear automatically after a short period of time. They are saved in the history list, however.

Remote command:

```
:SYSTem:ERRor:ALL? or  
:SYSTem:ERRor:CODE[:NEXT]?
```

16.1.2 Permanent notifications

Permanent notifications are displayed if an error occurs that impairs further instrument operation, e.g. a hardware fault. The error signaled by a permanent notification must be eliminated before correct instrument operation can be continued.

The message is displayed until the error is eliminated. It covers the status display in the info line. After error elimination, the message automatically disappears and is also recorded in the history.

Remote command:

```
:SYSTem:ERRor:STATic?
```

16.2 SCPI notifications


The SCPI notifications are similar for all SCPI instruments. Detailed information and an overview of all notifications as defined in the SCPI standard can be found in the corresponding documentation.

SCPI notifications have negative codes (numbers). The error text being entered into the error/event queue or being displayed is printed in bold face on the left together with the error code. Below the error text, there is an explanation to the respective error.

16.3 Device-specific notifications

Start-up error

If device-specific notifications occur during operation, the R&S SMA100B issues corresponding error messages, as listed under [Errors during operation](#). However, problems can also occur during start-up.



If your instrument prompts this notification when starting up, some information during initialization is missing. This error can occur when the power supply was interrupted during the last boot-up, e.g. due to power failure.

Remedy

- ▶ Select "Reset this error".
 - If the operating system and the firmware boot successfully, the functionality is restored.
 - If the notification reappears, a hardware error has occurred.
We recommend that you contact the Rohde & Schwarz customer support, or ship your R&S SMA100B directly to the service center experts for troubleshooting (www.services.rohde-schwarz.com).

Errors during operation

The following table contains all error messages specific for the instrument, marked by positive error codes in numerical order and an explanation of the error situation.

The device-specific error messages set bit 3 in the ESR register.



The index provides a list of the error messages sorted according to their error codes.

Error code	Error	Description	Remedy
50	External reference out of range or disconnected	The configured reference frequency source is external but there is no physical external signal or this signal is out of range.	In the "RF Frequency" > "Reference Frequency" dialog, set the correct reference signal source.
140	This modulation forces other modulations off	The instrument disables a modulation because you enabled another modulation.	
180	Adjustment failed	The instrument cannot execute an adjustment.	Generate the adjustment data and load it into the device.
182	Adjustment data missing	Adjustment data is missing.	Generate the adjustment data and load it into the device.
183	Adjustment data invalid	Adjustment data is invalid.	Generate the adjustment data and load it into the device.
200	Cannot access hardware	The data transmission to a module was unsuccessful.	The module is not installed, not properly installed or missing.
201	Hardware revision out of date	You cannot execute a specific function because of a too old hardware version. The driver does not support the installed version of a hardware module.	Consider installing a newer hardware module or downgrading the driver version
202	Cannot access the EEPROM	An error occurs when writing or reading a EEPROM.	The EEPROM is possibly defective. Replace it.
203	Invalid EEPROM data	Reading a EEPROM is possible, however the data are inconsistent.	
204	Driver initialization failed	Initialization of a driver fails when booting the instrument firmware.	The driver is not compatible with the hardware or software configuration of the instrument.

Error code	Error	Description	Remedy
241	No current list	There is no list file selected to execute the required operation.	Select a list file with the correct file extension. If no list files is available, create a list file.
242	Unknown list type specified	The list type selected is not valid for the required operation.	Check the selected list type.
460	Cannot open file	You or the application cannot open the selected file.	Check the file path and filename.
461	Cannot write file	You or the application cannot edit or write the selected file.	Check if the file is read-only.
462	Cannot read file	You or the application cannot read the selected file.	Check if the file contents are compatible with the file type.
463	Filename missing	You cannot execute a task because the filename is missing.	Enter the filename.
464	Invalid filename extension	The file extension is not valid for the required operation.	Check the file extension.
465	File contains invalid data	The file with its file extension contains invalid data. The file extension is wrong for the expected data.	Check the file extension.


16.4 Querying notifications

The R&S SMA100B monitors the functions performed and automatically detects irregularities. The instrument displays corresponding notifications in the "Info" line and collects all notifications in a history with a detailed description.

Find details to the system notifications in [Section 16, "Troubleshooting and notifications"](#), on page 818.

To monitor static notifications and history

- In the taskbar, select the "Info" icon.



- The "Static Notifications" dialog lists the recently monitored notifications chronologically and displays additional information on the highlighted message.
- The "History" dialog lists the accumulated messages with a short description. The software reports volatile notifications once. The "Info" line displays identical errors repeatedly only if the original error disappeared. Selecting this info line also opens the "Static Notifications" dialog.



Handling permanent notifications

If any critical error occurs, the R&S SMA100B automatically shows the warning icon  in the taskbar. Select the icon to obtain information on the error and the number of occurrences.

The icon is assigned to permanent notifications. The notification and icon are displayed until the error is eliminated.

Static Notifications/History

Toggles between "Static Notifications" and the "History" tab in the info dialog.

Remote command:

`:SYSTem:ERRor[:NEXT]?` on page 783

Each time a `:SYST:ERR:NEXT?` query is sent, the eldest entry in the error queue is returned and at the same time cleared in the list.

`:SYSTem:ERRor:STATic?` on page 784

Queries the list of all errors.

Clear History

Clears all messages in the "History" tab.

Remote command:

[:SYSTem:ERRor:ALL?](#) on page 781

Each time a `SYST:ERR:ALL?` query is sent, the error queue is returned and at the same time cleared.

[:SYSTem:ERRor:HISTory:CLEar](#) on page 784

Clears the messages in the "History" view.

16.5 Resolving network connection failures

Several issues may cause failures in the network connection to the instrument. This section lists the most likely reasons and the recommended solutions.

Common reasons for network connection failures

- Network connecting cables and cable connectors of poor quality
- Incompatibility between the network interface of the R&S SMA100B and certain switches or routers available on the market
- An invalid IP address assigned to the instrument

Possible solutions to network connection failures

1. **NOTICE!** Risk of network failure. Connecting to the network can cause network failure. Errors can affect the entire network.

Consult your network administrator before performing the following tasks:

- Connecting the instrument to the network
- Configuring the network
- Changing IP addresses

2. Try out the following to resolve network connection failures:

- Exchange connecting cables, if obvious damage is visible.
See also ["Cable selection to minimize electromagnetic interference"](#) on page 26.
- Observe the link status LED on the R&S SMA100B or the connected network device. The link status LED is located next to the LAN connector.
If a link failure is detected, connect the instrument to a different device port or to a different network device.
- Check whether the LAN interface and the required LAN services are enabled.
See [Section 13.4.4, "Configuring LAN services"](#), on page 395.
- If the IP address is set manually (no DHCP) or obtained with the Zeroconf (Avahi) protocol:
 - Check whether the IP address of the instrument is within the network's address range.
 - Check whether the IP address is valid.

See also ["IP Address"](#) on page 423.

16.6 Resolving errors during internal adjustments

Internal adjustments can fail for various reasons, e.g. if the adjustment data is invalid or missing, or if any error causes process to abort.

To resolve a failed adjustment process, you have the following options:

- Abort on error (default setting), see ["To resolve aborted internal adjustments"](#) on page 824
- Continue on error, see ["To continue internal adjustments on error"](#) on page 824
- Record the adjustment process in a log file and request technical support, see ["To record failed adjustments and request technical support"](#) on page 825

To resolve aborted internal adjustments

If an error occurs, the R&S SMA100B displays a notification in the "Information" field and saves the notification in the history list.

1. Select "Info".
2. Look up the error code of the notification in the overview of device-specific notifications.

See [Section 16.3, "Device-specific notifications"](#), on page 819.

The overview provides a brief explanation of all notifications and information on how to fix an error.

3. To resolve an adjustment failure, generate adjustment data and load it into the instrument.
4. Restart internal adjustments as described in ["Running internal adjustments"](#) on page 838

If the error persists:

Contact the Rohde & Schwarz customer support, see [Section 16.9, "Collecting information for technical support"](#), on page 830.

To continue internal adjustments on error

If the failed internal adjustments has no significant effect on your application, you can skip it and continue the calibration despite the error message. This function is password-protected.

1. Select "System Config > Setup > Security > Protection".
2. Unlock protection level 1, see ["Protection Level/Password"](#) on page 395.
3. Select "System Config > Setup > Internal Adjustment > Configuration > Continue Adjustment on Error > On".
4. Proceed as described in ["Running internal adjustments"](#) on page 838.

To record failed adjustments and request technical support

Logging the internal adjustment process is password-protected.

1. Select "System Config > Setup > Security > Protection".
2. Unlock protection level 1, see ["Protection Level/Password"](#) on page 395.
3. To enable recording, select "System Config > Setup > Internal Adjustment > Adjustment Configuration" > [Log Debug Info](#) > "On".
4. Send the report to the Rohde & Schwarz customer support for an initial check.
See [Section 16.9, "Collecting information for technical support"](#), on page 830.

16.7 Measuring USB cable quality

To check the quality of the USB cable, see the service manual of the R&S SMA100B.

16.8 Checking the instrument configuration

The R&S SMA100B uses various hardware and software components. To get an overview, you can check the instrument assemblies, hardware options, software options and the firmware version. The "Hardware Config" and "Versions/Options" dialogs list all components according to their hardware configuration, software options and connected Rohde & Schwarz equipment, like R&S NRP power sensors.

Installing software and hardware options

Activate newly purchased software options with a keycode. After purchase, the keycode is part of the delivery of the software option. See also [Section 13.3, "Managing licenses and license keys"](#), on page 380.

For installing newly purchased hardware options, contact Rohde & Schwarz customer support.

Checking the installed hardware options

To find out the installed options:

1. Select "System Config" > "Setup" > "Instrument Assembly" > "Versions / Options".

2. Select "Hardware Options".

Firmware	Hardware Options	Software Options	Versions	Conan Packages		✕
Option		Designation				
SMAB-B1H		OCXO with high performance				
SMAB-B28		Ramp Sweep				
SMAB-B29		Differential clock synthesizer				
SMAB-B81		Rear connectors 12.75 / 20 GHz; PC3.5				
SMAB-B86		Remote control GPIB USB				
SMAB-B93		Height Unit 3 HU				
SMAB-B140		Frequency range: 8 kHz to 40 GHz				

The dialog lists installed hardware options on the R&S SMA100B.

Proceed the same way to get information on the firmware or the installed software options in the corresponding tab.

Checking the RF hardware assembly

To find out the installed RF hardware:

1. Select "System Config" > "Setup" > "Instrument Assembly" > "Hardware Config".
2. Select "RF Assembly".

General	RF Assembly	Counter				✕
Assembly	Part Number	Serial Number	Revision	Slot		
RSYN1_AF	1420.0570.02	100000	01.00			
SMAF_REF			01.00			
MSYN6_AF	1420.0470.02	100000	01.00			
SMAF_MOD			01.00			
CSYN_AF	1420.0470.06	100000	01.00			
SMAF_MOD			01.00			
OPU6_AF	1420.0770.02	100000	01.00			
OPU6-CPLD			01.00			
			00.00			
ATT6HP_AF	1420.2050.02	100000	01.00			
ATT6HP-CPLD			01.00			
			00.00			

The dialog lists the installed RF hardware components installed on the R&S SMA100B.

Proceed the same way to get information on general or baseband hardware modules or on the operating times of the R&S SMA100B in the corresponding tab.

16.8.1 Hardware configuration settings

Access:

- Select "System Config" > "Setup" > "Instrument Assembly" > "Hardware Config".

General	RF Assembly	Counter				✕
Assembly	Part Number	Serial Number	Revision	Slot		
SMA100B	1419.8888k02	0				
FRONT_AF	1419.9690.02	100000	01.00	PCI-E slot		
PSU300	2118.2067.02	100000	01.00			
IFB.BV	1423.5009.02	100000	01.00			
MB2_AF	1420.1360.02	100000	01.00			
SMAF_COM			01.00			
ADAP_CPU_AF	1420.1960.02	100000	01.00			
DCDC2_AF	1420.1860.02	100000	01.00			
IPM21	1206.3122.02	100000	01.00	PCI-E slot		
BIOS						

The "Hardware Config" dialog lists all installed assemblies and connected external instruments with information on their part and serial numbers, and revision states. Also, it lists the BIOS version. A firmware update does not update the BIOS version. The "Counter" tab provides information on the operation time, the number of times that the instrument was powered on and the last factory calibration of the instrument.

The remote commands required to query the hardware configuration are described in [Section 15.8, "DIAGnostic subsystem"](#), on page 513.

Assembly

The tables in the tabs show characteristics of the installed assemblies.

"Assembly" Assembly designation.

"Part Number" Part number of the assembly.

"Serial Number" Serial number of the assembly.

"Revision" Revision state of the assembly.

"Slot" Indicates whether the assembly is connected to the serial bus or PCI bus.

Remote command:

`:DIAGnostic<hw>:BGInfo?` on page 514

Counter

Displays information on the operation times of the R&S SMA100B.

Operation Time / h ← Counter

Displays the operation time in hours so far.

Remote command:

[:DIAGnostic:INFO:OTIME?](#) on page 514

Power On Count ← Counter

Displays the number the instrument has been turned on.

Remote command:

[:DIAGnostic:INFO:POCount?](#) on page 515

Last Factory Calibration ← Counter

Displays the date of the last factory calibration.

Remote command:

[:CALibration:DATA:FACTory:DATE?](#) on page 506

16.8.2 Versions and options settings

Access:

- Select "System Config" > "Setup" > "Instrument Assembly" > "Versions / Options".

Firmware	Hardware Options	Software Options	Versions	Conan Packages	
Package	Version				
FW	5.00.113				
Service Pack	not installed				
BIOS Version	1.6				
Downgrade Info					
Package	Version				
Factory Version	5.00.113				
Min. Version	4.30.005.26				
The Min. Version is the first version supporting all hardware modules installed in this instrument. Please read release notes carefully before downgrading, some software options and features may get lost.					
Show Open Source Acknowledgments		LucasFonts RSCorpid EULA			

The "Versions / Options" dialog shows the version of the installed instrument firmware, the hardware and software options, the data sheet and the software components of the firmware. The BIOS version is also listed; firmware updates do not update the BIOS version.

The remote commands required to query the hardware configuration are described in [Section 15.8, "DIAGnostic subsystem"](#), on page 513.

Firmware

Shows the firmware version and the version of the software platform.

Note: Your instrument is delivered with the latest firmware version available. You can download firmware updates and the "Release Notes" that describe the modifications and the firmware update procedure.

See www.rohde-schwarz.com/firmware/sma100b

Remote command:

n.a.

Downgrade Info

Shows downgrade information, like factory firmware version and minimum firmware version to that the instrument can be downgraded.

Remote command:

n.a.

Show Open Source Acknowledgments

Accesses the list of the used open-source software packages and the corresponding verbatim license texts.

LucasFonts RSCorpid EULA

Accesses copyright information on LucasFonts font type RSCorpid EULA.

Hardware Options/Software Options

The tables in the "Hardware" and "Software" tabs list the installed hardware and software options.

"Option" Short name of option

"Designation" Name of option

"Expiration Date"

For regular options, "Permanent" is indicated in this column.

Remote command:

*[OPT?](#) on page 489

*[IDN?](#) on page 489

Versions

The "Versions" tab shows the versions of the technical specification of the R&S SMA100B and of the software components that comprise the firmware.

"Package" Name of the component.

"Version" Current issue of the component.

E.g. the data sheet covers the technical data of the hardware components of the factory settings.

See also [Section 14.7.4, "Datasheet"](#), on page 451.

Remote command:

:[SYSTem:SPECification:VERSion:FACTory?](#) on page 801

16.9 Collecting information for technical support

If you encounter problems that you cannot solve yourself, contact your Rohde & Schwarz support center at www.rohde-schwarz.com/support. Our support center staff is optimally trained to assist you in solving problems.


The support center finds solutions more quickly and efficiently if you provide them with information on the instrument and an error description.

- The following dialog boxes in the "Setup > Instrument Assembly" menu provide useful information:
 - **Hardware Configuration:** hardware assemblies
 - **Software and Options:** the status of all software and hardware options installed on your instrument
- **System Messages:** displayed in the "Info" line and provide information on any errors that have occurred
- **Support file:** a special file (*.tar.gz file) with important support information that can be created automatically.
The support *.tar.gz file has a user-definable name and contains the following files and information:
 - SgErrors.txt: chronological record of errors
 - SystemRestorationSMAB.savrc1.txt: instrument settings at the last correct shutdown of the instrument
 - UndoHistSuppInfo.xml: list of the last user interactions
 - DeviceFootprint_<SerialNumber>_<Date>_<Time>.xml: service-related information on the instrument's configuration.
 - crashlog.txt, coredump: Postmortem debug info
 - Several files with information on the last performed adjustment and self-test.

See also the description of error messages [Section 16.1, "Notifications"](#), on page 818.

To collect error information in a support file

1. Connect a USB device to the R&S SMA100B.
2. Select "System Config > Setup > Maintenance > Create R&S Support Information".
3. In the "Create R&S Support Information" dialog, navigate to the /usb directory.
Enter the support filename, for example RSSupport_DeviceInfo.



The error information and further required data are collected automatically. The support file `RSSupport_DeviceInfo.tar.gz` is created and stored in the `/usb` directory.

Collect the error information and attach it to an email in which you describe the problem. Send the email to the customer support address as listed on the Internet (www.rohde-schwarz.com/support).

To remove sensitive data

- For information on how to handle or remove the sensitive data from your instrument, refer to the description "R&S SMA100B Instrument Security Procedures".

To pack and transport the instrument

- If you need to transport or ship the instrument, see [Section 17, "Transporting"](#), on page 833.

16.10 Contacting customer support

Technical support – where and when you need it

For quick, expert help with any Rohde & Schwarz product, contact our customer support center. A team of highly qualified engineers provides support and works with you to find a solution to your query on any aspect of the operation, programming or applications of Rohde & Schwarz products.

Contact information

Contact our customer support center at www.rohde-schwarz.com/support, or follow this QR code:



Figure 16-1: QR code to the Rohde & Schwarz support page

17 Transporting

Lifting and carrying

For safety information, see:

- ["Lifting and carrying the product"](#) on page 16
- [Section 3.1.1, "Lifting and carrying"](#), on page 23

Packing

Use the original packaging material. It consists of antistatic wrap for electrostatic protection and packing material designed for the product.

If you do not have the original packaging, use similar materials that provide the same level of protection. You can also contact your local Rohde & Schwarz service center for advice.

Securing

When moving the R&S SMA100B in a vehicle or using transporting equipment, make sure that the R&S SMA100B is properly secured. Only use items intended for securing objects.

Transport altitude

The maximum transport altitude without pressure compensation is specified in the specifications document.

18 Maintenance, storage and disposal

We advise to check the nominal data from time to time.

18.1 Cleaning

How to clean the product is described in ["Cleaning the product"](#) on page 17.

Do not use any liquids for cleaning. Cleaning agents, solvents, acids and bases can damage the front panel labeling, plastic parts and display.

18.2 Storage

Protect the product against dust. Ensure that the environmental conditions, e.g. temperature range and climatic load, meet the values specified in the specifications document.

18.3 Performing maintenance tasks

The R&S SMA100B is accurate due to integrated adjustment procedures and additional test functions that assure correct functioning.

Internal adjustments are integrated self-calibration routines, which you can execute directly on the instrument.

How to: See [Section 18.3.1.3, "How to use the internal adjustments"](#), on page 838.

Self-calibration routines that require additional equipment are performed at an authorized Rohde & Schwarz service center. For description, see the R&S SMA100B service manual.

18.3.1 Internal adjustments

Using the integrated adjustment procedures, you can start the calibration directly on the instrument.

Minimum power rating required for internal adjustments

Depending on the instrument configuration, it can be required that you have to replace the DUT by an external 50 Ω termination at the RF output. The following tables show the minimum required power rating of the terminating resistor regarding the output power and frequency options. The termination must be specified for the entire frequency range of the instrument.

Table 18-1: Standard (no option) or high output power (R&S SMAB-B35/-B37/-B39/-K31/-K33/)

Frequency option	R&S SMAB-B103/.../B120	R&S SMAB-B131/.../B167	R&S SMAB-B131/.../B167
Firmware version	Not relevant	<4.60.112.29SP5	≥4.60.112.29SP5
Min. power rating	1 W (30 dBm)	1 W (30 dBm)	No termination required

Table 18-2: Ultra high output power (R&S SMAB-B32/-B34/-K36/-K38/-K40)

Frequency option	R&S SMAB-B103/.../B120	R&S SMAB-B131/.../B167	R&S SMAB-B131/.../B167
Firmware version	Not relevant	<4.60.112.29SP5	≥4.60.112.29SP5
Min. power rating	2 W (33 dBm)	2 W (33 dBm)	No termination required

Table 18-3: Super ultra high output power (R&S SMAB-B36S)

Frequency option	Not relevant		
Firmware version	Not relevant		
Min. power rating	2 W (33 dBm)		

18.3.1.1 Internal adjustment settings

Access:

- Select "System Config > Setup > General > Internal Adjustments".

In this dialog, you can perform internal calibration routines, and get information on the last performed calibration.

The "Temperature Offset" indicates the deviation of the current temperature of the instrument, compared to the temperature of the last adjustment.

The remote commands required to define these settings are described in [Section 15.6, "CALibration subsystem"](#), on page 504.

How to: See [Section 18.3.1.3, "How to use the internal adjustments"](#), on page 838.

Settings

Adjust All

Executes all available internal calibration routines of the instrument.

Note: Before you start the internal adjustment, make sure that you have connected a termination resistor, if necessary.

Remote command:

[:CALibration:ALL\[:MEASure\]? on page 504](#)

Last Full Adjustment

Displays the date of the last fully performed adjustment.

Remote command:

[:CALibration<hw>:ALL:DATE? on page 505](#)

Time

Displays the elapsed time since the last full adjustment.

Remote command:

[:CALibration<hw>:ALL:TIME? on page 506](#)

Temperature Offset

Displays the temperature difference, comparing the temperature of the last adjustment to the current instrument temperature.

A green checkmark indicates that the offset is within the permitted range. If the temperature deviates more than ± 5 K, the instrument indicates a warning icon.

Remote command:

[:CALibration<hw>:ALL:TEMP? on page 505](#)

Information

Displays information to the current adjustment state.

Remote command:

[:CALibration<hw>:ALL:INformation? on page 505](#)

Continue Adjustment on Error

Continues the calibration even though an error was detected. By default adjustments are aborted on error.

This function is password-protected. Unlock the protection level 1 to access it.

Remote command:

[:CALibration<hw>:CONTinueonerror on page 506](#)

Log Debug Info

Activates logging of the internal adjustments.

This function is password-protected. Unlock the protection level 1 to access it.


Remote command:

[:CALibration<hw>:DEBug on page 508](#)

18.3.1.2 Delayed adjustment settings

Access:

- ▶ Select "System Config > Setup > General > Delayed Adjustment".



In this dialog, you can set the internal adjustments to start automatically after the selected warm up time and to switch off the instrument after calibration.

The remote commands required to define these settings are described in [Section 15.6, "CALibration subsystem"](#), on page 504.

Settings

Adjust All Delayed	837
Warm Up Time	837
Shutdown After Adjustment	837

Adjust All Delayed

Performs all available internal calibration routines of the instrument.

How to: See [Starting internal adjustments automatically](#).

Remote command:

[:CALibration:DElay\[:MEASure\]?](#) on page 507

Warm Up Time

Sets the time for warming up the instrument before the calibration starts automatically.

How to: See [Starting internal adjustments automatically](#).

Remote command:

[:CALibration:DElay:MINutes](#) on page 507

Shutdown After Adjustment

Enables the automatic shutdown after internal adjustments.

How to: See [Starting internal adjustments automatically](#).

Remote command:

[:CALibration:DElay:SHUTdown\[:STATe\]](#) on page 507


18.3.1.3 How to use the internal adjustments

Deciding whether to run internal adjustments

1. Select "System Config > Setup > Internal Adjustment".
2. Check the status and color indication in the section "Since Last Full Adjustment".
Green: internal adjustments are not required.
Red: internal adjustments are required. Observe also the indication in the "Information" field.
3. We recommend that you run internal adjustments in the following cases:
 - Before starting any application that requires a maximum of level accuracy.
 - When a long period of time has passed since the last adjustments.
 - If the ambient temperature of the instrument significantly differs from the one of the last adjustments.
4. Proceed as described in ["Running internal adjustments"](#) on page 838.

Running internal adjustments


1. After switching on, the R&S SMA100B requires up to 30 minutes to warm up.
Wait until the instrument has reached operating temperature to achieve accurate adjustments.
2. **NOTICE!** High power at the RF 50 Ω output can destroy a connected DUT (device under test).
Disconnect the DUT.
3. Replace the DUT by a terminating resistor.
The required power rating of the resistor varies depending on whether the instrument is equipped with a high-power option, see ["Minimum power rating required for internal adjustments"](#) on page 834.
4. Select "System Config > Setup > Internal Adjustment > Adjust All".
A warning message prompts you to confirm that you have terminated the RF 50 Ω output.



5. Confirm with "Ok".

The R&S SMA100B verifies the termination at the output:

- If you have terminated with 50 Ω , the adjustment process starts.
- If you have not terminated with 50 Ω , a second warning message appears.



Confirm with "OK". The adjustment aborts.

The adjustment process takes some time depending on the equipment of the instrument.

If any error occurs, the process aborts. To resolve adjustment issues, see [Section 16.6, "Resolving errors during internal adjustments"](#), on page 824.

Starting internal adjustments automatically

The delayed adjustment function executes the adjustments automatically. You can set the warm-up time and shut down after the adjustment process finishes. Using this function, you can execute adjustments without being on-site and start measurements directly when back.

1. If necessary, terminate the RF 50 Ω output. See ["Running internal adjustments"](#) on page 838.
2. Select "System Config > Setup > General > Internal Adjustment".
3. Select "Delayed Adjustment".
4. Set the "Warm Up Time", e.g. 40 min.

The R&S SMA100B requires a warm-up time of at least 30 min.

5. Enable "Shut Down After Adjustment".
6. Select "Adjust All Delayed".

The process starts with warming up the instrument, indicating the progress in a status dialog. In this dialog, you can abort the process again, if necessary.

After warming up, the R&S SMA100B executes the internal adjustments and shuts down when finished.

18.3.2 Date and time

The R&S SMA100B uses an internal real-time clock to determine the date and time. It adjusts the time and date to the timezone of your location automatically, by providing a selection list of continents and cities.

The instrument records the time whenever you create or modify files on your instrument or you use timed licenses. By default, the instrument is set to the UTC timezone, but you can select the timezone according to your location.

Moreover, the instrument supports NTP protocol for synchronizing all connected instruments and computer systems to minimize time delays in the network.

18.3.2.1 Date and time settings

Access:

- Select "System Config" > "Setup" > "Maintenance" > "Date / Time".

Date / Time

Date [YYYY-MM-DD]2023-01-16

Time [hh:mm:ss]14:58:04

Time Zone

UTC

Time Protocol Settings

Time Protocol

NTP

NTP Address

The "Date / Time" dialog contains the time and data settings of the operating system.
This function is password-protected. Unlock the protection level 1 to access it.
You can also set the time zone for your location, and select a time protocol controlled by a time server for synchronization.

The required remote commands are described in [Section 15.19, "SYSTem subsystem"](#), on page 776.

Settings:

Date.....	840
Time.....	840
Timezone.....	841
Time Protocol.....	841
NTP Address.....	841

Date

Displays the date set in the operating system in the format [yyyy.mm.dd].

Remote command:

:SYSTem:DATE on page 802

Time

Displays the time set in the operating system in the format [hh.mm.ss].

The time setting corresponds to the selected [Timezone](#).

Remote command:

`:SYSTem:TIME` on page 802

Timezone

Selects the timezone in the date and time settings of the operating system.

You can select the timezone according to the major cities on the respective continents.

Tip: By typing the first letter, you can quickly navigate through the lists to find the desired destination.

Remote command:

`:SYSTem:TIME:ZONE` on page 803

`:SYSTem:TIME:ZONE:CATalog?` on page 803

Time Protocol

Enables the instrument to refer to a network time protocol.

A network time protocol synchronizes the system clocks of all participating devices in a computer network (Ethernet). A time server in the network provides the time base for the connected devices that refer to this time to synchronize events.

You can select a high-precision time protocol to achieve high clock accuracy and thus reduce the impact of varying network delays.

"None" Refers to the selected timezone, see "Timezone" on page 841.

"NTP" Uses the network time protocol (NTP).

Remote command:

`:SYSTem:TIME:PROTOcol` on page 803

NTP Address

Sets the IP address or host name of the NTP server.

When the server is detected and verified, the instrument enables the connection automatically.

Remote command:

`:SYSTem:NTP:HOSTname` on page 802

`:SYSTem:NTP:STATe` on page 802

18.3.2.2 How to set date and time

To select the timezone

1. Press the [Setup] key.
2. Select "Maintenance > Date /Time > Timezone".
3. Select continent and city of your location.
Tip: By typing the first letter, you can quickly navigate through the lists to find the desired destination.
4. Close the dialogs.

The instrument adjusts the time according to the selected location.

To set the date and time**1. NOTICE!**

This function is password-protected. Unlock the protection level 1 to access it.

Since the date and time settings affect time-based options, changing the date and time can therefore lead to loss of access to the function of the options. We recommend that you only change the system time in urgent cases.

If the time is not displayed correctly, the internal CMOS battery can be discharged. To change the battery, contact your Rohde & Schwarz support center at www.rohde-schwarz.com/support.

Press the [Setup] key.

2. Select "Security > Protection".
3. Enable the "Protection Level 1".
The default password is 123456.
4. Select "Setup > Maintenance > Date / Time".
5. Adjust the settings.
6. Close the dialogs.

The instrument sets the new date and time.

18.3.3 Check front panel

Within this dialog, you can verify the functionality of the control keys.

How To: See [Section 18.3.3.2, "How to test the front panel"](#), on page 843

18.3.3.1 Check front panel settings

Access:

- Select "System Config > Setup > Maintenance > Check Front Panel".



Reflecting the front panel, the "Check Front Panel" dialog contains all functions to test the operating elements of the instrument.

18.3.3.2 How to test the front panel

See:

- ["Testing the key panel"](#) on page 843
- ["Testing the touchscreen"](#) on page 844
- ["Terminating the test"](#) on page 845
- ["Debugging"](#) on page 845

Testing the key panel

To perform the key panel test, you operate the keys at the front panel, and check the response of the instrument in the "Check Front Panel" dialog. To perform this test properly, check each key of the front panel. The test is only completed, when you have verified all keys.

During the test, the actual functions of the keys are disabled.

1. Press the [Setup] key.
2. Select "Maintenance > Check Front Panel"
The "Check Front Panel" dialog opens.
3. Press a key on the front panel.
Check if the corresponding key in the "Check Front Panel" dialog turns green.
4. Press the same key a second time.
Check that the key in the dialog turns red.


Note: Pressing the same key again has no further effect, except for the [Esc] key. Pressing this key a third time, terminates the test procedure.

- Continue with the next key on the front panel and repeat [step 3](#) to [step 5](#) until all keys are tested.

The test is completed, when each key is verified successfully, confirmed by a "Test passed" message.

Testing the touchscreen


- Press the [Setup] key.
- Select "Maintenance > Check Touch Panel"
The "Finger Paint" test window opens.




- Drag with your finger one or more lines, for example diagonally across the screen. The test traces the movements of your finger on the screen.

The following results are expected:

- If the lines are uninterrupted, the touchscreen works properly.



- If there are any gaps, the touch-sensitive functionality is damaged.



- To return to the "Check Front Panel" dialog, press [Esc].

Terminating the test

- ▶ Press the [Esc] key.
Exits the "Check Front Panel" dialog.

Debugging

1. If you detect a malfunction, for example, when you press the front panel key for the first time, and the color of the button in the dialog turns red (instead of green), the front panel key has probably stuck.
2. Contact the Rohde & Schwarz customer support, see [Section 16.9, "Collecting information for technical support"](#), on page 830.

18.3.4 Check display screen

Using this function, you can verify the color depth and gradient, pixels and the text display of the screen.

Access:

- ▶ Select "System Config > Setup > Maintenance > Check Display Screen".
The R&S SMA100B fades out the current display and indicates the screen in red.
Short instructions on the screen explain how to execute the test.


The remote commands required to define these settings are described in [Section 15.21, "TEST subsystem"](#), on page 810.

Testing the display screen

1. Press the [Setup] key.
2. Select "Maintenance > Check Display Screen"

The "Check Display Screen" window opens.

3. Test the color and gradient of the display screen:



- a) Use the [Help] key to hide the indicated text.
 - b) To toggle between the provided colors manually, use the navigation controls [Left/Right] or the rotary knob.
The R&S SMA100B provides the colors red, green, blue, white, three levels of gray shades and black.
 - c) To switch between the screen colors automatically, use the [Up] key.
 - d) To toggle the gradient, use the [Down] key.
4. Check if the R&S SMA100B indicates the text correctly:
 - a) Press [1] on the numeric keypad.
The R&S SMA100B displays a test text over the entire screen.
 - b) To inspect the text in detail, you can use the rotary knob to zoom it out.
5. To exit the test, press the [Esc] key.

[Check Display Screen](#).....846

Check Display Screen

Opens the test window with instructions on how to perform the test.


Remote command:

:TEST:PIXel:WINDow on page 813
 :TEST:PIXel:COLor on page 811
 :TEST:PIXel:RGBA on page 812
 :TEST:PIXel:GRADient on page 812
 :TEST:PIXel:TEXT on page 812
 :TEST:PIXel:POINTsize on page 812

18.3.5 FPGA/uC update settings

Access:

- Select "System Config > Setup > Maintenance > FPGA/μC Update".



This dialog enables you to check for internal assembly updates and perform updates.

Settings:

Check For Updates.....	847
Assembly.....	847
Install.....	847
Shut down.....	848
Update External Devices.....	848
L Check For Updates.....	848

Check For Updates

Check for updates of the FPGA/μC.
Remote command:
n.a.

Assembly

The table shows the installed assemblies and their states.
"Assembly" Assembly designation.
"State" Indicates the current state of installed assemblies.

Install

Install all available updates for the FPGA/μC.
Remote command:
n.a.

Shut down

For at least one assembly "State = Done" and no pending assemblies, shuts the instrument down to apply installed updates.

Remote command:

:SYSTem:SHUTdown on page 806

Update External Devices

This dialog shows the update options of external devices connected to the instrument.

Check For Updates ← Update External Devices

Check for updates of external devices.

Remote command:


n.a.

18.3.6 Delete temporary files

During signal processing, the R&S SMA100B creates and saves various temporary files in a predefined directory on its non-volatile memory. This predefined directory is a protected system directory you cannot access in the "File Manager", but you can delete all temporary files saved there.

To achieve more free disc space on the internal memory

1. Select "System Config > Setup > Maintenance > Delete Temporary Files".



2. Select "Delete Temporary Files".

Deletes the content of the predefined directory.



Another way to achieve more free disc space on the internal memory is to use the [Execute Factory Preset](#).

This function removes all temporary files, too, but also resets several parameters to their factory preset values.

Remote command:

:SYSTem:FILEs:TEMPorary:DElete on page 806

18.4 Disposal

Rohde & Schwarz is committed to making careful, ecologically sound use of natural resources and minimizing the environmental footprint of our products. Help us by disposing of waste in a way that causes minimum environmental impact.

Disposing of electrical and electronic equipment

A product that is labeled as follows cannot be disposed of in normal household waste after it has come to the end of its life. Even disposal via the municipal collection points for waste electrical and electronic equipment is not permitted.



Figure 18-1: Labeling in line with EU directive WEEE

Rohde & Schwarz has developed a disposal concept for the eco-friendly disposal or recycling of waste material. As a manufacturer, Rohde & Schwarz completely fulfills its obligation to take back and dispose of electrical and electronic waste. Contact your local service representative to dispose of the product.

Annex

A Reference information for remote control

A.1 Telnet program examples

The following program example shows a simple `TcpClient` class that is intended to explain on how to get started with programming of sockets.

The example sets up a socket communication to R&S SMA100B and opens a simple user interface, very similar to the telnet, which allows input of commands. To enable real automation, further development of the program is required.

TcpClient.h

```
#include <string>
//defines structs for socket handling
#include <netinet/in.h>
using namespace std;
typedef struct sockaddr_in SockAddrStruct;
typedef struct hostent      HostInfoStruct;
class TcpClient
{
public:
    TcpClient();
    ~TcpClient();
    void connectToServer( string &hostname, int port );
    void disconnect( );
    void transmit( string &txString );
    void receive( string &rxString );
    string getCurrentHostName( ) const;
    int    getCurrentPort( ) const;
private:
    string      currentHostName;
    int         currentPort;
    int         currentSocketDescr;
    SockAddrStruct  serverAddress;
    HostInfoStruct * currentHostInfo;
    bool        clientIsConnected;
    int         receiveBufferSize;
};
```

TcpClient.cpp

```
#include <string>
//defines structs for socket handling
#include <netinet/in.h>
```

```

using namespace std;
typedef struct sockaddr_in SockAddrStruct;
typedef struct hostent     HostInfoStruct;
class TcpClient
{
public:
    TcpClient();
    ~TcpClient();
    void connectToServer( string &hostname, int port );
    void disconnect( );
    void transmit( string &txString );
    void receive( string &rxString );
    string getCurrentHostName( ) const;
    int    getCurrentPort( ) const;
private:
    string      currentHostName;
    int         currentPort;
    int         currentSocketDescr;
    SockAddrStruct  serverAddress;
    HostInfoStruct * currentHostInfo;
    bool        clientIsConnected;
    int         receiveBufferSize;
};

#include <netdb.h>
#include <netinet/in.h>
#include <unistd.h>
#include "TcpClient.h"
TcpClient::TcpClient()
: currentHostName( "" )
, currentPort( 0 )
, currentSocketDescr( 0 )
, serverAddress ( )
, currentHostInfo( NULL )
, clientIsConnected( false )
, receiveBufferSize( 1024 )
{
}

TcpClient::~~TcpClient()
{
    currentHostInfo = NULL;
}

void TcpClient::connectToServer( string &hostname, int port )
{
    currentHostInfo = gethostbyname( hostname.c_str( ) );
    if( currentHostInfo == NULL )
    {
        currentHostName = "";
        currentPort      = 0;
    }
}

```

```

        currentHostInfo    = NULL;
        clientIsConnected = false;
        printf("error connecting host\n" );
    }
    currentHostName = hostname;
    currentPort     = port;
    currentSocketDescr = socket(AF_INET, SOCK_STREAM, 0);
    if( currentSocketDescr == 0 )
    {
        currentHostName    = "";
        currentPort        = 0;
        currentHostInfo    = NULL;
        clientIsConnected = false;
        printf("can't create socket\n" );
    }
    serverAddress.sin_family = currentHostInfo->h_addrtype;
    serverAddress.sin_port   = htons( currentPort );
    memcpy( (char *) &serverAddress.sin_addr.s_addr,
        currentHostInfo->h_addr_list[0], currentHostInfo->h_length );
    if( connect( currentSocketDescr, ( struct sockaddr *) &serverAddress,
        sizeof( serverAddress ) ) < 0 )
    {
        throw string("can't connect server\n" );
    }
    clientIsConnected = true;
}
void TcpClient::disconnect( )
{
    if( clientIsConnected )
    {
        close( currentSocketDescr );
    }
    currentSocketDescr = 0;
    currentHostName    = "";
    currentPort        = 0;
    currentHostInfo    = NULL;
    clientIsConnected = false;
}
void TcpClient::transmit( string &txString )
{
    if( !clientIsConnected )
    {
        throw string("connection must be established before any data can be sent\n");
    }
    char * transmitBuffer = new char[txString.length() +1];
    memcpy( transmitBuffer, txString.c_str(), txString.length() );
    transmitBuffer[txString.length()] = '\n'; //newline is needed!
    if( send( currentSocketDescr, transmitBuffer, txString.length() + 1, 0 ) < 0 )
    {
        throw string("can't transmit data\n");
    }
}

```



```

    }
    delete [] transmitBuffer;
}
void TcpClient::receive( string &rxString )
{
    if( !clientIsConnected )
    {
        throw string("connection must be established before any data can be received\n");
    }
    char * receiveBuffer = new char[receiveBufferSize];
    memset( receiveBuffer, 0, receiveBufferSize );
    bool receiving = true;
    while( receiving )
    {
        int receivedByteCount = recv( currentSocketDescr,
            receiveBuffer, receiveBufferSize, 0 );
        if( receivedByteCount < 0 )
        {
            throw string("error while receiving data\n");
        }
        rxString += string( receiveBuffer );
        receiving = ( receivedByteCount == receiveBufferSize );
    }
    delete [] receiveBuffer;
}
string TcpClient::getCurrentHostName( ) const
{
    return currentHostName;
}
int TcpClient::getCurrentPort( ) const
{
    return currentPort;
}

```

TelnetClient.cpp

```

#include <iostream>
#include "TcpClient.h"
void printUsage()
{
    cout<<"usage: EthernetRawCommand <server-ip> [scpi-command]"<<endl;
}
int main( int argc, char *argv[] )
{
    int errorCode          = 0; //no error
    bool useSingleCommand = false;
    string singleCommand   = "";
    string hostname        = "";
    int    port            = 5025;
    string input           = "";
}

```

```
TcpClient client;
switch( argc )
{
    case 3:
        useSingleCommand = true;
        singleCommand     = argv[2];
    case 2:
        hostname          = argv[1];
        break;
    default:
        printUsage();
        return(-1);
}
try
{
    client.connectToServer( hostname, port );
    bool terminate = false;
    while( !terminate )
    {
        char buffer[1024];
        if( useSingleCommand )
        {
            input = singleCommand; //send string
        }
        else
        {
            cin.getline( buffer, 1024 );
            input = buffer;
            if( input == "end" )
            {
                terminate = true;
            }
        }
        if( !terminate)
        {
            client.transmit( input ); //send string
            int qPos = input.find( "?", 0 );
            //receive string only when needed
            if( qPos > 0 )
            {
                string rcStr = "";
                client.receive( rcStr );
                cout << rcStr << endl;
            }
        }
        if( useSingleCommand )
        {
            terminate = true;
        }
    }
}
```

```

}catch( const string errorString )
{
    cout<<errorString<<endl;
}
client.disconnect( );
return errorCode;
}

```

A.2 GPIB interface

Option: R&S SMAB-B86.

This section provides detailed information on the general-purpose interface bus (GPIB) interface "IEC 625/IEEE 488" for remote control of the instrument. It covers the following topics:

- ["Pin assignment"](#) on page 855
- ["Bus lines"](#) on page 855
- ["Interface functions"](#) on page 856

For other remote control interfaces, see [Section 14, "Network operation and remote control"](#), on page 408.

Pin assignment




Figure A-1: Pin assignment of the GPIB interface

Bus lines

- Data bus with eight lines D0 to D7:

The transmission is bit-parallel and byte-serial in the ASCII/ISO code. D0 is the least significant bit, D7 the most significant bit.

- Control bus with five lines:
 - IFC** (Interface Clear): active LOW resets the interfaces of the instruments connected to the default setting.
 - ATN** (Attention): active LOW signals the transmission of interface messages, inactive HIGH signals the transmission of device messages.
 - SRQ** (Service Request): active LOW enables the connected device to send a service request to the controller.
 - REN** (Remote Enable): active LOW permits switchover to remote control.
 - EOI** (End or Identify): two functions in connection with ATN:
 - ATN=HIGH active LOW marks the end of data transmission.
 - ATN=LOW active LOW triggers a parallel poll.
- Handshake bus with three lines:
 - DAV** (Data Valid): active LOW signals a valid data byte on the data bus.
 - NRFD** (Not Ready For Data): active LOW signals that one of the connected devices is not ready for data transfer.
 - NDAC** (Not Data Accepted): active LOW signals that the instrument connected is accepting the data on the data bus.

Interface functions

You can use different interface functions to control the instrument via the GPIB interface. [Table A-1](#) lists the interface functions for the R&S SMA100B.

Table A-1: GPIB interface functions

Control character	Interface function
SH1	Handshake source function (source handshake), full capability
AH1	Handshake sink function (acceptor handshake), full capability
L4	Listener function, full capability, de-addressed by MTA.
T6	Talker function, full capability, ability to respond to serial poll, deaddressed by MLA
SR1	Service request function (Service Request), full capability
PP1	Parallel poll function, full capability
RL1	Remote/Local switch-over function, full capability
DC1	Reset function (Device Clear), full capability
DT1	Trigger function (Device Trigger), full capability

For more information, refer to the specifications document.

B Available user files and file extensions

The table [Table B-1](#) lists available file extensions for user files on the instrument. Some files depend on the installed options.

For more information, refer to the specifications document.

Table B-1: User files and file extensions on the instrument

Context or function	Content type	File contents	File extension
Instrument state	Settings	Instrument settings	*.savrc1txt
User menu	Settings	User-defined favorite settings	*.user_menu
License key	License	License key	*.xml
User correction	List	User-defined level correction values	*.uco
List Mode	List	User-defined frequency/level value pairs	*.lsw
Pulse train	Settings	Pulse train data	*.pulstrn
Power sensing	Settings	R&S NRP settings	*.nrp, *.rsu
SCPI command list	List	Export file containing list of SCPIs	*.iec
SCPI command script	Command script	SCPI script file formats: Plain SCPI, MATLAB, NICVI, Python3	*.txt, *.m, *.c, *.py
R&S support information	Support file	Automatically collected support information	*.tar.gz
Tutorials	Tutorial files	Lists containing SCPIs and explanations	*.tut

C Unit shortcuts

When specifying units or quantities during data entry, the R&S SMA100B provides the following shortcuts for simplified input.

Shortcut	Designation	Context	Unit
a, A	ampere	Current	A
	atto-	Area, surface	am ²
c, C	centi-	Distance, length	cm
d, D	deci-	Distance, length	dm
		Level, power	dB, dBFS, dBm, dBu, dBW
	degree	Phase, polar/spherical coordinates	deg
e, E	exa-	Area, surface	em ²
f, F	femto-	Area, surface	fm ²
g, G	giga-	Area, surface	Gm ²
		Data rate, sample rate, symbol rate	Gbit/s, Gsample/s, Gsymbol/s, Gchip/s
		Frequency	GHz
		Impedance, resistance	GΩ
h, H	hertz	Frequency	Hz
k, K	kilo-	Area, surface	km ²
		Data rate, sample rate, symbol rate	kbit/s, ksample/s, ksymbol/s, kchip/s
		Distance, length	km
		Frequency	kHz
		Impedance, resistance	kΩ
		Velocity	km/h
m, M	milli-	Area, surface	mm ²
		Current	mA
		Distance, length	mm
		Electromagnetic force, level	mV
		Power	mW
		Time, period, etc.	ms
	mega-	Area, surface	Mm ²
		Data rate, sample rate, symbol rate	Mbit/s, Msample/s, Msym/s, Mchip/s
		Frequency	MHz
		Impedance, resistance	MΩ

Shortcut	Designation	Context	Unit
n, N	nano-	Area, surface	nm ²
		Current	nA
		Distance, length	nm
		Electromagnetic force, level	nV
		Power	nW
		Time, period, etc.	ns
o, O	ohm	Impedance, resistance	Ω
p, P	peta-	Area, surface	pm ²
	percent	Level, ratio	%
	pico-	Area, surface	pm ²
		Current	pA
		Electromagnetic force, level	pV
		Power	pW
		Time, period, etc.	ps
r, R	radiant	Phase, polar/spherical coordinates	rad
s, S	second	Time, period, etc.	s
t, T	terra-	Area, surface	Tm ²
		Data rate, sample rate, symbol rate	Tbit/s, Tsample/s, Tsym/s, Tchip/s
		Frequency	THz
		Impedance, resistance	TΩ
u, U	micro-	Current	μA
		Distance, length	μm
		Electromagnetic force, level	μV
		Power	μW
		Time, period, etc.	μs
v, V	volt	Level, voltage	V
w, W	watt	Level, power	W

D Morse code settings

The COM/ID tone is sent according to the selected code (see [Table D-1](#)). The length of the Morse code can be varied. For selected standard time scheme, the selected dot length determines the setting of all other length parameters of the Morse code (dash length, symbol space and letter space). For selected user time scheme, all length parameters of the code can be set independently. If no coding is entered, the COM/ID tone is sent uncoded (key down).



The following values are default values:

- A dot (.) has a tone duration of 100 ms
- A dash (-) has a tone duration of 300ms
- The time between two tones is 100ms
- The time between two letters is 300ms

After each word, a word space is entered. The word repetition rate is 7 words per minute. Since the word length can vary between 900 ms and 4500 ms, the word space between the words varies accordingly.

Example:

ID code = MUC

The word length =

$(300+100+300)+300+(100+100+100+100+300)+300+(300+100+100+100+300+100+100) = 3100 \text{ ms}$

Table D-1: Morse code

Letter	Morse code	Letter	Morse code
A	. -	N	- .
B	- . . .	O	- - -
C	- . . .	P	. - . .
D	- . .	Q	- - . -
E	.	R	. - .
F		S	. . .
G	- - .	T	-
H		U	. . -
I	. .	V	. . . -
J	. - - -	W	. - -
K	- . -	X	- . . -
L	. - . .	Y	- . - -
M	- -	Z	- - . .

Glossary: Terms and abbreviations

Symbols

1MA193: 1MA193_0e Application Note, "Aeronautical radio navigation measurement solutions"

A

Avahi: A licensed [Zeroconf](#) networking feature, including DNS service. The feature enables a device to self-configure an IP address and subnet mask automatically, when a [DHCP](#) server in the LAN is not available.

B

Base unit: This term describes a R&S SMA100B equipped with the option R&S SMAB-B103.

C

Clock: A mandatory internal or an external reference clock signal for generating the timing pulse in the instrument.

Complete file path: The complete file path specifies the root directory and all subdirectories that contain a file or folder.

Synonyms to this expression are "full file path" and "absolute file path".

See also [Section 15.5.2, "Handling files in the default or in a specified directory"](#), on page 495.

Computer name: [Hostname](#)

D

daisy chain: A connection scheme in which instruments are connected together in sequence, i.e. an output of the first one is connected to an input of the second one, etc.

DHCP: Dynamic host configuration protocol

DNS: Domain name system server

E

e.g.: For example

External mass memory: External memory, connected to the instrument via USB connector (Type A female). It can hold stored files with user data.

See also [System drive](#) and [SD card](#)

F

File transfer: The transmission of files from or to the instrument by a remote client.

The instrument supports the standard methods [FTP](#) and file sharing according to [SAMBA/SMB](#).

FTP: File transfer protocol

G

Glossary: List of the often used terms and abbreviations

GUI: Graphical user interface

H

HDD: Hard disk drive, see [System drive](#)

Hostname: An unambiguous indication of the instrument in a LAN that uses a [DNS](#) server.

The default hostname follows the syntax `SMAB-<serial number>`, e.g.

`SMA100B-102030`.

See [Serial number](#).

Synonym: [Computer name](#)

HUMS: Health and utilization monitoring system.

I

i.e.: That is

L

LF: Low frequency

LSB: Least significant bit

M

MIMO: Multiple input multiple output

MSB: Most significant bit

P

PC: Personal computer

Power: A term describing the signal level of the RF signal

product page: A designation of the R&S SMA100B product page www.rohde-schwarz.com/product/SMA100B.html

R

Remote access: [Remote operation](#)

Remote control: The operation of the R&S SMA100B by remote control commands or programs to perform automated tests.

The instrument is connected to a system controller via LAN/VXI-11, GPIB or USB using [VISA](#). The instrument is controlled directly or supported by instrument drivers.

Remote device: External device controls the R&S SMA100B in remote operation mode, see [Remote operation](#).

Synonyms: External controller, client device

Remote operation: Allows you to operate the R&S SMA100B from a remote device via VNC.

Both the R&S SMA100B and the remote device are connected in a LAN.

Synonym: Remote access

Removable memory: General term describing mass memory that can be unmounted from the instrument.

See also [SD card](#)

RF: Radio frequency

S

SAMBA/SMB: Server message protocol

SD card: Secure digital card is a type of removable memory storage, that can hold files with user data.

Support of this memory type is optional and requires option R&S SMAB-B85.

Throughout this description, the SD card is referred as a removable memory.

See also [System drive](#).

Serial number: Unique instrument identification, provided on the rear panel of the instrument and required to build the [Computer name](#).

The serial number are the last 6 digits in the string `<stock no.>-<serial number>`, e.g. SMA100B-102030

Smart device: A mobile, cordless device, such as a smartphone or tablet, capable of Internet browsing.

Synonyms: Smartphone, tablet

System drive: The system drive is a built-in internal memory that holds the operating system, the firmware, and the stored user data.

Throughout this description, the system drive is referred as an internal memory.

See also [SD card](#) and [Removable memory](#)

T

Trigger: Internally generated or externally supplied signal which starts signal generation at a particular point in time

Trigger event: A trigger event is caused by the received trigger signal or executed manual trigger.

U

UE: User equipment

USBTMC: (USB test & measurement class)

A protocol built on top of USB for communication with USB devices. Using [VISA](#) library, it supports service request, triggers, and other specific operations, similar to GPIB.

User directory: Describes the default file storage location for user data.

Depending on the installed options, the user directory is physically located on the [System drive](#) or on the [Removable memory](#)

In the file system, user directory is always indicated as `/var/user`

V

VISA: Virtual instrument software architecture

Z

Zeroconf: Zero-configuration, see [Avahi](#).

Glossary: Publications and references

Symbols

1GP60: Rohde & Schwarz application note "MATLAB Toolkit for R&S® Signal Generators"

www.rohde-schwarz.com/appnote/1GP60

1GP66: Rohde & Schwarz application note "Testing True Performance of ADCs using R&S®SMA100B Signal Generator"

www.rohde-schwarz.com/appnote/1GP66

1GP72: Rohde & Schwarz application note "Connectivity of Rohde & Schwarz Signal Generators"

www.rohde-schwarz.com/appnote/1GP72

1GP98: Rohde & Schwarz application note "SCPI-Recorder - Test Automation at Your Fingertips"

www.rohde-schwarz.com/appnote/1GP98

1GP120: Rohde & Schwarz application note "Remote Emulation with the R&S SMA100B Signal Generator"

www.rohde-schwarz.com/appnote/1GP120

1GP125: Rohde & Schwarz application note "Generation of Radar Signals for Multi-Antenna Receivers"

www.rohde-schwarz.com/appnote/1GP125

1GP141: Rohde & Schwarz application note "Using R&S® Power Sensors with R&S®Signal Generators"

www.rohde-schwarz.com/appnote/1GP141

1MA074: Rohde & Schwarz application note "RSCommander"

www.rohde-schwarz.com/appnote/1MA074

1MA99: Rohde & Schwarz application note "Guidance on Selecting and Handling Coaxial RF Connectors used with Rohde & Schwarz Test Equipment"

www.rohde-schwarz.com/appnote/1MA99

1MA100: Rohde & Schwarz application note "Test Port Adapter, R&S Interchangeable Port Connector"

www.rohde-schwarz.com/appnote/1MA100

1MA196: Rohde & Schwarz application note "Using R&S®Forum Application for Instrument Remote Control"

www.rohde-schwarz.com/appnote/1MA196

1MA257: Rohde & Schwarz application note "Wideband mm-Wave Signal Generation and Analysis"

www.rohde-schwarz.com/appnote/1MA257

1SL376: Rohde & Schwarz application note "Cross Correlation Phase Noise Measurement Using The R&S®FSMR3000"

www.rohde-schwarz.com/appnote/1SL376

G

GFM318: Rohde & Schwarz application note "Automotive Radar - Chirp Analysis with R&S RTP Oscilloscope"

www.rohde-schwarz.com/appnote/GFM318

GFM336: Rohde & Schwarz application note "Instrument Health & Utilization Monitoring"

www.rohde-schwarz.com/appnote/GFM336

List of Commands

:CALCulate[:POWer]:SWEep:FREQuency:MARKer<ch>:FEED.....	541
:CALCulate[:POWer]:SWEep:FREQuency:MARKer<ch>:STATe.....	541
:CALCulate[:POWer]:SWEep:FREQuency:MATH<ch>:STATe.....	542
:CALCulate[:POWer]:SWEep:FREQuency:MATH<ch>:SUBTract.....	542
:CALCulate[:POWer]:SWEep:FREQuency:MATH<ch>:XVAL.....	542
:CALCulate[:POWer]:SWEep:FREQuency:MATH<ch>:YVAL.....	543
:CALCulate[:POWer]:SWEep:POWer:MARKer<ch>:FEED.....	543
:CALCulate[:POWer]:SWEep:POWer:MARKer<ch>:STATe.....	543
:CALCulate[:POWer]:SWEep:POWer:MATH<ch>:STATe.....	544
:CALCulate[:POWer]:SWEep:POWer:MATH<ch>:SUBTract.....	544
:CALCulate[:POWer]:SWEep:POWer:MATH<ch>:XVAL.....	544
:CALCulate[:POWer]:SWEep:POWer:MATH<ch>:YVAL.....	545
:CALCulate[:POWer]:SWEep:TIME:GATE<ch>:AVERAge?.....	545
:CALCulate[:POWer]:SWEep:TIME:GATE<ch>:FEED.....	546
:CALCulate[:POWer]:SWEep:TIME:GATE<ch>:MAXimum?.....	546
:CALCulate[:POWer]:SWEep:TIME:GATE<ch>:START.....	546
:CALCulate[:POWer]:SWEep:TIME:GATE<ch>:STATe.....	547
:CALCulate[:POWer]:SWEep:TIME:GATE<ch>:STOP.....	546
:CALCulate[:POWer]:SWEep:TIME:MARKer<ch>:FEED.....	547
:CALCulate[:POWer]:SWEep:TIME:MARKer<ch>:STATe.....	547
:CALCulate[:POWer]:SWEep:TIME:MATH<ch>:STATe.....	548
:CALCulate[:POWer]:SWEep:TIME:MATH<ch>:SUBTract.....	548
:CALCulate[:POWer]:SWEep:TIME:MATH<ch>:XVAL.....	548
:CALCulate[:POWer]:SWEep:TIME:MATH<ch>:YVAL.....	549
:CALibration:ALL[:MEASure]?.....	504
:CALibration:DATA:EXPort.....	506
:CALibration:DATA:FACTory:DATE?.....	506
:CALibration:DELay:MINutes.....	507
:CALibration:DELay:SHUTdown[:STATe].....	507
:CALibration:DELay[:MEASure]?.....	507
:CALibration<hw>:ALL:DATE?.....	505
:CALibration<hw>:ALL:INFormation?.....	505
:CALibration<hw>:ALL:TEMP?.....	505
:CALibration<hw>:ALL:TIME?.....	506
:CALibration<hw>:CONTInueonerror.....	506
:CALibration<hw>:DEBUg.....	508
:CSYNthesis:FREQuency.....	509
:CSYNthesis:FREQuency:STEP.....	512
:CSYNthesis:FREQuency:STEP:MODE.....	512
:CSYNthesis:OFFSet.....	510
:CSYNthesis:OFFSet:STATe.....	510
:CSYNthesis:OTYPe.....	509
:CSYNthesis:PHASe.....	511
:CSYNthesis:PHASe:REFerence.....	511
:CSYNthesis:POWer.....	510
:CSYNthesis:POWer:STEP:MODE.....	512
:CSYNthesis:POWer:STEP[:INCRement].....	512

:CSYNthesis:STATe.....	509
:CSYNthesis:VOLTage.....	511
:DEvice:PRESet.....	493
:DIAGnostic:INFO:OTIme?.....	514
:DIAGnostic:INFO:POCounT?.....	515
:DIAGnostic<hw>:BGINfo:CATalog?.....	514
:DIAGnostic<hw>:BGINfo?.....	514
:DIAGnostic<hw>:POINt:CATalog?.....	515
:DIAGnostic<hw>[:MEASure]:POINt?.....	515
:DISPlay:ANNotation:AMPLitude.....	525
:DISPlay:ANNotation:FREQuency.....	526
:DISPlay:ANNotation[:ALL].....	526
:DISPlay:BRIGhtness.....	525
:DISPlay:BUTTon:BRIGhtness.....	525
:DISPlay:DIALog:CLOSe.....	527
:DISPlay:DIALog:CLOSe:ALL.....	528
:DISPlay:DIALog:ID?.....	526
:DISPlay:DIALog:OPEN.....	527
:DISPlay:PSAVe:HOLDoff.....	524
:DISPlay:PSAVe[:STATe].....	524
:DISPlay:UPDate[:STATe].....	525
:DISPlay[:WINDow][:POWer]:SWEep:BACKground:COLor.....	549
:DISPlay[:WINDow][:POWer]:SWEep:GRID:STATe.....	549
:FORMat:BORDER.....	528
:FORMat:SREGister.....	529
:FORMat[:DATA].....	529
:FPANel:KEYBoard:LAYout.....	535
:HCOPy:DATA?.....	531
:HCOPy:DEvice:LANGUage.....	531
:HCOPy:FILE[:NAME].....	531
:HCOPy:FILE[:NAME]:AUTO:DIRectory.....	532
:HCOPy:FILE[:NAME]:AUTO:DIRectory:CLEar.....	533
:HCOPy:FILE[:NAME]:AUTO:FILE?.....	533
:HCOPy:FILE[:NAME]:AUTO:STATe.....	533
:HCOPy:FILE[:NAME]:AUTO?.....	532
:HCOPy:FILE[:NAME]:AUTO[:FILE]:DAY:STATe.....	534
:HCOPy:FILE[:NAME]:AUTO[:FILE]:MONTH:STATe.....	534
:HCOPy:FILE[:NAME]:AUTO[:FILE]:NUMBer?.....	534
:HCOPy:FILE[:NAME]:AUTO[:FILE]:PREFix.....	534
:HCOPy:FILE[:NAME]:AUTO[:FILE]:PREFix:STATe.....	534
:HCOPy:FILE[:NAME]:AUTO[:FILE]:YEAR:STATe.....	534
:HCOPy:IMAGe:FORMat.....	531
:HCOPy:REGion.....	531
:HCOPy[:EXECute].....	532
:INITiate<hw>[:POWer]:CONTInuous.....	550
:KBOard:LAYout.....	535
:MEMory:HFRee?.....	503
:MMEMory:CATalog:LENGth?.....	499
:MMEMory:CATalog?.....	498
:MMEMory:CDIRectory.....	499

:MMEMory:COpy.....	499
:MMEMory:DATA.....	500
:MMEMory:DCATalog:LENGth?.....	501
:MMEMory:DCATalog?.....	501
:MMEMory:DELeTe.....	501
:MMEMory:LOAD:STATe.....	501
:MMEMory:MDIRectory.....	502
:MMEMory:MOVE.....	502
:MMEMory:MSIS.....	502
:MMEMory:RDIRectory.....	502
:MMEMory:RDIRectory:RECURSive.....	503
:MMEMory:STORe:STATe.....	503
:OUTPut:ALL[:STATe].....	536
:OUTPut:FPRoportional:SCALE.....	538
:OUTPut:USER:MARKer.....	538
:OUTPut<hw>:AFIXed:RANGe:LOWer?.....	539
:OUTPut<hw>:AFIXed:RANGe:UPPer?.....	539
:OUTPut<hw>:AMODE.....	537
:OUTPut<hw>:FILTer:MODE.....	537
:OUTPut<hw>:IMPedance?.....	538
:OUTPut<hw>:PROTection:CLEar.....	539
:OUTPut<hw>:PROTection:TRIPped?.....	539
:OUTPut<hw>[:STATe].....	536
:OUTPut<hw>[:STATe]:PON.....	537
:READ<ch>[:POWer]?.....	550
:SCONfiguration:EXTeRnal:ACONnect.....	610
:SCONfiguration:EXTeRnal:PBEHaviour.....	610
:SCONfiguration:EXTeRnal:REMOte:CLEan.....	613
:SCONfiguration:EXTeRnal:REMOte:CONNeCT[:ALL].....	610
:SCONfiguration:EXTeRnal:REMOte:DISConnect[:ALL].....	610
:SCONfiguration:EXTeRnal:REMOte:LIST?.....	611
:SCONfiguration:EXTeRnal:REMOte:REName.....	612
:SCONfiguration:EXTeRnal:RF<ch>:DIRection?.....	611
:SCONfiguration:EXTeRnal:RF<ch>:INAME?.....	611
:SCONfiguration:EXTeRnal:RF<ch>:RCONnection:STATe?.....	611
:SCONfiguration:EXTeRnal:RF<ch>:REMOte:CONNeCT.....	613
:SCONfiguration:EXTeRnal:RF<ch>:REMOte:DISConnect.....	613
:SCONfiguration:EXTeRnal:RF<ch>:REMOte:ICONnect.....	612
:SCONfiguration:EXTeRnal:RF<ch>:REMOte:INFO?.....	612
:SCONfiguration:EXTeRnal:RF<ch>:REMOte:ISElect.....	612
:SENSe[:POWer]:SWEep:ABORt.....	561
:SENSe[:POWer]:SWEep:FREQuency:REFerence:DATA:COpy.....	561
:SENSe[:POWer]:SWEep:FREQuency:REFerence:DATA:POINts?.....	562
:SENSe[:POWer]:SWEep:FREQuency:REFerence:DATA:XVALues.....	562
:SENSe[:POWer]:SWEep:FREQuency:REFerence:DATA:YVALues.....	562
:SENSe[:POWer]:SWEep:FREQuency:RMODE.....	562
:SENSe[:POWer]:SWEep:FREQuency:SPACing[:MODE].....	563
:SENSe[:POWer]:SWEep:FREQuency:STARt.....	563
:SENSe[:POWer]:SWEep:FREQuency:STEPs.....	563
:SENSe[:POWer]:SWEep:FREQuency:STOP.....	563

:SENSe[:POWer]:SWEep:FREQuency:TIMing[:MODE].....	564
:SENSe[:POWer]:SWEep:FREQuency:YSCale:AUTO.....	564
:SENSe[:POWer]:SWEep:FREQuency:YSCale:AUTO:RESet.....	565
:SENSe[:POWer]:SWEep:FREQuency:YSCale:MAXimum.....	565
:SENSe[:POWer]:SWEep:FREQuency:YSCale:MINimum.....	565
:SENSe[:POWer]:SWEep:HCOPy:DATA?.....	565
:SENSe[:POWer]:SWEep:HCOPy:DEVIce.....	566
:SENSe[:POWer]:SWEep:HCOPy:DEVIce:LANGUage.....	567
:SENSe[:POWer]:SWEep:HCOPy:DEVIce:LANGUage:CSV:DPOint.....	567
:SENSe[:POWer]:SWEep:HCOPy:DEVIce:LANGUage:CSV:HEADer.....	567
:SENSe[:POWer]:SWEep:HCOPy:DEVIce:LANGUage:CSV:ORientation.....	568
:SENSe[:POWer]:SWEep:HCOPy:DEVIce:LANGUage:CSV[:COLUMn]:SEParator.....	568
:SENSe[:POWer]:SWEep:HCOPy:DEVIce:SIZE.....	568
:SENSe[:POWer]:SWEep:HCOPy:FILE[:NAME].....	569
:SENSe[:POWer]:SWEep:HCOPy:FILE[:NAME]:AUTO:DIRectory.....	569
:SENSe[:POWer]:SWEep:HCOPy:FILE[:NAME]:AUTO:DIRectory:CLEar.....	569
:SENSe[:POWer]:SWEep:HCOPy:FILE[:NAME]:AUTO:FILE?.....	570
:SENSe[:POWer]:SWEep:HCOPy:FILE[:NAME]:AUTO:STATe.....	570
:SENSe[:POWer]:SWEep:HCOPy:FILE[:NAME]:AUTO[:FILE]:DAY:STATe.....	571
:SENSe[:POWer]:SWEep:HCOPy:FILE[:NAME]:AUTO[:FILE]:DAY?.....	571
:SENSe[:POWer]:SWEep:HCOPy:FILE[:NAME]:AUTO[:FILE]:MONTH:STATe.....	571
:SENSe[:POWer]:SWEep:HCOPy:FILE[:NAME]:AUTO[:FILE]:MONTH?.....	571
:SENSe[:POWer]:SWEep:HCOPy:FILE[:NAME]:AUTO[:FILE]:NUMBer?.....	572
:SENSe[:POWer]:SWEep:HCOPy:FILE[:NAME]:AUTO[:FILE]:PREFix.....	572
:SENSe[:POWer]:SWEep:HCOPy:FILE[:NAME]:AUTO[:FILE]:PREFix:STATe.....	572
:SENSe[:POWer]:SWEep:HCOPy:FILE[:NAME]:AUTO[:FILE]:YEAR:STATe.....	573
:SENSe[:POWer]:SWEep:HCOPy:FILE[:NAME]:AUTO[:FILE]:YEAR?.....	573
:SENSe[:POWer]:SWEep:HCOPy[:EXECute].....	573
:SENSe[:POWer]:SWEep:INITiate.....	573
:SENSe[:POWer]:SWEep:MODE.....	574
:SENSe[:POWer]:SWEep:POWer:REFerence:DATA:COpy.....	574
:SENSe[:POWer]:SWEep:POWer:REFerence:DATA:POINts?.....	574
:SENSe[:POWer]:SWEep:POWer:REFerence:DATA:XVALues.....	574
:SENSe[:POWer]:SWEep:POWer:REFerence:DATA:YVALues.....	575
:SENSe[:POWer]:SWEep:POWer:RMODE.....	575
:SENSe[:POWer]:SWEep:POWer:SPACing[:MODE].....	575
:SENSe[:POWer]:SWEep:POWer:STARt.....	575
:SENSe[:POWer]:SWEep:POWer:STEPs.....	576
:SENSe[:POWer]:SWEep:POWer:STOP.....	576
:SENSe[:POWer]:SWEep:POWer:TIMing[:MODE].....	576
:SENSe[:POWer]:SWEep:POWer:YSCale:AUTO.....	577
:SENSe[:POWer]:SWEep:POWer:YSCale:AUTO:RESet.....	577
:SENSe[:POWer]:SWEep:POWer:YSCale:MAXimum.....	578
:SENSe[:POWer]:SWEep:POWer:YSCale:MINimum.....	578
:SENSe[:POWer]:SWEep:RMODE.....	578
:SENSe[:POWer]:SWEep:TIME:AVERage[:COUNT].....	578
:SENSe[:POWer]:SWEep:TIME:REFerence:DATA:COpy.....	579
:SENSe[:POWer]:SWEep:TIME:REFerence:DATA:POINts?.....	579
:SENSe[:POWer]:SWEep:TIME:REFerence:DATA:XVALues.....	579
:SENSe[:POWer]:SWEep:TIME:REFerence:DATA:YVALues.....	579

:SENSe[:POWer]:SWEep:TIME:RMODe.....	580
:SENSe[:POWer]:SWEep:TIME:SPACing[:MODE].....	580
:SENSe[:POWer]:SWEep:TIME:STARt.....	580
:SENSe[:POWer]:SWEep:TIME:STEPs.....	581
:SENSe[:POWer]:SWEep:TIME:STOP.....	581
:SENSe[:POWer]:SWEep:TIME:TEVents.....	581
:SENSe[:POWer]:SWEep:TIME:YSCale:AUTO.....	582
:SENSe[:POWer]:SWEep:TIME:YSCale:AUTO:RESet.....	582
:SENSe[:POWer]:SWEep:TIME:YSCale:MAXimum.....	582
:SENSe[:POWer]:SWEep:TIME:YSCale:MINimum.....	583
:SENSe<ch>:UNIT[:POWer].....	601
:SENSe<ch>[:POWer]:APERTure:DEFault:STATe.....	601
:SENSe<ch>[:POWer]:APERTure:TIME.....	601
:SENSe<ch>[:POWer]:CORRection:SPDeVice:LIST?.....	602
:SENSe<ch>[:POWer]:CORRection:SPDeVice:SElect.....	602
:SENSe<ch>[:POWer]:CORRection:SPDeVice:STATe.....	602
:SENSe<ch>[:POWer]:DISPlay:PERManent:PRiority.....	602
:SENSe<ch>[:POWer]:DISPlay:PERManent:STATe.....	603
:SENSe<ch>[:POWer]:FILTer:LENGth:AUTO?.....	603
:SENSe<ch>[:POWer]:FILTer:LENGth[:USER].....	603
:SENSe<ch>[:POWer]:FILTer:NSRatio.....	604
:SENSe<ch>[:POWer]:FILTer:NSRatio:MTIME.....	604
:SENSe<ch>[:POWer]:FILTer:SONCe.....	604
:SENSe<ch>[:POWer]:FILTer:TYPE.....	605
:SENSe<ch>[:POWer]:FREQuency.....	605
:SENSe<ch>[:POWer]:LOGGing:STATe.....	606
:SENSe<ch>[:POWer]:OFFSet.....	606
:SENSe<ch>[:POWer]:OFFSet:STATe.....	606
:SENSe<ch>[:POWer]:SNUMber?.....	607
:SENSe<ch>[:POWer]:SOURce.....	607
:SENSe<ch>[:POWer]:STATus[:DEVice]?.....	607
:SENSe<ch>[:POWer]:SVERsion?.....	608
:SENSe<ch>[:POWer]:SWEep:FREQuency[:SENSor]:OFFSet.....	553
:SENSe<ch>[:POWer]:SWEep:FREQuency[:SENSor]:OFFSet:STATe.....	553
:SENSe<ch>[:POWer]:SWEep:FREQuency[:SENSor]:SRANge:STARt.....	553
:SENSe<ch>[:POWer]:SWEep:FREQuency[:SENSor]:SRANge:STOP.....	554
:SENSe<ch>[:POWer]:SWEep:FREQuency[:SENSor]:SRANge[:STATe].....	554
:SENSe<ch>[:POWer]:SWEep:POWer[:SENSor]:OFFSet.....	555
:SENSe<ch>[:POWer]:SWEep:POWer[:SENSor]:OFFSet:STATe.....	555
:SENSe<ch>[:POWer]:SWEep:POWer[:SENSor]:SFRequency.....	555
:SENSe<ch>[:POWer]:SWEep:POWer[:SENSor]:SFRequency:STATe.....	556
:SENSe<ch>[:POWer]:SWEep:TIME[:SENSor]:OFFSet.....	556
:SENSe<ch>[:POWer]:SWEep:TIME[:SENSor]:OFFSet:STATe.....	556
:SENSe<ch>[:POWer]:SWEep:TIME[:SENSor]:PULSe:STATe.....	557
:SENSe<ch>[:POWer]:SWEep:TIME[:SENSor]:PULSe:THReShold:BASE.....	557
:SENSe<ch>[:POWer]:SWEep:TIME[:SENSor]:PULSe:THReShold:POWer:HREFerence.....	557
:SENSe<ch>[:POWer]:SWEep:TIME[:SENSor]:PULSe:THReShold:POWer:LREFerence.....	558
:SENSe<ch>[:POWer]:SWEep:TIME[:SENSor]:PULSe:THReShold:POWer:REFerence.....	558
:SENSe<ch>[:POWer]:SWEep:TIME[:SENSor]:SFRequency.....	559
:SENSe<ch>[:POWer]:SWEep:TIME[:SENSor]:SFRequency:STATe.....	559

:SENSe<ch>[:POWER]:SWEep:TIME[:SENSor]:TRIGger:AUTO.....	559
:SENSe<ch>[:POWER]:SWEep:TIME[:SENSor]:TRIGger:DTIME.....	559
:SENSe<ch>[:POWER]:SWEep:TIME[:SENSor]:TRIGger:HYSteresis.....	560
:SENSe<ch>[:POWER]:SWEep:TIME[:SENSor]:TRIGger:LEVel.....	560
:SENSe<ch>[:POWER]:SWEep:TIME[:SENSor]:TRIGger:SLOPe.....	560
:SENSe<ch>[:POWER]:SWEep:TIME[:SENSor]:TRIGger:SOURce.....	561
:SENSe<ch>[:POWER]:TYPE?.....	608
:SENSe<ch>[:POWER]:ZERO.....	561
:SENSe<ch>[:POWER]:ZERO.....	608
:SLIST:CLEar:LAN.....	599
:SLIST:CLEar:USB.....	599
:SLIST:CLEar[:ALL].....	600
:SLIST:ELEMent<ch>:MAPPing.....	600
:SLIST:SCAN:LSENsor.....	598
:SLIST:SCAN:USENSor.....	599
:SLIST:SCAN[:STATe].....	598
:SLIST:SENSor:MAP.....	600
:SLIST[:LIST]?.....	598
:SOURce<hw>:PRESet.....	493
:STATus:OPERation:CONDition?.....	807
:STATus:OPERation:ENABLE.....	807
:STATus:OPERation:NTRansition.....	808
:STATus:OPERation:PTRansition.....	808
:STATus:OPERation[:EVENT].....	808
:STATus:PRESet.....	808
:STATus:QUEStionable:CONDition.....	809
:STATus:QUEStionable:ENABLE.....	809
:STATus:QUEStionable:NTRansition.....	809
:STATus:QUEStionable:PTRansition.....	810
:STATus:QUEStionable[:EVENT].....	809
:STATus:QUEue[:NEXT]?.....	810
:SWEep:TYPE.....	765
:SYSTem:BIOS:VERSion?.....	804
:SYSTem:COMMunicate:GPIB:LTERminator.....	788
:SYSTem:COMMunicate:GPIB:RESource?.....	788
:SYSTem:COMMunicate:GPIB[:SELF]:ADDReSS.....	788
:SYSTem:COMMunicate:HISLip:RESource?.....	789
:SYSTem:COMMunicate:NETWork:IPADdress.....	789
:SYSTem:COMMunicate:NETWork:IPADdress:MODE.....	789
:SYSTem:COMMunicate:NETWork:MACaddress.....	789
:SYSTem:COMMunicate:NETWork:RESource?.....	790
:SYSTem:COMMunicate:NETWork:REStart.....	790
:SYSTem:COMMunicate:NETWork:STATus?.....	790
:SYSTem:COMMunicate:NETWork[:COMMON]:DOMain.....	790
:SYSTem:COMMunicate:NETWork[:COMMON]:HOSTName.....	790
:SYSTem:COMMunicate:NETWork[:COMMON]:WORKGroup.....	791
:SYSTem:COMMunicate:NETWork[:IPADdress]:DNS.....	791
:SYSTem:COMMunicate:NETWork[:IPADdress]:GATeway.....	791
:SYSTem:COMMunicate:NETWork[:IPADdress]:SUBNet:MASK.....	791
:SYSTem:COMMunicate:SERial:BAUD.....	792

:SYSTem:COMMunicate:SERial:PARity.....	792
:SYSTem:COMMunicate:SERial:RESource?.....	792
:SYSTem:COMMunicate:SERial:SBITs.....	792
:SYSTem:COMMunicate:SOCKet:RESource?.....	792
:SYSTem:COMMunicate:USB:RESource?.....	793
:SYSTem:DATE.....	802
:SYSTem:DFPPrint.....	805
:SYSTem:DLOCK.....	784
:SYSTem:ERRor:ALL?.....	781
:SYSTem:ERRor:CODE:ALL?.....	782
:SYSTem:ERRor:CODE[:NEXT]?.....	782
:SYSTem:ERRor:COUNT?.....	783
:SYSTem:ERRor:GNEXT?.....	784
:SYSTem:ERRor:HISTory:CLEar.....	784
:SYSTem:ERRor:STATIC?.....	784
:SYSTem:ERRor[:NEXT]?.....	783
:SYSTem:FILEs:TEMPorary:DELeTe.....	806
:SYSTem:FPReset.....	493
:SYSTem:HELP:EXPort.....	793
:SYSTem:IDENtification.....	793
:SYSTem:IDENtification:PRESet.....	794
:SYSTem:INFormation:SCPI.....	795
:SYSTem:IRESpone.....	794
:SYSTem:KLOCK.....	785
:SYSTem:LANGuage.....	795
:SYSTem:LOCK:OWNer?.....	786
:SYSTem:LOCK:RELease:ALL.....	786
:SYSTem:LOCK:REQuest[:EXCLusive]?.....	786
:SYSTem:MMEMory:PATH:USER?.....	805
:SYSTem:NINFormation?.....	785
:SYSTem:NTP:HOSTname.....	802
:SYSTem:NTP:STATe.....	802
:SYSTem:ORESpone.....	794
:SYSTem:OSYStem?.....	804
:SYSTem:PRESet.....	493
:SYSTem:PROTect<ch>[:STATe].....	787
:SYSTem:RCL.....	787
:SYSTem:REBoot.....	805
:SYSTem:REStart.....	806
:SYSTem:SAV.....	787
:SYSTem:SECurity:NETWork:AVAHi[:STATe].....	795
:SYSTem:SECurity:NETWork:FTP[:STATe].....	795
:SYSTem:SECurity:NETWork:HTTP[:STATe].....	796
:SYSTem:SECurity:NETWork:RAW[:STATe].....	796
:SYSTem:SECurity:NETWork:REMSupport[:STATe].....	796
:SYSTem:SECurity:NETWork:RPC[:STATe].....	796
:SYSTem:SECurity:NETWork:SMB[:STATe].....	797
:SYSTem:SECurity:NETWork:SOE[:STATe].....	797
:SYSTem:SECurity:NETWork:SSH[:STATe].....	797
:SYSTem:SECurity:NETWork:SWUPdate[:STATe].....	798

:SYSTem:SECurity:NETWork:VNC[:STATe].....	798
:SYSTem:SECurity:NETWork[:STATe].....	798
:SYSTem:SECurity:SANitize[:STATe].....	798
:SYSTem:SECurity:VOLMode[:STATe].....	799
:SYSTem:SHUTdown.....	806
:SYSTem:SPECification:IDENtification:CATalog?.....	800
:SYSTem:SPECification:PARAmeter?.....	800
:SYSTem:SPECification:VERSion.....	800
:SYSTem:SPECification:VERSion:CATalog?.....	801
:SYSTem:SPECification:VERSion:FACTory?.....	801
:SYSTem:SPECification?.....	799
:SYSTem:SRData?.....	801
:SYSTem:STARtup:COMPLetE?.....	801
:SYSTem:TIME.....	802
:SYSTem:TIME:PROTocol.....	803
:SYSTem:TIME:ZONE.....	803
:SYSTem:TIME:ZONE:CATalog?.....	803
:SYSTem:ULOCK.....	785
:SYSTem:UPTime?.....	804
:SYSTem:VERSion?.....	804
:SYSTem:WAIT.....	806
:TEST:PIXel:COLor.....	811
:TEST:PIXel:GRADient.....	812
:TEST:PIXel:POINTsize.....	812
:TEST:PIXel:RGBA.....	812
:TEST:PIXel:TEXT.....	812
:TEST:PIXel:WINDow.....	813
:TEST<hw>:ALL:RESult?.....	811
:TEST<hw>:ALL:STARt.....	811
:TRACe[:POWer]:SWEep:MEASurement:FULLscreen:DISPlay:ANNotation[:STATe].....	593
:TRACe[:POWer]:SWEep:MEASurement:GATE:DISPlay:ANNotation[:STATe].....	593
:TRACe[:POWer]:SWEep:MEASurement:MARKer:DISPlay:ANNotation[:STATe].....	594
:TRACe[:POWer]:SWEep:MEASurement:PULSe:DISPlay:ANNotation[:STATe].....	594
:TRACe[:POWer]:SWEep:MEASurement:STANdard:DISPlay:ANNotation[:STATe].....	594
:TRACe<ch>:FREq:SWEep:SRC.....	585
:TRACe<ch>:POW:SWEep:SRC.....	585
:TRACe<ch>:TIME:SWEep:SRC.....	586
:TRACe<ch>[:POWer]:SWEep:COLor.....	586
:TRACe<ch>[:POWer]:SWEep:COPY.....	587
:TRACe<ch>[:POWer]:SWEep:DATA:POINTs?.....	587
:TRACe<ch>[:POWer]:SWEep:DATA:XVALues?.....	587
:TRACe<ch>[:POWer]:SWEep:DATA:YSValue?.....	588
:TRACe<ch>[:POWer]:SWEep:DATA:YVALues?.....	588
:TRACe<ch>[:POWer]:SWEep:FEED.....	588
:TRACe<ch>[:POWer]:SWEep:MEASurement:POWer:AVERage:DISPlay:ANNotation[:STATe].....	590
:TRACe<ch>[:POWer]:SWEep:MEASurement:POWer:AVERage?.....	589
:TRACe<ch>[:POWer]:SWEep:MEASurement:POWer:HREFerence:DISPlay:ANNotation[:STATe].....	590
:TRACe<ch>[:POWer]:SWEep:MEASurement:POWer:HREFerence?.....	589
:TRACe<ch>[:POWer]:SWEep:MEASurement:POWer:LREFerence:DISPlay:ANNotation[:STATe].....	590
:TRACe<ch>[:POWer]:SWEep:MEASurement:POWer:LREFerence?.....	589

:TRACe<ch>[:POWer]:SWEep:MEASurement:POWer:MAXimum:DISPlay:ANNOtation[:STATe].....	590
:TRACe<ch>[:POWer]:SWEep:MEASurement:POWer:MAXimum?.....	589
:TRACe<ch>[:POWer]:SWEep:MEASurement:POWer:MINimum:DISPlay:ANNOtation[:STATe].....	590
:TRACe<ch>[:POWer]:SWEep:MEASurement:POWer:MINimum?.....	589
:TRACe<ch>[:POWer]:SWEep:MEASurement:POWer:PULSe:BASE:DISPlay:ANNOtation[:STATe].....	590
:TRACe<ch>[:POWer]:SWEep:MEASurement:POWer:PULSe:BASE?.....	589
:TRACe<ch>[:POWer]:SWEep:MEASurement:POWer:PULSe:TOP:DISPlay:ANNOtation[:STATe].....	590
:TRACe<ch>[:POWer]:SWEep:MEASurement:POWer:PULSe:TOP?.....	589
:TRACe<ch>[:POWer]:SWEep:MEASurement:POWer:REFerence:DISPlay:ANNOtation[:STATe].....	590
:TRACe<ch>[:POWer]:SWEep:MEASurement:POWer:REFerence?.....	589
:TRACe<ch>[:POWer]:SWEep:MEASurement:PULSe:ALL:DISPlay:ANNOtation[:STATe].....	591
:TRACe<ch>[:POWer]:SWEep:MEASurement:PULSe:DCYClE:DISPlay:ANNOtation[:STATe].....	590
:TRACe<ch>[:POWer]:SWEep:MEASurement:PULSe:DCYClE?.....	589
:TRACe<ch>[:POWer]:SWEep:MEASurement:PULSe:DURation:DISPlay:ANNOtation[:STATe].....	590
:TRACe<ch>[:POWer]:SWEep:MEASurement:PULSe:DURation?.....	589
:TRACe<ch>[:POWer]:SWEep:MEASurement:PULSe:PERiod:DISPlay:ANNOtation[:STATe].....	590
:TRACe<ch>[:POWer]:SWEep:MEASurement:PULSe:PERiod?.....	589
:TRACe<ch>[:POWer]:SWEep:MEASurement:PULSe:SEPARation:DISPlay:ANNOtation[:STATe].....	590
:TRACe<ch>[:POWer]:SWEep:MEASurement:PULSe:SEPARation?.....	589
:TRACe<ch>[:POWer]:SWEep:MEASurement:PULSe:STATe?.....	589
:TRACe<ch>[:POWer]:SWEep:MEASurement:TRANSition:NEGative:DURation:DISPlay: ANNOtation[:STATe].....	590
:TRACe<ch>[:POWer]:SWEep:MEASurement:TRANSition:NEGative:DURation?.....	589
:TRACe<ch>[:POWer]:SWEep:MEASurement:TRANSition:NEGative:OCCurrence:DISPlay: ANNOtation[:STATe].....	590
:TRACe<ch>[:POWer]:SWEep:MEASurement:TRANSition:NEGative:OCCurrence?.....	589
:TRACe<ch>[:POWer]:SWEep:MEASurement:TRANSition:NEGative:OVERshoot:DISPlay: ANNOtation[:STATe].....	590
:TRACe<ch>[:POWer]:SWEep:MEASurement:TRANSition:NEGative:OVERshoot?.....	589
:TRACe<ch>[:POWer]:SWEep:MEASurement:TRANSition:POSitive:DURation:DISPlay: ANNOtation[:STATe].....	590
:TRACe<ch>[:POWer]:SWEep:MEASurement:TRANSition:POSitive:DURation?.....	589
:TRACe<ch>[:POWer]:SWEep:MEASurement:TRANSition:POSitive:OCCurrence:DISPlay: ANNOtation[:STATe].....	590
:TRACe<ch>[:POWer]:SWEep:MEASurement:TRANSition:POSitive:OCCurrence?.....	589
:TRACe<ch>[:POWer]:SWEep:MEASurement:TRANSition:POSitive:OVERshoot:DISPlay: ANNOtation[:STATe].....	590
:TRACe<ch>[:POWer]:SWEep:MEASurement:TRANSition:POSitive:OVERshoot?.....	589
:TRACe<ch>[:POWer]:SWEep:PULSe:THReshold:BASE?.....	591
:TRACe<ch>[:POWer]:SWEep:PULSe:THReshold:POWer:HREFerence.....	591
:TRACe<ch>[:POWer]:SWEep:PULSe:THReshold:POWer:LREFerence.....	592
:TRACe<ch>[:POWer]:SWEep:PULSe:THReshold:POWer:REFerence.....	592
:TRACe<ch>[:POWer]:SWEep:STATe.....	592
:TRIGGer<hw>:FPSWeep:SOURce.....	815
:TRIGGer<hw>:FSWeep:SOURce.....	814
:TRIGGer<hw>:FSWeep[:IMMediate].....	816
:TRIGGer<hw>:LFFSweep.....	816
:TRIGGer<hw>:LFFSweep:IMMediate.....	816
:TRIGGer<hw>:LFFSweep:SOURce.....	814
:TRIGGer<hw>:PSWeep:SOURce.....	814

:TRIGger<hw>:PSWeep[:IMMediate].....	816
:TRIGger<hw>[:SWEep]:SOURce.....	814
:TRIGger<hw>[:SWEep][:IMMediate].....	816
:UNIT:ANGLE.....	817
:UNIT:POWer.....	817
[:SOURce]:CORRection:CSET:CATalog?.....	694
[:SOURce]:CORRection:CSET:DELeTe.....	695
[:SOURce]:INPut:TRIGger:SLOPe.....	710
[:SOURce]:LFOutput:OFFSet.....	716
[:SOURce]:LFOutput:VOLTage.....	716
[:SOURce]:LFOutput<ch>:BANDwidth?.....	713
[:SOURce]:LFOutput<ch>:FREQuency.....	713
[:SOURce]:LFOutput<ch>:INTernal:VOLTage.....	715
[:SOURce]:LFOutput<ch>:SOURce.....	716
[:SOURce]:LFOutput<ch>:SOURce:PATH.....	716
[:SOURce]:LFOutput<ch>[:STATe].....	715
[:SOURce]:PM<ch>[:DEViation].....	635
[:SOURce]:POWer:WIGNore.....	754
[:SOURce]:PULM[:INTernal][:TRAin]:TRIGger:IMMediate.....	638
[:SOURce]:ROSCillator:EXTernal:FREQuency.....	757
[:SOURce]:ROSCillator:EXTernal:FREQuency:VARiable.....	758
[:SOURce]:ROSCillator:EXTernal:MLRange?.....	758
[:SOURce]:ROSCillator:EXTernal:NSBAndwidth?.....	759
[:SOURce]:ROSCillator:EXTernal:RFOFF[:STATe].....	757
[:SOURce]:ROSCillator:EXTernal:SBANDwidth.....	758
[:SOURce]:ROSCillator:INTernal:TUNing:SLOPe.....	757
[:SOURce]:ROSCillator:INTernal:TUNing[:STATe].....	757
[:SOURce]:ROSCillator:OUTPut:ALTerNate:FREQuency:MODE.....	759
[:SOURce]:ROSCillator:OUTPut:FREQuency:MODE.....	759
[:SOURce]:ROSCillator:PRESet.....	756
[:SOURce]:ROSCillator:SOURce.....	756
[:SOURce]:ROSCillator[:INTernal]:ADJust:VALue.....	760
[:SOURce]:ROSCillator[:INTernal]:ADJust[:STATe].....	760
[:SOURce<hw>]:ADF:COMid:CODE.....	655
[:SOURce<hw>]:ADF:COMid:DASH.....	655
[:SOURce<hw>]:ADF:COMid:DEPTh.....	655
[:SOURce<hw>]:ADF:COMid:DOT.....	655
[:SOURce<hw>]:ADF:COMid:FREQuency.....	656
[:SOURce<hw>]:ADF:COMid:LETTer.....	656
[:SOURce<hw>]:ADF:COMid:PERiod.....	656
[:SOURce<hw>]:ADF:COMid:SYMBol.....	657
[:SOURce<hw>]:ADF:COMid:TSCHEMA.....	657
[:SOURce<hw>]:ADF:COMid[:STATe].....	657
[:SOURce<hw>]:ADF:PRESet.....	652
[:SOURce<hw>]:ADF:SETTing:CATalog.....	652
[:SOURce<hw>]:ADF:SETTing:DELeTe.....	652
[:SOURce<hw>]:ADF:SETTing:LOAD.....	653
[:SOURce<hw>]:ADF:SETTing:STORe.....	653
[:SOURce<hw>]:ADF:STATe.....	653
[:SOURce<hw>]:AM:DEPTh:SUM.....	620

[SOURce<hw>]:AM:DEVIation:MODE.....	620
[SOURce<hw>]:AM:MODE.....	619
[SOURce<hw>]:AM:RATio.....	620
[SOURce<hw>]:AM:TYPE.....	621
[SOURce<hw>]:AM<ch>:DEPTh:EXPonential.....	619
[SOURce<hw>]:AM<ch>:DEPTh:LINear.....	619
[SOURce<hw>]:AM<ch>:SENSitivity:EXPonential.....	621
[SOURce<hw>]:AM<ch>:SENSitivity[.LINear].....	621
[SOURce<hw>]:AM<ch>:SOURce.....	618
[SOURce<hw>]:AM<ch>:STATe.....	618
[SOURce<hw>]:AM<ch>[:DEPTh].....	619
[SOURce<hw>]:CHIRp:BANDwidth.....	624
[SOURce<hw>]:CHIRp:COMPression:RATio?.....	624
[SOURce<hw>]:CHIRp:DIRection.....	624
[SOURce<hw>]:CHIRp:PULSe:NUMBer.....	624
[SOURce<hw>]:CHIRp:PULSe:PERiod.....	625
[SOURce<hw>]:CHIRp:PULSe:WIDTh.....	625
[SOURce<hw>]:CHIRp:STATe.....	625
[SOURce<hw>]:CHIRp:TRIGger:IMMediate.....	625
[SOURce<hw>]:CHIRp:TRIGger:MODE.....	626
[SOURce<hw>]:COMBined:FREQuency:START.....	771
[SOURce<hw>]:COMBined:FREQuency:STOP.....	771
[SOURce<hw>]:COMBined:POWer:START.....	771
[SOURce<hw>]:COMBined:POWer:STOP.....	772
[SOURce<hw>]:CORRection:CSET:DATA:FREQuency.....	692
[SOURce<hw>]:CORRection:CSET:DATA:FREQuency:POINts?.....	693
[SOURce<hw>]:CORRection:CSET:DATA:POWer.....	692
[SOURce<hw>]:CORRection:CSET:DATA:POWer:POINts?.....	693
[SOURce<hw>]:CORRection:CSET:DATA[:SENSor<ch>][:POWer]:SONCe.....	693
[SOURce<hw>]:CORRection:CSET:DATA[:SENSor<ch>][:POWer]:SONCe.....	694
[SOURce<hw>]:CORRection:CSET[:SELeCt].....	693
[SOURce<hw>]:CORRection:DEXChange:AFILe:CATalog?.....	695
[SOURce<hw>]:CORRection:DEXChange:AFILe:EXTeNsion.....	695
[SOURce<hw>]:CORRection:DEXChange:AFILe:SELeCt.....	696
[SOURce<hw>]:CORRection:DEXChange:AFILe:SEParator:COLumn.....	696
[SOURce<hw>]:CORRection:DEXChange:AFILe:SEParator:DECimal.....	696
[SOURce<hw>]:CORRection:DEXChange:EXECute.....	696
[SOURce<hw>]:CORRection:DEXChange:MODE.....	697
[SOURce<hw>]:CORRection:DEXChange:SELeCt.....	697
[SOURce<hw>]:CORRection:VALue?.....	693
[SOURce<hw>]:CORRection:ZERoing:STATe.....	694
[SOURce<hw>]:CORRection[:STATe].....	694
[SOURce<hw>]:EFRontend:ALIGnment:FILE:CATalog?.....	699
[SOURce<hw>]:EFRontend:ALIGnment:FILE:FREQuency:RANGe:LOWer?.....	699
[SOURce<hw>]:EFRontend:ALIGnment:FILE:FREQuency:RANGe:UPPer?.....	699
[SOURce<hw>]:EFRontend:ALIGnment:FILE[:SELeCt].....	699
[SOURce<hw>]:EFRontend:ALIGnment[:STATe].....	700
[SOURce<hw>]:EFRontend:IDN?.....	698
[SOURce<hw>]:EFRontend:OPT?.....	699
[SOURce<hw>]:EFRontend:SCReW:POSition?.....	700

[SOURce<hw>]:EFFRontend[:FREQuency]:IFRequency[:VALue]?	698
[SOURce<hw>]:FM:DEViation:MODE	629
[SOURce<hw>]:FM:DEViation:SUM	630
[SOURce<hw>]:FM:MODE	630
[SOURce<hw>]:FM:RATio	630
[SOURce<hw>]:FM:SENSitivity?	630
[SOURce<hw>]:FM<ch>:SOURce	629
[SOURce<hw>]:FM<ch>:STATe	628
[SOURce<hw>]:FM<ch>[:DEViation]	628
[SOURce<hw>]:FREQuency:CENTer	705
[SOURce<hw>]:FREQuency:MANual	704
[SOURce<hw>]:FREQuency:MODE	701
[SOURce<hw>]:FREQuency:MULTiplier	704
[SOURce<hw>]:FREQuency:OFFSet	704
[SOURce<hw>]:FREQuency:PHASe:CONTinuous:HIGH?	707
[SOURce<hw>]:FREQuency:PHASe:CONTinuous:LOW?	708
[SOURce<hw>]:FREQuency:PHASe:CONTinuous:MODE	708
[SOURce<hw>]:FREQuency:PHASe:CONTinuous:STATe	709
[SOURce<hw>]:FREQuency:PLL:MODE	707
[SOURce<hw>]:FREQuency:SPAN	705
[SOURce<hw>]:FREQuency:STARt	705
[SOURce<hw>]:FREQuency:STEP:MODE	706
[SOURce<hw>]:FREQuency:STEP[:INCRement]	707
[SOURce<hw>]:FREQuency:STOP	706
[SOURce<hw>]:FREQuency[:CW FIXed]	702
[SOURce<hw>]:FREQuency[:CW FIXed]:RCL	703
[SOURce<hw>]:ILS:GS GSLope:PRESet	665
[SOURce<hw>]:ILS:LOCalizer:COMid:CODE	666
[SOURce<hw>]:ILS:LOCalizer:COMid:DASH	666
[SOURce<hw>]:ILS:LOCalizer:COMid:DEPTH	667
[SOURce<hw>]:ILS:LOCalizer:COMid:DOT	667
[SOURce<hw>]:ILS:LOCalizer:COMid:FREQuency	667
[SOURce<hw>]:ILS:LOCalizer:COMid:LETter	667
[SOURce<hw>]:ILS:LOCalizer:COMid:PERiod	668
[SOURce<hw>]:ILS:LOCalizer:COMid:SYMBol	668
[SOURce<hw>]:ILS:LOCalizer:COMid:TSCHEMA	668
[SOURce<hw>]:ILS:LOCalizer:COMid[:STATe]	669
[SOURce<hw>]:ILS:LOCalizer:DDM:COUPLing	669
[SOURce<hw>]:ILS:LOCalizer:DDM:CURREnt	669
[SOURce<hw>]:ILS:LOCalizer:DDM:DIRection	670
[SOURce<hw>]:ILS:LOCalizer:DDM:LOGarithmic	670
[SOURce<hw>]:ILS:LOCalizer:DDM:PCT	670
[SOURce<hw>]:ILS:LOCalizer:DDM:POLarity	671
[SOURce<hw>]:ILS:LOCalizer:DDM:STEP	671
[SOURce<hw>]:ILS:LOCalizer:DDM[:DEPTH]	671
[SOURce<hw>]:ILS:LOCalizer:FREQuency	672
[SOURce<hw>]:ILS:LOCalizer:FREQuency:MODE	672
[SOURce<hw>]:ILS:LOCalizer:FREQuency:SYNChronize[:STATe]	654
[SOURce<hw>]:ILS:LOCalizer:FREQuency:SYNChronize[:STATe]	672
[SOURce<hw>]:ILS:LOCalizer:ICAO:CHANnel	673

[SOURce<hw>]:ILS:LOCalizer:LLOBe[:FREQuency].....	673
[SOURce<hw>]:ILS:LOCalizer:MODE.....	674
[SOURce<hw>]:ILS:LOCalizer:PHASe.....	674
[SOURce<hw>]:ILS:LOCalizer:PRESet.....	674
[SOURce<hw>]:ILS:LOCalizer:RLOBe[:FREQuency].....	675
[SOURce<hw>]:ILS:LOCalizer:SDM.....	675
[SOURce<hw>]:ILS:LOCalizer:SOURce.....	675
[SOURce<hw>]:ILS:PRESet.....	652
[SOURce<hw>]:ILS:SETTing:CATalog?.....	652
[SOURce<hw>]:ILS:SETTing:DELeTe.....	653
[SOURce<hw>]:ILS:SETTing:LOAD.....	653
[SOURce<hw>]:ILS:SETTing:STORe.....	653
[SOURce<hw>]:ILS:STATe.....	654
[SOURce<hw>]:ILS:TYPE.....	659
[SOURce<hw>]:ILS[:GS GSLope]:DDM:COUPling.....	659
[SOURce<hw>]:ILS[:GS GSLope]:DDM:CURRent.....	660
[SOURce<hw>]:ILS[:GS GSLope]:DDM:DIRection.....	660
[SOURce<hw>]:ILS[:GS GSLope]:DDM:LOGarithmic.....	660
[SOURce<hw>]:ILS[:GS GSLope]:DDM:PCT.....	661
[SOURce<hw>]:ILS[:GS GSLope]:DDM:POLarity.....	661
[SOURce<hw>]:ILS[:GS GSLope]:DDM:STEP.....	661
[SOURce<hw>]:ILS[:GS GSLope]:DDM[:DEPT]h.....	662
[SOURce<hw>]:ILS[:GS GSLope]:FREQuency.....	662
[SOURce<hw>]:ILS[:GS GSLope]:FREQuency:MODE.....	662
[SOURce<hw>]:ILS[:GS GSLope]:FREQuency:SYNChronize[:STATe].....	654
[SOURce<hw>]:ILS[:GS GSLope]:FREQuency:SYNChronize[:STATe].....	663
[SOURce<hw>]:ILS[:GS GSLope]:ICAO:CHANnel.....	663
[SOURce<hw>]:ILS[:GS GSLope]:LLOBe[:FREQuency].....	664
[SOURce<hw>]:ILS[:GS GSLope]:MODE.....	664
[SOURce<hw>]:ILS[:GS GSLope]:PHASe.....	664
[SOURce<hw>]:ILS[:GS GSLope]:SDM.....	665
[SOURce<hw>]:ILS[:GS GSLope]:SOURce.....	665
[SOURce<hw>]:ILS[:GS GSLope]:ULOBe[:FREQuency].....	666
[SOURce<hw>]:INPut:MODext:COUPling<ch>.....	709
[SOURce<hw>]:INPut:MODext:IMPedance<ch>.....	710
[SOURce<hw>]:LFOutput:FREQuency:MANual.....	714
[SOURce<hw>]:LFOutput:FREQuency:MODE.....	714
[SOURce<hw>]:LFOutput:FREQuency:START.....	715
[SOURce<hw>]:LFOutput:FREQuency:STOP.....	715
[SOURce<hw>]:LFOutput:SWEep[:FREQuency]:DWELL.....	720
[SOURce<hw>]:LFOutput:SWEep[:FREQuency]:EXECute.....	720
[SOURce<hw>]:LFOutput:SWEep[:FREQuency]:MODE.....	720
[SOURce<hw>]:LFOutput:SWEep[:FREQuency]:POINTs.....	721
[SOURce<hw>]:LFOutput:SWEep[:FREQuency]:RETRace.....	721
[SOURce<hw>]:LFOutput:SWEep[:FREQuency]:RUNNING?.....	721
[SOURce<hw>]:LFOutput:SWEep[:FREQuency]:SHAPE.....	722
[SOURce<hw>]:LFOutput:SWEep[:FREQuency]:SPACing.....	722
[SOURce<hw>]:LFOutput:SWEep[:FREQuency]:STEP:LOGarithmic.....	722
[SOURce<hw>]:LFOutput:SWEep[:FREQuency]:STEP[:LINear].....	723
[SOURce<hw>]:LFOutput<ch>:PERiod?.....	713

[SOURce<hw>]:LFOutput<ch>:SHApe.....	717
[SOURce<hw>]:LFOutput<ch>:SHApe:PULSe:DCYCLe.....	717
[SOURce<hw>]:LFOutput<ch>:SHApe:PULSe:PERiod.....	717
[SOURce<hw>]:LFOutput<ch>:SHApe:PULSe:WIDTh.....	718
[SOURce<hw>]:LFOutput<ch>:SHApe:TRAPeZe:FALL.....	718
[SOURce<hw>]:LFOutput<ch>:SHApe:TRAPeZe:HIGH.....	718
[SOURce<hw>]:LFOutput<ch>:SHApe:TRAPeZe:PERiod.....	718
[SOURce<hw>]:LFOutput<ch>:SHApe:TRAPeZe:RISE.....	719
[SOURce<hw>]:LFOutput<ch>:SHApe:TRlangle:PERiod.....	719
[SOURce<hw>]:LFOutput<ch>:SHApe:TRlangle:RISE.....	719
[SOURce<hw>]:LIST:CATalog?.....	731
[SOURce<hw>]:LIST:DELeTe.....	731
[SOURce<hw>]:LIST:DELeTe:ALL.....	732
[SOURce<hw>]:LIST:DEXChange:AFILe:CATalog?.....	733
[SOURce<hw>]:LIST:DEXChange:AFILe:EXTeNsion.....	734
[SOURce<hw>]:LIST:DEXChange:AFILe:SELeCt.....	734
[SOURce<hw>]:LIST:DEXChange:AFILe:SEParator:COLumn.....	734
[SOURce<hw>]:LIST:DEXChange:AFILe:SEParator:DECimal.....	734
[SOURce<hw>]:LIST:DEXChange:EXECute.....	735
[SOURce<hw>]:LIST:DEXChange:MODE.....	735
[SOURce<hw>]:LIST:DEXChange:SELeCt.....	735
[SOURce<hw>]:LIST:DWELI.....	726
[SOURce<hw>]:LIST:DWELI:LIST.....	727
[SOURce<hw>]:LIST:DWELI:LIST:POINts?.....	727
[SOURce<hw>]:LIST:DWELI:MODE.....	726
[SOURce<hw>]:LIST:FREE?.....	732
[SOURce<hw>]:LIST:FREQuency.....	727
[SOURce<hw>]:LIST:FREQuency:POINts?.....	728
[SOURce<hw>]:LIST:INDeX.....	728
[SOURce<hw>]:LIST:INDeX:STARt.....	728
[SOURce<hw>]:LIST:INDeX:STOP.....	728
[SOURce<hw>]:LIST:MODE.....	729
[SOURce<hw>]:LIST:POWeR.....	729
[SOURce<hw>]:LIST:POWeR:POINts?.....	729
[SOURce<hw>]:LIST:RESeT.....	732
[SOURce<hw>]:LIST:RUINg?.....	731
[SOURce<hw>]:LIST:SELeCt.....	733
[SOURce<hw>]:LIST:TRIGger:EXECute.....	730
[SOURce<hw>]:LIST:TRIGger:SOURce.....	730
[SOURce<hw>]:MODulation[:ALL][:STATe].....	614
[SOURce<hw>]:NOISe:BANDwidth BWIDTh.....	736
[SOURce<hw>]:NOISe:BWIDTh:STATe.....	736
[SOURce<hw>]:NOISe:DISTRibution.....	737
[SOURce<hw>]:NOISe:LEVel:RELative?.....	737
[SOURce<hw>]:NOISe:LEVel[:ABSolute]?.....	737
[SOURce<hw>]:PGENerator:OUTPut:POLarity.....	738
[SOURce<hw>]:PGENerator:OUTPut[:STATe].....	738
[SOURce<hw>]:PGENerator:STATe.....	739
[SOURce<hw>]:PHASe.....	739
[SOURce<hw>]:PHASe:REFerence.....	739

[SOURce<hw>]:PM:DEVIation:MODE.....	634
[SOURce<hw>]:PM:DEVIation:SUM.....	634
[SOURce<hw>]:PM:MODE.....	633
[SOURce<hw>]:PM:RATio.....	634
[SOURce<hw>]:PM:SENSitivity?.....	635
[SOURce<hw>]:PM<ch>:SOURce.....	633
[SOURce<hw>]:PM<ch>:STATe.....	632
[SOURce<hw>]:POWer:ALC:DSENSitivity.....	743
[SOURce<hw>]:POWer:ALC:EDETector:FACTor.....	744
[SOURce<hw>]:POWer:ALC:EDETector:LEVel.....	744
[SOURce<hw>]:POWer:ALC:SONCe.....	744
[SOURce<hw>]:POWer:ALC[:STATe].....	743
[SOURce<hw>]:POWer:ATTenuation:PATTenuator.....	745
[SOURce<hw>]:POWer:ATTenuation:RFOff:MODE.....	745
[SOURce<hw>]:POWer:EMF:STATe.....	745
[SOURce<hw>]:POWer:LBEHaviour.....	746
[SOURce<hw>]:POWer:LIMit[:AMPLitude].....	746
[SOURce<hw>]:POWer:MANual.....	746
[SOURce<hw>]:POWer:MODE.....	747
[SOURce<hw>]:POWer:POWer.....	747
[SOURce<hw>]:POWer:RANGe:LOWer?.....	753
[SOURce<hw>]:POWer:RANGe:MAX?.....	754
[SOURce<hw>]:POWer:RANGe:MIN?.....	754
[SOURce<hw>]:POWer:RANGe:UPPer?.....	753
[SOURce<hw>]:POWer:SPC:CRANGe.....	748
[SOURce<hw>]:POWer:SPC:DELay.....	748
[SOURce<hw>]:POWer:SPC:MEASure.....	749
[SOURce<hw>]:POWer:SPC:MODE.....	749
[SOURce<hw>]:POWer:SPC:PEAK.....	749
[SOURce<hw>]:POWer:SPC:SElect.....	749
[SOURce<hw>]:POWer:SPC:SINGLE.....	750
[SOURce<hw>]:POWer:SPC:STATe.....	750
[SOURce<hw>]:POWer:SPC:TARGet.....	750
[SOURce<hw>]:POWer:SPC:WARning?.....	750
[SOURce<hw>]:POWer:STARt.....	748
[SOURce<hw>]:POWer:STEP:MODE.....	751
[SOURce<hw>]:POWer:STEP[:INCRement].....	751
[SOURce<hw>]:POWer:STOP.....	748
[SOURce<hw>]:POWer[:LEVel][:IMMediate]:OFFSet.....	752
[SOURce<hw>]:POWer[:LEVel][:IMMediate]:RCL.....	752
[SOURce<hw>]:POWer[:LEVel][:IMMediate]:REFLevel.....	753
[SOURce<hw>]:POWer[:LEVel][:IMMediate][:AMPLitude].....	752
[SOURce<hw>]:PULM:DELay.....	638
[SOURce<hw>]:PULM:DOUBle:DELay.....	639
[SOURce<hw>]:PULM:DOUBle:STATe.....	639
[SOURce<hw>]:PULM:DOUBle:WIDTh.....	639
[SOURce<hw>]:PULM:IMPedance.....	640
[SOURce<hw>]:PULM:MODE.....	637
[SOURce<hw>]:PULM:PERiod.....	638
[SOURce<hw>]:PULM:POLarity.....	640

[SOURce<hw>]:PULM:SOURce.....	639
[SOURce<hw>]:PULM:STATE.....	639
[SOURce<hw>]:PULM:THReshold.....	641
[SOURce<hw>]:PULM:TRAI:n:CATalog?.....	642
[SOURce<hw>]:PULM:TRAI:n:DELeTe.....	642
[SOURce<hw>]:PULM:TRAI:n:DEXChange:AFILe:CATalog?.....	645
[SOURce<hw>]:PULM:TRAI:n:DEXChange:AFILe:EXTension.....	645
[SOURce<hw>]:PULM:TRAI:n:DEXChange:AFILe:SELeCt.....	646
[SOURce<hw>]:PULM:TRAI:n:DEXChange:AFILe:SEParator:COLumn.....	645
[SOURce<hw>]:PULM:TRAI:n:DEXChange:AFILe:SEParator:DECimal.....	645
[SOURce<hw>]:PULM:TRAI:n:DEXChange:EXECute.....	646
[SOURce<hw>]:PULM:TRAI:n:DEXChange:MODE.....	644
[SOURce<hw>]:PULM:TRAI:n:DEXChange:SELeCt.....	646
[SOURce<hw>]:PULM:TRAI:n:OFFTime.....	643
[SOURce<hw>]:PULM:TRAI:n:OFFTime:POINts?.....	643
[SOURce<hw>]:PULM:TRAI:n:ONTime.....	643
[SOURce<hw>]:PULM:TRAI:n:ONTime:POINts?.....	643
[SOURce<hw>]:PULM:TRAI:n:REPetition.....	643
[SOURce<hw>]:PULM:TRAI:n:REPetition:POINts?.....	643
[SOURce<hw>]:PULM:TRAI:n:SELeCt.....	644
[SOURce<hw>]:PULM:TRIGger:MODE.....	637
[SOURce<hw>]:PULM:TTPe.....	640
[SOURce<hw>]:PULM:WIDTh.....	638
[SOURce<hw>]:SWEep:COMBined:COUnT.....	772
[SOURce<hw>]:SWEep:COMBined:DWELI.....	772
[SOURce<hw>]:SWEep:COMBined:EXECute.....	773
[SOURce<hw>]:SWEep:COMBined:MODE.....	773
[SOURce<hw>]:SWEep:COMBined:RETRace.....	774
[SOURce<hw>]:SWEep:COMBined:SHAPE.....	774
[SOURce<hw>]:SWEep:GENeration.....	766
[SOURce<hw>]:SWEep:MARKer:OUTPut:POLarity.....	775
[SOURce<hw>]:SWEep:POWer:DWELI.....	765
[SOURce<hw>]:SWEep:POWer:EXECute.....	769
[SOURce<hw>]:SWEep:POWer:MODE.....	766
[SOURce<hw>]:SWEep:POWer:POINts.....	766
[SOURce<hw>]:SWEep:POWer:RETRace.....	770
[SOURce<hw>]:SWEep:POWer:RUNNing?.....	770
[SOURce<hw>]:SWEep:POWer:SHAPE.....	769
[SOURce<hw>]:SWEep:POWer:SPACing:MODE?.....	767
[SOURce<hw>]:SWEep:POWer:STEP[:LOGarithmic].....	767
[SOURce<hw>]:SWEep:RESeT[:ALL].....	774
[SOURce<hw>]:SWEep[:FREQuency]:ANALog:SWPOINts?.....	767
[SOURce<hw>]:SWEep[:FREQuency]:DWELI.....	768
[SOURce<hw>]:SWEep[:FREQuency]:EXECute.....	769
[SOURce<hw>]:SWEep[:FREQuency]:MARKer:ACTive.....	775
[SOURce<hw>]:SWEep[:FREQuency]:MARKer<ch>:FREQuency.....	775
[SOURce<hw>]:SWEep[:FREQuency]:MARKer<ch>:FSTate.....	776
[SOURce<hw>]:SWEep[:FREQuency]:MODE.....	768
[SOURce<hw>]:SWEep[:FREQuency]:POINts.....	768
[SOURce<hw>]:SWEep[:FREQuency]:RETRace.....	770

[SOURce<hw>]:SWEep[:FREQuency]:RUNNing?	770
[SOURce<hw>]:SWEep[:FREQuency]:SHAPE	769
[SOURce<hw>]:SWEep[:FREQuency]:SPACing	769
[SOURce<hw>]:SWEep[:FREQuency]:STEP:LOGarithmic	770
[SOURce<hw>]:SWEep[:FREQuency]:STEP[:LINear]	771
[SOURce<hw>]:SWEep[:FREQuency]:TIME	774
[SOURce<hw>]:VOR:COMid:CODE	682
[SOURce<hw>]:VOR:COMid:DASH	682
[SOURce<hw>]:VOR:COMid:DEPTH	683
[SOURce<hw>]:VOR:COMid:DOT	683
[SOURce<hw>]:VOR:COMid:FREQuency	683
[SOURce<hw>]:VOR:COMid:LETTer	684
[SOURce<hw>]:VOR:COMid:PERiod	684
[SOURce<hw>]:VOR:COMid:SYMBol	684
[SOURce<hw>]:VOR:COMid:TSCHEMA	685
[SOURce<hw>]:VOR:COMid[:STATe]	685
[SOURce<hw>]:VOR:FREQuency	685
[SOURce<hw>]:VOR:FREQuency:MODE	686
[SOURce<hw>]:VOR:ICAO:CHANnel	686
[SOURce<hw>]:VOR:MODE	687
[SOURce<hw>]:VOR:PRESet	652
[SOURce<hw>]:VOR:REFerence[:DEViation]	688
[SOURce<hw>]:VOR:SETTing:CATalog?	652
[SOURce<hw>]:VOR:SETTing:DELeTe	653
[SOURce<hw>]:VOR:SETTing:LOAD	653
[SOURce<hw>]:VOR:SETTing:STORe	653
[SOURce<hw>]:VOR:SOURce	681
[SOURce<hw>]:VOR:STATe	654
[SOURce<hw>]:VOR:SUBCarrier:DEPTH	688
[SOURce<hw>]:VOR:SUBCarrier[:FREQuency]	688
[SOURce<hw>]:VOR:VAR:FREQuency	689
[SOURce<hw>]:VOR:VAR[:DEPTH]	689
[SOURce<hw>]:VOR[:BANGLE]	681
[SOURce<hw>]:VOR[:BANGLE]:DIRection	682
[SOURce<hw>][:ILS]:MBEacon:COMid:CODE	676
[SOURce<hw>][:ILS]:MBEacon:COMid:DASH	676
[SOURce<hw>][:ILS]:MBEacon:COMid:DEPTH	676
[SOURce<hw>][:ILS]:MBEacon:COMid:DOT	677
[SOURce<hw>][:ILS]:MBEacon:COMid:FREQuency	677
[SOURce<hw>][:ILS]:MBEacon:COMid:LETTer	677
[SOURce<hw>][:ILS]:MBEacon:COMid:PERiod	677
[SOURce<hw>][:ILS]:MBEacon:COMid:SYMBol	678
[SOURce<hw>][:ILS]:MBEacon:COMid:TSCHEMA	678
[SOURce<hw>][:ILS]:MBEacon:COMid[:STATe]	678
[SOURce<hw>][:ILS]:MBEacon:FREQuency	679
[SOURce<hw>][:ILS]:MBEacon:FREQuency:MODE	679
[SOURce<hw>][:ILS]:MBEacon:MARKer:FREQuency	679
[SOURce<hw>][:ILS]:MBEacon:PRESet	680
[SOURce<hw>][:ILS]:MBEacon[:MARKer]:DEPTH	680
[SOURce<hw>][:ILS]:MBEacon[:MARKer]:PULSed	680

*CLS.....	488
*ESE.....	488
*ESR?.....	488
*IDN?.....	489
*IST?.....	489
*OPC.....	489
*OPT?.....	489
*PRE.....	490
*PSC.....	490
*RCL.....	490
*RST.....	490
*SAV.....	491
*SRE.....	491
*STB?.....	491
*TRG.....	491
*TST?.....	492
*WAI.....	492
<subsystem>:FREQuency:SYNChronize:STATe.....	654
<subsystem>:PRESet.....	652
<subsystem>:SETTing:CATalog.....	652
<subsystem>:SETTing:DELeTe.....	652
<subsystem>:SETTing:LOAD.....	653
<subsystem>:SETTing:STORe.....	653
<subsystem>:STATe.....	653
DIAGnostic:HUMS:DELeTe:ALL.....	516
DIAGnostic:HUMS:DEvice:HISTory:DELeTe:ALL.....	517
DIAGnostic:HUMS:DEvice:HISTory?.....	516
DIAGnostic:HUMS:FORMat.....	517
DIAGnostic:HUMS:SAVE.....	518
DIAGnostic:HUMS:STATe.....	518
DIAGnostic:HUMS:TAGS:ALL?.....	518
DIAGnostic:HUMS:TAGS:DELeTe.....	519
DIAGnostic:HUMS:TAGS:DELeTe:ALL.....	519
DIAGnostic:HUMS:TAGS[:VALue].....	519
SYSTem:COMMunicate:REST:ENABle.....	520
SYSTem:COMMunicate:SNMP:COMMunity:RO.....	520
SYSTem:COMMunicate:SNMP:COMMunity:RW.....	520
SYSTem:COMMunicate:SNMP:CONtact.....	521
SYSTem:COMMunicate:SNMP:LOCation.....	521
SYSTem:COMMunicate:SNMP:USM:USER.....	521
SYSTem:COMMunicate:SNMP:USM:USER:ALL?.....	522
SYSTem:COMMunicate:SNMP:USM:USER:DELeTe.....	522
SYSTem:COMMunicate:SNMP:USM:USER:DELeTe:ALL.....	522
SYSTem:COMMunicate:SNMP:VERSion.....	522

Index

Symbols

/var/user directory	494
/var/volatile directory	494
>L	464
&LLO	464
&NREN	464
50 - Extern reference out of range or disconnected	820
140 - This modulation forces other modulations off	820
180 - Adjustment failed	820
182 - Adjustment data missing	820
183 - Adjustment data invalid	820
200 - Cannot access hardware	820
201 - Hardware revision out of date	820
202 - Cannot access the EEPROM	820
203 - Invalid EEPROM data	820
204 - river initialization failed	820
241 - No current list	821
242 - Unknown list type specified	821
460 - Cannot open the file	821
461 - Cannot write file	821
462 - Cannot read file	821
463 - Filename missing	821
464 - Invalid filename extension	821
465 - File contains invalid data	821

A

About	
ALC states and their effects	232
Attenuator	228
External ALC	232
Internal adjustments	834
Power-On/EMF	370
Reference oscillator	317
Selftests	834
UCOR	236, 237
Accept	
Security settings	399
Access modes	
Overview	409
Active connections	
Remote access settings	430
Active elements	54
Add LAN sensor	
NRP sensor mapping	265
Add sensor	
NRP sensor mapping	265
Add USBTMC sensor	
NRP sensor mapping	266
Add, change, delete	
User key action	379
Address	
GPIB interface	427
ADF	
About	162
Adjust	
Display and keyboard	367
Display settings	366
Keyboard settings	366
Adjustment frequency	
Reference oscillator	322

Adjustments	
All	836
All delayed	837
Continue	836
Delay settings	837
Information	836
Last full adjustment	836
Log debug info	836
Settings	835
Shutdown	837
Warm up time	837
Advanced configuration	
LXI	448
ALC	
Detector coupling factor	235
Detector sensitivity	234
Required generator level	235
Settings	234
State	234
ALC states and their effects	232
Alphanumeric keys	
Front panel keyboard	369
Alphanumeric values	
Entering	57
AM	
Deviation mode	89
Overview	121
Ratio	90
Subsystem	615
Total deviation	89
Amplitude modulation	87
Depth	89
Deviation mode	89
Mode	88
Ratio	90
Sensitivity	89
Subsystem	615
Type	88
Analog modulation	
Options	77
Overview	119
Signal source	77
Annotation	
Disable amplitude display	393
Disable frequency display	392
Disable level	393
Aperture time	
Power sensors	262
Application cards	22
Application notes	22
Apply	
Settings of external instrument	180
Apply and connect	
Settings of external instrument	180
ATN	855
Attention	855
Attenuator	
About	228
RF signal	228
Settings	229
Attenuator settings	
Level range	230
Mode	230

RF OFF mode	230
Step attenuator below 20 GHz	230
Auto once	
Power sensors	262
Power viewer	262
Automatic level control	
Detector coupling factor (ext. ALC)	235
Detector sensitivity	234
How to: set external ALC	235
Readjust internal switch position	74, 231
Required generator level (ext. ALC)	235
Settings	234
State	234
Automation	408
Autonegotiation	
Failed	823
Avahi	
LAN services	397
Average	
Power analysis	280
Average level	
Power viewer	260
Avionics standards	
Overview	124

B

Bandwidth	
Chirp modulation	94
Modulation input	116
Noise generator	117
Basics	
Editor	104, 225, 243
Export list files	105, 246
Fill with sensor list files	244
Import list files	105, 246
Baud rate	
RS232 interface	427
Bench top, placing	24
Brochures	21
Browser settings	
LXI	445
Bytes order	
Definition	528

C

Calibrate RF output level with power sensor	313
Calibration certificate	22
CALibration subsystem	504
Carrier frequency	
ILS localizer	149
ILS marker beacons	158
VOR	129
Carrier frequency mode	
ILS localizer	149
ILS marker beacons	158
VOR	129
Carrying the instrument	23
Catch range	
NRP power control	257
Central storage	
Accessing	359
Change	
GPIO address	456, 463
Change password	
Setup (security)	402

Change user password	
Setup (security)	401
Check display screen	
Display screen test	845
Check front panel	
Key panel test	843
Performing	843
Settings	842
Check touch panel	
Touchscreen test	844
Checking the instrument	23
Chirp	
Modulation	91
CHIRp	
Subsystem	622
Chirp modulation	77, 90
Bandwidth	94
Compression ratio	94
Direction	92
Gated signal	93
Number of pulses	94
Pulse external settings	95
Pulse period	93
Pulse width	94
Remote control commands	622
Settings	92
Single trigger	94
State	92
Subsystem	622
Trigger mode	93
Trigger settings	95
Clean	
List of external instrument	179
Cleaning	834
Clear	
NRP sensor mapping	265
RF output protection	231
User menu	377
Clear history	
Undo/Redo	407
Clear status	
Remote	488
Clk Syn connector	39, 42
Clock	
Amplitude	329
DC offset	330
Frequency	329
Phase, reset	330
Phase, set	330
Shape	328
Clock synthesis	508
Clock synthesis inverted output	327
Clock synthesis output	327
Close	
Show SCPI command	467
Closed connections	
Remote access settings	431
Configuring external ALC	235
Color	
Power analysis	273
COM/ID code	
ADF	166
COM/ID dash length	
ADF	167
COM/ID depth	
ADF	166

COM/ID dot length	ADF	166
COM/ID frequency	ADF	166
COM/ID letter space	ADF	167
COM/ID period	ILS localizer	166
COM/ID settings	ADF	165
COM/ID state	ADF	166
COM/ID symbol space	ADF	167
COM/ID time schema	ADF	166
Combined RF frequency / level sweep	Step count	213
Combined sweep	Spacing	208, 211
Command sequence	Remote	492
Commands of all settings	SCPI list	343
Compression ratio	Chirp modulation	94
Configuration	Restoring	344
	Restoring instrument settings	341
Configure	Power analysis	270
Configure diagram	Power analysis	282
Configure gate mode	Power analysis	300
Configure measurement	Power analysis	278
Configure remote access		453
Configure sensor	Power analysis	290
Configure time mode	Power analysis	293
Configuring LAN services		395
Confirm user password	Setup (security)	401
Connect		176
	External instrument	180
Connect remote instruments	Keep connection on preset	177
	On start-up	177
Connecting	Keyboard	27
	LAN	27
	Memory stick	27
	Mouse	27
	Power	26
	To Ref In/Ref Out	30
	To RF	30
	To RF coaxial connectors	28
	USB devices	27
Connecting external ALC		233, 235
Connecting to RF coaxial connectors	To connect to pluggable connectors	29
	To connect to screwable connectors	29
	To prepare for connecting	28
Connection fault	169 254 **	823

Connector	
AC power supply	42
Clk Syn N	39, 42
EFC	41
Ext	39, 42
GPIB	40
IEC/IEEE	40
Inst Trig	42
LAN	41
LF	39, 42
Marker User1	4
Pulse Ext	39, 42
Pulse Sync	38, 42
Pulse Video	38, 42
Ref In	41
Ref Out	41
RF 50 Ω	38, 42
Sensor	37
Signal Valid	42
Stop	41
USB	37, 41
USB In	41
V/GHz X-Axis	41
Z-Axis	41
Connector direction	
Settings	177
Connectors	
RF signal	64
Context-sensitive menu	54
Continue	
Internal adjustments	836
Continue on error	
Failed internal adjustments	824
Control bus	855
Convert	
Remote command list	474
Copy	
Instrument settings	350
Several files	348, 356, 357
Show SCPI command	467
Counter	828
Coupling mode	
AM, FM, PhiM	115
External modulation input	115
Create	
New directory	350
Current frequency	
Sweep	205
Current index	
List mode	218
Current level	
Sweep	205
Customer support	831
Cut	
Instrument settings	350
CW	
Frequency	68
CW mode	
Output level	71
CW signal	
Settings	6

D

Data	
Accessing	331
Handling	331
Retrieving	331
Data editor	
UCOR	241
Data entry	56
Data format	
Definition	529
Data list	
Access	346
How to open	495
Select, edit, new	347
Data sheets	21
Data valid	855
Datasheet	
LXI	451
Date	840
DAV	855
Deactivate RF output	319
Deactivated licenses	382
Declassification	392
Default directory	
Mass memory	494
User data	333, 494
Default settings	128, 140, 164
Default values	
Remote	490
Define	
User key action	379
Delay	
Double pulse (PULM)	101
PULM	101
Delay time	
NRP power control	257
Delete	
Instrument settings	350
List mode file	220
Delete instrument settings	501
Delete temporary files	848
Delta phase	
RF frequency	76
Detector coupling factor	
Automatic level control (ext. ALC)	235
Detector sensitivity	
Automatic level control	234
Deviation	
Fixed total deviation	85, 86
PhiM	86
Deviation mode	
AM	89
Amplitude modulation	89
FM	85
Frequency modulation	85
Phase modulation	86
PhiM	86
Device ID	381
NRP sensor mapping	266
Device reset	493
Device-specific notifications	819
Dialog boxes	55
Direction	
Chirp modulation	92
Connector	177

Directory	
Temporary data	494
User data	494
Disable	
Frequency display	392
Level display	393
Disconnect	176
Disk & memory	
Security settings	390
Display	
Active elements	54
Brightness	368, 369
Context-sensitive menu	54
Info line	54
Information	52
Lock	393
On-screen keypad	54
Overview	33
Power sensors	260
Screen saver	368
Settings	367
Setup	367
Status bar	53
Tab labels	54
Taskbar	53
Tile diagram	53
USB keyboard	369
Wait time (screen saver)	368
Display correction file data	
UCOR	241
Display correction value	
UCOR	240
Display permanent	
Power sensors	260
Display screen	
Checking	845
Display screen test	
Perform	845
DISPlay subsystem	523
Disposal	834
Distribution	
Noise generator	116
DNS server	424
DNS suffix	424
Documentation overview	20
Double pulse delay	
PULM	101
Double pulse width	
PULM	101
Downgrade information	829
Factory version	829
Min. version	829
Dwell time	
Sweep	208
Dwell time mode	
List mode	219

E

Edit	
Editor	104, 225, 243
List mode data	221
UCOR data	241
Editor	
Basics	104, 225, 243
Edit	104, 225, 243
Fill with sensor	243

Goto	104
Save	104, 225, 243
Save as	104, 225, 243
Select row	225, 243
EFC	
Activate	321
Sensitivity	321
EMF display	
RF level	370
Emulation	
IDN string	429
Language	429
Mode	429
Set IDN and OPT to default	429
Enable	
LAN interface	397
Enable registers	
Remote	490
Enter license key	381
Enter password	
Setup (security)	399
EOI	855
Error log	830
Error messages	821
Adjustment data invalid (183)	820
Adjustment data missing (182)	820
Adjustment failed (180)	820
Cannot access hardware (200)	820
Cannot access the EEPROM (202)	820
Cannot open file (460)	821
Cannot read file (462)	821
Cannot write file (461)	821
Driver initialization failed (204)	820
Extern reference out of range or disconnected (50) ..	820
File contains invalid data (465)	821
Filename missing (463)	821
Hardware revision out of date (201)	820
Invalid EEPROM data (203)	820
Invalid filename extension (464)	821
No current list (241)	821
SCPI	819
See notifications	818
This modulation forces other modulations off (140) ..	820
Unknown list type specified (242)	821
Event status enable register (ESE)	
Remote	488
Event status register (ESR)	
Remote	488
Exclude frequency	344
Exclude level	344
Execute	
Single sweep	209
Trigger (list mode)	220
Execute single	
NRP power control	257
Expiration date of option	829
Export	
Execute	107, 223, 248
SCPI	348
SCPI export	470
SCPI list	468
SCPI settings	468
Export deactivation response	382
Export license key	382
Export list files	
Basics	105, 246

Express level in	
Volts	740
Ext AM	
VOR	129
External ALC	232
How to: setting up	235
Remote command sequence	740
External frequency	
Reference oscillator	319
External instrument	
Settings	178
External RF	
Configuration and settings	176

F

Factory	
Preset	338
Factory preset	
Change GPIB address	456
GPIB address	463
Factory version	
Firmware	829
File	
SCPI export	469
File catalog	
List mode	220
File content	
SCPI export	470
File handling	334
File list	498
File manager	348
File name	361
File select	
Dialog	346
File server	
Data exchange	359
File sharing	354
File storage location	494
File system	332
Accessing	354
File transfer	334
From file server	359
FTP/SAMBA	408
How to	354
File type selection	350
Filename	
Pulse graph	108
Files	
User data	331
Fill	
User correction data	104, 225, 243
Fill table	
Automatically	104, 225, 243
UCOR	241
Fill with sensor	
Basics	244
Editor	243
Filter	
Power sensors	261
Filter length	
Auto	262
User-defined	262
Finding out the default directory	333, 494

Firmware		
Factory version	829	
Min. version	829	
Version	829	
Fixed		
Frequency	68	
Floating licenses	829	
FM		77
Deviation	84	
Deviation mode	85	
Ratio	85	
Subsystem	626	
Total deviation	85	
Format		
SCPI Export	469	
FORMat subsystem	528	
FPGA/μC		
Check for updates	847	
Check for updates of external	848	
Shut down after update internal	848	
Update installation internal assembly	847	
Update table	847	
Free space		
internal memory	848	
Frequency		
Annotation disable	392	
CW, fixed	68	
LF generator	114	
LF sweep	114	
Multiplier	69	
Offset	69	
Power sensors	261	
RF signal	67	
UCOR	241	
Frequency marker		
Activate	216	
Boost marker x	217	
Duration	217	
Polarity	217	
State	216	
Frequency modulation	84	
Deviation mode	85	
Ratio	85	
Subsystem	626	
Frequency multiplier		
Test setup	169	
Frequency range		
Phase continuous signal	76	
Frequency range from		
Phase continuous signal	76	
Frequency range to		
Phase continuous signal	76	
Frequency sweep		
Sweep type	204, 215	
V/GHz	215	
X-Axis	215	
Frequency, internal		
AM	114	
FM	114	
Front panel		
Checking	842	
Front panel test		
Performing	843	
Front panel tour	32	
FTP		
How to access the instrument	354	
LAN services	397	
Function keys		
Overview	35	
G		
Gated signal		
Chirp modulation	93	
Gateway	424	
General configuration of instrument	366	
General instrument functions		
User key	372	
User menu	372	
General instrument settings	366	
General settings		
ADF	163	
ILS	139	
Generating an unmodulated signal	61	
Getting started	21	
Global dwell time		
List mode	219	
Goto		
Editor	104	
GPIO		
Address	427	
Change address	456, 463	
Channel address	426	
Characteristics	414	
Interface	414	
Set up remote control	463	
Visa resource string	426	
GPIO address		
Factory preset	463	
GUI		
Setting	371	
GUI update		
Setup	366	
H		
Hard copy		
Create, how to	364	
File format	362	
Print, how to	364	
Hard disk		
Deleting temp files	848	
Hardcopy	360	
Options	362	
Hardware channel		
Remote Instrument	179	
Health and utilization		
LXI	451	
Help	21, 58	
HiSLIP		
Visa resource string	425	
HiSLIP		
Resource string	411	
History		
Undo/Redo	407	
Host name		
NRP sensor mapping	265	
Hostname	423	
LXI	444	
Remote Instrument	179	
How to		
Calibrate RF output level with power sensor	313	
Change the default directory	495	
Checking hardware options	825	

Checking RF assembly	826	Carrier frequency mode	142
Configure the R&S SMA100B for frontend control ...	171	Ext AM	143
Configuring external ALC	235	General settings	142
Connect an R&S SZM	170	ICAO channel	143
Connecting external ALC	233, 235	Signal settings	144
Internal adjustments	838	Sync with localizer	143, 150
Multiplying RF output frequencies	175	ILS glide slope amplitude	145
Output the external frontend RF signal	175	DDM - SDM coupling	148
Resolve adjustments errors	824	DDM current	147
Run delayed adjustments	839	DDM depth	147
Set external ALC	235	DDM logarithmic	147
Use an complete file path	495	DDM percent	147
User key	376	DDM step	147
User menu	374	Fly mode	146
Using power sensors	249	Sum of depth	146
How to:		ILS glide slope signal	
Enable VNC	476	DDM polarity	145
Remote control with LXI browser	456	Down frequency	145
Return to manual operation	465	Operating mode	144
HTTP		Up frequency	145
LAN services	397	Up/Down phase	145
HUMS	432	ILS localizer	
About	432	Amplitude settings	152
Add device tags	443	COM/ID settings	155
Delete device tag entry	443	Ext AM	150
Delete device tags	443	General settings	149
Delete history	434	Signal settings	151
Device ID	442	Sync with glide slope	143, 150
Device tag key	442	ILS localizer amplitude	
Device tag value	442	DDM - SDM coupling	154
Device tags	441	DDM current	154
Enhanced settings	434	DDM depth	154
Export history	434	DDM logarithmic	155
LXI	451	DDM percent	155
Protocol settings	435	DDM step	154
REST	436	Fly mode	153
SNMP protocol	436	Sum of depth	153
SNMPv2 access	437	ILS localizer COM/ID	
SNMPv2 community	436	Code	156
SNMPv2 configuration	436	Dash length	157
SNMPv3 user	437	Depth	156
State	434	Dot length	157
		Frequency	156
I		Letter space	157
ICAO channel		Period	156
ILS localizer	150	State	156
VOR	129	Symbol space	157
Identification		Time schema	157
Emulation mode	429	ILS localizer signal	
Remote	489	DDM polarity	152
IDN string		Left frequency	152
Emulation mode	429	Left/right phase	152
IEC/IEEE bus interface		Operating mode	151
Channel address	426	Right frequency	152
IFC	855	ILS marker beacons	
ILS		COM/ID settings	160
About	135	General settings	158
Configuration and settings	139	Signal settings	159
Glide slope settings	141	ILS marker beacons COM I/D	
Localizer	148	Code	161
Marker beacons settings	157	Dash length	162
ILS component		Depth	161
Component	141	Dot length	162
ILS glide slope		Frequency	161
Amplitude settings	145	Letter space	162
Carrier frequency	143	Period	161
		State	161

Symbol space	162
Time schema	161
ILS marker beacons signal	
Marker depth	159
Marker frequency	159
Pulsed marker	159
Impedance	
External modulation source	116
Import	
Execute	107, 223, 248
SCPI	348
Import license key	382
Import list files	
Basics	105, 246
Import/Export	
Lists	221
Select file	107, 222, 223, 248
Inactive licenses	382
Index	
List mode	218
Info line	54, 821
Information	
Internal adjustments	836
Input	
Impedance external modulations	116
Pulse Ext	90
Pulse polarity	109
Pulse threshold	110
Trigger impedance	109
Input connector	39, 41, 42
Input connectors	
Stop	41
Installed assembly	827
Instrument	
Carrying	23
Checking	23
Lifting	23
Operating site	23, 24
Unpacking	23
Instrument emulations	428
Instrument help	21
Instrument name	
External instrument	178
Instrument security procedures	21
Instrument settings	
Recall	490, 501
Save	491, 503
Instrument tour	32
Interface	
Functions (GPIB)	856
GPIB	414
Interface clear	855
Interfaces	
GPIB	414
RS232	413
USB	413
Internal adjustments	
How to	838
Internal adjustment	
Continue on error	824
Obtain technical support on error	825
Internal adjustments	
Abort on error	824
About	834
Troubleshooting	824
internal memory	
Deleting temp files	848

IP address	411
Dynamic	423
LXI	444
Not recognized	823
NRP sensor mapping	265
Remote Instrument	179
Zeroconf	423
IP address mode	423
IP configuration	
LXI	447
IST flag	
Remote	489

K

Key	
★ (User)	37
Arrow	36
Backspace	36
Down	36
Enter	36
Esc	36
Freq	35
Help	34
Home	37
Left	36
Level	35
Local	34
Mod on/off	35, 80
Next window	37
On/Off	37
On/Standby	34
Preset	34
Resize window	37
RF on/off	35
Right	36
Setup	34
Up	36
Key panel test	
Check front panel	843
Keyboard	
On-screen	56
Setting	371
Settings	367
Setup	367
Subsystem	535
Usage	51
Keypad	
On-screen	56
Overview	35

L

LAN	
Connecting	27
Environment	27
Interface	411
IP address	411
Main services	397
Reset	445
Samba services	398
Services	395
LAN configuration	
LXI	447
LAN interface	
Avahi	397
Enable	397

- FTP 397
 - HTTP 397
 - LAN over SCPI 397
 - SMB (Samba) 397
 - SSH 397
 - VNC 397
 - LAN status
 - LXI 444
 - Landing systems
 - Overview 124
 - Language
 - Emulation 429
 - Last factory calibration 828
 - Last full adjustment
 - Internal adjustments 836
 - Layout
 - USB keyboard 369
 - Level
 - Annotation disable 393
 - Behavior (RF) 73, 213, 257
 - Noise generator 119
 - Level default unit
 - Change 740
 - Level in SCPI in V 740
 - Level limit 72, 257
 - Level offset
 - Power sensors 261
 - RF level 72
 - State (power sensors) 261
 - Level range
 - Attenuator settings 230
 - Level settings
 - On start-up 370
 - LF frequency sweep
 - State 111, 205
 - LF generator
 - Shape 112
 - LF Out
 - Overview 120
 - LF output 117
 - Load impedance 118
 - Offset 118
 - Period 114
 - Pulse duty cycle 114
 - Pulse width 114
 - Shape 112
 - Source 118, 121
 - Sweep reset 209
 - Trapezoid high 114
 - Trapezoid rise, fall 114
 - Triangle rise 114
 - Voltage 118
 - LF sweep
 - Frequency 114
 - License
 - Keys 380
 - License for software option 829
 - Infos 829
 - Licenses 380
 - Server 383
 - Settings 380
 - Lifting the instrument 23
 - Limit
 - RF level 72, 257
 - List
 - Define 221
 - Range 221
 - State 218
 - List file
 - Catalog 220
 - List mode
 - Create list automatically 104, 225, 243
 - Current index 218
 - Dwell time mode 219
 - Edit 221
 - Execute trigger 220
 - Export user data 107, 223, 248
 - File settings, import/export 106, 222, 247
 - Global dwell time 219
 - Import/export 106, 221, 222, 247
 - Load from file 107, 222, 248
 - Load user data 221
 - Reset 220
 - Select file 220
 - Settings 217
 - State 218
 - Trigger execute 220
 - Trigger source 219
 - Load
 - Impedance 118
 - See recall 342
 - Load instrument settings 490, 501
 - Loading
 - Trying out 48
 - Lock
 - Display 393
 - Log debug info
 - Internal adjustments 836
 - LSB/MSB order
 - Definition 528
 - LucasFonts
 - RSCorpid EULA 829
 - LXI
 - Advanced configuration 448
 - Browser settings 445
 - Configuration 482
 - Datasheet 451
 - Health and utilization 451
 - Hostname 444
 - IP address 444
 - IP configuration 447
 - LAN configuration 447
 - LAN status 444
 - MAC address 444
 - Ping 449
 - Remote trace (SCPI) 449
 - Reset (LXI) 445
 - Status settings 444
 - Tracing 457
 - LXI browser
 - Starting remote control 456
- ## M
- Mac address 424
 - MAC address
 - LXI 444
 - Maintenance 834
 - Managing license keys 380
 - Managing licenses 380
 - Manual interaction 51

Manual operation	
Security settings	392
Map network share	
Settings	350
Mapping network folders	352
Mark frequency	
Sweep	216
Marker	
Power analysis	270
Marker settings	
Power analysis	276
Marker User1	41
Mass storage location	494
Max	
RF level sweep	214
Maximal deviation	
Frequency modulation	84
PhiM	86
Measured level	
NRP level control	256
Measurement window	
Power analysis	270
Min	
RF level sweep	214
Min. version	
Firmware	829
Min/max Y scale	
Power analysis	282
Minimum locking range	320
Mode	
AM	88
Attenuator settings	230
Emulation	429
Frequency modulation	85
IP address	423
List	219
NRP power control	256
PhiM	87
PULM	97
Pulse modulation	97
Sweep	205
User variation	69, 74
Modulation	
AM	80
Analog	77
Bandwidth, external input	116
Chirp modulation	80, 90, 91
Chirp modulation settings	92, 95
External coupling	115
FM	80
Input impedance	116
Overview	119
Phase	80
PhiM	80
PM	80
Pulse	80
Source	84
State	84
Modulation depth	
AM	89
Modulation sensitivity	
AM	89
Modulations state	
Toggle	80
More free disc space	
Deleting temp files	848
Mounting, in a rack	25

Mouse	
Usage	51
Multiple files	
Copy	348, 356, 357
Multiplier	
Frequency	69
N	
Naming conventions	
Allowed file names	332
Navigation	
Keys	36
Navigation controls	
Overview	35
NDAC	855
Network	
Connection fails	823
Environment	27
Settings	422
Network share	
Mapping	350, 352
Network status	422
New password	
Setup (security)	401
New user password	
Setup (security)	401
Noise	
Distribution	116
Noise bandwidth limitation	
System bandwidth	117
Noise generator	
Bandwidth	117
Noise level	
Absolute system bandwidth	119
Relative system bandwidth	119
Noise ratio	
Power sensors	262
Non-operational data	331
Notifications	818, 821
Device-specific	819
NRFD	855
NRP	
see Power analysis	266
NRP level control	
Measured level	256
NRP power control	254
Catch range	257
Delay time	257
Execute single	257
Mode	256
Reference level	256
Remote command sequence	741
Select sensor	256
Settings	255
State	255
Take measured level as reference	256
Target level	256
NRP power viewer	253
Settings	253
Use S-Parameter	263
NRP sensor configuration	258
NRP sensor mapping	263
Add LAN sensor	265
Add sensor	265
Add USBTMC sensor	266
Clear	265

Connector	264
Device ID	266
Host name	265
IP address	265
Protocol	264
Scan	265
Sensor name	264, 266
Serial number	266
Settings	264
NTP	
Address	841
Number of licenses	829
Number of pulses	
Chirp modulation	94
Numeric data entry	56
Numeric values	
Entering	56
O	
Obtain technical support	
Failed internal adjustments	825
Offset	
Frequency	69
Old password	
Setup (security)	401
Old user password	
Setup	400
On-screen keypad	54
Open source acknowledgment (OSA)	22
Open-source acknowledgments	829
Operating site	
Choosing	23
Setting up the instrument	24
Operation	
Concepts	50
Manual	51
Operation complete	
Remote	489
Operation hours	828
Operation mode	342
Operation status register	420
Operational data	331
Option	
Expiration date	829
Option: expiration date	829
Options	
Analog modulation	77
Identification (remote)	489
Oscillator	
Reference	317
Output	
Clk Syn	327
LF	118
SCPI list (select file)	469
Source (LF output)	121
OUTPUT	
Subsystem	536
Output connector	38, 42
Output connectors	
Clk Syn	39, 42
Marker User1	41
Pulse Sync	38, 42
RF 50 Ω	38, 42
Stop	41
V/GHz X-Axis	41
Z-Axis	41

Output, LF	
Offset	118
Voltage	118
Overview	
AM	121
LF Out	120

P

Parallel poll register enable	
Remote	490
Parity	
RS232 interface	427
Password	
Change (security password)	402
Change (user password (security))	401
Confirm (security password)	401
Confirm (user password (security))	401
Enter (security password)	399
New (security password)	401
New (user password (security))	401
Old (security password)	401
Old user password	400
Protection level	395
Password management	
Security	399
Paste	
Instrument settings	350
PCI bus	827
Phase	
Subsystem	739
Phase continuous active	
RF frequency	75
Phase continuous mode	
RF signal	63
Phase continuous signal	
Frequency range	76
Frequency range from	76
Frequency range to	76
Phase modulation	86
Deviation	86
Deviation mode	86
Mode	87
Ratio	87
Subsystem	631
Phase reference	76
Phase settings	
RF signal	74
PhiM	
Deviation mode	86
Mode	87
Ratio	87
Settings	86
Total deviation	86
Ping	
LXI	449
Placing, on a bench top	24
PLL bandwidth	69
PM	77
Subsystem	631
Polarity	
Pulse generator output	101
Pulse modulation	109
Power	
Connecting the instrument	26
UCOR	241

Power analysis	266
Access	269
Example	271
Marker settings	276
Options	266
Trace reference settings	274
Trace settings	273
Traces	271
Power Analysis Diagram	
Power analysis	270
Power On	34
Power sensors	
Activation	260
Aperture time	262
Auto once	262
Filter	261
Filter length	262
Frequency	261
Level (average)	260
Level (peak)	260
Level offset	261
Noise ratio	262
NRP power control	254
Serial number	260
Source	261
State	260
State (level offset)	261
Timeout	262
Unit	260
Update	251
Use default aperture time	262
Zero	260
Power Sensors	
Display	260
Display permanent	260
Power supply	
Connector	42
Power viewer	
Auto once	262
Power-On	
Settings	370
Power-On count	828
Power-On state	
RF level	370
Power-On/EMF	
About	370
RF signal	370
Prefix, year, month, Day	363
Preparing for use	23
Preset	
Factory preset	338
Print	
Hard copy	364
Protection	
Settings	394
Setup	389
Protection level	
1	389
2	389
3, 4, 5	389
Adjustments	389
Calibration	389
Factory only	389
Protection level	395
Service department	389

PULM	
Delay	101
Double pulse delay	101
Double pulse width	101
Impedance (trigger input)	109
Mode	97
Period	100
Pulse polarity (input)	109
Repetition frequency	101
see PM	80
Source	81
State	81
Subsystem	635
Threshold (pulse input)	110
Transition type	82
Width	101
Pulse	
Duty cycle	114
Length (PULM)	101
Period	114
Width	114
Width (PULM)	101
Pulse generator	
Delay	101
Output polarity	101
Output state	101
Single Trigger	101
Subsystem	737
Width	101
Pulse graph	
Filename	108
Zoom In/Out	108
Zoom position	108
Zooming	108
Pulse modulation	80
Double pulse delay	101
Double pulse width	101
Mode	97
Period	100
Pulse input threshold	110
Pulse polarity (input)	109
Repetition frequency	100, 101
see PM	80
Select pulse train file	103
Source	81
State	81, 82
Subsystem	635
Trigger input impedance	109
Trigger mode	98
Pulse period	
Chirp modulation	93
Pulse Sync connector	38, 42
Pulse train	
File catalog	103
Import/export	106, 222, 247
On/off time	104
Repetition	104
Select	103
Pulse width	
Chirp modulation	94

Q

QR code	443
Questionable status register	420
Quick recall	344
Quick save	344

R

Rack installation	42	Network resource (Ethernet resource string)	425
Rack, mounting	25	Network settings	422
Radio navigation systems		Network status	422
Overview	124	OPT string	430
Ratio		QR code	443
AM	90	RS232	427
Amplitude modulation	90	Serial resource (VISA resource string)	426
FM	85	Set IDN and OPT to default	429
Frequency modulation	85	Settings	421
Phase modulation	87	Socket resource (VISA resource string)	426
PhiM	87	Subnet mask	423
Readjust		USB resource (VISA resource string)	426
Automatic level control	74, 231	Visa resource strings settings	425
Recall		VXI11 resource (VISA resource string)	425
Instrument settings	344	Workgroup name	423
User menu	377	Remote command list	
Recall instrument settings	490, 501	Convert	474
Recall intermediate	490	Remote connection	
Recorded SCPI commands		Status	178
SCPI list	468	Remote control	50
Recording list		Access modes	409
SCPI settings	467	Configure access	453
Redo	406	GPIB	463
Clear history	407	GPIB interface	414
History	407	Interfaces and protocols	410
Settings	406	Programming examples	487
State	407	Programs and libraries	415
Reference frequency output		return to manual operation	465
1 GHz	321	SCPI	408
10 MHz, 100 MHz	321	Setting up	452
Loop through	321	Source subsystem	613
Reference oscillator	317	Remote Desktop	50
Adjustment	322	Remote interfaces and protocols	410
Adjustment frequency	322	Remote operation	50
External frequency	319	Stop access	482
Output frequency	321	VNC	408
Preset	319	Remote to local switch over	464
Reference frequency, variable	320	Remote trace	
RF off state	319	LXI	449
Source	319	Removing sensitive data	830
Synchronization bandwidth	320	REN	855
Use external tuning	321	Rename	
Release notes	22	File	502
Reload		Instrument settings	350
SCPI list	470	Repetition frequency	
Remote access	408	Pulse modulation	101
Active connection settings	430	Required generator level	
Closed connection settings	431	Automatic level control (ext. ALC)	235
Configuring	453	Reset	
DNS server	424	List mode	220
DNS suffix	424	RF frequency (delta phase)	76
GPIB address	426	Sweep	209
GPIB resource (VISA resource string)	426	Reset device parameters	493
HISLIP resource (VISA resource string)	425	Reset values	
HUMS	432	Remote	490
Identification	429	Resolving internal adjustment failures	824
IDN string	429	Resource string	
IEC/ IEEE bus address	426	RS232	414
Instrument emulations	428	USB	413
IP address mode	423	VISA	411
Language	429	Restoring configuration	337
Network gateway	424	Resulting file name	363
Network hostname	423	Retrace	
Network IP address	423	Sweep	206
Network Mac address	424	RF 50 Ω connector	38, 42
		RF combined sweep	
		State	205

- RF frequency
 - Configuring 61
- RF frequency sweep
 - State 204
- RF frontend
 - Cable correction settings 184
 - Configuration and settings 180
 - General settings 181
 - Versions and options 182
- RF level
 - Configuring 61
 - EMF display 370
 - Offset 72
 - Power-On state 370
 - Setting characteristics 73, 213, 257
 - Settings 70
- RF level sweep
 - State 205
- RF OFF mode
 - Attenuator settings 230
- RF off state
 - Reference oscillator 319
- RF ON, RF OFF, RF ON/OFF 61
- RF output
 - Amplitude 71
 - Harmonic filter 73
 - Impedance 61
 - Protection 231
 - State 61
- RF Output
 - Level range 74
- RF output signal
 - Phase 76
 - Phase continuous active 75
 - Phase continuous frequency range 76
 - Phase continuous frequency range from 76
 - Phase continuous frequency range to 76
 - Phase reference 76
- RF phase
 - Configuring 61
- RF signal
 - Analog modulation 77
 - Attenuator 228
 - Connectors 64
 - Frequency 67
 - Phase continuous mode 63
 - Phase settings 74
 - Power-On/EMF 370
 - User correction 236
- Rotary knob 35
 - User step 330
 - User variation 69, 74
- RS232
 - Baud rate 427
 - Interfaces 413
 - Parity 427
 - Remote access 427
 - Resource string 414
 - Serial (VISA resource string) 426
 - Stop bits 428
- S**
- S-Parameter
 - Activate corrections 263
- Safety instructions 15, 21
- Samba services
 - SMB client 398
 - SMB server 399
- SAMBA/SMB
 - How to access the instrument 354
- Sanitize 392
- save
 - Save 342
- Save
 - Editor 104, 225, 243
 - Instrument settings 344
 - Power analysis 302
 - User menu 377
- Save and load 341
- Save as
 - Editor 104, 225, 243
- Save hard copy as
 - bmp, jpg, png 362
- Save instrument settings 491, 503
- Save intermediate 491
- Save to Red
 - Power analysis 273
- Save/Recall 341
 - ADF 128, 141, 164
 - Dialog 342
 - How to 344
 - ILS 128, 141, 164
 - SCPI-Export 472
 - VOR 128, 141, 164
- Saving 48
- Saving files 495
- Scan
 - NRP sensor mapping 265
- SCONfiguration subsystem 608
- SCPI
 - Error messages 819
 - Export 348
 - Export settings 468
 - Import 348
 - LAN services 397
 - Output file 469
 - Recording list settings 467
- SCPI export 470
 - File content 470
 - Select file 469
- SCPI Export
 - Format 469
- SCPI list
 - Commands of all settings 343
 - Export 468
 - Recorded SCPI commands 468
 - Show all commands 343
- SCPI recording
 - Settings 466
- SCPI remote trace
 - LXI 449
- SCPI script
 - Select 379
- SCPI-Export
 - Save/Recall 472
- Screen saver
 - Activate 371
 - State 368
 - Wait time 368
- SD card slot 37

- Security
 - Accept settings 399
 - Change password (setup) 402
 - Change user password (setup) 401
 - Confirm password (setup) 401
 - Confirm user password (setup) 401
 - Disk & memory settings 390
 - Display lock 393
 - Enter password (setup) 399
 - Manual operation settings 392
 - New password (setup) 401
 - New user password (setup) 401
 - Old password (setup) 401
 - Old user password 400
 - Password management 399
 - Sanitize 392
 - Security password 401
 - Setup 389
 - USB storage (setup) 391
 - User name (setup) 400
 - User password 400
 - Volatile memory 391
- Security password
 - Security 401
 - Setup 401
- Security procedures 21
- Security settings 389
- Select
 - List mode data file 220
 - Setup file 379
 - User correction data file 240
- Select file 347
- Select instrument
 - Remote Instrument 179
- Select row
 - Editor 225, 243
- Self-test
 - Remote 492
- Selftests
 - About 834
- Sensitive information
 - Protecting 333, 340
- Sensor
 - NRP power control 256
- Sensor name
 - NRP sensor mapping 266
- Serial
 - Visa resource string 426
- Serial bus 827
- Serial number 455
 - NRP sensor mapping 266
 - Power sensors 260
- Service manual 21
- Service request enable register (SRE)
 - Remote 491
- Services
 - LAN 395
- Set IDN and OPT to default
 - Emulation mode 429
- Set to default 128, 140, 164
- Set up remote control
 - GPIB 463
- Setting up
 - remote control 452
- Settings
 - Active connections 430
 - ALC 234, 235
 - AM 87
 - Attenuator 229
 - Automatic level control 234
 - Check front panel 842
 - Closed remote connections 431
 - Delayed adjustment 837
 - Display 367
 - Instrument emulations 428
 - Internal adjustments 835
 - Keyboard 367
 - Licenses 380
 - List mode 217
 - Managing 331
 - NRP power control 255
 - NRP power viewer 253
 - NRP sensor mapping 264
 - On power-on 370
 - Phase 74
 - Protection 394
 - Remote access 421
 - RF level 70
 - SCPI export 468
 - SCPI recording 466
 - SCPI recording list 467
 - Security 390, 392
 - Show SCPI command 467
 - UCOR 239
 - Undo/Redo 406
 - User key 378
- Setup
 - Accept security settings 399
 - Adjusting display 366
 - Adjusting keyboard 366
 - Annotation frequency 392
 - Annotation level 393
 - Change password 401
 - Change password (security) 402
 - Confirm password 401
 - Confirm password (security) 401
 - Display lock 393
 - Enter password (security) 399
 - GUI update 366
 - Keyboard settings 367
 - Layout (front panel keyboard) 369
 - Layout (USB keyboard) 369
 - New password 401
 - New password (security) 401
 - Old password (security) 401
 - Password (protection) 395
 - Performing the front panel test 843
 - Protection level 395
 - Screen saver 368
 - Security password 401
 - USB storage (security) 391
 - User name (security) 400
 - User password 400
 - Wait time 368
- Setup files
 - Data exchange 359
- Setup key 366
- Shape
 - LF generator 112
 - LF output 112
 - Period 114
 - Pulse duty cycle 114
 - Pulse width 114
 - Sweep 207

- Trapeze high 114
 - Trapezoid rise, fall 114
 - Triangle rise 114
- Show
 - SCPI list 343
- Show SCPI command
 - Close 467
 - Copy 467
 - Settings 467
- Signal output
 - LF 117
- Signal source
 - Analog modulation 77
- Single
 - Execute (list mode) 220
- Single trigger
 - Chirp modulation 94
- SMB (Samba)
 - LAN services 397
- Socket
 - Visa resource string 426
- Softkey bar
 - See Taskbar 53
- Source
 - AM, FM, Φ M 84
 - Analog modulation 77
 - LF output 118, 121
 - Power sensors 261
 - Pulse modulation 81
 - Reference oscillator 319
 - Sweep trigger 205
- Source subsystem
 - Remote control commands 613
- Spacing
 - Frequency sweep 208, 211
 - RF frequency / level sweep 208, 211
 - RF level sweep 213
- Span
 - Frequency sweep 211
- Specifications 21
- SRQ 855
- SSH
 - LAN services 397
- Standard settings 128, 140, 164
- Standby 34
- Start
 - Frequency sweep 210
 - Power analysis 271
 - RF level sweep 212
- State
 - ADF 128, 140, 164
 - Adjustment (reference oscillator) 322
 - AM, FM, Φ M 84
 - Automatic level control 234
 - Chirp modulation 92
 - Clock synthesis 328
 - DC offset 329
 - ILS 128, 140, 164
 - LF frequency sweep 111, 205
 - List mode 218
 - NRP power control 255
 - Power sensors 260
 - Pulse generator output 101
 - Pulse modulation 81
 - RF frequency / level sweep 205
 - RF frequency sweep 204
 - RF level sweep 205
- RF output 61
- RF output protection 231
- Screen saver 368
- UCOR 240
- Undo/Redo 407
- VOR 128, 140, 164
- Status
 - Remote connection 178
- Status bar
 - Display 53
- Status byte
 - Remote 488, 491
- Status information 382
- Status register
 - Response format definition 529
- Status reporting system 418
 - Common commands 488
 - Overview of status registers 418
- Status settings
 - LXI 444
- Step
 - Frequency sweep 211
 - Linear (frequency sweep) 211
 - Logarithmic (frequency sweep) 211
 - RF level sweep 213
- Step attenuator below 20 GHz
 - Attenuator settings 230
- Step count
 - Combined RF frequency / level sweep 213
- Step width
 - User variation 69, 74, 330
- Stop
 - Frequency sweep 210
 - Power analysis 271
 - RF level sweep 212
- Stop bits
 - RS232 interface 428
- Stop connector 41
- Stopping remote operation 482
- Storage 834
- Storage location
 - /usb/ 332
 - /var/user 332
 - /var/volatile 332
 - Mass memory 494
- Subnet mask 423
- Subsystem
 - AM 615
 - CHIRp 622
 - FM 626
 - Keyboard 535
 - Phase 739
 - PM 631
 - Power 740
 - PULM 635
 - Pulse generator 737
- Support 830
- Sweep
 - Center frequency 210
 - Current frequency 205
 - Current level 205
 - Dwell time 208
 - Execute single 209
 - Frequency span 211
 - Level range 214
 - Mode 205
 - Reset 209

Retrace	206
Shape	207
Spacing	208, 211, 213
Start/stop frequency	210
Start/stop level	212
State (LF frequency)	111, 205
State (RF combined)	205
State (RF frequency)	204
State (RF level)	205
Step	211, 213
Trigger manually	209
Sweep time	
RF sweep	208
Sweep type	
Frequency sweep	204, 215
Switching	
On or off	30
Symbolic name	
Remote Instrument	179
Synchronization bandwidth	
Reference oscillator	320
Synthesizer	
PLL bandwidth	69
System	
Factory preset	338
System bandwidth	
Noise level (absolute)	119
Noise level (relative)	119

T

Tab labels	54
Take measured level as reference	
NRP power control	256
Target level	
NRP power control	256
Temperature offset	
Internal adjustments	836
Temporary files	333, 340
Test	
Check front panel	843
Text entry	56
Threshold	
Pulse modulation	110
Tile diagram	
Display	53
Time	
UTC	840
Time protocol	
Settings	841
Timeout	
Filter (power sensors)	262
Tooltips	
Show	58
Touchscreen	33
Compared with mouse	51
Usage	51
Touchscreen test	
Perform	844
Trace	
Power analysis	270
Trace indication	
Power analysis	273
Trace reference settings	
Power analysis	274
Trace settings	
Power analysis	273, 288

Traces	
Power analysis	271
Tracing	
Messages	457
SCPI commands	457
Transition	
PULM	82
Pulse modulation	82
Transporting	833
Trapezoid	
High (LF generator)	114
Rise, fall	114
Triangle	
Rise	114
Trigger	
Event (remote)	491
Execute (list mode)	220
Power Sensors	298
Sweep, manually	209
Trigger mode	
Chirp modulation	93
Trigger source	
List mode	219
Sweep	205
Tripped	
RF output protection	231
Type	
AM	88

U

UCOR	
About	237
Calibrate RF output level with power sensor	313
Data	240
Data editor	241
Display correction file data	241
Display correction value	240
Edit data	241
Export user data	107, 223, 248
File catalog	240
File settings, import/export	106, 222, 247
Fill with sensor	245
Import/export	106, 221, 222, 247
Load from file	107, 222, 248
RF signal	236
Select file	240
Settings	239
State	240
Undo	406
Clear history	407
History	407
Settings	406
State	407
Unpacking the instrument	23
USB	
Interfaces	413
Resource string	413
Storage (security)	391
Visa resource string	426
Use default aperture time	
Power sensors	262
User correction	
see UCOR	236
User correction	
Data editor	241

User data	
Access	346
Load from a specific directory	496
User files	332
User interface	
Front panel keyboard	369
Lock	393
User key	372
Action name	378
Add, change, delete action	379
Assign actions	376
Define action	378, 379
SCPI command	379
Select dialog ID	379
Settings	378
Toggle between define and execute mode	379
User manual	21
User menu	372
Access	374
Clear	377
Create	374
Recall	377
Save	377
Settings	377
User name	
Setup (security)	400
User password	
Security	400
Setup	400
User preset	337
User variation	
Activating	69, 74, 330
Clock synthesis	330
Level	69, 74
RF	69, 74
User-definable preset	
Recall	373
Utility keys	
Overview	34
V	
V/GHz	
Frequency sweep	215
V/GHz X-Axis connector	41
Variable reference frequency	320
Varying	
RF frequency and level	69, 74
Version	
Firmware	829
Videos	22
VISA	411
Resource string	411
Visa resource string	
Ethernet	425
GPIB	426
HISLIP	425
Serial	426
Socket	426
USB	426
VXI11	425
Visa resource strings	425
VNC	50
How to enable	476
LAN services	397
Volatile memory	333, 340

Volatile mode	
Activate	391
VOR	
About	125
COM/ID settings	133
General settings	127
Position settings	132
Signal settings	130
VOR COM/ID	
Code	133
Dash length	134
Depth	134
Dot length	134
Frequency	134
Letter space	135
Period	134
State	133
Symbol space	135
Time schema	134
VOR position	
Bearing angle	132
Direction	132
VOR signal	
Mode	130
REF deviation	131
Subcarrier depth	131
Subcarrier frequency	131
VAR depth	131
VAR/REF frequency	131
VXI11	
Visa resource string	425
W	
Wait	
Remote	492
Wait time	
Screen saver	368
Warnings	818, 821
Web interface	50
What's new	20
White papers	22
Wi-Fi	
WLAN	479
Width	
Double pulse (PULM)	101
PULM	101
Pulse modulation	101
Workgroup name	423

X

X-Axis	
Frequency sweep	215

Y

y-axis	
Power analysis	282

Z

Z-Axis connector	41
Zero	
Power Sensors	260
Zero - Power Sensors	561

Zeroconf	
IP address	823
Zoom In/Out	
Pulse graph	108
Zoom position	
Pulse graph	108
Zooming	
Pulse graph	108